
# ETSITS 129 002 V7.15.0 (2010-06)

Technical Specification

Digital cellular telecommunications system (Phase 2+); Universal Mobile Telecommunications System (UMTS); Mobile Application Part (MAP) specification (3GPP TS 29.002 version 7.15.0 Release 7)



# Reference RTS/TSGC-0429002v7f0 Keywords GSM, UMTS

#### **ETSI**

650 Route des Lucioles F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° 7803/88

#### Important notice

Individual copies of the present document can be downloaded from: <u>http://www.etsi.org</u>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<a href="http://portal.etsi.org/tb/status/status.asp">http://portal.etsi.org/tb/status/status.asp</a></a>

If you find errors in the present document, please send your comment to one of the following services: http://portal.etsi.org/chaircor/ETSI\_support.asp

#### **Copyright Notification**

No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2010. All rights reserved.

**DECT**<sup>TM</sup>, **PLUGTESTS**<sup>TM</sup>, **UMTS**<sup>TM</sup>, **TIPHON**<sup>TM</sup>, the TIPHON logo and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members.

**3GPP**<sup>™</sup> is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **LTE**<sup>™</sup> is a Trade Mark of ETSI currently being registered

for the benefit of its Members and of the 3GPP Organizational Partners. **GSM**® and the GSM logo are Trade Marks registered and owned by the GSM Association.

# Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (http://webapp.etsi.org/IPR/home.asp).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

### **Foreword**

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under <a href="http://webapp.etsi.org/key/queryform.asp">http://webapp.etsi.org/key/queryform.asp</a>.

# Contents

Intelle	ectual Property Rights	2
Forew	ord	2
Forew	ord	26
1	Scope	27
2	References	27
3	Abbreviations	32
4	Void	33
5	Overload and compatibility overview	33
5.1	Overload control	
5.1.1	Overload control for MSC (outside MAP)	33
5.1.2	Overload control for MAP entities	
5.1.3	Congestion control for Signalling System No. 7	
5.2	Compatibility	
5.2.1	General	
5.2.2	Strategy for selecting the Application Context (AC) version	
5.2.2.1		
5.2.2.2	*	
5.2.2.3		
_		
	Requirements concerning the use of SCCP and TC	
6.1	Use of SCCP	
6.1.1	SCCP Class	
6.1.2	Sub-System Number (SSN)	
6.1.3	SCCP addressing	
6.1.3.1		
6.1.3.2	$\mathcal{E}$	
6.1.3.2	8	
6.1.3.2		
6.1.3.2		
6.1.3.2		
6.1.3.3	$\mathcal{E}$	
6.1.3.3	$\mathcal{E}$	
6.1.3.3	1 0 1	
6.1.3.3		
6.1.3.3		
6.1.3.3		
6.1.3.3 6.1.3.3	1 0 1	
6.1.3.3 6.1.3.3		
6.1.3.4 6.1.3.4		
6.1.3.4 6.1.3.4		
6.1.3.4 6.1.3.5	•	
6.1.3.5 6.1.3.6		
6.1.3.7 6.1.3.8		
6.1.3.9 6.1.3.1		
6.1.3.1 6.1.3.1		
6.1.3.1 6.1.3.1		
6.1.3.1 6.1.3.1		
6.1.3.1 6.1.3.1	· · · · · · · · · · · · · · · · · · ·	
0.1.3.1	1 Suiiiiiai y lauic	40

6.2	Use of TC	49
7	General on MAP services.	49
7.1	Terminology and definitions	
7.2	Modelling principles.	
7.3	Common MAP services.	
7.3.1	MAP-OPEN service	
7.3.2	MAP-CLOSE service	
7.3.3	MAP-DELIMITER service	
7.3.4	MAP-U-ABORT service	
7.3.5	MAP-P-ABORT service	
7.3.6	MAP-NOTICE service	
7.3.7	Void	
7.3.8	Void	
7.3.9	Void	
7.3.10	Void	
7.4	Sequencing of services	
7.5	General rules for mapping of services onto TC	
7.5.1	Mapping of common services	
7.5.2	Mapping of user specific services	
7.6	Definition of parameters	
7.6.1	Common parameters	
7.6.1.1		
7.6.1.2		
7.6.1.3		
7.6.1.4		
7.6.2	Numbering and identification parameters	
7.6.2.1		
7.6.2.2		
7.6.2.3		
7.6.2.3		
7.6.2.4		
7.6.2.5		
7.6.2.6		
7.6.2.7		
7.6.2.8	· · · · · · · · · · · · · · · · · · ·	
7.6.2.8		
7.6.2.9	Void	65
7.6.2.1	Originating entity number	65
7.6.2.1	1 MSC number	65
7.6.2.1	2 Target MSC number	65
7.6.2.1	3 HLR number	65
7.6.2.1	4 VLR number	65
7.6.2.1	5 HLR Id	65
7.6.2.1	6 LMSI	65
7.6.2.1	7 MS ISDN	65
7.6.2.1	8 OMC Id	65
7.6.2.1	9 Roaming number	65
7.6.2.1	9A Relocation Number List	65
7.6.2.2	0 Void	65
7.6.2.2	Handover number	65
7.6.2.2		
7.6.2.2	č	
7.6.2.2		
7.6.2.2		
7.6.2.2		66
7.6.2.2	e e e e e e e e e e e e e e e e e e e	
7.6.2.2		
7.6.2.2		
7.6.2.2		
7.6.2.2		
7623	0 Location Information	66

7.6.2.30a	Location Information for GPRS	
7.6.2.31	GMSC Address	
7.6.2.32	VMSC Address	
7.6.2.33	Group Id	
7.6.2.34	North American Equal Access preferred Carrier Id	67
7.6.2.35	Void	
7.6.2.36	Void	67
7.6.2.37	Serving cell Id	67
7.6.2.38	SGSN number	67
7.6.2.39	SGSN address	67
7.6.2.40	GGSN address	67
7.6.2.41	GGSN number	67
7.6.2.42	APN	67
7.6.2.43	Network Node number	67
7.6.2.44	PDP-Type	67
7.6.2.45	PDP-Address	
7.6.2.46	Additional number	
7.6.2.47	P-TMSI	68
7.6.2.48	B-subscriber number	
7.6.2.49	B-subscriber subaddress	
7.6.2.50	LMU Number	
7.6.2.51	MLC Number	
7.6.2.52	Multicall Bearer Information	
7.6.2.53	Multiple Bearer Requested	
7.6.2.54	Multiple Bearer Not Supported	
7.6.2.55	PDP-Charging Characteristics.	
7.6.2.56	Selected RAB ID.	
7.6.2.57	RAB ID	
7.6.2.58	gsmSCF Address	
7.6.2.59	V-GMLC Address	
7.6.2.60	Void	
7.6.2.61	H-GMLC Address	
7.6.2.62	PPR Address	
7.6.2.63	Routeing Number	
7.6.2.64	Additional V-GMLC Address	
7.6.3	Subscriber management parameters.	
7.6.3.1	Category	
7.6.3.2	Equipment status	
7.6.3.2a	BMUEF	
7.6.3.3	Extensible Bearer service	
7.6.3.4	Extensible Teleservice	
7.6.3.5	Extensible Basic Service Group	
7.6.3.6	GSM bearer capability	
7.6.3.7	Subscriber Status	
7.6.3.8	CUG Outgoing Access indicator	
7.6.3.9	Operator Determined Barring General Data	
7.6.3.10	ODB HPLMN Specific Data	
7.6.3.11	Regional Subscription Data	
7.6.3.12	Regional Subscription Response	
7.6.3.13	Roaming Restriction Due To Unsupported Feature	
7.6.3.14	Extensible SS-Info	
7.6.3.15	Extensible forwarding information	
7.6.3.16	Extensible forwarding feature	
7.6.3.17	Extensible SS-Status	
7.6.3.17	Extensible Forwarding Options.	
7.6.3.19	Extensible No reply condition timer	
7.6.3.19	Extensible No Tepty Condition times  Extensible Call barring information	
7.6.3.20	Extensible Call barring finormation	
7.6.3.21	CUG info	
7.6.3.23	CUG subscription	
7.6.3.24	CUG interlock	
7.6.3.24	CUG index	
1.0.3.43	COO maca	

7.6.3.26	CUG feature	
7.6.3.27	Inter CUG options	
7.6.3.28	Intra CUG restrictions	
7.6.3.29	Extensible SS-Data	
7.6.3.30	Subscriber State	
7.6.3.31	Requested Info	
7.6.3.31A	Requested Domain	
7.6.3.32	Suppression of Announcement	
7.6.3.33	Suppress T-CSI	
7.6.3.34	GMSC CAMEL Subscription Info	
7.6.3.35	VLR CAMEL Subscription Info	
7.6.3.36	Supported CAMEL Phases in the VLR	
7.6.3.36A	Supported CAMEL Phases in the SGSN	
7.6.3.36B	Offered CAMEL4 CSIs in the VLR	
7.6.3.36C	Offered CAMEL4 CSIs in the SGSN	
7.6.3.36D	Offered CAMEL4 CSIs	
7.6.3.36E	Offered CAMEL4 CSIs in interrogating node	
7.6.3.36F	Offered CAMEL4 CSIs in VMSC	
7.6.3.36G	Offered CAMEL Planetionalities	
7.6.3.36H	Supported CAMEL Phases	
7.6.3.36I	Supported CAMEL Phases in interrogating node	
7.6.3.37	CUG Subscription Flag	
7.6.3.38 7.6.3.39	CAMEL Subscription Info Withdraw	
7.6.3.40	Voice Broadcast Service (VBS) Data	
7.6.3.41	ISDN bearer capability	
7.6.3.42	Lower layer Compatibility	
7.6.3.43	High Layer Compatibility	
7.6.3.44	Alerting Pattern	
7.6.3.45	GPRS Subscription Data Withdraw	
7.6.3.46	GPRS Subscription Data	
7.6.3.47	QoS-Subscribed	
7.6.3.48	VPLMN address allowed	77
7.6.3.49	Roaming Restricted In SGSN Due To Unsupported Feature	78
7.6.3.50	Network Access Mode	
7.6.3.51	Mobile Not Reachable Reason	
7.6.3.52	Cancellation Type	
7.6.3.53	All GPRS Data	
7.6.3.54	Complete Data List Included	
7.6.3.55	PDP Context Identifier	
7.6.3.56	LSA Information	
7.6.3.57	SoLSA support indicator	
7.6.3.58	LSA Information Withdraw	
7.6.3.59 7.6.3.60	LMU Indicator LCS Information	
7.6.3.61	GMLC List	
7.6.3.62	LCS Privacy Exception List	
7.6.3.62A	Additional LCS Privacy Exception List	
7.6.3.63	LCS Privacy Exception Parameters	
7.6.3.64	External Client List	
7.6.3.65	Internal Client List	
7.6.3.65A	MO-LR List	
7.6.3.65B	Privacy Notification to MS User	
7.6.3.65C	GMLC List Withdraw	
7.6.3.65D	Service Type List	80
7.6.3.66	IST Alert Timer	
7.6.3.67	Call Termination Indicator	
7.6.3.68	IST Information Withdraw	
7.6.3.69	IST Support Indicator	
7.6.3.70	Super-Charger Supported In HLR.	
7.6.3.71	Super-Charger Supported In Serving Network Entity	
7.6.3.72	Age Indicator	81

7.6.3.73	GPRS enhancements support indicator	81
7.6.3.74	Extension QoS-Subscribed	
7.6.3.75	SGSN CAMEL Subscription Info	81
7.6.3.75A	Extension-2 QoS-Subscribed	81
7.6.3.75B	Extension-3 QoS-Subscribed	81
7.6.3.76	MO-SMS-CSI	81
7.6.3.76a	MT-SMS-CSI	81
7.6.3.77	GPRS-CSI	81
7.6.3.78	CAMEL subscription info	81
7.6.3.83	Call Barring Data	82
7.6.3.84	Call Forwarding Data	82
7.6.3.85	ODB Data	
7.6.3.86	Requested Subscription Info	82
7.6.3.87	CS Allocation/Retention priority	82
7.6.3.88	ODB Info	82
7.6.3.89	Suppress VT-CSI	82
7.6.3.90	Suppress Incoming Call Barring	
7.6.3.91	gsmSCF Initiated Call	83
7.6.3.91a	SuppressMTSS	
7.6.3.92	Call barring support indicator	83
7.6.3.93	MNP Info Result	83
7.6.3.94	Allowed Services	83
7.6.3.95	Unavailability Cause	83
7.6.3.96	MNP Requested Info	83
7.6.3.97	Access Restriction Data	83
7.6.3.98	Supported RAT types indicator	83
7.6.4 St	upplementary services parameters	84
7.6.4.1	SS-Code	84
7.6.4.1A	SS-Code 2	84
7.6.4.2	SS-Status	84
7.6.4.3	SS-Data	84
7.6.4.4	Override Category	85
7.6.4.5	CLI Restriction Option	85
7.6.4.6	Forwarding Options	85
7.6.4.7	No reply condition timer	85
7.6.4.8 - 7.6.4.1	4 Void	85
7.6.4.15	Forwarding information	85
7.6.4.16	Forwarding feature	85
7.6.4.17	Void	86
7.6.4.18	Call barring information	86
7.6.4.19	Call barring feature	86
7.6.4.20	New password	86
7.6.4.21	Current password	86
7.6.4.22	Guidance information	86
7.6.4.23	Void	87
7.6.4.24	SS-Info	87
7.6.4.25 - 7.6.4.	35Void	87
7.6.4.36	USSD Data Coding Scheme	87
7.6.4.37	USSD String	87
7.6.4.38	Bearer service	87
7,6,4.38A	Bearer Service 2	87
7.6.4.39	Teleservice	87
7.6.4.39A	Teleservice 2	87
7.6.4.40	Basic Service Group	88
7.6.4.41	eMLPP information.	88
7.6.4.42	SS-event	88
7.6.4.43	SS-event data	88
7.6.4.44	LCS Privacy Exceptions	88
7.6.4.45	Mobile Originating Location Request (MO-LR)	
7.6.4.46	NbrUser	89
7.6.4.47	MC Subscription Data	89
7.6.4.48	MC Information	89

7.6.4.49	CCBS Request State	89
7.6.4.50	Basic Service Group 2	89
7.6.5	Call parameters	89
7.6.5.1	Call reference number	89
7.6.5.2	Interrogation type	90
7.6.5.3	OR interrogation	90
7.6.5.4	OR capability	90
7.6.5.5	Forwarding reason	90
7.6.5.6	Forwarding interrogation required	90
7.6.5.7	O-CSI	90
7.6.5.7A	D-CSI	90
7.6.5.7B	T-CSI	90
7.6.5.7C	VT-CSI	90
7.6.5.7D	O-IM-CSI	90
7.6.5.7E	D-IM-CSI	91
7.6.5.7F	VT-IM-CSI	91
7.6.5.8	Void	91
7.6.5.9	Void	91
7.6.5.10	Void	91
7.6.5.11	CCBS Feature	91
7.6.5.12	UU Data	91
7.6.5.14	Number Portability Status	91
7.6.5.15	Pre-paging supported	91
7.6.5.16	MT Roaming Retry Supported	
7.6.5.17	MT Roaming Retry	
7.6.6	Radio parameters	
7.6.6.1 - 7.6	.6.3 Void	92
7.6.6.4	GERAN Classmark	92
7.6.6.5	BSSMAP Service Handover	92
7.6.6.5A	BSSMAP Service Handover List	
7.6.6.6	RANAP Service Handover	
7.6.6.7	HO-Number Not Required	
7.6.6.8	Integrity Protection Information	92
7.6.6.9	Encryption Information	
7.6.6.10	Radio Resource Information	
7.6.6.10A	Radio Resource List	
7.6.6.10B	Chosen Radio Resource Information	
7.6.6.11	Key Status	
7.6.6.12	Selected UMTS Algorithms	
7.6.6.13	Allowed GSM Algorithms	
7.6.6.14	Allowed UMTS Algorithms	
7.6.6.15	Selected GSM Algorithm	
7.6.6.16	Iu-Currently Used Codec	
7.6.6.17	Iu-Supported Codecs List	
7.6.6.17A	Iu-Available Codecs List	
7.6.6.18	Iu-Selected Codec	
7.6.6.19	RAB Configuration Indicator	
7.6.6.20	UESBI-Iu	
7.6.6.21	Alternative Channel Type	
7.6.7	Authentication parameters	
7.6.7.1	Authentication set list	
7.6.7.2	Rand	
7.6.7.3	Sres	
7.6.7.4	Kc	
7.6.7.5	Xres	
7.6.7.5A	Ck	
7.6.7.5B	Ik	
7.6.7.5C	Autn	
7.6.7.6	Cksn	
7.6.7.6A	Ksi	
7.6.7.6B	Auts	94 94
/ h / /	umnering mode	U/

7.6.7.8	Current Security Context	
7.6.7.9	Failure cause	
7.6.7.10	Re-attempt	
7.6.7.11	Access Type	
7.6.8	Short message parameters	
7.6.8.1	SM-RP-DA	
7.6.8.2	SM-RP-OA	
7.6.8.3	MWD status	
7.6.8.4	SM-RP-UI	
7.6.8.5	SM-RP-PRI	
7.6.8.6	SM Delivery Outcome	
7.6.8.7	More Messages To Send	
7.6.8.8	Alert Reason	
7.6.8.9	Absent Subscriber Diagnostic SM	
7.6.8.10	Alert Reason Indicator	
7.6.8.10A	Additional Alert Reason Indicator	
7.6.8.11	Additional SM Delivery Outcome	
7.6.8.12	Additional Absent Subscriber Diagnostic SM	
7.6.8.13	Delivery Outcome Indicator	
7.6.8.14	GPRS Node Indicator	
7.6.8.15	GPRS Support Indicator	
7.6.8.16	SM-RP-MTI	
7.6.8.17	SM-RP-SMEA	
7.6.8.18	IP-SM-GW SM Delivery Outcome	
7.6.8.19	IP-SM-GW Absent Subscriber Diagnostic SM	
7.6.8.20	IP-SM-GW Indicator	
7.6.9	Access and signalling system related parameters	
7.6.9.1 7.6.9.2		
7.6.9.2	CM service type	
7.6.9.3 7.6.9.4	External Signal Information	
7.6.9.4	Access signalling information	
7.6.9.5 7.6.9.6	Location update type	
7.6.9.7	Protocol ID	
7.6.9.8	Network signal information	
7.6.9.8A	Network signal information 2	
7.6.9.9	Call Info	
7.6.9.10	Additional signal info	
7.6.10	System operations parameters.	
7.6.10.1	Network resources.	
7.6.10.2	Trace reference	
7.6.10.2A	Trace reference 2	100
7.6.10.3	Trace type	
7.6.10.4	Additional network resources	
7.6.10.5	Trace depth list	100
7.6.10.6	Trace NE type list	
7.6.10.7	Trace interface list	100
7.6.10.8	Trace event list	101
7.6.10.9	Trace support indicator	101
7.6.10.10	Trace Propagation List	101
7.6.11	Location Service Parameters	
7.6.11.1	Age of Location Estimate	
7.6.11.2	Deferred MT-LR Response Indicator	
7.6.11.3	Deferred MT-LR Data	
7.6.11.4	LCS Client ID	
7.6.11.5	LCS Event	
7.6.11.7	LCS Priority	
7.6.11.8	LCS QoS	
7.6.11.9	CS LCS Not Supported by UE	
7.6.11.10	PS LCS Not Supported by UE	
7.6.11.11	Location Estimate	
7.6.11.11A	GERAN Positioning Data	102

7.6.11.11		
7.6.11.11		
7.6.11.11		
7.6.11.12	71	
7.6.11.13		
7.6.11.14		
7.6.11.15	J	
7.6.11.16		
7.6.11.17	Supported LCS Capability Sets	103
7.6.11.18		
7.6.11.19	1	
7.6.11.20	· · · · · · · · · · · · · · · · · · ·	
7.6.11.21		
7.6.11.22		
7.6.11.23	B LCS-Reference Number	104
7.6.11.24		
7.6.11.25	1 2	
7.6.11.26		
7.6.11.27	7 Velocity Estimate	104
7.6.11.28	· · · · · · · · · · · · · · · · · · ·	
7.6.11.29	MO-LR Short Circuit Indicator	105
7.6.11.30	Reporting PLMN List	105
7.6.11.31	Periodic LDR information	105
7.6.11.32	Sequence Number	105
7.6.12	Void	105
7.7	Representation of a list of a basic parameter in service-primitives	105
8 M	Iobility services	106
8.1	Location management services.	
8.1.1	Void	
8.1.1.1		
8.1.1.2	Void	
8.1.1.3	VoidVoid	
8.1.2	MAP_UPDATE_LOCATION service	
8.1.2.1	Definition	
8.1.2.1	Service primitives	
8.1.2.3	Parameter definitions and use	
8.1.3	MAP_CANCEL_LOCATION service	
8.1.3 8.1.3.1		
	Definition	
8.1.3.2 8.1.3.3	Parameter definitions and use	
8.1.3.3 8.1.4	MAP_SEND_IDENTIFICATION service	
8.1.4.1		
8.1.4.1	Definition	
8.1.4.2	Parameter definitions and use	
	Void	
8.1.5 8.1.5.1	Void	
8.1.5.1		
	Void	
8.1.5.3	Void	
8.1.6	MAP_PURGE_MS service	
8.1.6.1 8.1.6.2	Definition	
8.1.6.2	<u>.</u>	
	Parameter definitions and use	
8.1.7	MAP_UPDATE_GPRS_LOCATION service	
8.1.7.1	Definition	
8.1.7.2	Service primitives	
8.1.7.3	Parameter definitions and use	
8.1.8	MAP-NOTE-MM-EVENT	
8.1.8.1	Definition	
8.1.8.2	Service primitives	
8.1.8.3	Parameter use	
8.2	Paging and search	

8.2.1	MAP_PAGE service	
8.2.1.1	Definition	
8.2.1.2	Service primitives	117
8.2.1.3	Parameter definitions and use	117
8.2.2	MAP_SEARCH_FOR_MS service	118
8.2.2.1	Definition	118
8.2.2.2	Service primitives	118
8.2.2.3	Parameter definitions and use	118
8.3	Access management services	119
8.3.1	MAP_PROCESS_ACCESS_REQUEST service	119
8.3.1.1	Definition	
8.3.1.2	Service primitives	
8.3.1.3	Parameter definitions and use	
8.4	Handover services	120
8.4.1	MAP_PREPARE_HANDOVER service	120
8.4.1.1	Definition	
8.4.1.2	Service primitives	
8.4.1.3	Parameter use	121
8.4.2	MAP_SEND_END_SIGNAL service	125
8.4.2.1	Definition	125
8.4.2.2	Service primitives	
8.4.2.3	Parameter use	
8.4.3	MAP_PROCESS_ACCESS_SIGNALLING service	
8.4.3.1	Definition	
8.4.3.2	Service primitives	
8.4.3.3	Parameter use	
8.4.4	MAP_FORWARD_ACCESS_SIGNALLING service	
8.4.4.1	Definition	
8.4.4.2	Service primitives	
8.4.4.3	Parameter use	
8.4.5	MAP_PREPARE_SUBSEQUENT_HANDOVER service	
8.4.5.1	Definition	
8.4.5.2	Service primitives	
8.4.5.3	Parameter use	
8.4.6	MAP_ALLOCATE_HANDOVER_NUMBER service	
8.4.6.1	Definition	
8.4.6.2	Service primitives	
8.4.6.3	Parameter use	
8.4.7	MAP SEND HANDOVER REPORT service	
8.4.7.1	Definition	
8.4.7.2	Service primitives	
8.4.7.3	Parameter use	
8.5	Authentication management services	
8.5.1	MAP_AUTHENTICATE service	
8.5.1.1	Definition	
8.5.1.2	Service primitives	
8.5.1.3	Parameter use	
8.5.2	MAP_SEND_AUTHENTICATION_INFO service	
8.5.2.1	Definition	
8.5.2.2	Service primitives	
8.5.2.3	Parameter use	
8.5.3	MAP_AUTHENTICATION_FAILURE_REPORT service	
8.5.3.1	Definition	
8.5.3.2	Service primitives	
8.5.3.3	Parameter use	
8.6	Security management services	
8.6.1	MAP_SET_CIPHERING_MODE service	
8.6.1.1	Definitions	
8.6.1.2	Service primitives	
8.6.1.3	Parameter use	
8.7	International mobile equipment identities management services	
8.7.1	MAP_CHECK_IMEI service	

8.7.1.1	Definition	136
8.7.1.2	Service primitives	136
8.7.1.3	Parameter use	137
8.7.2	MAP_OBTAIN_IMEI service	
8.7.2.1	Definition	
8.7.2.2	Service primitives	
8.7.2.3	Parameter use	
8.8	Subscriber management services	
8.8.1	MAP-INSERT-SUBSCRIBER-DATA service	
8.8.1.1	Definition	
8.8.1.2	Service primitives	
8.8.1.3	Parameter use	
8.8.1.4	Basic service information related to supplementary services	
8.8.2	MAP-DELETE-SUBSCRIBER-DATA service	
8.8.2.1	Definition	
8.8.2.2	Service primitives	
8.8.2.3	Parameter use	
8.9	Identity management services	
8.9.1	MAP-PROVIDE-IMSI service	
8.9.1.1	Definition	
8.9.1.2	Service primitives	
8.9.1.3	Parameter use	
8.9.2	MAP-FORWARD-NEW-TMSI service	
8.9.2.1	Definition	
8.9.2.2	Service primitives	
8.9.2.3	Parameter use	
8.10	Fault recovery services	
8.10.1 8.10.1.1	MAP_RESET service	
8.10.1.1	Definition	
8.10.1.2	Parameter definition and use	
8.10.1.3	MAP_FORWARD_CHECK_SS_INDICATION service	
8.10.2.1	Definition	
8.10.2.2	Service primitives	
8.10.2.3	Parameter definition and use	
8.10.3	MAP_RESTORE_DATA service	
8.10.3.1	Definition	
8.10.3.2	Service primitives	
8.10.3.3	Parameter definitions and use	
8.11	Subscriber Information services	
8.11.1	MAP-ANY-TIME-INTERROGATION service	156
8.11.1.1	Definition	
8.11.1.2	Service primitives	157
8.11.1.3	Parameter definition and use	
8.11.2	MAP-PROVIDE-SUBSCRIBER-INFO service	158
8.11.2.1	Definition	158
8.11.2.2	Service primitives	158
8.11.2.3	Parameter definition and use	158
8.11.3	MAP-ANY-TIME-SUBSCRIPTION-INTERROGATION service	158
8.11.3.1	Definition	158
8.11.3.2	Service primitives	158
8.11.3.3	Parameter definition and use	
8.11.4	MAP-ANY-TIME-MODIFICATION service	
8.11.4.1	Definition	
8.11.4.2	Service primitives	
8.11.4.3	Parameter definition and use	
8.11.5	MAP-NOTE-SUBSCRIBER-DATA-MODIFIED service	
8.11.5.1	Definition	
8.11.5.2	Service primitives	
8.11.5.3	Parameter definition and use	161
9 O	peration and maintenance services	162.
_	1	

9.1	Subscriber tracing services	
9.1.1	MAP-ACTIVATE-TRACE-MODE service	
9.1.1.1	Definition	
9.1.1.2	1	162
9.1.1.3		
9.1.2	MAP-DEACTIVATE-TRACE-MODE service	
9.1.2.1	Definition	164
9.1.2.2	Service primitives	164
9.1.2.3	Parameter use	
9.1.3	MAP-TRACE-SUBSCRIBER-ACTIVITY service	165
9.1.3.1	Definition	165
9.1.3.2	1	
9.1.3.3		
9.2	Other operation and maintenance services	
9.2.1	MAP-SEND-IMSI service	
9.2.1.1		
9.2.1.2	1	
9.2.1.3	Parameter use	166
10	Call handling services	166
10.1	MAP SEND ROUTING INFORMATION service	
10.1.1	Definition	
10.1.1	Service primitives	
10.1.2	Parameter use	
10.1.5	MAP_PROVIDE_ROAMING_NUMBER service	
10.2.1	Definition	
10.2.2	Service primitives	
10.2.3	Parameter use	
10.3	MAP_RESUME_CALL_HANDLING service	
10.3.1	Definition	
10.3.2	Service primitives	
10.3.3	Parameter use	
10.4	MAP_PREPARE_GROUP_CALL service	
10.4.1	Definition	
10.4.2	Service primitives	
10.4.3	Parameter definitions and use	
10.5	MAP_PROCESS_GROUP CALL_SIGNALLING service	
10.5.1	Definitions	
10.5.2	Service primitives	
10.5.3	Parameter definitions and use	
10.6	MAP_FORWARD_GROUP_CALL_SIGNALLING service	180
10.6.1	Definitions	
10.6.2	Service primitives	180
10.6.3	Parameter definitions and use	180
10.7	MAP_SEND_GROUP_CALL_END_SIGNAL service	181
10.7.1	Definitions	181
10.7.2	Service primitives	181
10.7.3	Parameter definitions and use	181
10.7A	MAP_SEND_GROUP_CALL_INFO service	182
10.7A.1		
10.7A.2	1	182
10.7A.3		
10.8	Void	
10.9	Void	
10.10	MAP_SET_REPORTING_STATE service	
10.10.1		
10.10.2		
10.10.3		
10.11	MAP_STATUS_REPORT service	
10.11.1		
10.11.2	1	
10 11 3	Parameter use	185

10.12		
10.12.1	.1 Definition	186
10.12.2	2 Service primitives	186
10.12.3	3 Parameter use	186
10.13	MAP_IST_ALERT service	187
10.13.1	1 Definition	187
10.13.2		
10.13.3	1	
10.14		
10.14.1		
10.14.2		
10.14.3	*	
10.15		
10.15.1		
10.15.2		
10.15.2	*	
10.13.3	.5 Farameter use	105
11	Supplementary services related services	189
11.1	MAP REGISTER SS service	
11.1.1		
11.1.2		
11.1.3	*	
11.1.3	MAP_ERASE_SS service	
11.2.1		
11.2.1		
11.2.2	1	
11.3	MAP_ACTIVATE_SS service	
11.3.1		
11.3.2	r	
11.3.3		
11.4	MAP_DEACTIVATE_SS service	
11.4.1		
11.4.2	1	
11.4.3		
11.5	MAP_INTERROGATE_SS service	
11.5.1	Definitions	195
11.5.2	Service primitives	195
11.5.3	Parameter use	195
11.6	Void	197
11.7	MAP_REGISTER_PASSWORD service	
11.7.1		
11.7.2		
11.7.3	1	
11.7.5	MAP GET PASSWORD service	
11.8.1		
11.8.2		
11.8.3	•	
11.9	MAP_PROCESS_UNSTRUCTURED_SS_REQUEST service	
11.9.1		
11.9.2	r	
11.9.3		
11.10	`	
11.10.1		
11.10.2	r	
11.10.3		
11.11	MAP_UNSTRUCTURED_SS_NOTIFY service	201
11.11.1	.1 Definitions	201
11.11.2	2 Service primitives	201
11.11.3	3 Parameter use	201
11.12		
11.12.1		
11 12 2		202

11.12.3	Parameter use	202
11.13	MAP_REGISTER_CC_ENTRY service	202
11.13.1	l Definition	202
11.13.2	2 Service primitives	203
11.13.3	1	
11.14	MAP ERASE CC ENTRY service	
11.14.1		
11.14.2		
11.14.3		
12	Short message service management services	
12.1	MAP-SEND-ROUTING-INFO-FOR-SM service	
12.1.1	Definition	205
12.1.2	Service primitives	205
12.1.3	Parameter use	
12.2	MAP-MO-FORWARD-SHORT-MESSAGE service	
12.2.1	Definition	207
12.2.2	Service primitives	207
12.2.3	Parameter use	207
12.3	MAP-REPORT-SM-DELIVERY-STATUS service	208
12.3.1	Definition	208
12.3.2	Service primitives	208
12.3.3	Parameter use	208
12.4	MAP-READY-FOR-SM service	210
12.4.1	Definition	
12.4.2	Service primitives	210
12.4.3	Parameter use	
12.5	MAP-ALERT-SERVICE-CENTRE service	211
12.5.1	Definition	
12.5.2	Service primitives	
12.5.3	Parameter use	
12.6	MAP-INFORM-SERVICE-CENTRE service	
12.6.1	Definition	
12.6.2	Service primitives	
12.6.3	Parameter use	
12.7	MAP-SEND-INFO-FOR-MT-SMS service	
12.7.1	Definition	
12.7.2	Service primitives	
12.7.3	Parameter use	
12.8	MAP-SEND-INFO-FOR-MO-SMS service	
12.8.1	Definition	
12.8.2	Service primitives	
12.8.3	Parameter use	
12.9	MAP-MT-FORWARD-SHORT-MESSAGE service	
12.9.1	Definition	
12.9.2	Service primitives	
12.9.3	Parameter use	
12.10	MAP-MT-FORWARD-SM-FOR-VGCS service	
12.10 12.10.1		
12.10.2		
12.10.2	1	
13	Network-Requested PDP Context Activation services	217
13.1	MAP_SEND_ROUTING_INFO_FOR_GPRS service	217
13.1.1	Definition	
13.1.2	Service primitives	
13.1.3	Parameter definition and use	
13.2	MAP_FAILURE_REPORT service	
13.2.1	Definition	
13.2.2	Service primitives	
13.2.3	Parameter definition and use	
13.3	MAP NOTE MS PRESENT FOR GPRS service	

13.3.1	Definition	219
13.3.2	Service primitives	219
13.3.3	Parameter definition and use	219
13A I	Location Service Management Services	220
13A.1	MAP-SEND-ROUTING-INFO-FOR-LCS Service	
13A.1.1		
13A.1.2		
13A.1.2		
13A.1.3 13A.2	MAP-PROVIDE-SUBSCRIBER-LOCATION Service	
13A.2.1		
13A.2.1		
13A.2.3		
13A.3	MAP-SUBSCRIBER-LOCATION-REPORT Service	
13A.3.1		
13A.3.2		
13A.3.3		
13A.4	Void	
13A.4.1		
13A.4.2		
13A.4.3		
13A.5	Void	
13A.5.1		
13A.5.2		
13A.5.3	, , , = <del></del>	
13A.6	Void	
13A.6.1		
13A.6.2		
13A.6.3		
13A.7	Void	
13A.7.1		
13A.7.2		
13A.7.3		
13A.8	Void	
13A.8.1		
13A.8.2		
13A.8.3		
13A.9	Void	
13A.9.1		
13A.9.2		
13A.9.3	3 Void	231
14	General	231
14.1	Overview	231
14.2	Underlying services	
14.3	Model	
14.4	Conventions	231
15 I	Elements of procedure	222
15.1	Handling of unknown operations	
15.1		
15.2 15.2.1	Dialogue establishment	
	Behaviour at the initiating side	
15.2.2	Behaviour at the responding side	
15.3	Dialogue continuation	
15.4	Load control	
15.5	Procedures for MAP specific services	
15.5.1	Service invocation	
15.5.2	Void	
15.5.3	Service invocation receipt	
15.5.4	Void	
15.5.5	Handling of components received from TC	
15.6	SDL descriptions	235

16	Mapping on to TC services	268
16.1	Dialogue control	268
16.1.1	Directly mapped parameters	268
16.1.2	Use of other parameters of dialogue handling primitives	268
16.1.2.	1 Dialogue Id	268
16.1.2.	2 Application-context-name	268
16.1.2.	3 User information	268
16.1.2.	4 Component present	268
16.1.2.	5 Termination	268
16.1.2.	6 P-Abort-Cause	268
16.1.2.	7 Quality of service	269
16.2	Service specific procedures	269
16.2.1	Directly mapped parameters	
16.2.2	Use of other parameters of component handling primitives	
16.2.2.		
16.2.2.		
16.2.2.	3 Linked Id	269
16.2.2.	4 Operation	270
16.2.2.:	•	
16.2.2.	6 Parameters	271
16.2.2.		
16.2.2.3		
16.2.2.9	<u>.</u>	
16.2.2.		
16.2.2.	11 0	
16.2.2.	11 0	
17	Abstract syntax of the MAP protocol	273
17.1	General	273
17.1.1	Encoding rules	273
17.1.2	Use of TC	273
17.1.2.	1 Use of Global Operation and Error codes defined outside MAP	274
17.1.3	Use of information elements defined outside MAP	274
17.1.4	Compatibility considerations	274
17.1.5	Structure of the Abstract Syntax of MAP	275
17.1.6	Application Contexts	277
17.2	Operation packages	278
17.2.1	General aspects	278
17.2.2	Packages specifications	279
17.2.2.	1 Location updating	279
17.2.2.	2 Location cancellation	279
17.2.2.	Roaming number enquiry	280
17.2.2.4	4 Information retrieval	280
17.2.2.:	5 Inter-VLR information retrieval	280
17.2.2.	6 IMSI retrieval	280
17.2.2.	7 Call control transfer	281
17.2.2.		
17.2.2.		
17.2.2.		
17.2.2.		
17.2.2.		
17.2.2.		
17.2.2.	$\epsilon$	
17.2.2.		
17.2.2.		
17.2.2.	E Company of the Comp	
17.2.2.	8	
17.2.2.		
17.2.2.	Ç	
17.2.2.	· · · · · · · · · · · · · · · · · · ·	
17.2.2.	· · · · · · · · · · · · · · · · · · ·	
17.2.2.	· · · · · · · · · · · · · · · · · · ·	
	25 Short meddage gate may bet vices	204

17.2.2.24	MT Short message relay services	284
17.2.2.25	Void	
17.2.2.26	Message waiting data management	
17.2.2.20	Alerting	
17.2.2.27		
	Data restoration	
17.2.2.29	Purging	
17.2.2.30	Subscriber information enquiry	
17.2.2.31	Any time information enquiry	
17.2.2.32	Group Call Control	
17.2.2.32A	Group Call Info Retrieval	
17.2.2.33	Void	
17.2.2.34	Void	
17.2.2.35	Gprs location updating	
17.2.2.36	Gprs Interrogation	
17.2.2.37	Failure reporting	287
17.2.2.38	GPRS notifying	287
17.2.2.39	Supplementary Service invocation notification	288
17.2.2.40	Set Reporting State	288
17.2.2.41	Status Report	288
17.2.2.42	Remote User Free	288
17.2.2.43	Call Completion	
17.2.2.44	Location service gateway services	
17.2.2.45	Location service enquiry	
17.2.2.45A	Location service reporting	
17.2.2.46	Void	
17.2.2.47	Void	
17.2.2.48	Void	
17.2.2.49	IST Alerting	
17.2.2.50	Service Termination	
17.2.2.51	Mobility Management event notification	
17.2.2.53	Subscriber Data modification notification	
17.2.2.54	Authentication Failure Report	
17.2.2.55	Resource Management	
17.2.2.56	MT Short message relay VGCS services	
	pplication contexts	
17.3.1	General aspects	
17.3.2	Application context definitions	
17.3.2.1	Void	
17.3.2.1	Location Updating	
17.3.2.2	Location Cancellation	
17.3.2.4	Roaming number enquiry	
17.3.2.4	· · · · · · · · · · · · · · · · · · ·	
	VoidLocation Information Retrieval	
17.3.2.6 17.3.2.7		
	Call control transfer	
17.3.2.8	Void	
17.3.2.9	Void	
17.3.2.10	Void	
17.3.2.11	Location registers restart	
17.3.2.12	Handover control	
17.3.2.13	IMSI Retrieval	
17.3.2.14	Equipment Management	
17.3.2.15	Information retrieval	
17.3.2.16	Inter-VLR information retrieval	
17.3.2.17	Stand Alone Subscriber Data Management	
17.3.2.18	Tracing	
17.3.2.19	Network functional SS handling	
17.3.2.20	Network unstructured SS handling	
17.3.2.21	Short Message Gateway	
17.3.2.22	Mobile originating Short Message Relay	
17.3.2.23	Void	
17.3.2.24	Short message alert	
17 3 2 25	Short message waiting data management	297

17.3.2.26	Mobile terminating Short Message Relay	
17.3.2.27	MS purging	298
17.3.2.28	Subscriber information enquiry	298
17.3.2.29	Any time information enquiry	298
17.3.2.30	Group Call Control	299
17.3.2.30	A Group Call Info Retrieval	299
17.3.2.31	Void	299
17.3.2.32	Gprs Location Updating	
17.3.2.33	Gprs Location Information Retreival	
17.3.2.34	Failure Reporting	
17.3.2.35	GPRS Notifying	
17.3.2.36	Supplementary Service invocation notification	
17.3.2.37	Reporting	
17.3.2.38	Call Completion	
17.3.2.39	Location Service Gateway	
17.3.2.40	Location Service Enquiry	
17.3.2.41	Void	
17.3.2.42	Void	301
17.3.2.43	Void	301
17.3.2.44	IST Alerting	
17.3.2.45	Service Termination	
17.3.2.46	Mobility Management event notification	
17.3.2.48	Subscriber Data modification notification	
17.3.2.49	Authentication Failure Report	
17.3.2.50	Resource Management	
17.3.2.51	Mobile terminating Short Message Relay VGCS	
17.3.3	ASN.1 Module for application-context-names	
17.4	MAP Dialogue Information	
17.5	MAP operation and error codes	
17.6	MAP operations and errors.	
17.6.1	Mobile Service Operations	
17.6.2	Operation and Maintenance Operations	
17.6.3	Call Handling Operations	
17.6.4	Supplementary service operations	
17.6.5	Short message service operations	
17.6.6	Errors	
17.6.7	Group Call operations	
17.6.8	Location service operations	
17.6.9	Void	
17.7	MAP constants and data types	
17.7.1	Mobile Service data types	
17.7.2	Operation and maintenance data types	
17.7.3	Call handling data types	
17.7.4	Supplementary service data types	
17.7.5	Supplementary service codes	
17.7.6	Short message data types	
17.7.7	Error data types	
17.7.8	Common data types	
17.7.9	Teleservice Codes	
17.7.10	Bearer Service Codes	
17.7.11	Extension data types	
17.7.12	Group Call data types	
17.7.13	Location service data types	
17.7.14	Void	
	eneral on MAP user procedures	
18.1 18.2	Introduction	
	Common aspects of user procedure descriptions	
18.2.1	General conventions	
18.2.2	Naming conventions	
18.2.3	Convention on primitives parameters	
18.2.3.1	Open service	423

18.2.3.2	2 Close service	425
18.2.4	Version handling at dialogue establishment	
18.2.4.1		
18.2.4.2	5 11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
18.2.5	Abort Handling	
18.2.6	SDL conventions	
18.3	Interaction between MAP Provider and MAP Users	426
19	Mobility procedures	427
19.1	Location management Procedures	427
19.1.1	Location updating	
19.1.1.1		
19.1.1.2		
19.1.1.3		
19.1.1.4		
19.1.1.5		
19.1.2	Location Cancellation	
19.1.2.1		
19.1.2.2		
19.1.2.3		
19.1.2.4		
19.1.3	Void	
19.1.4	MS Purging	
19.1.4.1		
19.1.4.2		
19.1.4.3 19.1.4.4		
19.1.4. <sup>2</sup> 19.2		
19.2.1	Handover procedures	
19.2.1	Procedure in MSC-A	
19.2.2.1		
19.2.2.2		
19.2.2.3		
19.2.3	Procedure in MSC-B.	
19.2.3.1		
19.2.3.2		
19.2.3.3		
19.2.4	Macro Receive Error From HO CA	
19.2.5	Procedure in VLR-B	
19.3	Fault recovery procedures	
19.3.1	VLR fault recovery procedures	
19.3.1.1	1 General 492	
19.3.1.2		493
19.3.1.3	Procedure in the HLR	493
19.3.2	HLR fault recovery procedures	495
19.3.2.1	l General	495
19.3.2.2		
19.3.2.3		
19.3.2.4		
19.4	Mobility Management event notification procedure	
19.4.1	General	
19.4.2	Procedure in the VLR or SGSN	
19.4.3	Procedure in the gsmSCF	
19.4	HLR Insert Subscriber Data macros	
19.5.1	Macro Insert_Subs_Data_Framed_HLR	
19.5.2	Macro Insert_GPRS_Subs_Data_Framed_HLR	506
20	Operation and maintenance procedures	509
20.1	General	
20.1.1	Tracing Co-ordinator for the VLR	
20.1.2	Tracing Co-ordinator for the SGSN	
20.1.3	Subscriber Data Management Co-ordinator for the VLR	500

20.1.4	Subscriber Data Management Co-ordinator for the SGSN			
20.2	Tracing procedures			
20.2.1	Subscriber tracing activation procedure			
20.2.1.1	Procedures in the HLR	517		
20.2.1.2	Procedure in the VLR	517		
20.2.1.3	Procedure in the SGSN	517		
20.2.2	Subscriber tracing deactivation procedure	517		
20.2.2.1	Procedures in the HLR	517		
20.2.2.2	Procedure in the VLR			
20.2.2.3	Procedure in the SGSN			
20.3	Subscriber data management procedures			
20.3.1	Subscriber deletion procedure			
20.3.1.1	Procedure in the HLR			
20.3.1.2	Procedure in the VLR			
20.3.1.3	Procedure in the SGSN			
20.3.2	Subscriber data modification procedure			
20.3.2.1	Procedure in the HLR.			
20.3.2.2	Procedures in the VLR			
20.3.2.3	Procedures in the SGSN			
20.4	Subscriber Identity procedure			
20.4.1	Procedure in the VLR			
20.4.2	Procedure in the HLR			
21 Ca	all handling procedures	549		
21.1	General	549		
21.2	Retrieval of routing information	549		
21.2.1	General	549		
21.2.2	Procedure in the GMSC	552		
21.2.9	Process in the gsmSCF	553		
21.2.4	Procedure in the HLR	553		
21.2.5	Procedure in the VLR to provide a roaming number	553		
21.2.6	Procedure in the VLR to restore subscriber data			
21.2.7	Procedure in the VLR to provide subscriber information	553		
21.3	Transfer of call handling			
21.3.1	General			
21.3.2	Process in the VMSC	562		
21.3.3	Process in the GMSC	563		
21.4	Inter MSC Group Call Procedures			
21.4.1	General			
21.4.2	Process in the Anchor MSC			
21.4.3	Process in the Relay MSC	567		
21.4A	Inter MSC Group Call Info Retrieval			
21.4A.1	General			
21.4A.2	Process in the MSC			
21.5	Void			
21.6	CCBS: monitoring and reporting the status of the subscriber			
21.6.1	Reporting co-ordinator process in the VLR			
21.6.2	Setting the reporting state – stand-alone			
21.6.2.1	Process in the HLR.			
21.6.2.2	Process in the VLR			
21.6.3	Status Reporting			
21.6.3.1	Process in the VLR			
21.6.3.2	Process in the HLR.			
21.6.4	CCBS: Remote User Free			
21.6.4.1	Process in the HLR.			
21.6.3.2	Process in the VLR.			
21.0.3.2	Void			
21.7	Void			
21.8	Immediate Service Termination (IST)			
21.9.1	IST Alert			
21.9.1	Procedure in the MSC			
21.9.1.1	Procedure in the HLR	591 591		

21.9.2	IST Command	
21.9.2.1		
21.9.2.2		
21.10	Resource Management	
21.10.1	General	
21.3.2	Process in the GMSC	
21.3.3	Process in the VMSC	597
22 \$	Supplementary services procedures	600
22.1	Supplementary service co-ordinator processes	
22.1.1	Supplementary service co-ordinator process for the MSC	
22.1.2	Void	
22.1.3	Functional supplementary service co-ordinator process for the HLR	600
22.1.4	Call completion supplementary service co-ordinator process for the HLR	600
22.2	Registration procedure	605
22.2.1	General	
22.2.2	Procedure in the MSC	606
22.2.3	Procedure in the VLR	
22.2.4	Procedure in the HLR	
22.3	Erasure procedure	
22.3.1	General	
22.3.2	Procedure in the MSC	
22.3.3	Procedure in the VLR	
22.3.4	Procedure in the HLR	
22.4 22.4.1	Activation procedure	
22.4.1	General Procedure in the MSC	
22.4.2	Procedure in the VLR	
22.4.3	Procedure in the YLK.	
22.5	Deactivation procedure	
22.5.1	General	
22.5.2	Procedure in the MSC	
22.5.3	Procedures in the VLR.	
22.5.4	Procedures in the HLR.	
22.6	Interrogation procedure	
22.6.1	General	622
22.6.2	Procedure in the MSC	623
22.6.3	Procedures in the VLR	
22.6.4	Procedure in the HLR	
22.7	Void	
22.8	Password registration procedure	
22.8.1	General	
22.8.2	Procedure in the MSC	
22.8.3	Procedure in the VLR	
22.8.4	Procedure in the HLR	
22.9	Mobile Initiated USSD procedure	
22.9.1 22.9.2	General Procedure in the MSC	
22.9.2	Procedure in the VLR	
22.9.3	Procedure in the YLK.	
22.9.4	Procedures in the gsmSCF/secondary HLR	
22.10	Network initiated USSD procedure	
22.10.1	General	
22.10.2		
22.10.3	Procedure in the VLR	
22.10.4		
22.10.5	Procedure in the gsmSCF or secondary HLR	
22.11	Common macros for clause 22	
22.11.1	SS Password handling macros	670
22.11.2		
22.12	Supplementary Service Invocation Notification procedure	674
22.12.1	General	674

22.12.2	Procedure in the MSC	
22.12.3	Procedure in the gsmSCF	
22.13	Activation of a CCBS request	
22.13.1	General	
22.13.2	Procedure in the VLR	677
22.13.3	Procedure in the HLR	
22.14	Deactivation of a CCBS request	
22.14.1	General	
22.14.2	Procedure in the VLR	680
22.14.3	Procedure in the HLR	680
23 S	hort message service procedures	683
23.1	General	
23.1.1	Mobile originated short message service Co-ordinator for the MSC	
23.1.2	Short message Gateway Co-ordinator for the HLR	
23.2	The mobile originated short message transfer procedure	
23.2.1	Procedure in the serving MSC	688
23.2.2	Procedure in the VLR	
23.2.3	Procedure in the SGSN	
23.2.4	Procedure in the SMS Interworking MSC (SMS-IWMSC)	
23.3	The mobile terminated short message transfer procedure	
23.3.1	Procedure in the SMS-GMSC	
23.3.2	Procedure in the HLR	
23.3.3	Procedure in the Serving MSC	709
23.3.4	Procedure in the VLR	
23.3.5	Procedure in the SGSN	
23.3.6	Procedure in the SMS Router	
23.3.7	Procedure in the IP-SM-GW	
23.4	The Short Message Alert procedure	
23.4.1	Procedure in the Serving MSC – the MS has memory available	
23.4.2	Procedures in the VLR	
23.4.2.1	The Mobile Subscriber is present	759
23.4.2.2	The MS has memory available	759
23.4.3	Procedures in the SGSN	760
23.4.3.1	The Mobile Subscriber is present	760
23.4.3.2	The Mobile Equipment has memory available	760
23.4.4	Procedure in the HLR	760
23.4.5	Procedure in the SMS Interworking MSC	
23.5	The SM delivery status report procedure	
23.5.1	Procedure in the SMS-GMSC	769
23.5.2	Procedure in the HLR	
23.5.3	Procedure in the IP-SM-GW	
23.6	The macro Report_SM_Delivery_Stat_HLR	
23.7	The mobile terminated short message transfer procedure for VGCS	
23.7.1	Procedure in the SMS-GMSC	
23.7.2	Procedure in the Anchor MSC	779
24 C	SPRS process description	783
24.1	Procedure for retrieval of routeing information for GPRS	784
24.1.1	Process in the GGSN	
24.1.2	Process in the HLR	784
24.2	Procedure for reporting failure to establish a network requested PDP context	787
24.2.1	Process in the GGSN	
24.2.2	Process in the HLR	
24.3	Procedure for reporting that an MS has become reachable for GPRS	790
24.3.1	Process in the HLR	
24.3.2	Process in the GGSN for Note Ms Present For Gprs	790
24A C	CSE interrogation and control of subscriber data	793
24A.1	General	
24A.2	Any Time Subscription Interrogation procedure	
24A.2.1	General	
2/4/2/2	Process in the gemSCE	

24A.2.3		
24A.3	Any Time Modification procedure	798
24A.3.1	l General	798
24A.3.2	Process in the gsmSCF	798
24A.3.3	Process in the HLR	798
24A.4	Subscriber Data Modification Notification procedure	801
24A.4.1		
24A.4.2		
24A.4.3		
24A.5	Any Time Interrogation procedure	
	I General	
24A.5.2		
24A.5.3		
24A.5.4		
24B 1	Location Services process description	813
24B.1	Routeing information retrieval procedure for LCS	813
24B.1.1		
24B.1.2	Process in the GMLC	813
24B.1.3	Process in the HLR	813
24B.2	Provide Subscriber Location procedure	
24B.2.1		
24B.2.2		
24B.2.3		
24B.2.4		
24B.3	Subscriber Location Report procedure	
24B.3.1	1 1	
24B.3.2		
24B.3.3		
24B.3.4		
25 (	General macro description	824
25.1	MAP_OPEN handling macros	824
25.1.1	Macro Receive_Open_Ind	824
25.1.2	Macro Receive_Open_Cnf	
25.2	Macros to check the content of indication and confirmation primitives	
25.2.1	Macro Check_Indication	
25.2.2	Macro Check_Confirmation	
25.3	The page and search macros	
25.3.1	Macro PAGE_MSC	
25.3.2	Macro Search_For_MS_MSC	
25.4	Macros for handling an Access Request	
25.4.1	Macro Process_Access_Request_MSC	
25.4.2	Macro Process_Access_Request_VLR	
25.4.3	Macro Obtain_Identity_VLR	
25.4.4	Process Update_Location_Child_VLR	
25.5	Authentication macros and processes	
25.5.1	Macro Authenticate_MSC	
25.5.1	Macro Authenticate_VLR	
25.5.2	Macro Obtain_Authent_Params_VLR	
25.5.3		
	Process Obtain_Authentication_Sets_VLR	
25.5.6	Process Obtain_Authent_Sets_SGSN	
25.5.6	Process Obtain_Authent_Sets_HLR	
25.5.7	Authentication Failure Reporting	
25.5.7.1		
25.5.7.2		
25.5.7.3		
25.5.7.4		
25.6	IMEI Handling Macros	
25.6.1	Macro Check_IMEI_MSC	
25.6.2	Macro Check_IMEI_VLR	
25 6 3	Process Check IMFL SGSN	862

History			919
Annex l	E (informative):	Change History	904
Annex l	D (informative):	Void	903
C.3.3	Result		900
C.3.2		icit indication	
C.3.1		explicit indication	
C.3			
C.2.3			
C.2.2			
C.2.1			
C.2			
C.1			
Annex (	C (informative):	Message Segmentation Mechanisms	
Annex l	B (informative):	Void	
	,	• • •	
	A (informative):	ASN.1 Cross-reference listing and fully expanded sources	
25.10.4		VICE_COMMC_INDX	
25.10.3		vice_Centre_HLR	
25.10.1		erPresent_SGSN	
25.10.1		er_Present_VLR	
25.10		procedures	
25.9.0		Fracing_With_SGSN_HLR	
25.9.5 25.9.6		Fracing_With_VLR_HLR	
25.9.4		Tracing_VLR Tracing_SGSN	
25.9.3 25.9.4		· · · · · · · · · · · · · · · · · · ·	
25.9.2		bscriber_Activity_VLRbscriber_Activity_SGSN	
25.9.1		bscriber_Activity_MSC	
25.9		haquiban Astinitu MCC	
25.8.2		MSI_VLR	
25.8.1		MSI_MSC	
25.8		08	
25.7.7		sert_Subs_Data_HLR	
25.7.6		_Insert_GPRS_Subs_Data_Cnf	
25.7.5		_Insert_Subs_Data_Cnf	
25.7.4		PRS_Subs_Data_Stand_Alone_HLR	
25.7.3		ubs_Data_Stand_Alone_HLR	
25.7.2	Macro Insert_Subs_Data_SGSN		
25.7.1	Macro Insert_Subs_Data_VLR.		
25.7	Insert Subscriber Data macros and processes		
25.6.6		MEI_VLR	
25.6.5		MEI_MSC	
25.6.4	Process Check_I	MEI_EIR	862

## **Foreword**

This Technical Specification (TS) has been produced by the 3<sup>rd</sup> Generation Partnership Project (3GPP).

The present document specifies the Mobile Application Part (MAP), the requirements for the signalling system and procedures within the 3GPP system at application level.

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
  - 1 presented to TSG for information;
  - 2 presented to TSG for approval;
  - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

# 1 Scope

It is necessary to transfer between entities of a Public Land Mobile Network (PLMN) information specific to the PLMN in order to deal with the specific behaviour of roaming Mobile Stations (MS)s. The Signalling System No. 7 specified by CCITT is used to transfer this information.

The present document describes the requirements for the signalling system and the procedures needed at the application level in order to fulfil these signalling needs.

Clauses 1 to 6 are related to general aspects such as terminology, mobile network configuration and other protocols required by MAP.

MAP consists of a set of MAP services that are provided to MAP service-users by a MAP service-provider.




Figure 1.1/1: Modelling principles

Clauses 7 to 13A of the present document describe the MAP services.

Clauses 14 to 17 define the MAP protocol specification and the behaviour of service provider (protocol elements to be used to provide MAP services, mapping on to TC service primitives, abstract syntaxes, etc.).

Clauses 18 to 25 describe the MAP user procedures that make use of MAP services.

# 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.
- [1] 3GPP TS 21.905: "3G Vocabulary".
  [2] 3GPP TS 22.001: "Digital cellular telecommunications system (Phase 2+); Principles of telecommunication services supported by a Public Land Mobile Network (PLMN)".
  [3] 3GPP TS 22.002: "Bearer Services Supported by a Public Land Mobile Network (PLMN)".
  [4] 3GPP TS 22.003: "Circuit Teleservices Supported by a Public Land Mobile Network (PLMN)".
  [5] 3GPP TS 22.004: "General on Supplementary Services".
  [6] 3GPP TS 42.009: "Digital cellular telecommunications system (Phase 2+); Security aspects".
  [7] 3GPP TS 22.016: "International Mobile station Equipment Identities (IMEI)".

[8]	3GPP TS 22.041: "Operator Determined Barring".
[9]	3GPP TS 22.081: "Line identification supplementary services - Stage 1".
[10]	3GPP TS 22.082: "Call Forwarding (CF) supplementary services - Stage 1".
[11]	$3GPP\ TS\ 22.083;\ "Call\ Waiting\ (CW)\ and\ Call\ Hold\ (HOLD)\ Supplementary\ Services\ -\ Stage\ 1".$
[12]	3GPP TS 22.084: "Multi Party (MPTY) Supplementary Services - Stage 1".
[13]	3GPP TS 22.085: "Closed User Group (CUG) supplementary services - Stage 1".
[14]	3GPP TS 22.086: "Advice of charge (AoC) Supplementary Services - Stage 1".
[15]	3GPP TS 22.088: "Call Barring (CB) supplementary services - Stage 1".
[16]	3GPP TS 22.090: "Unstructured Supplementary Service Data (USSD); - Stage 1".
[17]	3GPP TS 23.003: "Numbering, addressing and identification".
[18]	Void
[19]	3GPP TS 23.007: "Restoration procedures".
[20]	3GPP TS 23.008: "Organisation of subscriber data".
[21]	3GPP TS 23.009: "Handover procedures".
[22]	3GPP TS 23.011: "Technical realization of Supplementary Services - General Aspects".
[23]	3GPP TS 23.012: "Location management procedures".
[24]	3GPP TS 43.020: "Security related network functions".
[25]	3GPP TS 23.038: "Alphabets and language".
[25a]	3GPP TS 23.039: "Interface protocols for the connection of Short Message Service Centres (SMSCs) to Short Message Entities (SMEs)".
[26]	3GPP TS 23.040: "Technical realization of the Short Message Service (SMS) Point to Point (PP)".
[26a]	3GPP TS 23.271: "Functional stage2 description of LCS".
[27]	3GPP TS 23.081: "Line Identification Supplementary Services - Stage 2".
[28]	3GPP TS 23.082: "Call Forwarding (CF) Supplementary Services - Stage 2".
[29]	$3 GPP\ TS\ 23.083;\ "Call\ Waiting\ (CW)\ and\ Call\ Hold\ (HOLD)\ Supplementary\ Services\ -\ Stage\ 2".$
[30]	3GPP TS 23.084: "Multi Party (MPTY) Supplementary Services - Stage 2".
[31]	3GPP TS 23.085: "Closed User Group (CUG) Supplementary Services - Stage 2".
[32]	3GPP TS 23.086: "Advice of Charge (AoC) Supplementary Services - Stage 2".
[33]	3GPP TS 23.088: "Call Barring (CB) Supplementary Services - Stage 2".
[34]	3GPP TS 23.090: "Unstructured Supplementary Services Data (USSD) - Stage 2".
[34a]	3GPP TS 33.204: "3G Security; Network domain security; TCAP user security".
[35]	3GPP TS 24.008: "Mobile Radio Interface Layer 3 specification; Core Network Protocols - Stage 3".
[36]	3GPP TS 24.010: "Mobile radio interface layer 3 Supplementary Services specification - General aspects".
[37]	3GPP TS 24.011: "Point-to-Point (PP) Short Message Service (SMS) support on mobile radio interface".

[37a]	3GPP TS 44.071: "Location Services (LCS) – stage 3".
[38]	$3\mbox{GPP TS }24.080;$ "Mobile radio interface layer 3 supplementary services specification - Formats and coding".
[39]	3GPP TS 24.081: "Line identification supplementary services - Stage 3".
[40]	3GPP TS 24.082: "Call Forwarding (CF) Supplementary Services - Stage 3".
[41]	$3GPP\ TS\ 24.083; "Call\ Waiting\ (CW)\ and\ Call\ Hold\ (HOLD)\ supplementary\ services\ -\ Stage\ 3".$
[42]	3GPP TS 24.084: "Multi Party (MPTY) Supplementary Services - Stage 3".
[43]	3GPP TS 24.085: "Closed User Group (CUG) Supplementary Services - Stage 3".
[44]	3GPP TS 24.086: "Advice of Charge (AoC) Supplementary Services - Stage 3".
[45]	3GPP TS 24.088: "Call Barring (CB) Supplementary Services - Stage 3".
[46]	3GPP TS 24.090: "Unstructured Supplementary Services Data - Stage 3".
[47]	3GPP TS 48.002: " Base Station System - Mobile-services Switching Centre (BSS - MSC) interface principles".
[48]	3GPP TS 48.006: "Signalling transport mechanism specification for the Base Station System - Mobile-services Switching Centre (BSS - MSC) interface".
[49]	$3\mbox{GPP TS }48.008$ : "Mobile Switching Centre - Base Station System (MSC - BSS) interface; Layer 3 specification".
[49a1]	3GPP TS 48.031: "Location Services (LCS); Serving Mobile Location Centre (SMLC) – Serving Mobile Location Centre (SMLC); SMLC Peer Protocol (SMLCPP)".
[49b]	3GPP TS 48.071: "Location Services (LCS); Serving Mobile Location Centre - Base Station System (SMLC - BSS) interface Layer 3 specification".
[50]	3GPP TS 49.001: "General network interworking scenarios".
[51]	3GPP TS 29.002: "Mobile Application Part (MAP) specification".
[52]	Void
[53]	Void
[54]	Void
[55]	3GPP TS 29.006: "Interworking between a Public Land Mobile Network (PLMN) and a Packet Switched Public Data Network/Integrated Services Digital Network (PSPDN/ISDN) for the support of Packet Switched data transmission services".
[56]	3GPP TS 29.007: "General requirements on interworking between the Public Land Mobile Network (PLMN) and the Integrated Services Digital Network (ISDN) or Public Switched Telephone Network (PSTN)".
[57]	3GPP TS 29.008: "Application of the Base Station System Application Part (BSSAP) on the E-interface".
[58]	3GPP TS 29.010: "Information element mapping between Mobile Station - Base Station System and BSS - Mobile-services Switching Centre (MS - BSS - MSC) Signalling procedures and the Mobile Application Part (MAP)".
[59]	3GPP TS 29.011: "Signalling interworking for Supplementary Services".
[59a]	3GPP TS 49.031: "Digital cellular telecommunications system (Phase 2+); Location Services (LCS); Base Station System Application Part LCS Extension (BSSAP-LE)".
[60]	Void

[61]	3GPP TS 52.008: " GSM Subscriber and Equipment Trace".
[62]	ETS 300 102-1 (1990): "Integrated Services Digital Network (ISDN); User-network interface layer 3 specifications for basic call control".
[63]	ETS 300 136 (1992): "Integrated Services Digital Network (ISDN); Closed User Group (CUG) supplementary service description".
[64]	ETS 300 138 (1992): "Integrated Services Digital Network (ISDN); Closed User Group (CUG) supplementary service Digital Subscriber Signalling System No.one (DSS1) protocol".
[65]	ETS 300 287: "Integrated Services Digital Network (ISDN); Signalling System No.7; Transaction Capabilities (TC) version 2".
[66]	ETR 060: "Signalling Protocols and Switching (SPS); Guide-lines for using Abstract Syntax Notation One (ASN.1) in telecommunication application protocols".
[66b]	ETR 091: "ETSI object identifier tree; Common domain Mobile domain"
[67]	ITU-T Recommendation E.164: " The international public telecommunication numbering plan".
[68]	ITU-T Recommendation E.212: " The international identification plan for mobile terminals and mobile users".
[69]	ITU-T Recommendation E.213: "Telephone and ISDN numbering plan for land mobile stations in public land mobile networks (PLMN) ".
[70]	ITU-T Recommendation E.214: " Structure of the land mobile global title for the signalling connection control part (SCCP) ".
[71]	ITU-T Recommendation Q.699: "Interworking between ISDN access and non-ISDN access over ISDN User Part of Signalling System No. 7".
[72]	ITU-T Recommendation Q.711: "Specifications of Signalling System No.7; Functional description of the Signalling Connection Control Part".
[73]	ITU-T Recommendation Q.712: "Definition and function of SCCP messages".
[74]	ITU-T Recommendation Q.713: "Specifications of Signalling System No.7; SCCP formats and codes".
[75]	ITU-T Recommendation Q.714: "Specifications of Signalling System No.7; Signalling Connection Control Part procedures".
[76]	ITU-T Recommendation Q.716: "Specifications of Signalling System No.7; Signalling connection control part (SCCP) performances".
[77]	ITU-T Recommendation Q.721 (1988): "Specifications of Signalling System No.7; Functional description of the Signalling System No.7 Telephone user part".
[78]	ITU-T Recommendation Q.722 (1988): "Specifications of Signalling System No.7; General function of Telephone messages and signals".
[79]	ITU-T Recommendation Q.723 (1988): "Specifications of Signalling System No.7; Formats and codes".
[80]	ITU-T Recommendation Q.724 (1988): "Specifications of Signalling System No.7; Signalling procedures".
[81]	ITU-T Recommendation Q.725 (1988): "Specifications of Signalling System No.7; Signalling performance in the telephone application".
[82]	ITU-T Recommendation Q.761 (1988): "Specifications of Signalling System No.7; Functional description of the ISDN user part of Signalling System No.7".
[83]	ITU-T Recommendation Q.762 (1988): "Specifications of Signalling System No.7; General function of messages and signals".

[84]	ITU-T Recommendation Q.763 (1988): "Specifications of Signalling System No.7; Formats and codes".
[85]	ITU-T Recommendation Q.764 (1988): "Specifications of Signalling System No.7; Signalling procedures".
[86]	ITU-T Recommendation Q.767: "Specifications of Signalling System No.7; Application of the ISDN user part of CCITT signalling System No.7 for international ISDN interconnections".
[87]	ITU-T Recommendation Q.771: "Specifications of Signalling System No.7; Functional description of transaction capabilities".
[88]	ITU-T Recommendation Q.772: "Specifications of Signalling System No.7; Transaction capabilities information element definitions".
[89]	ITU-T Recommendation Q.773: "Specifications of Signalling System No.7; Transaction capabilities formats and encoding".
[90]	ITU-T Recommendation Q.774: "Specifications of Signalling System No.7; Transaction capabilities procedures".
[91]	ITU-T Recommendation Q.775: "Specifications of Signalling System No.7; Guide-lines for using transaction capabilities".
[92]	ITU-T Recommendation X.200: "Reference Model of Open systems interconnection for CCITT Applications".
[93]	ITU-T Recommendation X.680: "Information technology – Abstract Syntax Notation One (ASN.1): Specification of basic notation".
[93b]	ITU-T Recommendation X.681: "Information technology – Abstract Syntax Notation One (ASN.1): Information object specification"
[94]	ITU-T Recommendation X.690: "Information technology – ASN.1 encoding rules: Specification of Basic Encoding Rules (BER), Canonical Encoding Rules (CER) and Distinguished Encoding Rules (DER)".
[95]	ITU-T Recommendation X.210: "Open systems interconnection layer service definition conventions".
[97]	3GPP TS 23.018: "Basic Call Handling".
[98]	3GPP TS 23.078: "Customised Applications for Mobile network Enhanced Logic (CAMEL) Phase 4 - Stage 2".
[99]	3GPP TS 23.079: "Support of Optimal Routeing (SOR) - Stage 2".
[100]	3GPP TS 43.068: "Voice Group Call Service (VGCS) - Stage 2".
[101]	3GPP TS 43.069: "Voice Broadcast service (VBS) - Stage 2".
[102]	ANSI T1.113: "Signaling System No. 7 (SS7) - ISDN User Part".
[103]	Void
[104]	3GPP TS 23.060: "General Packet Radio Service (GPRS) Description; Stage 2".
[105]	3GPP TS 29.060: "General Packet Radio Service (GPRS); GPRS Tunnelling Protocol (GTP) across the Gn and Gp Interface".
[106]	3GPP TS 29.018: "General Packet Radio Service (GPRS); Serving GPRS Support Node (SGSN) - Visitors Location Register (VLR); Gs interface layer 3 specification".
[107]	3GPP TS 23.093: "Technical Realization of Completion of Calls to Busy Subscriber (CCBS); Stage 2".
[108]	3GPP TS 23.066: "Support of Mobile Number Portability (MNP); Technical Realisation Stage 2".

[109]	ANSI T1.112 (1996): "Telecommunication – Signalling No. 7 - Signaling Connection Control Part (SCCP)".
[110]	3GPP TS 23.116: "Super-Charger Technical Realisation; Stage 2."
[111]	Void.
[112]	Void
[113]	Void
[114]	Void
[115]	Void
[116]	ITU-T Recommendation Q.850 (May 1998): "Usage of cause and location in the Digital Subscriber Signalling System No. 1 and the Signalling System No. 7 ISDN User Part".
[117]	3GPP TS 22.135: "Multicall; Service description; Stage 1".
[118]	3GPP TS 23.135: "Multicall supplementary service; Stage 2".
[119]	3GPP TS 24.135: "Multicall supplementary service; Stage 3".
[120]	3GPP TS 25.413: "UTRAN Iu Interface RANAP Signalling".
[121]	3GPP TS 29.202: "SS7 signalling transport in core network"
[122]	3GPP TS 23.032: "Universal Geographical Area Description (GAD)"
[123]	3GPP TS 22.071: "Location Services (LCS); Service description, Stage 1"
[124]	ITU-T Recommendation X.880: "Data networks and open system communication - Open System Interconnection - Service definitions - Remote operations: Concepts, model and notation".
[125]	3GPP TS 23.278: 'Customised Applications for Mobile Network Enhanced Logic (CAMEL) Phase 4 – Stage 2 IM CN Interworking (Rel-5)'
[126]	3GPP TS 23.172: "Technical realization of Circuit Switched (CS) multimedia service; UDI/RDI fallback and service modification"
[127]	3GPP TS 26.103: "Speech codec list for GSM and UMTS".
[128]	3GPP TS 23.141: "Presence Service; Architecture and Functional Description"
[129]	3GPP TS 23.094: "Follow Me (FM) – Stage 2"
[130]	3GPP TS 32.422: "Subscriber and equipment trace; Trace control and Configuration Management (CM)".
[131]	3GPP TS 32.421: "Subscriber and equipment trace: Trace concepts and requirements".
[132]	3GPP TS 32.422: "Subscriber and equipment trace; Trace control and Configuration Management".
[133]	3GPP TS 23.236: " Intra-domain connection of Radio Access Network (RAN) nodes to multiple Core Network (CN) nodes"
[134]	3GPP TS 23.204: "Support of Short Message Service (SMS) over generic 3GPP Internet Protocol (IP) access"

# 3 Abbreviations

ADD Automatic Device Detection

GANSS Galileo and Additional Navigation Satellite Systems

All other abbreviations used in the present document are listed in 3GPP TS 21.905.

# 4 Void

# 5 Overload and compatibility overview

### 5.1 Overload control

There is a requirement for an overload/congestion control for all entities of the Public Land Mobile Network and the underlying Signalling System No. 7.

### 5.1.1 Overload control for MSC (outside MAP)

For the entity MSC the following two procedures (outside MAP) may be applied to control the processor load:

- ISDN
   CCITT Recommendation Q.764 (Automatic Congestion Control), applicable to reduce the mobile terminating traffic;
- BSSAP 3GPP TS 48.008 [49] (A-interface Flow Control), applicable to reduce the mobile originating traffic.

#### 5.1.2 Overload control for MAP entities

For all MAP entities, especially the HLR, the following overload control method is applied.

If overload of a MAP entity is detected requests for certain MAP operations (see tables 5.1/1, 5.1/2, 5.1/3 and 5.1/4) may be ignored by the responder. The decision as to which MAP Operations may be ignored is made by the MAP service provider and is based upon the priority of the application context.

Since most of the affected MAP operations are supervised in the originating entity by TC timers (medium) an additional delay effect is achieved for the incoming traffic.

If overload levels are applicable in the Location Registers the MAP operations should be discarded taking into account the priority of their application context (see table 5.1/1 for HLR, table 5.1/2 for MSC/VLR, table 5.1/3 for the SGSN and table 5.1/4 for the SMLC; the lowest priority is discarded first).

The ranking of priorities given in the tables 5.1/1, 5.1/2, 5.1/3 and 5.1/4 is not normative. The tables can only be seen as a proposal that might be changed due to network operator/implementation matters.

Table 5.1/1: Priorities of Application Contexts for HLR as Responder

Priority high	Responder = HLR	Initiating Entity
,	Mobility Management	
	networkLocUp	VLR
	(updateLocation),	
	(restoreData/v2),	
	(sendParameters/v1)	
	gprsLocationUpdate	SGSN
	(updateGPRSLocation/v3),	
	infoRetrieval	VLR/SGSN
	(sendAuthenticationInfo/v2/v3),	
	(sendParameters/v1)	
	istAlerting	MSC
	(istAlert/v3)	msPurging VLR
	(purgeMS/v2/v3)	
	msPurging	SGSN
	(purgeMS/v3)	
	Short Message Service	
	shortMsgGateway	GMSC
	(sendRoutingInfoforSM),	
	(reportSM-DeliveryStatus)	
	mwdMngt VLR/SGSN	
	(readyForSM/v2/v3),	
	(noteSubscriberPresent/v1)	
	Mobile Terminating Traffic	
	locInfoRetrieval	GMSC
	(sendRoutingInfo)	COD
	anyTimeEnquiry	gsmSCF
	(anyTimeInterrogation/v3)	MD
	reporting	VLR
	(statusReport)	
	<u>Location Services</u>	
	locationSvcGateway	GMLC
	(sendRoutingInfoforLCS/v3) Subscriber Controlled Inputs (Supplementary Services)	
	networkFunctionalSs	VLR
	(registerSS),	V EAC
	(registeres),	
	(activateSS),	
	(deactivateSS),	
	(interrogateSS),	
	(registerPassword),	
	(processUnstructuredSS-Data/v1),	
	(beginSubscriberActivity/v1)	
	callCompletion	VLR
	(registerCCEntry),	
	(eraseCCEntry)	
	networkUnstructuredSs	VLR
	(processUnstructuredSS-Request/v2)	
	imsiRetrieval	VLR
	(sendIMSI/v2)	
	gprsLocationInfoRetrieval	GGSN/SGSN
	(sendRoutingInfoForGprs/v3/v4)	
	failureReport	GGSN/SGSN
	(failureReport/v3)	
	authenticationFailureReport	VLR/SGSN
	(authenticationFailureReport/v3)	

NOTE: The application context name is the last component but one of the object identifier.

Operation names are given in brackets for information with "/vn" appended to vn only operations.

Table 5.1/3: Priorities of Application Contexts for SGSN as Responder

Responder = SGSN	Initiating Entity
Priority high	
Mobility and Location Register Management	
locationCancel	HLR
(cancelLocation v3)	
reset	HLR
(reset)	
subscriberDataMngt	HLR
(insertSubscriberData v3),	
(deleteSubscriberData v3)	
tracing	HLR
(activateTraceMode),	
(deactivateTraceMode)	
Short Message Service	
shortMsgMT-Relay	MSC
(MT-ForwardSM v3),	
(forwardSM v1/v2)	
<u>Location Services</u>	
locationSvcEnquiry	GMLC
(provideSubscriberLocation v3)	G.M.E.C
(pro riado acistro de Escatus de 18)	
Network-Requested PDP context activation	
gprsNotify	HLR
(noteMsPresentForGprs v3),	1121
(	
(Subscriber Location & State retrieval)	
subscriberInfoEnquiry	HLR
(provideSubscriberInformation/v3)	
Priority low	

NOTE: The application context name is the last component but one of the object identifier. Operation names are given in brackets for information with "/vn" appended to vn.

Table 5.1/2: Priorities of Application Contexts for MSC/VLR as Responder

_	der = MSC/VLR	Initiating Entity
Priority high	Handover	
1	<u>Handover</u> nandoverControl	MSC
1	(prepareHandover/v2/v3),	MBC
	(performHandover/v1)	
	Group call and Broadcast call	
Ş	groupCallControl	MSC
	(prepareGroupCall/v3)	
٤	groupCallInfoRetrieval	MSC
	(sendGroupCallInfo/v3)	
	Mobility and Location Register Management	
l	ocationCancel	HLR
_	(cancelLocation)	III D
I	eset (reset)	HLR
;	mmediateTermination	HLR
1	(istCommand/v3)	HLK
i	nterVlrInfoRetrieval	VLR
1	(sendIdentification/v2/v3),	LIK
	(sendParameters/v1)	
S	subscriberDataMngt	HLR
	(insertSubscriberData),	
	(deleteSubscriberData)	
t	racing	HLR
	(activateTraceMode),	
	(deactivateTraceMode)	
	Short Message Service	110000001
S	shortMsgMO-Relay	MSC/SGSN
	(MO-ForwardSM v3),	
	(forwardSM v1/v2)	MCC
S	shortMsgMT-Relay	MSC
	(MT-ForwardSM v3), (forwardSM v1/v2)	
	shortMsgAlert	HLR
S	(alertServiceCentre/v2),	TILK
	(alertServiceCentreWithoutResult/v1)	
	Mobile Terminating Traffic	
Г	resourceMngt (releaseResources)	GMSC
r	oamingNbEnquiry	HLR
1	(provideRoamingNumber)	
C	callControlTransfer	MSC
	(resumeCallHandling)	
S	subscriberInfoEnquiry	HLR
	(provideSubscriberInformation/v3)	
r	reporting	HLR
	(remoteUserFree),	
	(SetReportingState)	
_	<u>Location Services</u>	C) II C
I	ocationSvcEnquiry (provideSubscriberLocation/v3)	GMLC
	Network-Initiated USSD	
r	networkUnstructuredSs	HLR
1	(unstructuredSS-Request/v2),	TILAX
	(unstructuredSS-Notify/v2)	
Priority low	,	

NOTE: The application context name is the last component but one of the object identifier.

Operation names are given in brackets for information with "/vn" appended to vn only operations.

# 5.1.3 Congestion control for Signalling System No. 7

The requirements of SS7 Congestion control have to be taken into account as far as possible.

Means that could be applied to achieve the required traffic reductions are described in clauses 5.1.1 and 5.1.2.

# 5.2 Compatibility

## 5.2.1 General

The present document of the Mobile Application Part is designed in such a way that an implementation which conforms to it can also conform to the Mobile Application Part operational version 1 specifications, except on the MSC-VLR interface.

A version negotiation mechanism based on the use of an application-context-name is used to negotiate the protocol version used between two entities for supporting a MAP-user signalling procedure.

When starting a signalling procedure, the MAP-user supplies an application-context-name to the MAP-provider. This name refers to the set of application layer communication capabilities required for this dialogue. This refers to the required TC facilities (e.g. version 1 or 2) and the list of operation packages (i.e. set of operations) from which operations can be invoked during the dialogue.

A version one application-context-name may only be transferred to the peer user in a MAP-U-ABORT to an entity of version two or higher (i.e. to trigger a dialogue which involves only communication capabilities defined for MAP operational version 1).

If the proposed application-context-name can be supported by the responding entity the dialogue continues on this basis otherwise the dialogue is refused and the initiating user needs to start a new dialogue, which involves another application-context-name which requires less communication capabilities but provides similar functionality (if possible).

When a signalling procedure can be supported by several application contexts that differ by their version number, the MAP-User needs to select a name. It can either select the name that corresponds to the highest version it supports or follow a more specific strategy so that the number of protocol fallbacks due to version compatibility problems is minimised.

# 5.2.2 Strategy for selecting the Application Context (AC) version

A method should be used to minimise the number of protocol fall-backs which would occur sometimes if the highest supported AC-Name were always the one selected by GSM entities when initiating a dialogue. The following method is an example that can be used mainly at transitory phase stage when the network is one of mixed phase entities.

## 5.2.2.1 Proposed method

A table (table 1) may be set up by administrative action to define the highest application context (AC) version supported by each destination; a destination may be another node within the same or a different PLMN, or another PLMN considered as a single entity. The destination may be defined by an E.164 number or an E.214 number derived from an IMSI or in North America (World Zone 1) by an E.164 number or an IMSI (E.212 number). The table also includes the date when each destination is expected to be able to handle at least one AC of the latest version of the MAP protocol. When this date is reached, the application context supported by the node is marked as "unknown", which will trigger the use of table 2.

A second table (table 2) contains an entry for each destination that has an entry in table 1. For a given entity, the entry in table 2 may be a single application context version or a vector of different versions applying to different application contexts for that entity. Table 2 is managed as described in clause 5.2.2.2.

The data for each destination will go through the following states:

- a) the version shown in table 1 is "version n-1", where 'n' is the highest version existing in this specification; table 2 is not used:
- b) the version shown in table 1 is "unknown"; table 2 is used, and maintained as described in clause 5.2.2.2;
- c) when the PLMN operator declares that an entity (single node or entire PLMN) has been upgraded to support all the MAP version n ACs defined for the relevant interface, the version shown in table 1 is set to "version n" by administrative action; table 2 is no longer used, and the storage space may be recovered.

## 5.2.2.2 Managing the version look-up table

**WHEN** it receives a MAP-OPEN ind the MAP-User determines the originating entity number either using the originating address parameter or the originating reference parameter or retrieving it from the subscriber data using the IMSI or the MSISDN.

**IF** the entity number is known:

#### **THEN**

It updates (if required) the associated list of highest supported ACs.

#### **ELSE**

It creates an entry for this entity and includes the received AC-name in the list of highest supported ACs.

WHEN starting a procedure, the originating MAP-user looks up its version control table.

**IF** the destination address is known and not timed-out.

#### THEN

It retrieves the appropriate AC-name and uses it

**IF** the dialogue is accepted by the peer

#### THEN

It does not modify the version control table

**ELSE** (this should never occur)

It starts a new dialogue with the common highest version supported (based on information implicitly or explicitly provided by the peer).

It replaces the old AC-name by the new one in the list of associated highest AC supported.

#### **ELSE**

It uses the AC-name that corresponds to the highest version it supports.

**IF** the dialogue is accepted by the peer.

#### **THEN**

It adds the destination node in its version control table and includes the AC-Name in the list of associated highest AC supported.

#### **ELSE**

It starts a new dialogue with the common highest version supported (based on information implicitly or explicitly provided by the peer).

IF the destination node was not known

#### THEN

It adds the destination node in its version control table and includes the new AC-Name in the list of associated highest AC supported.

#### **ELSE**

It replaces the old AC-name by the new one in the list of highest supported AC and reset the timer.

## 5.2.2.3 Optimising the method

A table look-up may be avoided in some cases if both the HLR and the VLR or both the HLR and the SGSN store for each subscriber the version of the AC-name used at location updating. Then:

- for procedures which make use of the same application-context, the same AC-name (thus the same version) can be selected (without any table look-up) when the procedure is triggered;
- for procedures which make use of a different application-context but which includes one of the packages used by the location updating AC, the same version can be selected (without any table look-up) when the procedure is triggered;

#### for HLR:

- Subscriber data modification (stand alone);

#### for VLR:

Data Restoration.

# 6 Requirements concerning the use of SCCP and TC

# 6.1 Use of SCCP

The Mobile Application Part (MAP) makes use of the services offered by the Signalling Connection Control Part (SCCP).

MAP supports the following SCCP versions:

- Signalling Connection Control Part, Signalling System no. 7 CCITT ("Blue Book SCCP");
- Signalling Connection Control Part, Signalling System no. 7 ITU-T Recommendation (07/96) Q.711 to Q.716 ("White Book SCCP"). Support of White Book SCCP at the receiving side shall be mandated from 00:01hrs, 1st July 2002(UTC). However, for signalling over the MAP E-interface to support inter-MSC handover/relocation, the support of White Book SCCP shall be mandated with immediate effect.

A White Book SCCP message will fail if any signalling point used in the transfer of the message does not support White Book SCCP. Therefore it is recommended that the originator of the White Book SCCP message supports a drop back mechanism or route capability determination mechanism to interwork with signalling points that are beyond the control of GSM/UMTS network operators.

In North America (World Zone 1) the national version of SCCP is used as specified in ANSI T1.112. Interworking between a PLMN in North America and a PLMN outside North America will involve an STP to translate between ANSI SCCP and ITU-T/CCITT SCCP.

The SCCP is identified as an MTP3-user and the transport of SCCP messages between two entities shall be accomplished according to the 3GPP TS 29.202 [121].

## 6.1.1 SCCP Class

MAP will only make use of the connectionless classes (0 or 1) of the SCCP.

# 6.1.2 Sub-System Number (SSN)

The Application Entities (AEs) defined for MAP consist of several Application Service Elements (ASEs) and are addressed by sub-system numbers (SSNs). The SSNs for MAP are specified in 3GPP TS 23.003 [17].

When the SGSN emulates MSC behaviour for processing messages (MAP-MO-FORWARD-SHORT-MESSAGE, MAP\_CHECK\_IMEI, MAP\_SUBSCRIBER\_LOCATION\_REPORT) towards entities which do not support interworking to SGSNs, it shall use the MSC SSN in the calling party address instead of the SGSN SSN.

When present in the network, the Presence Network Agent emulates the behaviour of the GSM Service Control Function (gsm SCF) for processing of messages (MAP-NOTE-MM-EVENT, MAP-ANY-TIME-INTERROGATION and MAP-ANY-TIME-MODIFICATION).

When a FFN (Follow Me Functional Node, see TS 23.094 [129]) is implemented in a network entity different from HLR, this network entity shall emulate HLR behaviour, i.e. it shall accept MAP-PROCESS-UNSTRUCTURED-SS-REQUEST messages addressed with SSN for HLR.

# 6.1.3 SCCP addressing

#### 6.1.3.1 Introduction

Within the GSM System there will be a need to communicate between entities within the same PLMN and in different PLMNs. Using the Mobile Application Part (MAP) for this function implies the use of Transaction Capabilities (TC) and the Signalling Connection Control Part (SCCP) of CCITT Signalling System No. 7.

Only the entities that should be addressed are described below. If the CCITT or ITU-T SCCP is used, the format and coding of address parameters carried by the SCCP for that purpose shall comply with CCITT Recommendation Q.713 with the following restrictions:

#### 1) Intra-PLMN addressing

For communication between entities within the same PLMN, a MAP SSN shall always be included in the called and calling party addresses. All other aspects of SCCP addressing are network specific.

### 2) Inter-PLMN addressing

- a) Called Party Address
  - SSN indicator = 1 (MAP SSN always included);
  - Global title indicator = 0100 (Global title includes translation type, numbering plan, encoding scheme and nature of address indicator);
  - the translation type field will be coded "00000000" (Not used). For call related messages for non-optimal routed calls (as described in 3GPP TS 23.066 [108]) directed to another PLMN the translation type field may be coded "10000000" (CRMNP);
  - Routing indicator = 0 (Routing on global title);

#### b) Calling Party Address

- SSN indicator = 1 (MAP SSNs always included);
- Point code indicator = 0;
- Global title indicator = 0100 (Global title includes translation type, numbering plan, encoding scheme and nature of address indicator);
- Numbering Plan = 0001 (ISDN Numbering Plan, E.164; In Case of Inter-PLMN Signalling, the dialogue initiating entity and dialogue responding entity shall always include its own E.164 Global Title as Calling Party Address);
- the translation type field will be coded "00000000" (Not used);
- Routing indicator = 0 (Routing on Global Title).

If ANSI T1.112 SCCP is used, the format and coding of address parameters carried by the SCCP for that purpose shall comply with ANSI specification T1.112 with the following restrictions:

1) Intra-PLMN addressing

For communication between entities within the same PLMN, a MAP SSN shall always be included in the called and calling party addresses. All other aspects of SCCP addressing are network specific.

- 2) Inter-PLMN addressing
  - a) Called Party Address
    - SSN indicator = 1 (MAP SSN always included);
    - Global title indicator = 0010 (Global title includes translation type);
    - the Translation Type (TT) field will be coded as follows:

TT = 9, if IMSI is included;

TT = 14, if MSISDN is included:

Or TT = 10, if Network Element is included. (If TT=10, then Number Portability GTT is not invoked, if TT=14, then Number Portability GTT may be invoked).

- Routing indicator = 0 (Routing on global title);
- b) Calling Party Address
  - SSN indicator = 1 (MAP SSNs always included);
  - Point code indicator = 0;
  - Global Title indicator = 0010 (Global title includes translation type);

TT = 9, if IMSI is included;

TT = 14, if MSISDN is included;

Or TT = 10, if Network Element is included. (If TT=10, then Number Portability GTT is not invoked, if TT=14, then Number Portability GTT may be invoked).

Routing indicator = 0 (Routing on Global Title).

If a Global Title translation is required for obtaining routeing information, one of the numbering plans E.164, E.212 and E.214 is applicable.

- E.212 numbering plan.

When CCITT or ITU-T SCCP is used, an E.212 number must not be included as Global Title in an SCCP UNITDATA message. The translation of an E.212 number into a Mobile Global Title is applicable in a dialogue initiating VLR, SGSN or GGSN if the routeing information towards the HLR is derived from the subscriber's IMSI. In World Zone 1 when ANSI SCCP is used, the IMSI (E.212 number) is used as a Global Title to address the HLR. When an MS moves from one VLR service area to another, the new VLR may derive the address of the previous VLR from the Location Area Identification provided by the MS in the location registration request. The PLMN where the previous VLR is located is identified by the E.212 numbering plan elements of the Location Area Identification, i.e. the Mobile Country Code (MCC) and the Mobile Network Code (MNC).

- E.214 and E.164 numbering plans.

When CCITT or ITU-T SCCP is used, only address information belonging to either E.214 or E.164 numbering plan is allowed to be included as Global Title in the Called and Calling Party Address. In World Zone 1 when ANSI SCCP is used, the IMSI (E.212 number) is used as a Global Title to address the HLR.

If the Calling Party Address associated with the dialogue initiating message contains a Global Title, the sending network entity shall include its E.164 entity number.

When receiving an SCCP UNITDATA message, SCCP shall accept either of the valid numbering plans in the Called Party Address and in the Calling Party Address.

When CCITT or ITU-T SCCP is used and an N-UNITDATA-REQUEST primitive from TC is received, SCCP shall accept an E.164 number or an E.214 number in the Called Address and in the Calling Address. In World Zone 1 when ANSI SCCP is used, the IMSI (E.212 number) is used instead of E.214 number.

The following clauses describe the method of SCCP addressing appropriate for each entity both for the simple intra-PLMN case and where an inter-PLMN communication is required. The following entities are considered:

- the Mobile-services Switching Centre (MSC);
- the Home location Register (HLR);
- the Visitor Location Register (VLR);
- the Gateway Mobile-services Switching Centre (GMSC);
- the GSM Service Control Function (gsmSCF);
- the Interworking Mobile-services Switching Centre (IWMSC);
- the Serving GPRS Support Node (SGSN);
- the Gateway GPRS Support Node (GGSN);
- the Gateway Mobile Location Centre (GMLC).

## 6.1.3.2 The Mobile-services Switching Centre (MSC)

There are several cases where it is necessary to address the MSC.

### 6.1.3.2.1 MSC interaction during handover or relocation

The address is derived from the target Cell id or from the target RNC id.

#### 6.1.3.2.2 MSC for short message routing

When a short message has to be routed to an MS, the GMSC addresses the VMSC by an MSC identity received from the HLR that complies with E.164 rules.

For MS originating short message, the IWMSC address is derived from the Service Centre address.

#### 6.1.3.2.3 MSC for location request routing

When a location request for a particular MS needs to be sent to the MS"s VMSC, the GMLC addresses the VMSC using an E.164 address received from the MS"s HLR.

#### 6.1.3.2.4 MSC for LMU Control

When a control message has to be routed to an LMU from an SMLC, the SMLC addresses the serving MSC for the LMU using an E.164 address.

## 6.1.3.3 The Home Location Register (HLR)

There are several cases where the HLR has to be addressed.

#### 6.1.3.3.1 During call set-up

When a call is initiated the HLR of the called mobile subscriber will be interrogated to discover the whereabouts of the MS. The addressing required by the SCCP will be derived from the MSISDN dialled by the calling subscriber. The dialled number will be translated into either an SPC, in the case of communications within a PLMN, or a Global Title if other networks are involved (i.e. if the communication is across a PLMN boundary).

If the calling subscriber is a fixed network subscriber, the interrogation can be initiated from the Gateway MSC of the home PLMN in the general case. If the topology of the network allows it, the interrogation could be initiated from any Signalling Point that has MAP capabilities, e.g. local exchange, outgoing International Switching Centre (ISC), etc.

## 6.1.3.3.2 Before location updating completion

When an MS registers for the first time in a VLR, the VLR has to initiate the update location dialogue with the MS's HLR and a preceding dialogue for authentication information retrieval if the authentication information must be retrieved from the HLR. When initiating either of these dialogues, the only data for addressing the HLR that the VLR has available is contained in the IMSI, and addressing information for SCCP must be derived from it. When continuing the established update location dialogue (as with any other dialogue), the VLR must derive the routeing information towards the HLR from the Calling Party Address received with the first responding CONTINUE message until the dialogue terminating message is received. This means that the VLR must be able to address the HLR based on:

- an E.214 Mobile Global Title originally derived by the VLR from the IMSI (when CCITT or ITU-T SCCP is used), or an E.212 number originally derived from IMSI (when ANSI SCCP is used, an IMSI); or
- an E.164 HLR address; or
- in the case of intra-PLMN signalling, an SPC.

When answering with Global Title to the VLR, the HLR shall insert its E.164 address in the Calling Party Address of the SCCP message containing the first responding CONTINUE message.

If the HLR is in the same PLMN as the VLR, local translation tables may exist to derive an SPC. For authentication information retrieval and location updating via the international PSTN/ISDN signalling network that requires the use of CCITT or ITU-T SCCP, the Global Title must be derived from the IMSI, using the principles contained in CCITT Recommendation E.214 and the Numbering Plan Indicator (NPI) value referenced by the SCCP Specifications. In World Zone 1 where the ANSI SCCP is used, IMSI (E.212 number) is used as Global Title. A summary of the translation from the IMSI (CCITT Recommendation E.212) to Mobile Global Title (described in CCITT Recommendation E.214) is shown below:

- E.212 Mobile Country Code translates to E.164 Country Code;
- E.212 Mobile Network Code translates to E.164 National Destination Code;
- E.212 Mobile Subscriber Identification Number (MSIN) is carried unchanged if within the E.164 number maximum length (15 digits). If the Mobile Global Title is more than 15 digits the number is truncated to 15 by deleting the least significant digits.

This translation will be done either at the application or at SCCP level in the VLR. The Mobile Global Title thus derived will be used to address the HLR.

If location updating is triggered by an MS that roams from one MSC Area into a different MSC Area served by the same VLR, the VLR shall address the HLR in the same way as if the MS registers for the first time in the VLR.

## 6.1.3.3.3 After location updating completion

In this case, the subscriber's basic MSISDN has been received from the HLR during the subscriber data retrieval procedure as well as the HLR number constituting a parameter of the MAP message indicating successful completion of the update location dialogue. From either of these E.164 numbers the address information for initiating dialogues with the roaming subscriber's HLR can be derived. Also the subscriber's IMSI may be used for establishing the routeing information towards the HLR. This may apply in particular if the dialogue with the HLR is triggered by subscriber controlled input.

Thus the SCCP address of the roaming subscriber's HLR may be an SPC, or it may be a Global title consisting of the E.164 MSISDN or the E.164 number allocated to the HLR or either the E.214 Mobile Global Title derived from the IMSI if CCITT or ITU-T SCCP is used, or the IMSI if ANSI SCCP is used (ANSI SCCP is used in World Zone 1).

#### 6.1.3.3.4 VLR restoration

If a roaming number is requested by the HLR for an IMSI that has no data record in the interrogated VLR, the VLR provides the roaming number in the dialogue terminating message. Subsequently the VLR must retrieve the authentication data from the MS's HLR, if required, and must then trigger the restore data procedure. For this purpose, the VLR has to initiate in succession two independent dialogues with the MS's HLR. The MTP and SCCP address information needed for routeing towards the HLR can be derived from the IMSI received as a parameter of the MAP message requesting the roaming number. In this case, the IMSI received from the HLR in the roaming number request shall be processed in the same way as the IMSI that is received from an MS that registers for the first time within a VLR. Alternatively to the IMSI, the Calling Party Address associated with the roaming number request may be used to obtain the routeing information towards the HLR.

## 6.1.3.3.5 During Network-Requested PDP Context Activation

When receiving a PDP PDU the GGSN may interrogate the HLR of the MS for information retrieval. When initiating such a dialogue, the only data for addressing the HLR that the GGSN has available is contained in the IMSI, and addressing information must be derived from it. The IMSI is obtained from the IP address or the X.25 address in the incoming IP message by means of a translation table. This means that the GGSN shall be able to address the HLR based on an E.214, (if CCITT or ITU-T SCCP is used), or E.212 (if ANSI SCCP is used), Mobile Global Title originally derived by the GGSN from the IMSI in the case of inter-PLMN signalling. In the case of intra-PLMN signalling, an SPC may also be used.

If the HLR is in the same PLMN as the GGSN, local translation tables may exist to derive an SPC. For information retrieval via the international PSTN/ISDN signalling network, the Global title must be derived from the IMSI, using the principles contained in CCITT Recommendation E.214 and the Numbering Plan Indicator (NPI) value referenced by the SCCP Specifications. A summary of the translation from the IMSI (CCITT Recommendation E.212) to Mobile Global Title (described in CCITT Recommendation E.214) is shown below:

- E.212 Mobile Country Code translates to E.164 Country Code;
- E.212 Mobile Network Code translates to E.164 National Destination Code;
- E.212 Mobile Subscriber Identification Number (MSIN) is carried unchanged if within the E.164 number maximum length (15 digits). If the Mobile Global Title is more than 15 digits the number is truncated to 15 by deleting the least significant digits.

This translation will be done either at the application or at SCCP level in the GGSN. The Mobile Global Title thus derived will be used to address the HLR.

## 6.1.3.3.6 Before GPRS location updating completion

When an MS registers for the first time in an SGSN, the SGSN has to initiate the update location dialogue with the MS's HLR and a preceding dialogue for authentication information retrieval if the authentication information must be retrieved from the HLR. When initiating either of these dialogues, the only data for addressing the HLR that the SGSN has available is contained in the IMSI, and addressing information for SCCP must be derived from it. When continuing the established update location dialogue (as with any other dialogue), the SGSN must derive the routeing information towards the HLR from the Calling Party Address received with the first responding CONTINUE message until the dialogue terminating message is received. This means that the SGSN must be able to address the HLR based on:

- an E.214 (if CCITT or ITU-T SCCP is used) or E.212 (if ANSI SCCP is used) Mobile Global Title originally derived by the SGSN from the IMSI; or
- an E.164 HLR address; or
- in the case of intra-PLMN signalling, an SPC.

If the HLR is in the same PLMN as the SGSN, local translation tables may exist to derive an SPC. For authentication information retrieval and location updating via the international PSTN/ISDN signalling network, the Global title must be derived from the IMSI, using the principles contained in CCITT Recommendation E.214 and the Numbering Plan Indicator (NPI) value referenced by the SCCP Specifications. A summary of the translation from the IMSI (CCITT Recommendation E.212) to Mobile Global Title (described in CCITT Recommendation E.214) is shown below:

- E.212 Mobile Country Code translates to E.164 Country Code;

- E.212 Mobile Network Code translates to E.164 National Destination Code:
- E.212 Mobile Subscriber Identification Number (MSIN) is carried unchanged if within the E.164 number maximum length (15 digits). If the Mobile Global Title is more than 15 digits the number is truncated to 15 by deleting the least significant digits.

This translation will be done either at the application or at SCCP level in the SGSN. The Mobile Global Title thus derived will be used to address the HLR.

## 6.1.3.3.7 After GPRS location updating completion

In this case, the subscriber's Basic MSISDN has been received from the HLR during the subscriber data retrieval procedure as well as the HLR number constituting a parameter of the MAP message indicating successful completion of the update location dialogue. From either of these E.164 numbers the address information for initiating dialogues with the roaming subscriber's HLR can be derived. Also the subscriber's IMSI may be used for establishing the routeing information towards the HLR.

Thus the SCCP address of the roaming subscriber's HLR may be an SPC, or it may be a Global title consisting of the E.164 MSISDN or the E.164 number allocated to the HLR or the E.214 Mobile Global Title derived from the IMSI.

## 6.1.3.3.8 Query for a Location Request

For a location request from an external client, the GMLC needs to address the home HLR of the target MS to obtain the address of the target MS's serving MSC. The GMLC uses either the international E.164 MSISDN, the international E.214 number (if CCITT or ITU-T SCCP is used) or the international E.212 number (if ANSI SCCP is used) of the MS as means to route a query to the HLR.

## 6.1.3.4 The Visitor Location Register (VLR)

There are several cases when the VLR needs to be addressed.

#### 6.1.3.4.1 Inter-VLR information retrieval

When an MS moves from one VLR service area to another, the new VLR may request the IMSI and authentication sets from the previous VLR. The new VLR derives the address of the previous VLR from the Location Area Identification provided by the MS in the location registration request.

## 6.1.3.4.2 HLR request

The HLR will only request information from a VLR if it is aware that one of its subscribers is in the VLR service area. This means that a location updating dialogue initiated by the VLR has been successfully completed, i.e. the HLR has indicated successful completion of the update location procedure to the VLR.

When initiating dialogues towards the VLR after successful completion of location updating, the routeing information used by the HLR is derived from the E.164 VLR number received as a parameter of the MAP message initiating the update location dialogue. If the VLR is in the same PLMN as the HLR, the VLR may be addressed directly by an SPC derived from the E.164 VLR number. For dialogues via the international PSTN/ISDN signalling network, presence of the E.164 VLR number in the Called Party Address is required.

## 6.1.3.5 The Interworking MSC (IWMSC) for Short Message Service

The IWMSC is the interface between the mobile network and the network to access to the Short Message Service Centre. This exchange has an E.164 address known in the SGSN or in the MSC.

### 6.1.3.6 The Equipment Identity Register (EIR)

The EIR address is either unique or could be derived from the IMEI. The type of address is not defined.

### 6.1.3.7 Void

## 6.1.3.8 The Serving GPRS Support Node (SGSN)

The HLR will initiate dialogues towards the SGSN if it is aware that one of its subscribers is in the SGSN serving area. This means that a GPRS location updating has been successfully completed, i.e., the HLR has indicated successful completion of the GPRS location update to the SGSN. The routeing information used by the HLR is derived form the E.164 SGSN number received as parameter of the MAP message initiating the GPRS update location procedure. If the SGSN is in the same PLMN as the HLR, the SGSN may be addressed directly by an SPC derived from the E.164 SGSN number. For dialogues via the international PSTN/ISDN signalling network, the presence of the E.164 SGSN number in the Called Party Address is required.

When the GMSC initiates dialogues towards the SGSN the SGSN (MAP) SSN (See 3GPP TS 23.003 [17]) shall be included in the called party address. The routeing information used by the GMSC is derived from the E.164 SGSN number received as a parameter of the MAP message initiating the forward short message procedure. If the GMSC does not support the GPRS functionality the MSC (MAP) SSN value shall be included in the called party address.

NOTE: Every VMSC and SGSN shall have uniquely identifiable application using E.164 numbers, for the purpose of SMS over GPRS when the GMSC does not support the GPRS functionality.

## 6.1.3.9 The Gateway GPRS Support Node (GGSN)

The GGSN provides interworking with external packet-switched networks, network screens and routing of the Network-Requested PDP Context activation. If a Network-Requested PDP Context activation fails, the HLR will alert the GGSN when the subscriber becomes reachable. The HLR will use the E.164 GGSN number received as parameter of the MAP message reporting the failure.

## 6.1.3.10 The Gateway MSC (GMSC) for Short Message Service

The GMSC provides interworking with the network to access the Short Message Service Centre, the mobile network and routing of Send Routing Info For SM. The GMSC has on E.164 address known in the HLR, SGSN or MSC.

6.1.3.10A Void

6.1.3.10A.1 Void

6.1.3.10A.2 Void

## 6.1.3.10B The Gateway Mobile Location Centre (GMLC)

The GMLC initiates location requests on behalf of external clients. The E.164 address of the GMLC is provided to an HLR when the GMLC requests a serving MSC address or SGSN address from the HLR for a target MS. The E.164 address of the GMLC is also provided to a serving MSC or SGSN when the GMLC requests the location of a target MS served by this MSC or SGSN.

## 6.1.3.11 Summary table

The following tables summarise the SCCP address used for invoke operations. As a principle, within a PLMN either an SPC or a GT may be used (network operation option), whereas when addressing an entity outside the PLMN the GT must be used. The address type mentioned in the table (e.g. MSISDN) is used as GT or to derive the SPC.

For a response, the originating address passed in the invoke is used as SCCP Called Party Address. For extra-PLMN addressing the own E.164 entity address is used as SCCP Calling Party Address; for intra-PLMN addressing an SPC derived from the entity number may be used instead. When using an SPC, the SPC may be taken directly from MTP.

**Table 6.1/1** 

to from	fixed net	HLR	VLR	MSC	EIR	gsmSCF	SGSN	GGSN
ITOIII	work							
fixed network		E:GT T:MSISDN						
Home Location Register			I:SPC/GT E:GT T:VLR NUMBER		-	I:SPC/GT E:GT T:gsmSCF NUMBER	I:SPC/GT E:GT T:SGSN NUMBER	I:SPC/GT E:GT T:GGSN NUMBER
Visitor Location Register		I:SPC/GT E:GT T:MGT (outside World Zone 1)/MSISDN (World Zone 1/)HLR NUMBER (note)	I:SPC/GT E:GT T:VLR NUMBER		1	I:SPC/GT E:GT T:gsmSCF NUMBER	-1	ł
mobile- services switching centre		I:SPC/GT E:GT T:MSISDN	I:SPC/GT E:GT T:VLR NUMBER	I:SPC/GT E:GT T:MSC NUMBER	I:SPC/GT E:GT T:EIR NUMBER	I:SPC/GT E:GT T:gsmSCF NUMBER	I:SPC/GT E:GT T:SGSN NUMBER	
gsm Service Control Function		I:SPC/GT E:GT T:MSISDN						
Serving GPRS Support Node		I:SPC/GT E:GT T:MGT/ MSISDN/HL R NUMBER		I:SPC/GT E:GT T:MSC NUMBER	I:SPC/GT E:GT T:EIR NUMBER	I:SPC/GT E:GT T:gsmSCF NUMBER		
Gateway GPRS Support Node		I:SPC/GT E:GT T:MGT						
Gateway Mobile Location Centre		I:SPC/GT E:GT T:MSISDN, MGT (outside World Zone 1) or IMSI (World Zone 1) (note)		I:SPC/GT E:GT T:MSC NUMBER			I:SPC/GT E:GT T:SGSN NUMBER	I

Intra-PL MN. 1: Extra (Inter)-PLMN. E: T: Address Type. GT: Global Title.

MGT: E.214 Mobile Global Title. Signalling Point Code. SPC:

NOTE:

For initiating the location updating procedure and an authentication information retrieval from the HLR preceding it, the VLR has to derive the HLR address from the IMSI of the MS. The result can be an SPC or an E.214 Mobile Global Title if CCITT or ITU-T SCCP is used, or IMSI itself if ANSI SCCP is used (ANSI SCCP is used in World Zone 1). When continuing the established update location dialogue (as with any other dialogue) the VLR must derive the routeing information towards the HLR from the Calling Party Address received with the first responding CONTINUE message until the dialogue terminating message is received.

For transactions invoked by the VLR after update location completion, the VLR may derive the information for addressing the HLR from addresses received in the course of the update location procedure (MSISDN or HLR number) or from the IMSI.

When invoking the Restore Data procedure and an authentication information retrieval from the HLR preceding it, the VLR must derive the information for addressing the HLR from the address information received in association with the roaming number request. This may be either the IMSI received as a parameter of the MAP message requesting the Roaming Number or the Calling Party Address associated with the MAP message requesting the Roaming Number.

The gsmSCF shall be addressed using more than one Global Title number. The first Global Title number is used to address a gsmSCF for MAP. The second Global Title number is used to address a gsmSCF for CAP.

For querying the HLR to obtain the VMSC address to support location services, the GMLC has to derive the HLR address from either the MSISDN or IMSI of the target MS. When using the IMSI, the result can be an SPC or an E.214 Mobile Global Title if CCITT or ITU-T SCCP is used, or IMSI itself if ANSI SCCP is used (ANSI SCCP is used in World Zone 1).

Table 6.1/2

		. 4.5.0 01.72	
t	0		GMLC
fro	om		
fixed net	work		
Home Lo	cation		
Register			
Visitor L			
Register			
Mobile-s			I:SPC/GT
Switchin	g Centre		E:GT T:MLC Number
gsm Ser	vico		I:SPC/GT
Control I			E:GT
Control	unction		T:MSISDN
Serving			I:SPC/GT
GPRS			E:GT
Support			T:MLC Number
Node			
Gateway	•		
GPRS			
Support			
Node			
Gateway			
Location			
l:	Intra-PLM		
E:		er)-PLMN.	
T:	Address	7 1	
GT:	Global Ti		
MGT:		bile Global Title.	
SPC:	Signalling	Point Code.	

## 6.2 Use of TC

The Mobile Application part makes use of the services offered by the Transaction Capabilities (TC) of Signalling System No. 7. ETS 300 287, which is based on CCITT White Book Recommendations Q.771 to Q.775, should be consulted for the full specification of TC.

The MAP uses all the services provided by TC except the ones related to the unstructured dialogue facility.

From a modelling perspective, the MAP is viewed as a single Application Service Element. Further structuring of it is for further study.

Transaction Capabilities refers to a protocol structure above the network layer interface (i.e., the SCCP service interface) up to the application layer including common application service elements but not the specific application service elements using them.

TC is structured as a Component sub-layer above a Transaction sub-layer.

The Component sub-layer provides two types of application services: services for the control of end-to-end dialogues and services for Remote Operation handling. These services are accessed using the TC-Dialogue handling primitives and TC-Component handling primitives respectively.

Services for dialogue control include the ability to exchange information related to application-context negotiation as well as initialisation data.

Services for Remote Operation handling provide for the exchange of protocol data units invoking tasks (operations), and reporting their outcomes (results or errors) plus any non-application-specific protocol errors detected by the component sub-layer. The reporting of application-specific protocol errors by the TC user, as distinct from application process errors, is also provided. The Transaction sub-layer provides a simple end-to-end connection association service over which several related protocol data units (i.e. built by the Component Sub-Layer) can be exchanged. A Transaction termination can be prearranged (no indication provided to the TC user) or basic (indication provided).

# 7 General on MAP services

# 7.1 Terminology and definitions

The term service is used in clauses 7 to 12 as defined in CCITT Recommendation X.200. The service definition conventions of CCITT Recommendation X.210 are also used.

# 7.2 Modelling principles

MAP provides its users with a specified set of services and can be viewed by its users as a "black box" or abstract machine representing the MAP service-provider. The service interface can then be depicted as shown in figure 7.2/1.




Figure 7.2/1: Modelling principles

The MAP service-users interact with the MAP service-provider by issuing or receiving MAP service-primitives at the service interface.

A MAP service-user may receive services from several instances of the MAP service-provider at the same time. In such cases the overall procedure is synchronised by the service-user.

The MAP service-primitives are named using the following notation:

#### MAP-ServicePrimitiveName type

where **type** can be any of: request (req), indication (ind), response (rsp) or confirm (cnf). (In the user arrow diagrams type is not indicated in the case of req/ind and indicated as "ack" in the case of rsp/cnf).

The services are further classified as unconfirmed-service, confirmed-service and provider-initiated-service where the first two categories refer to whether or not the service is confirmed by the service-provider. The confirmation may or may not correspond to a response provided by the other service-user.

MAP services are also classified as common MAP services that are available to all MAP service-users, and MAP service-user specific services, which are services available to one or several, but not all, MAP service-users.

A MAP dialogue is defined as an exchange of information between two MAP users in order to perform a common task. A MAP dialogue will consist of one or several MAP services.

# 7.3 Common MAP services

All MAP service-users require access to services for performing basic application layer functions:

- for establishing and clearing MAP dialogues between peer MAP service-users;
- for accessing functions supported by layers below the applications layer;
- for reporting abnormal situations;
- for handling of different MAP versions;
- for testing whether or not a persistent MAP dialogue is still active at each side.

For these purposes the following common services are defined:

- MAP-OPEN service;
- MAP-CLOSE service;
- MAP-DELIMITER service;
- MAP-U-ABORT service;
- MAP-P-ABORT service;
- MAP-NOTICE service.

In defining the service-primitives the following convention is used for categorising parameters:

- M the inclusion of the parameter is mandatory. The M category can be used for any primitive type and specifies that the corresponding parameter must be present in the indicated primitive type;
- O the inclusion of the parameter is a service-provider option. The O category can be used in indication and confirm type primitives and is used for parameters that may optionally be included by the service-provider;
- U the inclusion of the parameter is a service-user option. The U category can be used in request and response type primitives. The inclusion of the corresponding parameter is the choice of the service-user;
- C the inclusion of the parameter is conditional. The C category can be used for the following purposes:
  - to indicate that if the parameter is received from another entity it must be included for the service being considered;
  - to indicate that the service user must decide whether to include the parameter, based on the context on which the service is used;

- to indicate that one of a number of mutually exclusive parameters must be included (e.g. parameters indicating a positive result versus parameters indicating a negative result);
- to indicate that a service user optional parameter (marked "U") or a conditional parameter (marked "C") presented by the service user in a request or response type primitive is to be presented to the service user in the corresponding indication or confirm type primitive;
- (=) when appended to one of the above, this symbol means that the parameter takes the same value as the parameter appearing immediately to its left;

blank the parameter is not present.

A primitive type may also be without parameters, i.e. no parameter is required with the primitive type; in this case the corresponding column of the table is empty.

## 7.3.1 MAP-OPEN service

This service is used for establishing a MAP dialogue between two MAP service-users. The service is a confirmed service with service primitives as shown in table 7.3/1.

Request Indication Response Confirm **Parameters** U Application context name Μ M(=)C(=)Destination address Μ M(=)Destination reference U C(=)U Originating address 0 U Originating reference C(=)Specific information U U C(=) C(=)Responding address U C(=)

М

С

M(=)

C(=)

Table 7.3/1: Service-primitives for the MAP-OPEN service

#### Application context name:

This parameter identifies the type of application context being established. If the dialogue is accepted the received application context name shall be echoed. In case of refusal of dialogue this parameter shall indicate the highest version supported.

#### Destination address:

Result

Refuse-reason

Provider error

A valid SCCP address identifying the destination peer entity (see also clause 6). As an implementation option, this parameter may also, in the indication, be implicitly associated with the service access point at which the primitive is issued.

## <u>Destination-reference</u>:

This parameter is a reference that refines the identification of the called process. It may be identical to Destination address but its value is to be carried at MAP level. Table 7.3/2 describes the MAP services using this parameter. Only these services are allowed to use it.

Table 7.3/2: Use of the destination reference

MAP service	Reference type	Use of the parameter
MAP-REGISTER-SS	IMSI	Subscriber identity
MAP-ERASE-SS	IMSI	Subscriber identity
	T	1
MAP-ACTIVATE-SS	IMSI	Subscriber identity
MAD DEACTIVATE CC	IMCI	G 1
MAP-DEACTIVATE-SS	IMSI	Subscriber identity
MAP-INTERROGATE-SS	IMSI	Subscriber identity
WAI -INTERROGATE-33	IMSI	Subscriber identity
MAP-REGISTER-PASSWORD	IMSI	Subscriber identity
	1 - 3 - 3 - 3 - 3 - 3 - 3 - 3 - 3 - 3 -	, 2 3 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2
MAP-PROCESS-UNSTRUCTURED-	IMSI (note 1)	Subscriber identity
SS-REQUEST		
	1	
MAP-UNSTRUCTURED-	IMSI (note 2)	Subscriber identity
SS-REQUEST		
MAP-UNSTRUCTURED-SS-NOTIFY	IMSI (note 2)	Subscriber identity
MAT-UNSTRUCTURED-SS-NOTH-T	INISI (liote 2)	Subscriber identity
MAP-FORWARD-SHORT-MESSAGE	IMSI (note 3)	Subscriber identity
The second secon	(1000 0)	222001 Identity
MAP-REGISTER-CC-ENTRY	IMSI	Subscriber identity
	•	· · · · · · · · · · · · · · · · · · ·
MAP-ERASE-CC-ENTRY	IMSI	Subscriber identity

- NOTE 1: On the HLR HLR interface and on the HLR gsmSCF interface the Destination reference shall be either IMSI or MSISDN.
- NOTE 2: On the gsmSCF HLR interface and on the HLR HLR interface the Destination reference shall be either IMSI or MSISDN.
- NOTE 3: Only when the IMSI and the LMSI are received together from the HLR in the mobile terminated short message transfer.

## Originating address:

A valid SCCP address identifying the requestor of a MAP dialogue (see also clause 6). As an implementation option, this parameter may also, in the request, be implicitly associated with the service access point at which the primitive is issued.

#### Originating-reference:

This parameter is a reference that refines the identification of the calling process. It may be identical to the Originating address but its value is to be carried at MAP level. Table 7.3/3 describes the MAP services using the parameter. Only these services are allowed to use it. Processing of the Originating-reference shall be performed according to the supplementary service descriptions and other service descriptions, e.g. operator determined barring. Furthermore the receiving entity may be able to use the value of the Originating-reference to screen the service indication.

Table 7.3/3: Use of the originating reference

Reference type	Use of the parameter
ISDN-Address-String	Originated entity address
ISDN-Address-String	Originated entity address
T	
ISDN-Address-String	Originated entity address
Transit a c	
ISDN-Address-String	Originated entity address
ICDN Address Chaire	Originate dentitos address
ISDN-Address-String	Originated entity address
ISDN_Address_String	Originated entity address
1551 Address String	Originated entity address
ISDN-Address-String	Originated entity address
ISDN-Address-String (note)	Originated entity address
Transit and the second	
ISDN-Address-String (note)	Originated entity address
ISDN-Address-String	Originated entity address
1221, 11dd 223 Sunig	originated entity address
ISDN-Address-String	Originated entity address
	ISDN-Address-String ISDN-Address-String ISDN-Address-String ISDN-Address-String ISDN-Address-String ISDN-Address-String ISDN-Address-String

NOTE: The Originating reference may be omitted.

### Specific information:

This parameter may be used for passing any user specific information. Establishment and processing of the Specific information is not specified by GSM and shall be performed according to operator specific requirements.

## Responding address:

An address identifying the responding entity. The responding address is included if required by the context (e.g. if it is different from the destination address).

## Result:

This parameter indicates whether the peer accepts the dialogue.

## Refuse reason:

This parameter is present only if the Result parameter indicates that the dialogue is refused. It takes one of the following values:

- Application-context-not-supported;
- Invalid-destination-reference;
- Invalid-originating-reference;
- No-reason-given;
- Remote node not reachable;
- Potential version incompatibility.

## 7.3.2 MAP-CLOSE service

This service is used for releasing a previously established MAP dialogue. The service may be invoked by either MAP service-user depending on rules defined within the service-user. The service is an unconfirmed service with parameters as shown in table 7.3/4.

Table 7.3/4: Service-primitives for the MAP-CLOSE service

Parameters	Request	Indication
Release method	M	
Specific Information	U	C(=)

#### Release method:

This parameter can take the following two values:

- normal release; in this case the primitive is mapped onto the protocol and sent to the peer;
- prearranged end; in this case the primitive is not mapped onto the protocol. Prearranged end is managed independently by the two users, i.e. only the request type primitive is required in this case.

#### **Specific information:**

This parameter may be used for passing any user specific information. Establishment and processing of the Specific information is not specified by GSM GSM and shall be performed according to operator specific requirements.

## 7.3.3 MAP-DELIMITER service

This service is used to explicitly request the transfer of the MAP protocol data units to the peer entities.

See also clause 7.4 and 7.5 for the detailed use of the MAP-DELIMITER service.

The service is an unconfirmed service with service-primitives as shown in table 7.3/5.

Table 7.3/5: Service-primitives for the MAP-DELIMITER service

Parameters	Request	Indication

## 7.3.4 MAP-U-ABORT service

This service enables the service-user to request the MAP dialogue to be aborted. The service is an unconfirmed service with service-primitives as shown in table 7.3/6.

Table 7.3/6: Service-primitives for the MAP-U-ABORT service

Parameters	Request	Indication
User reason	M	M(=)
Diagnostic information	U	C(=)
Specific information	U	C(=)

## User reason:

This parameter can take the following values:

- resource limitation (congestion);
  - the requested user resource is unavailable due to congestion;
- resource unavailable;

the requested user resource is unavailable for reasons other than congestion;

- application procedure cancellation;
  - the procedure is cancelled for reasons detailed in the diagnostic information parameter;
- procedure error;
  - processing of the procedure is terminated for procedural reasons.

#### **Diagnostic information:**

This parameter may be used to give additional information for some of the values of the user-reason parameter:

Table 7.3/7: User reason and diagnostic information

User reason	Diagnostic information
Resource limitation (congestion)	-
Resource unavailable	Short term/long term problem
Application procedure cancellation	Handover cancellation/
	Radio Channel release/
	Network path release/
	Call release/
	Associated procedure failure/
	Tandem dialogue released/
	Remote operations failure
Procedure error	-

#### Specific information:

This parameter may be used for passing any user specific information. Establishment and processing of the Specific information is not specified by GSM and shall be performed according to operator specific requirements.

## 7.3.5 MAP-P-ABORT service

This service enables the MAP service-provider to abort a MAP dialogue. The service is a provider-initiated service with service-primitives as shown in table 7.3/8.

Table 7.3/8: Service-primitives for the MAP-P-ABORT service

Parameters	Indication
Provider reason	М
Source	М

## Provider reason:

This parameter indicates the reason for aborting the MAP dialogue:

- provider malfunction;
- supporting dialogue/transaction released;
- resource limitation;
- maintenance activity;
- version incompatibility;
- abnormal MAP dialogue.

#### Source:

This parameter indicates the source of the abort. For Transaction Capabilities (TC) applications the parameter may take the following values:

- MAP problem;
- TC problem;
- network service problem.

Table 7.3/9: Values of provider reason and source parameters and examples of corresponding events

Provider reason	Source	Corresponding event	
Provider	MAP	Malfunction at MAP level at peer entity	
malfunction	TC	"Unrecognised message type" or	
		"Badly formatted transaction portion" or	
		"Incorrect transaction portion" received in TC-P-ABORT	
		"Abnormal dialogue"	
	Network service	Malfunction at network service level at peer entity	
Supporting dialogue/			
transaction released			
	TC	"Unrecognised transaction ID" received in TC-ABORT	
Resource	MAP	Congestion towards MAP peer service-user	
limitation	TC	"Resource limitation" received in TC-P-ABORT	
Maintenance	MAP	Maintenance at MAP peer service-user	
activity	Network service	Maintenance at network peer service level	
Abnormal MAP	MAP	MAP dialogue is not in accordance with specified	
dialogue		application context	
Version	TC	A Provider Abort indicating "No common dialogue portion"	
incompatibility		is received in the dialogue initiated state	

## 7.3.6 MAP-NOTICE service

This service is used to notify the MAP service-user about protocol problems related to a MAP dialogue not affecting the state of the protocol machines.

The service is a provider-initiated service with service-primitive as shown in table 7.3/10.

Table 7.3/10: Service-primitive for the MAP-NOTICE service

Parameters	Indication
Problem diagnostic	M

## Problem diagnostic:

This parameter can take one of the following values:

- abnormal event detected by the peer;
- response rejected by the peer;
- abnormal event received from the peer;
- message cannot be delivered to the peer.

- 7.3.7 Void
- 7.3.8 Void
- 7.3.9 Void
- 7.3.10 Void

# 7.4 Sequencing of services

The sequencing of services is shown in figure 7.4/1 and is as follows:

#### Opening:

The MAP-OPEN service is invoked before any user specific service-primitive is accepted. The sequence may contain none, one or several user specific service-primitives. If no user specific service-primitive is contained between the MAP-OPEN and the MAP-DELIMITER primitives, then this will correspond to sending an empty Begin message in TC. If more than one user specific service-primitive is included, all are to be sent in the same Begin message. The sequence ends with a MAP-DELIMITER primitive.

## Continuing:

This sequence may not be present in some MAP dialogues. If it is present, it ends with a MAP-DELIMITER primitive. If more than one user specific service-primitive is included, all are to be included in the same Continue message.

#### Closing:


The sequence can only appear after an opening sequence or a continuing sequence. The sequence may contain none, one or several user specific service-primitives if the MAP-CLOSE primitive specifies normal release. If no user specific service-primitive is included, then this will correspond to sending an empty End message in TC. If more than one user specific service-primitive is included, all are to be sent in the same End message. If prearranged end is specified, the sequence cannot contain any user specific service-primitive. The MAP-CLOSE primitive must be sent after all user specific service-primitives have been delivered to the MAP service-provider.

#### Aborting:

A MAP service-user can issue a MAP-U-ABORT primitive at any time after the MAP dialogue has been opened or as a response to an attempt to open a MAP dialogue.

The MAP service-provider may issue at any time a MAP-P-ABORT primitive towards a MAP service-user for which a MAP dialogue exists.

MAP-U-ABORT primitives and MAP-P-ABORT primitives terminate the MAP dialogue.






Figure 7.4/1: Sequencing of services

If the reason "resource unavailable (short term problem)" is indicated in the MAP-U-ABORT indication primitive, the MAP service-user may decide to attempt a new MAP dialogue establishment immediately.

Sequencing of user specific service-primitives is done by the MAP service-user and based on rules applicable for each MAP service-user instance.

A MAP-NOTICE indication primitive may be received at any time during the active period of a MAP dialogue.

# 7.5 General rules for mapping of services onto TC

# 7.5.1 Mapping of common services

Table 7.5/1 gives an overview of the mapping rules for mapping of common services onto TC-services. Table 7.5/2 gives the mapping rules for mapping of TC-services onto common services.

Protocol machine description is given in clauses 14 to 17.

Table 7.5/1: Mapping of common services onto TC services

MAP service-primitive	TC service-primitive		
MAP-OPEN request			
(+ any user specific service primitives)	TC-BEGIN request		
+ MAP-DELIMITER request	(+ component handling primitives)		
MAP-OPEN response			
(+ any user specific service primitives)	TC-CONTINUE request (note)		
+ MAP-DELIMITER request	(+ component handling primitives)		
(any user specific service primitives)	TC-CONTINUE request		
+ MAP-DELIMITER request	(+ component handling primitives)		
(any user specific service primitives)	TC-END request		
+ MAP-CLOSE request	(+ component handling primitives)		

	MAP-U-ABORT request	TC-U-ABORT request
NOTE:	Or TC-END if the MAP-CLOSE request has	s been received before the MAP-DELIMITER
	request.	

Table 7.5/2: Mapping of TC services onto common service

TC service-primitive	MAP service-primitive		
TC-BEGIN indication	MAP-OPEN indication		
(+ component handling primitives)	(+ user specific service primitives)		
	+ MAP-DELIMITER indication (note 1)		
TC-CONTINUE indication	First time:		
(+ component handling primitives)	MAP-OPEN confirm		
	(+ user specific service primitives)		
	+ MAP-DELIMITER indication (note 1)		
	Subsequent times:		
	Subsequent times:		
	(user specific service primitives)		
TO END indication	+ MAP-DELIMITER indication (note 1)		
TC-END indication	MAP-OPEN confirm (note 6)		
(+ component handling primitives)	(user specific service primitives)		
	+ MAP-CLOSE indication		
TC-U-ABORT indication	MAP-U-ABORT indication or		
	MAP-P-ABORT indication (note 2)		
	MAP-OPEN confirmation (note 3)		
TC-P-ABORT indication	MAP-P-ABORT indication (note 4)		
	MAP-OPEN confirmation (note 5)		
NOTE 1: It may not be necessary to present this p			
NOTE 2: The mapping depends on whether the To			
	ervice-provider or a MAP-user-abort-PDU from the		
remote MAP service-user.			
NOTE 3: Only if the opening sequence is pending and if the "Abort Reason" in the TC-U-ABORT indication			
is set to "Application Context Not Supported".			
NOTE 4: If the "Abort Reason" in the TC-P-ABORT indication is set to a value different from "Incorrect Transaction Portion".			
	and if the "Abort Reason" in the TC-P-ABORT indication		
NOTE 5: Only if the opening sequence is pending and if the "Abort Reason" in the TC-P-ABORT indication is set to "Incorrect Transaction Portion".			
NOTE 6: Only if opening sequence is pending.			

# 7.5.2 Mapping of user specific services

Table 7.5/3 gives the general mapping rules which apply to mapping of MAP user specific services onto TC services and table 7.5/4 gives the similar rules for mapping of TC services onto MAP user specific services. Detailed mapping is given in clauses 14 to 17.

Table 7.5/3: Mapping of MAP user specific services onto TC services

MAP service-primitive	TC-service-primitive
MAP-xx request	TC-INVOKE request
MAP-xx response	TC-RESULT-L request
(note 1)	TC-U-ERROR request
	TC-U-REJECT request
	TC-INVOKE request (note 2)

Table 7.5/4: Mapping of TC services onto MAP user specific services

TC-service-primitive	MAP service-primitive
TC-INVOKE indication	MAP-xx indication
TC-RESULT-L indication (note 4)	MAP-xx confirm
TC-U-ERROR indication	
TC-INVOKE indication (note 2)	

TC-L-CANCEL indication	
TC-U-REJECT indication	MAP-xx confirm or
TC-L-REJECT indication	MAP-NOTICE indication (note 3)
TC-R-REJECT indication	·

Notes to tables 7.5/3 and 7.5/4:

- NOTE 1: The mapping is determined by parameters contained in the MAP-xx response primitive.
- NOTE 2: This applies only to TC class 4 operations where the operation is used to pass a result of another class 2 or class 4 operation.
- NOTE 3: The detailed mapping rules are given in clause 16.
- NOTE 4: If RESULT-NL components are present they are mapped onto the same MAP-xx confirm.

# 7.6 Definition of parameters

# 7.6.1 Common parameters

The following set of parameters is used in several MAP service-primitives.

### 7.6.1.1 Invoke Id

This parameter identifies corresponding service primitives. The parameter is supplied by the MAP service-user and must be unique over each service-user/service-provider interface.

#### 7.6.1.2 Linked Id

This parameter is used for linked services and it takes the value of the invoke Id of the service linked to.

## 7.6.1.3 Provider error

This parameter is used to indicate a protocol related type of error:

- duplicated invoke Id;
- not supported service;
- mistyped parameter;
- resource limitation;
- initiating release, i.e. the peer has already initiated release of the dialogue and the service has to be released;
- unexpected response from the peer;
- service completion failure;
- no response from the peer;
- invalid response received.

## 7.6.1.4 User error

This parameter can take values as follows:

NOTE: The values are grouped in order to improve readability; the grouping has no other significance.

a) Generic error:

- system failure, i.e. a task cannot be performed because of a problem in the entity reporting the error or in another entity. The type of entity or network resource may be indicated by use of the network resource parameter or additional network resource parameter. If and only if the problem is in the entity reporting the error, a cause of failure (FailureCauseParam) shall be included;
- data missing, i.e. an optional parameter required by the context is missing;
- unexpected data value, i.e. the data type is formally correct but its value or presence is unexpected in the current context;
- resource limitation;
- initiating release, i.e. the receiving entity has started the release procedure;
- facility not supported, i.e. the requested facility is not supported by the PLMN with detailed reasons as follows:
  - Shape of location estimate not supported;
  - Needed LCS capability not supported in serving node;
- incompatible terminal, i.e. the requested facility is not supported by the terminal.

#### b) Identification or numbering problem:

- unknown subscriber, i.e. no such subscription exists;
- number changed, i.e. the subscription does not exist for that number any more;
- unknown MSC;
- unidentified subscriber, i.e. if the subscriber is not contained in the database and it has not or cannot be established whether or not a subscription exists;
- unallocated roaming number;
- unknown equipment;
- unknown location area.

#### c) Subscription problem:

- roaming not allowed, i.e. a location updating attempt is made in an area not covered by the subscription;
- illegal subscriber, i.e. illegality of the access has been established by use of authentication procedure;
- bearer service not provisioned;
- teleservice not provisioned;
- illegal equipment, i.e. the IMEI check procedure has shown that the IMEI is blacklisted or not whitelisted.

## d) Handover problem:

- no handover number available, i.e. the VLR cannot allocate a number for handover or cannot allocate the required amount of numbers for relocation;
- subsequent handover failure, i.e. handover to a third MSC failed for some reason;
- target cell outside group call area.

#### e) Operation and maintenance problem:

- tracing buffer full, i.e. tracing cannot be performed because the tracing capacity is exceeded.
- f) Call set-up problem:

- no roaming number available, i.e. a roaming number cannot be allocated because all available numbers are in use;
- absent subscriber, i.e. the subscriber has activated the detach service or the system detects the absence condition. This error may be qualified to indicate whether the subscriber was IMSI detached, in a restricted area or did not respond to paging;
- busy subscriber. This error may be qualified to indicate that the subscriber was busy due to CCBS and that CCBS is possible;
- no subscriber reply;
- forwarding violation, i.e. the call has already been forwarded the maximum number of times that is allowed;
- CUG reject, i.e. the call does not pass a CUG check; additional information may also be given in order to indicate rejection due to e.g. incoming call barred or non-CUG membership;
- call barred. Optionally, additional information may be included for indicating either that the call meets a barring condition set by the subscriber or that the call is barred for operator reasons. In the case of barring of Mobile Terminating Short Message, the additional information may indicate a barring condition due to "Unauthorised Message Originator";
- optimal routeing not allowed, i.e. the entity which sends the error does not support optimal routeing, or the HLR will not accept an optimal routeing interrogation from the GMSC, or the call cannot be optimally routed because it would contravene optimal routeing constraints;
- forwarding failed, i.e. the GMSC interrogated the HLR for forwarding information but the HLR returned an error.
- g) Supplementary services problem:
  - call barred;
  - illegal SS operation;
  - SS error status;
  - SS not available;
  - SS subscription violation;
  - SS incompatibility;
  - negative password check;
  - password registration failure;
  - Number of Password Attempts;
  - USSD Busy;
  - Unknown Alphabet;
  - short term denial;
  - long term denial.

For definition of these errors see 3GPP TS 24.080 [38].

- h) Short message problem:
  - SM delivery failure with detailed reason as follows:
    - memory capacity exceeded;
    - MS protocol error;
    - MS not equipped;

- unknown service centre (SC);
- SC congestion;
- invalid SME address;
- subscriber is not an SC subscriber;
- and possibly detailed diagnostic information, coded as specified in 3GPP TS 23.040, under SMS-SUBMIT-REPORT and SMS-DELIVERY-REPORT. If the SM entity that returns the SM Delivery Failure error includes detailed diagnostic information, it shall be forwarded in the MAP\_MO\_FORWARD\_SHORT\_MESSAGE and in the MAP\_MT\_FORWARD\_SHORT\_MESSAGE response.
- message waiting list full, i.e. no further SC address can be added to the message waiting list.
- Subscriber busy for MT SMS, i.e. the mobile terminated short message transfer cannot be completed because:
  - another mobile terminated short message transfer is going on and the delivery node does not support message buffering; or
  - another mobile terminated short message transfer is going on and it is not possible to buffer the message for later delivery; or
  - the message was buffered but it is not possible to deliver the message before the expiry of the buffering time defined in 3GPP TS 23.040;
- Absent Subscriber SM, i.e. the mobile terminated short message transfer cannot be completed because the network cannot contact the subscriber. Diagnostic information regarding the reason for the subscriber's absence may be included with this error.
- i) Location services problem:
  - Unauthorised Requesting Network
  - Unauthorised LCS Client with detailed reasons as follows:
    - NoAdditional Information
    - Client not in MS Privacy Exception List
    - Call to Client not setup
    - Disallowed by Local Regulatory Requirements
    - Unauthorised Privacy Class
    - Unauthorised Call/Session Unrelated External Client
    - Unauthorised Call/Session Related External Client
    - Privacy override not applicable
  - Position method failure with detailed reasons as follows:
    - Congestion
    - Insufficient resources
    - Insufficient Measurement Data
    - Inconsistent Measurement Data
    - Location procedure not completed
    - QoS not attainable

- Position Method Not Available in Network
- Position Method Not Available in Location Area
- Unknown or unreachable LCS Client.

## 7.6.1.5 All Information Sent

This parameter indicates to the receiving entity when the sending entity has sent all necessary information.

# 7.6.2 Numbering and identification parameters

## 7.6.2.1 IMSI

This parameter is the International Mobile Subscriber Identity defined in 3GPP TS 23.003 [17].

## 7.6.2.2 TMSI

This parameter is the Temporary Mobile Subscriber Identity defined in 3GPP TS 23.003 [17].

## 7.6.2.3 IMEI

This parameter is the International Mobile Equipment Identity defined in 3GPP TS 23.003 [17].

### 7.6.2.3a IMEISV

This parameter is the International Mobile Equipment Identity and Software Version Number defined in 3GPP TS 23.003 [17].

## 7.6.2.4 Previous location area ld

This parameter refers to the identity of the location area from which the subscriber has roamed.

### 7.6.2.5 Stored location area ld

This parameter refers to the location area where the subscriber is assumed to be located.

#### 7.6.2.6 Current location area ld

This parameter is used to indicate the location area in which the subscriber is currently located.

## 7.6.2.7 Target location area ld

This parameter refers to the location area into which the subscriber intends to roam.

## 7.6.2.8 Target cell ld

This parameter refers to the identity of the cell to which a call has to be handed over.

## 7.6.2.8A Target RNC Id

This parameter refers to the identity of the RNC to which a call has to be relocated.

### 7.6.2.9 Void

## 7.6.2.10 Originating entity number

This parameter refers to an application layer identification of a system component in terms of its associated ISDN number.

### 7.6.2.11 MSC number

This parameter refers to the ISDN number of an MSC.

## 7.6.2.12 Target MSC number

This parameter refers to the ISDN number of an MSC to which a call has to be handed over.

### 7.6.2.13 HLR number

This parameter refers to the ISDN number of an HLR.

#### 7.6.2.14 VLR number

This parameter refers to the ISDN number of a VLR.

### 7.6.2.15 HLR Id

This parameter refers to the identity of an HLR derived from the IMSI defined in CCITT Recommendation E.212.

### 7.6.2.16 LMSI

This parameter refers to a local identity allocated by the VLR to a given subscriber for internal management of data in the VLR. LMSI shall not be sent to the SGSN.

## 7.6.2.17 MS ISDN

This parameter refers to one of the ISDN numbers assigned to a mobile subscriber in accordance with CCITT Recommendation E.213.

## 7.6.2.18 OMC ld

This parameter refers to the identity of an Operation and Maintenance Centre.

## 7.6.2.19 Roaming number

This parameter refers to the roaming number as defined in CCITT Recommendation E.213.

## 7.6.2.19A Relocation Number List

This parameter refers to the number(s) used for routing one call or several calls between MSCs during relocation.

## 7.6.2.20 Void

## 7.6.2.21 Handover number

This parameter refers to the number used for routing a call between MSCs during handover.

### 7.6.2.22 Forwarded-to number

This parameter refers to the address to which a call is to be forwarded. A subaddress may be appended. For subscribers having an originating CAMEL Phase 2 or higher subscription, this address need not be in E.164 international format.

## 7.6.2.22A Long forwarded-to number

This parameter refers to the address to which a call is to be forwarded. A subaddress may be appended. For subscribers having an originating CAMEL Phase 2 or higher subscription this address need not be in international format.

## 7.6.2.22B Long FTN Supported

This parameter indicates that the sending entity supports Long Forwarded-to Numbers.

#### 7.6.2.23 Forwarded-to subaddress

This parameter refers to the sub-address attached to the address to which a call is to be forwarded.

#### 7.6.2.24 Called number

This parameter refers to a called party number as defined in CCITT Recommendation Q.767.

## 7.6.2.25 Calling number

This parameter refers to a calling party number as defined in CCITT Recommendation Q.767.

## 7.6.2.26 Originally dialled number

This parameter refers to the number dialled by the calling party in order to reach a mobile subscriber.

#### 7.6.2.27 Service centre address

This parameter represents the address of a Short Message Service Centre.

### 7.6.2.28 Zone Code

This parameter is used to define location areas into which the subscriber is allowed or not allowed to roam (regional subscription). With a complete list of Zone Codes the VLR or the SGSN is able to determine for all its location areas whether roaming is allowed or not.

#### 7.6.2.29 MSIsdn-Alert

This parameter refers to the MSISDN stored in a Message Waiting Data File in the HLR. It is used to alert the Service Centre when the MS is again attainable.

### 7.6.2.30 Location Information

This parameter indicates the location of the served subscriber as defined in 3GPP TS 23.018 [97].

## 7.6.2.30a Location Information for GPRS

This parameter indicates the location of the served subscriber as defined in 3GPP TS 23.078 [98].

## 7.6.2.31 GMSC Address

This parameter refers to the E.164 address of a GMSC.

### 7.6.2.32 VMSC Address

This parameter refers to the E.164 address of a VMSC.

## 7.6.2.33 Group ld

This parameter is used to describe groups a subscriber can be a member of. A subscriber can partake in all group calls (VBS/VGCS) where he subscribed to the respective groups.

## 7.6.2.34 North American Equal Access preferred Carrier Id

This parameter refers to the carrier identity preferred by the subscriber for calls requiring routing via an inter-exchange carrier. This identity is used at:

- outgoing calls: when the subscriber does not specify at call set-up a carrier identity;
- forwarded calls: when a call is forwarded by the subscriber;
- incoming calls: applicable to the roaming leg of the call.

#### 7.6.2.35 Void

### 7.6.2.36 Void

## 7.6.2.37 Serving cell ld

This parameter indicates the cell currently being used by the served subscriber.

### 7.6.2.38 SGSN number

This parameter refers to the ISDN number of a SGSN.

## 7.6.2.39 SGSN address

This parameter refers to the IP-address of a SGSN. This parameter is defined in 3GPP TS 23.003 [17].

## 7.6.2.40 GGSN address

This parameter refers to the IP-address of a GGSN. This parameter is defined in 3GPP TS 23.003 [17].

## 7.6.2.41 GGSN number

This parameter refers to the ISDN number of a GGSN or the ISDN number of the protocol-converter if a protocol-converting GSN is used between the GGSN and the HLR.

### 7.6.2.42 APN

This parameter refers to the DNS name of a GGSN. This parameter is defined in 3GPP TS 23.060 [104].

### 7.6.2.43 Network Node number

This parameter refers either to the ISDN number of SGSN or to the ISDN number of MSC.

## 7.6.2.44 PDP-Type

This parameter indicates which type of protocol is used by the MS as defined in 3GPP TS 23.060 [104].

### 7.6.2.45 PDP-Address

This parameter indicates the address of the data protocol as defined in 3GPP TS 23.060 [104].

### 7.6.2.46 Additional number

This parameter can refer either to the SGSN number or to the MSC number.

#### 7.6.2.47 P-TMSI

This parameter is the Packet Temporary Mobile Subscriber Identity defined in 3GPP TS 23.003 [17].

#### 7.6.2.48 B-subscriber number

This parameter refers to the number of the destination B dialled by the A user. This may include a subaddress.

#### 7.6.2.49 B-subscriber subaddress

This parameter refers to the sub-address attached to the destination B dialled by the A user.

### 7.6.2.50 LMU Number

This parameter refers to a local number assigned to an LMU by an SMLC.

#### 7.6.2.51 MLC Number

This parameter refers to the ISDN (E.164) number of an MLC.

#### 7.6.2.52 Multicall Bearer Information

This parameter refers to the number of simultaneous bearers supported per user by the serving network.

## 7.6.2.53 Multiple Bearer Requested

This parameter indicates whether multiple bearers are requested for a relocation.

## 7.6.2.54 Multiple Bearer Not Supported

This parameter indicates whether multiple bearers are supported.

## 7.6.2.55 PDP-Charging Characteristics

This parameter indicates the charging characteristics associated with a specific PDP context as defined in 3GPP TS 32.215.

## 7.6.2.56 Selected RAB ID

The selected radio access bearer to be kept at subsequent inter-MSC handover from UMTS to GSM.

## 7.6.2.57 RAB ID

This parameter indicates the radio access bearer identifier as defined in 3GPP TS 25.413. This parameter is used to relate the radio resources with the radio access bearers.

## 7.6.2.58 gsmSCF Address

This parameter refers to the ISDN number assigned to the gsmSCF address. In an IP Multimedia Core Network, the gsmSCF-address shall contain the IM-SSF address when the IM-SSF takes the role of the gsmSCF.

### 7.6.2.59 V-GMLC Address

This parameter refers to the IP address of a V-GMLC.

## 7.6.2.60 Void

### 7.6.2.61 H-GMLC Address

This parameter refers to the IP address of a H-GMLC.

#### 7.6.2.62 PPR Address

This parameter refers to the IP address of a Privacy Profile Register.

## 7.6.2.63 Routeing Number

This parameter refers to a number used for routing purpose and identifying a network operator. See 3GPP TS 23.066 [108].

#### 7.6.2.64 Additional V-GMLC Address

This parameter refers to the IP address of a V-GMLC.

## 7.6.3 Subscriber management parameters

## 7.6.3.1 Category

This parameter refers to the calling party category as defined in CCITT Recommendation Q.767.

### 7.6.3.2 Equipment status

This parameter refers to the status of the mobile equipment as defined in 3GPP TS 22.016 [7].

#### 7.6.3.2a BMUEF

This parameter refers to the Bit Map of UE Faults and corresponds to the UESBI-Iu parameter defined in 3GPP TS 25.413 [120].

## 7.6.3.3 Extensible Bearer service

This parameter may refer to a single bearer service, a set of bearer services or to all bearer services as defined in 3GPP TS 22.002 [3]. This parameter is used only for subscriber profile management. Extensible Bearer service values include all values defined for a Bearer service parameter (7.6.4.38).

## 7.6.3.4 Extensible Teleservice

This parameter may refer to a single teleservice, a set of teleservices or to all teleservices as defined in 3GPP TS 22.003 [4]. This parameter is used only for subscriber profile management. Extensible Teleservice values include all values defined for a Teleservice parameter (7.6.4.39).

## 7.6.3.5 Extensible Basic Service Group

This parameter refers to the Basic Service Group either as an extensible bearer service (see clause 7.6.3.3) or an extensible teleservice (see clause 7.6.3.4). This parameter is used only for subscriber profile management. The null value (i.e. neither extensible bearer service nor extensible teleservice) is used to denote the group containing all extensible bearer services and all extensible teleservices.

# 7.6.3.6 GSM bearer capability

This parameter refers to the GSM bearer capability information element defined in 3GPP TS 24.008 [35].

## 7.6.3.7 Subscriber Status

This parameter refers to the barring status of the subscriber:

- service granted;
- Operator Determined Barring.

## 7.6.3.8 CUG Outgoing Access indicator

This parameter represents the Outgoing Access as defined in ETS 300 136.

## 7.6.3.9 Operator Determined Barring General Data

This parameter refers to the set of subscriber features that the network operator or the service provider can regulate. This set only includes those limitations that can be

- a) controlled in the VLR,
- b) controlled in the SGSN,
- c) controlled in the SGSN applied for short message transfer only,
- d) interrogated or modified by the gsmSCF:

ODB category	Controlled in the VLR	Controlled in the SGSN	Controlled in the SGSN applied for short message transfer only	Interrogatable and modifyable by the gsmSCF
All outgoing calls barred	X		X	X
International outgoing calls barred	X		X	X
International outgoing calls except those to the home PLMN country barred	X		X	X
Interzonal outgoing calls barred	X		X	X
Interzonal outgoing calls except those to the home PLMN country barred	X		X	X
Interzonal outgoing calls AND international outgoing calls except those directed to the home PLMN country barred	X		X	X
Premium rate (information) outgoing calls barred	X			X

Premium rate (entertainment) outgoing calls barred	X		X
Supplementary service access barred	X		X
Invocation of call transfer barred	X		X
Invocation of chargeable call transfer barred	X		Х
Invocation of internationally chargeable call transfer barred	X		X
Invocation of interzonally chargeable call transfer barred	X		X
Invocation of call transfer where both legs are chargeable barred	X		X
Invocation of call transfer if there is already an ongoing transferred call for the served subscriber in the serving MSC/VLR barred	X		X
All packet Oriented Services barred		X	X
Roamer Access to HPLMN-AP barred		Х	X
Roamer Access to VPLMN-AP barred		X	X
Outgoing calls when roaming outside the home PLMN country			X
All incoming calls			X
Incoming calls when roaming outside the home PLMN country			X
Incoming calls when roaming outside the zone of the home PLMN country			X
Roaming outside the home PLMN			X
Roaming outside the home PLMN country			X

Registration of any call forwarded-to number		X
Registration of any international call forwarded-to number		X
Registration of any international call forwarded-to number except to a number within the HPLMN country		X
Registration of any inter-zone call forwarded-to number		X
Registration of any inter-zone call forwarded-to number except to a number within the HPLMN country		X

### 7.6.3.10 ODB HPLMN Specific Data

This parameter refers to the set of subscriber features that the network operator or the service provider can regulate only when the subscriber is registered in the HPLMN. This set only includes those limitations that can be controlled in the VLR or in the SGSN:

- Operator Determined Barring Type 1;
- Operator Determined Barring Type 2;
- Operator Determined Barring Type 3;
- Operator Determined Barring Type 4.

### 7.6.3.11 Regional Subscription Data

This parameter defines the regional subscription area in which the subscriber is allowed to roam. It consists of a list of Zone Codes (see clause 7.6.2.28).

### 7.6.3.12 Regional Subscription Response

This parameter indicates either that the regional subscription data cannot be handled or that the current MSC or SGSN area is entirely restricted because of regional subscription.

## 7.6.3.13 Roaming Restriction Due To Unsupported Feature

This parameter defines that a subscriber is not allowed to roam in the current MSC area. It may be used by the HLR if a feature or service is indicated as unsupported by the VLR.

### 7.6.3.14 Extensible SS-Info

This parameter refers to all the information related to a supplementary service and is a choice between:

- extensible forwarding information (see clause 7.6.3.15);
- extensible call barring information (see clause 7.6.3.20);
- CUG info (see clause 7.6.3.22);
- extensible SS-Data (see clause 7.6.3.29).

### 7.6.3.15 Extensible forwarding information

This parameter represents the information related to each call forwarding service:

- the SS-Code of the relevant call forwarding service (see clause 7.6.4.1);
- if required, a list of extensible forwarding feature parameters (see clause 7.6.3.16).

The list may contain one item per Basic Service Group.

### 7.6.3.16 Extensible forwarding feature

This parameter applies to each combination of call forwarding service and Basic Service Group and contains the following information, as required:

extensible Basic Service Group (see clause 7.6.3.5);
extensible SS-Status (see clause 7.6.3.17);
forwarded-to number (see clause 7.6.2.22);
forwarded-to subaddress (see clause 7.6.2.23);
extensible forwarding options (see clause 7.6.3.18);
extensible no reply condition timer (see clause 7.6.4.19);
long forwarded-to number (see clause 7.6.2.22A).

If a number is required to define the forwarded-to destination then:

- If the VLR supports Long Forwarded-to Numbers then the long forwarded-to number shall be present and the forwarded-to number shall be absent;
- If the VLR does not support Long Forwarded-to Numbers then the forwarded-to number shall be present and the long forwarded-to number shall be absent.

#### 7.6.3.17 Extensible SS-Status

This parameter refers to the state information of individual supplementary services as defined in 3GPP TS 23.011 [22].

#### 7.6.3.18 Extensible Forwarding Options

This parameter refers to a set of forwarding options attached to a supplementary service. It contains the following information:

-	notification to forwarding party parameter);	(see 3GPP TS 22.082 [10] for the meaning of this
-	redirection notification to the forwarded-to party parameter);	(see 3GPP TS 22.082 [10] for the meaning of this
-	notification to calling party parameter);	(see 3GPP TS 22.082 [10] for the meaning of this
-	redirecting presentation parameter);	(see 3GPP TS 22.082 [10] for the meaning of this

forwarding reason parameter).

(see 3GPP TS 22.082 [10] for the meaning of this

### 7.6.3.19 Extensible No reply condition timer

This parameter refers to the extensible no reply condition timer for call forwarding on no reply.

### 7.6.3.20 Extensible Call barring information

This parameter contains for each call barring service:

- SS-Code (see clause 7.6.4.1);

- a list of extensible call barring feature parameters (see clause 7.6.3.21).

The list may contain one item per Basic Service Group.

### 7.6.3.21 Extensible Call barring feature

This parameter gives the status of call barring services as applicable to each Basic Service Group. The parameter contains the following information:

- Extensible Basic Service Group (see clause 7.6.3.5);

- provisioned SS-Status (see clause 7.6.3.17).

#### 7.6.3.22 CUG info

This parameter refers to the overall information required for operation for each CUG:

- CUG subscriptionList;
- CUG featureList.

### 7.6.3.23 CUG subscription

This parameter refers to the set of basic information for each CUG defined in that subscription. The following information is stored:

- CUG index:
- CUG interlock;
- Intra CUG restrictions;
- Basic Service Group List.

#### 7.6.3.24 CUG interlock

This parameter represents the CUG interlock code defined in ETS 300 138.

### 7.6.3.25 CUG index

This parameter represents the CUG index defined in ETS 300 138.

### 7.6.3.26 CUG feature

This parameter contains two parameters that are associated with the Basic Service Group. If the Basic Service Group Code is not present the feature applies to all Basic Services. The following parameters are included:

- Preferential CUG indicator:

- indicates which CUG index is to be used at outgoing call set-up using the associated Basic Service Group;
- Inter CUG Option:
  - describes whether it for the associated Basic Service Group is allowed to make calls outside the CUG and whether incoming calls are allowed;
- Basic Service Group.

See 3GPP TS 22.085 [13] for meaning of this parameter.

### 7.6.3.27 Inter CUG options

This parameter indicates the subscribers' ability to make and receive calls outside a specific closed user group. It takes any of the following values:

- CUG only facility (only calls within CUG are allowed);
- CUG with outgoing access (calls outside CUG allowed);
- CUG with incoming access (calls from outside CUG into CUG allowed);
- CUG with both incoming and outgoing access (all calls allowed).

#### 7.6.3.28 Intra CUG restrictions

This parameter describes whether or not the subscriber is allowed to originate calls to or to receive calls from within the CUG. It can take any of the following values:

- no CUG restrictions;
- CUG incoming calls barred;
- CUG outgoing calls barred.

### 7.6.3.29 Extensible SS-Data

This parameter refers to the necessary set of information required in order to characterise one supplementary service:

-	SS-Code	(see clause 7.6.4.1);
-	Extensible SS-Status (if applicable)	(see clause 7.6.3.17);
-	Extensible Override subscription option (if applicable)	(see clause 7.6.3.30);
-	Extensible CLI Restriction (if applicable)	(see clause 7.6.3.31);
_	Extensible Basic Service Group Code	(see clause 7.6.3.5).

### 7.6.3.30 Subscriber State

This parameter indicates the state of the MS as defined in 3GPP TS 23.018 [97].

#### 7.6.3.31 Requested Info

This parameter indicates the subscriber information being requested as defined in 3GPP TS 23.018 [97] and 3GPP TS 23.078 [98].

### 7.6.3.31A Requested Domain

This parameter indicates the domain (circuit switched, i.e. from the MSC/VLR, or packet switched, i.e. from the SGSN) from which the requested information should be retrieved.

### 7.6.3.32 Suppression of Announcement

This parameter indicates if the announcement or tones shall be suppressed as defined in 3GPP TS 23.078 [98].

### 7.6.3.33 Suppress T-CSI

This parameter is used to suppress the invocation of terminating CAMEL services.

### 7.6.3.34 GMSC CAMEL Subscription Info

This parameter contains CAMEL subscription information, i.e. O-CSI and/or D-CSI and/or T-CSI, which indicates to the GMSC that originating and/or terminating CAMEL services shall be invoked for the incoming call.

### 7.6.3.35 VLR CAMEL Subscription Info

This parameter identifies the subscriber as having CAMEL services that are invoked in the MSC or VLR.

#### 7.6.3.36 Supported CAMEL Phases in the VLR

This parameter indicates which phases of CAMEL are supported in the VLR.

### 7.6.3.36A Supported CAMEL Phases in the SGSN

This parameter indicates which phases of CAMEL are supported in the SGSN.

#### 7.6.3.36B Offered CAMEL4 CSIs in the VLR

This parameter indicates which CSIs of CAMEL phase 4 are offered in the VLR as defined in 3GPP TS 23.078.

#### 7.6.3.36C Offered CAMEL4 CSIs in the SGSN

This parameter indicates which CSIs of CAMEL phase 4 are offered in the SGSN as defined in 3GPP TS 23.078.

#### 7.6.3.36D Offered CAMEL4 CSIs

This parameter indicates which CSIs of CAMEL phase 4 are offered as defined in 3GPP TS 23.078.

#### 7.6.3.36E Offered CAMEL4 CSIs in interrogating node

This parameter indicates which CSIs of CAMEL phase 4 are offered in the GMSC or in the gsmSCF as defined in 3GPP TS 23.078.

#### 7.6.3.36F Offered CAMEL4 CSIs in VMSC

This parameter indicates which CSIs of CAMEL phase 4 are offered in the VMSC as defined in 3GPP TS 23.078.

#### 7.6.3.36G Offered CAMEL4 Functionalities

### 7.6.3.36H Supported CAMEL Phases

This parameter indicates which phases of CAMEL are supported as defined in 3GPP TS 23.078.

#### 7.6.3.361 Supported CAMEL Phases in interrogating node

This parameter indicates which phases of CAMEL are supported as defined in 3GPP TS 23.078. The interrogating node may be a GMSC or a gsmSCF.

This parameter indicates which functionalities of CAMEL phase 4 are offered as defined in 3GPP TS 23.078.

### 7.6.3.37 CUG Subscription Flag

This parameter indicates that a subscriber with a T-CSI also has a CUG subscription. It is defined in 3GPP TS 23.078.

### 7.6.3.38 CAMEL Subscription Info Withdraw

This parameter indicates that CAMEL Subscription Info shall be deleted from the VLR or SGSN.

#### 7.6.3.39 Voice Group Call Service (VGCS) Data

This parameter refers to one or more groups a subscriber may be a member of for voice group calls.

### 7.6.3.40 Voice Broadcast Service (VBS) Data

This parameter refers to one or more groups a subscriber may be a member of for the voice broadcast service. Per group it is further indicated whether the subscriber is only allowed to listen to respective group calls or whether he is in addition entitled to initiate respective voice broadcast calls.

### 7.6.3.41 ISDN bearer capability

This parameter refers to the ISDN bearer capability information element defined in 3GPP TS 29.007 [56].

### 7.6.3.42 Lower layer Compatibility

This parameter refers to the lower layer compatibility information element defined in 3GPP TS 24.008 [35].

#### 7.6.3.43 High Layer Compatibility

This parameter refers to the high layer compatibility information element defined in 3GPP TS 24.008 [35].

### 7.6.3.44 Alerting Pattern

This parameter is an indication that can be used by the MS to alert the user in a specific manner in case of mobile terminating traffic (switched call or USSD). That indication can be an alerting level or an alerting category.

### 7.6.3.45 GPRS Subscription Data Withdraw

This parameter indicates that GPRS Subscription Data shall be deleted from the SGSN.

#### 7.6.3.46 GPRS Subscription Data

This parameter refers to the list of PDP-Contexts that subscriber has subscribed to.

#### 7.6.3.47 QoS-Subscribed

This parameter indicates the quality of service subscribed for a certain service. It is defined in 3GPP TS 23.060 [104].

#### 7.6.3.48 VPLMN address allowed

This parameter specifies whether the MS is allowed to use a dynamic address allocated in the VPLMN. It is defined in 3GPP TS 23.060 [104].

### 7.6.3.49 Roaming Restricted In SGSN Due To Unsupported Feature

This parameter defines that a subscriber is not allowed to roam in the current SGSN area. It may be used by the HLR if a feature or service is indicated as unsupported by the SGSN.

#### 7.6.3.50 Network Access Mode

This parameter is defined in 3GPP TS 23.108.

#### 7.6.3.51 Mobile Not Reachable Reason

This parameter stores the reason for the MS being absent when an attempt to deliver a short message to an MS fails at the MSC, SGSN or both. It is defined in 3GPP TS 23.040.

### 7.6.3.52 Cancellation Type

This parameter indicates the reason of location cancellation. It is defined in 3GPP TS 23.060 [104].

#### 7.6.3.53 All GPRS Data

This parameter indicates to the SGSN that all GPRS Subscription Data shall be deleted for the subscriber.

### 7.6.3.54 Complete Data List Included

This parameter indicates to the SGSN that the complete GPRS Subscription Data stored for the Subscriber shall be replaced with the GPRS Subscription Data received.

#### 7.6.3.55 PDP Context Identifier

This parameter is used to identify a PDP context for the subscriber.

### 7.6.3.56 LSA Information

This parameter refers to one or more localised service areas a subscriber may be a member of, together with the priority, the preferential access indicator, the active mode support indicator and active mode indication of each localised service area. The access right outside these localised service areas is also indicated.

### 7.6.3.57 SoLSA support indicator

This parameter indicates that the VLR or the SGSN supports SoLSA subscription.

#### 7.6.3.58 LSA Information Withdraw

This parameter indicates that LSA information shall be deleted from the VLR or the SGSN.

#### 7.6.3.59 LMU Indicator

This parameter indicates the presence of an LMU.

### 7.6.3.60 LCS Information

This parameter defines the LCS related information for an MS subscriber and contains the following components:

- GMLC List (see clause 7.6.3.61).

- LCS Privacy Exception List (see clause 7.6.3.62).

- MO-LR List (see clause 7.6.3.65A).

- Additional LCS Privacy Exception List (see clause 7.6.3.62A).

#### 7.6.3.61 GMLC List

This parameter contains the addresses of all GMLCs that are permitted to issue a call/session unrelated or call/session related MT-LR location request for this MS. Usage of this parameter is defined in 3GPP TS 23.271.

#### 7.6.3.62 LCS Privacy Exception List

This parameter defines the classes of LCS Client that are allowed to locate any target MS. For each class, the following information is provided:

- SS-Code (see clause 7.6.4.1);

- a list of LCS privacy exception parameters (see clause 7.6.3.63).

### 7.6.3.62A Additional LCS Privacy Exception List

This parameter defines the classes of LCS Client that are allowed to locate any target MS. For each class, the following information is provided:

- SS-Code (see clause 7.6.4.1);

- a list of LCS privacy exception parameters (see clause 7.6.3.63).

The Additional LCS Privacy Exception List shall be present only if the LCS Privacy Exception List is present and contains LCS privacy exception parameters for 4 privacy exception classes.

### 7.6.3.63 LCS Privacy Exception Parameters

This parameter gives the status of each LCS privacy exception class and any additional parameters relevant to this class. The parameter contains the following information:

- provisioned SS-Status (see clause 7.6.3.17);
- privacy notification to MS user (see clause 7.6.3.65B);
- external client List (see clause 7.6.3.64);
- internal client List (see clause 7.6.3.65).
- service type List (see clause 7.6.3.65D);

#### 7.6.3.64 External Client List

This parameter is only applicable to the call/session unrelated privacy class and call/session related privacy class, and gives the identities of the external clients that are allowed to locate a target MS for a MT-LR. Each identity is an international (e.g.E.164) address. For each identified external client, GMLC restrictions may be defined. It may also be indicated if the MS shall be notified of a non-restricted MT-LR from each identified LCS client and, if so, whether notification only or notification with privacy verification shall apply. Usage of this parameter is defined in 3GPP TS 23.271.

### 7.6.3.65 Internal Client List

This parameter is only applicable to the PLMN operator privacy class and gives the identities of the internal PLMN operator clients that are allowed to locate a target MS for an NI-LR or MT-LR. Usage of this parameter is defined in 3GPP TS 23.271.

#### 7.6.3.65A MO-LR List

This parameter defines the classes of MO-LR for which a subscription exists for a particular MS. For each class, the following information is provided:

- SS-Code (see clause 7.6.4.1).

### 7.6.3.65B Privacy Notification to MS User

This parameter is applicable to the call/session unrelated privacy class and call/session related privacy class. For non-call/call related privacy class it indicates whether the MS user shall be notified for that class MT-LR from any value added LCS client when the MT-LR is restricted and be enabled to accept or override the restriction. Usage of this parameter is defined in 3GPP TS 23.271.

#### 7.6.3.65C GMLC List Withdraw

This parameter indicates whether the subscriber"s LCS GMLC list shall be deleted from the VLR or SGSN.

### 7.6.3.65D Service Type List

This parameter is only applicable to the Service type privacy class and gives the identities of the service type of the clients that are allowed to locate a target MS for an MT-LR. Usage of this parameter is defined in 3GPP TS 23.271.

#### 7.6.3.66 IST Alert Timer

This parameter indicates the IST Alert Timer value that must be used in the MSC to inform the HLR about the call activities that the subscriber performs. Units are minutes.

#### 7.6.3.67 Call Termination Indicator

This parameter indicates whether the MSC shall terminate a specific ongoing call, or all the call activities related to a specified subscriber.

#### 7.6.3.68 IST Information Withdraw

This parameter indicates that IST information shall be deleted from the VMSC.

### 7.6.3.69 IST Support Indicator

This parameter indicates the degree of IST functionality supported by the MSC (Visited MSC or Gateway MSC). It can take one of the following values:

- Basic IST functionality;
- IST command service (in addition to the basic IST functionality and including the ability to terminate all calls being carried for the identified subscriber).

### 7.6.3.70 Super-Charger Supported In HLR

This parameter is used by the HLR to indicate support of the Super-Charger functionality and an indication of the age of the subscription data stored in the HLR.

### 7.6.3.71 Super-Charger Supported In Serving Network Entity

This parameter is used to indicate support of the Super-Charger functionality by the originating entity and to indicate either that subscription data is required or the date and time of the last know subscriber data modification.

### 7.6.3.72 Age Indicator

This parameter is used by the HLR to determine the validity of the subscription data retained by the serving network entity in a Super-Charged network.

#### 7.6.3.73 GPRS enhancements support indicator

This parameter indicates to the HLR that the SGSN supports GPRS enhancements.

#### 7.6.3.74 Extension QoS-Subscribed

This parameter indicates the enhanced QoS subscribed for a certain service. It is defined in 3GPP TS 23.060. This parameter is an extension to QoS-Subscribed.

#### 7.6.3.75 SGSN CAMEL Subscription Info

This parameter identifies the subscriber as having CAMEL services that are invoked in the SGSN.

### 7.6.3.75A Extension-2 QoS-Subscribed

This parameter indicates the additional QoS information to the Extension QoS-subscribed parameter. It is a further extension to Extension QoS-Subscribed. This parameter shall be used when the maximum bit rate exceeds 8640 kbps. For more details, refer to 3GPP TS 24.008 [35].

#### 7.6.3.75B Extension-3 QoS-Subscribed

This parameter indicates the additional QoS information to the Extension QoS-subscribed parameter. It is a further extension to Extension QoS-Subscribed. This parameter shall be used when the maximum/guaranteed bit rate for uplink exceeds 8640 kbps. For more details, refer to 3GPP TS 24.008 [35].

#### 7.6.3.76 MO-SMS-CSI

This parameter identifies the subscriber as having mobile originating SMS CAMEL services as defined in 3GPP TS 23.078. For the CAMEL phase 3 the MO-SMS-CSI is the same as the SMS-CSI.

#### 7.6.3.76a MT-SMS-CSI

This parameter identifies the subscriber as having mobile terminating SMS CAMEL services as defined in 3GPP TS 23.078.

#### 7.6.3.77 GPRS-CSI

This parameter identifies the subscriber as having GPRS CAMEL services as defined in 3GPP TS 23.078.

### 7.6.3.78 CAMEL subscription info

This parameter indicates the CSI that can be controlled by CSE.

### 7.6.3.79 Extensible Call barring information for CSE

This parameter contains for each call barring service for CSE:

- SS-Code;
- a list of extensible call barring feature parameters.

The list may contain one item per Basic Service Group.

password;

- wrong password attempt counter;
- notification-to-CSE flag.

### 7.6.3.80 Extensible Forwarding information for CSE

This parameter represents the information for CSE related to each call forwarding service:

- the SS-Code of the relevant call forwarding service;
- if required, a list of extensible forwarding feature parameters;
- the list may contain one item per Basic Service Group;
- notification-to-CSE flag.

### 7.6.3.81 Modification Request for CSI

This parameter indicates the CAMEL subscription information to be modified by CSE.

### 7.6.3.81a Modification Request for ODB data

This parameter indicates the operator determined barring data to be modified by CSE.

### 7.6.3.82 Modification Request for SS Information

This parameter indicates the call forwarding and call barring supplementary service data to be modified by CSE.

### 7.6.3.83 Call Barring Data

This parameter contains the extensible call barring feature list (see clause 7.6.3.21) and Notification to CSE flag.

### 7.6.3.84 Call Forwarding Data

This parameter contains the extensible call forwarding feature list (see clause 7.6.3.16) and Notification to CSE flag.

### 7.6.3.85 ODB Data

This parameter contains the ODB general data, ODB HPLMN specific data.

### 7.6.3.86 Requested Subscription Info

This parameter indicates the subscription information being requested.

### 7.6.3.87 CS Allocation/Retention priority

This parameter indicates the allocation/retention priority for Circuit Switched (CS). It corresponds to the allocation/retention priority that is defined in 3GPP TS 23.107.

#### 7.6.3.88 ODB Info

This parameter contains the ODB data and Notification to CSE flag.

#### 7.6.3.89 Suppress VT-CSI

This parameter is used to suppress the invocation of terminating CAMEL services at the VMSC.

### 7.6.3.90 Suppress Incoming Call Barring

This parameter is used to suppress the invocation of Incoming Call Barrings.

### 7.6.3.91 gsmSCF Initiated Call

This parameter is used to indicate that the call was initiated by the gsmSCF.

#### 7.6.3.91a SuppressMTSS

This parameter is used to suppress the invocation of terminating supplementary services

### 7.6.3.92 Call barring support indicator

This parameter is used to indicate that the SGSN supports the call barring services for SMS.

#### 7.6.3.93 MNP Info Result

This parameter refers to the Mobile Number Portability (MNP) information result (see 3GPP TS 23.078 [98] and 3GPP TS 23.066 [108]). This parameter may contain the following information:

- Routeing Number (see clause 7.6.2.63).

- IMSI (see 3GPP TS 23.078[98], see also clause 7.6.2.1).

MSISDN (see clause 7.6.2.17).
 Number Portability Status (see clause 7.6.5.14).

## 7.6.3.94 Allowed Services

This parameter is used by the HLR to indicate which service is available for a call when two services have been requested, for the SCUDIF feature described in 3GPP TS 23.172 [126].

### 7.6.3.95 Unavailability Cause

This parameter is used to indicate the reason for the unavailability of one of the services as indicated by the Allowed Services IE (see 7.6.3.94) when two services have been requested, for the SCUDIF feature described in 3GPP TS 23.172 [126].

### 7.6.3.96 MNP Requested Info

This parameter indicates by its presence that Mobile Number Portability (MNP) information is requested for the subscriber, as defined in 3GPP TS 23.078 [98].

### 7.6.3.97 Access Restriction Data

This parameter refers to the radio access technologies that are possibly restricted to a subscriber via subscription data. For the use of the parameter, see 3GPP TS 23.012[23] for CS domain and 3GPP TS 23.060[104] for PS domain.

### 7.6.3.98 Supported RAT types indicator

This parameter indicates which RAT types are supported/served by the MSC/VLR or SGSN

## 7.6.4 Supplementary services parameters

#### 7.6.4.1 SS-Code

This parameter may refer to one supplementary service or a set of supplementary services as defined in 3GPP TS 22.004. For MAP this includes:

- Calling Line Identification Presentation service (CLIP);
- Calling Line Identification Restriction service (CLIR);
- Connected Line Identification Presentation service (COLP);
- Connected Line Identification Restriction service (COLR);
- Calling Name Presentation (CNAP);
- All Call Forwarding services, including Call Deflection;
- Call Waiting (CW);
- Call Hold (HOLD);
- Multi-Party service (MPTY);
- Closed User Group (CUG);
- All Charging services;
- All Call Restriction services;
- Explicit Call Transfer service (ECT);
- enhanced Multi-Level Precedence and Pre-emption service (eMLPP);
- Completion of Calls to Busy Subscriber, originating side (CCBS-A);
- Completion of Calls to Busy Subscriber, destination side (CCBS-B);
- All LCS privacy exceptions (see clause 7.6.4.44);
- Mobile Originating Location Request (MO-LR) (see clause 7.6.4.45);
- Multicall (MC).

#### 7.6.4.1A SS-Code 2

This parameter is used to refer to one or a set of supplementary services (as 7.6.4.1 "SS-Code") related to Network Signal Info 2 for SCUDIF calls (see 3GPP TS 23.172 [126]).

#### 7.6.4.2 SS-Status

This parameter refers to the state information of individual supplementary services as defined in 3GPP TS 23.011.

#### 7.6.4.3 SS-Data

This parameter refers to the necessary set of information required in order to characterise one supplementary service:

SS-Code (see clause 7.6.4.1);
 SS-Status (if applicable) (see clause 7.6.4.2);
 Override subscription option (see clause 7.6.4.4);
 CLI Restriction (see clause 7.6.4.5);

- Basic Service Group Code (see clause 7.6.4.40).

### 7.6.4.4 Override Category

This parameter refers to the subscription option Override Category attached to a supplementary service. It can take the following two values:

- Enabled;
- Disabled.

### 7.6.4.5 CLI Restriction Option

This parameter refers to the subscription option Restriction mode attached to the CLIR supplementary service. It can take the following three values:

- Permanent;
- Temporary (Default Restricted);
- Temporary (Default Allowed).

### 7.6.4.6 Forwarding Options

This parameter refers to a forwarding option attached to a supplementary service. It can take one of the following values:

-	notification to forwarding party	(see 3GPP TS 22.082 [10] for the meaning of this parameter);
-	notification to calling party	(see 3GPP TS 22.082 [10] for the meaning of this parameter);
-	redirecting presentation	(see 3GPP TS 22.082 [10] for the meaning of this parameter);
_	Forwarding reason	(see 3GPP TS 22.082 [10] for the meaning of this parameter).

### 7.6.4.7 No reply condition timer

This parameter refers to the no reply condition timer for call forwarding on no reply.

### 7.6.4.8 - 7.6.4.14 Void

### 7.6.4.15 Forwarding information

This parameter represents the information related to each call forwarding service:

the SS-Code of the relevant call forwarding service (see clause 7.6.4.1);
 if required, a list of forwarding feature parameters (see clause 7.6.4.16).
 the list may contain one item per Basic Service Group.

### 7.6.4.16 Forwarding feature

This parameter applies to each combination of call forwarding service and Basic Service Group and contains the following information, as required:

-	Basic Service Group	(see clause 7.6.4.40);
-	SS-Status	(see clause 7.6.4.2);
-	forwarded-to number	(see clause 7.6.2.22);
-	forwarded-to subaddress	(see clause 7.6.2.23);

forwarding options (see clause 7.6.4.6); no reply condition timer (see clause 7.6.4.7); long forwarded-to number (see clause 7.6.2.22A).

If a number is required to define the forwarded-to destination then:

- If the VLR supports Long Forwarded-to Numbers then the long forwarded-to number shall be present and the forwarded-to number shall be absent.
- If the VLR does not support Long Forwarded-to Numbers then the forwarded-to number shall be present and the long forwarded-to number shall be absent.

#### 7.6.4.17 Void

### 7.6.4.18 Call barring information

This parameter contains for each call barring service:

- SS-Code (see clause 7.6.4.1);

- a list of call barring feature parameters (see clause 7.6.4.19).

The list may contain one item per Basic Service Group.

## 7.6.4.19 Call barring feature

This parameter gives the status of call barring services as applicable to each Basic Service Group. The parameter contains the following information:

- Basic Service Group (see clause 7.6.4.40);
- SS-Status (see clause 7.6.4.2).

#### 7.6.4.20 New password

This parameter refers to the password which the subscriber just registered in the network.

This parameter refers to a password used by the subscriber for supplementary service control.

### 7.6.4.21 Current password

This parameter refers to a password used by the subscriber for supplementary service control.

#### 7.6.4.22 Guidance information

This parameter refers to guidance information given to a subscriber who is requested to provide a password. One of the following information may be given:

- "enter password";

this information is used for checking of the old password;

- "enter new password";

this information is used during password registration for the request of the first new password;

"enter new password again";

this information is used during password registration for the request of the new password again for verification.

#### 7.6.4.23 Void

#### 7.6.4.24 SS-Info

This parameter refers to all the information related to a supplementary service and is a choice between:

forwarding information (see clause 7.6.4.15);
call barring information (see clause 7.6.4.18);
CUG info (see clause 7.6.4.8);
SS-Data (see clause 7.6.4.3).
eMLPP information (see clause 7.6.4.41).

#### 7.6.4.25 - 7.6.4.35 Void

### 7.6.4.36 USSD Data Coding Scheme

This parameter contains the information of the alphabet and the language used for the unstructured information in an Unstructured Supplementary Service Data operation. The coding of this parameter is according to the Cell Broadcast Data Coding Scheme as specified in 3GPP TS 23.038 [25].

### 7.6.4.37 USSD String

This parameter contains a string of unstructured information in an Unstructured Supplementary Service Data operation. The string is sent either by the mobile user or the network. The contents of a string sent by the MS are interpreted by the network as specified in 3GPP TS 22.090 [16].

#### 7.6.4.38 Bearer service

This parameter may refer to a single bearer service, a set of bearer services or to all bearer services as defined in 3GPP TS 22.002 [3]. This parameter is used only for supplementary service management.

### 7,6,4.38A Bearer Service 2

This parameter is used to indicate the bearer service or set of bearer services (as 7.6.4.38 "Bearer service") related to Network Signal Info 2 for SCUDIF calls (see 3GPP TS 23.172 [126]).

#### 7.6.4.39 Teleservice

This parameter may refer to a single teleservice, a set of teleservices or to all teleservices as defined in 3GPP TS 22.003 [4]. This parameter is used only for supplementary service management.

### 7.6.4.39A Teleservice 2

This parameter is used to indicate the teleservice or set of teleservices (as 7.6.4.39 "Teleservice") related to Network Signal Info 2 for SCUDIF calls (see 3GPP TS 23.172 [126]).

### 7.6.4.40 Basic Service Group

This parameter refers to the Basic Service Group either as a bearer service (see clause 7.6.4.38) or a teleservice (see clause 7.6.4.39). This parameter is used only for supplementary service management. The null value (i.e. neither bearer service nor teleservice) is used to denote the group containing all bearer services and all teleservices.

#### 7.6.4.41 eMLPP information

This parameter contains two parameters which are associated with the eMLPP service. The following two parameters are included:

- maximum entitled priority:
  - indicates the highest priority level the subscriber is allowed to apply for an outgoing call set-up;
- default priority:
  - defines the priority level which shall be assigned to a call if no explicit priority is indicated during call set-up.

#### 7.6.4.42 SS-event

This parameter indicates the Supplementary Service for which an invocation notification is sent towards the gsmSCF. It can indicate one of the following services:

- Explicit Call Transfer (ECT)
- Call Deflection (CD)
- Multi-Party call (MPTY)
- Completion of Calls to Busy Subscriber (CCBS)

### 7.6.4.43 SS-event data

This parameter contains additional information related to Supplementary Service invocation. Depending on the service invoked it can contain the following information:

- ECT A list with all Called Party Numbers involved.
- CD The called Party number involved.

### 7.6.4.44 LCS Privacy Exceptions

Distinct SS codes are assigned to the following classes of LCS client in a target MS subscriber"s privacy exception list.

- Universal Class;
- Call/session related value added class;
- Call/session unrelated value added class:
- PLMN operator class.
- Service type class.

#### 7.6.4.45 Mobile Originating Location Request (MO-LR)

Distinct SS codes are assigned to the following classes of MO-LR:

- Basic Self Location;
- Autonomous Self Location;

- Transfer to Third Party.

#### 7.6.4.46 NbrUser

This parameter indicates the maximum number of parallel bearers that may be used as defined by the user at registration of the MC SS.

### 7.6.4.47 MC Subscription Data

This parameter contains two parameters which are associated with the MC service. The following two parameters are included:

• NbrUser:

indicates the maximum number of parallel bearers that may be used as defined by the user at registration of the MC SS

NbrSB:

indicates the maximum number of parallel bearers that may be used as defined by the user"s subscription.

#### 7.6.4.48 MC Information

This parameter contains three parameters which are associated with the MC service. The following parameters are included:

- NbrSB;
- NbrUser;
- NbrSN.

Definitions of these parameters are provided in 3GPP TS 23.135.

### 7.6.4.49 CCBS Request State

This parameter indicates the current state of the CCBS request. It can take one of seven values:

- request;
- recall;
- active;
- completed;
- suspended;
- frozen;
- deleted.

### 7.6.4.50 Basic Service Group 2

This parameter refers to the Basic Service Group either as a bearer service (see clause 7.6.4.38) or a teleservice (see clause 7.6.4.39). This parameter is used only for supplementary service management.

## 7.6.5 Call parameters

#### 7.6.5.1 Call reference number

This parameter refers to a call reference number allocated by a call control MSC.

### 7.6.5.2 Interrogation type

This parameter refers to the type of interrogation for routing information which is sent from a GMSC to an HLR. It can take either of two values:

- basic call (for information to route a call before the call has been extended to the VMSC of the called party);
- forwarding (for information to route the call to the forwarded-to destination after the VMSC of the forwarding party has requested the GMSC to resume handling of the call.

### 7.6.5.3 OR interrogation

This parameter indicates that the GMSC which interrogated the HLR for routeing information is not in the same PLMN as the HLR, and therefore that the call will potentially be optimally routed.

### 7.6.5.4 OR capability

This parameter indicates the phase of OR which the GMSC supports.

## 7.6.5.5 Forwarding reason

This parameter indicates the reason for which the call is to be forwarded. It can take one of three values:

- busy subscriber;
- mobile subscriber not reachable;
- no subscriber reply.

### 7.6.5.6 Forwarding interrogation required

This parameter indicates that if the VMSC of the forwarding subscriber requests the GMSC to resume handling of the call the GMSC shall interrogate the HLR for forwarding information.

### 7.6.5.7 O-CSI

This parameter identifies the subscriber as having originating CAMEL services as defined in 3GPP TS 23.078.

### 7.6.5.7A D-CSI

This parameter identifies the subscriber as having originating CAMEL dialled services as defined in 3GPP TS 23.078.

### 7.6.5.7B T-CSI

This parameter identifies the subscriber as having terminating CAMEL services in the GMSC, as defined in 3GPP TS 23.078.

#### 7.6.5.7C VT-CSI

This parameter identifies the subscriber as having terminating CAMEL services in the VMSC, as defined in 3GPP TS 23.078.

### 7.6.5.7D O-IM-CSI

This parameter identifies the subscriber as having originating IP Multimedia Core Network CAMEL services as defined in 3GPP TS 23.278.

#### 7.6.5.7E D-IM-CSI

This parameter identifies the subscriber as having originating IP Multimedia Core Network CAMEL dialled services as defined in 3GPP TS 23.278.

#### 7.6.5.7F VT-IM-CSI

This parameter identifies the subscriber as having terminating IP Multimedia Core Network CAMEL services as defined in 3GPP TS 23.278.

_	$\sim$	_	$\sim$	١.		•	
	h	.5.	×	١.	/o	. 1	$\boldsymbol{\neg}$
	v	. U.	v	v	··	ш	u

7.6.5.9 Void

7.6.5.10 Void

### 7.6.5.11 CCBS Feature

This parameter corresponds to the 'CCBS Description' parameter in 3GPP TS 23.093. It refers to the necessary set of information required in order to characterise a certain CCBS request. The parameter may contain the following information:

- CCBS Index (see 3GPP TS 23.093 for the use of this parameter);

- B-subscriber number (see clause 7.6.2.48);

- B-subscriber subaddress (see clause 7.6.2.49);

- Basic Service Group Code (see clause 7.6.4.40).

### 7.6.5.12 UU Data

This parameter includes User-To-User Data. It is defined in 3GPP TS 23.087.

#### 7.6.5.13 UUS CF Interaction

This parameter indicates if the call forwarding or call deflection has been activated after UUS1 request has been accepted. It is defined in 3GPP TS 23.087.

### 7.6.5.14 Number Portability Status

This parameter indicates the number portability status of subscriber. See 3GPP TS 23.066 [108].

#### 7.6.5.15 Pre-paging supported

This parameter indicates that the entity which sent it supports pre-paging.

### 7.6.5.16 MT Roaming Retry Supported

The parameter indicates that the entity which sent it supports MT Roaming Retry. When sent by the HLR, it further indicates that the GMSC also supports MT Roaming Retry.

#### 7.6.5.17 MT Roaming Retry

The parameter indicates that the GMSC receiving the IE shall start MT roaming retry (see 3GPP TS 23.018 [97] and 3GPP TS 23.012 [23]).

## 7.6.6 Radio parameters

#### 7.6.6.1 - 7.6.6.3 Void

#### 7.6.6.4 GERAN Classmark

This information element is sent from one MSC to the other MSC in the signalling for inter MSC handover. It is used to convey information related to cell capabilities, as defined in 3GPP TS 48.008.

#### 7.6.6.5 BSSMAP Service Handover

This parameter refers to the Service Handover information element defined in 3GPP TS 48.008

### 7.6.6.5A BSSMAP Service Handover List

This parameter refers to the list of Service Handover information elements defined in 3GPP TS 48.008. This parameter shall be used when there are multiple bearers and at least one of the bearers has an associated BSSMAP Service Handover parameter.

#### 7.6.6.6 RANAP Service Handover

This parameter refers to the Service Handover information element defined in 3GPP TS 25.413.

### 7.6.6.7 HO-Number Not Required

This parameter indicates that no handover or relocation number allocation is necessary.

### 7.6.6.8 Integrity Protection Information

This parameter refers to the Integrity Protection Information element defined in 3GPP TS 25.413.

### 7.6.6.9 Encryption Information

This parameter refers to the Encryption Information element defined in 3GPP TS 25.413.

#### 7.6.6.10 Radio Resource Information

This parameter refers to the Channel Type information element defined in 3GPP TS 48.008 [49].

#### 7.6.6.10A Radio Resource List

This parameter refers to list of RAB-id's and their associated Channel Type information elements defined in 3GPP TS 48.008. This parameter shall be used when there are multiple bearers and at least one of the bearers has an associated Radio Resource Information parameter.

#### 7.6.6.10B Chosen Radio Resource Information

This parameter refers to the Chosen Channel and Speech Version information elements defined in 3GPP TS 48.008.

### 7.6.6.11 Key Status

This parameter refers to the Key Status element defined in 3GPP TS 25.413.

### 7.6.6.12 Selected UMTS Algorithms

This parameters identifies the UMTS integrity and optionally encryption algorithms selected by MSC-B. Coding of this parameter is defined in 3GPP TS 25.413.

### 7.6.6.13 Allowed GSM Algorithms

This parameters identifies the allowed GSM algorithms in MSC-B. Coding of this parameter is defined in 3GPP TS 48.008.

### 7.6.6.14 Allowed UMTS Algorithms

This parameters identifies the allowed UMTS algorithms in MSC-B. Coding of this parameter is defined in 3GPP TS 25.413.

### 7.6.6.15 Selected GSM Algorithm

This parameter identifies the GSM algorithm selected by GSM BSC controlled by MSC-B. Coding of this parameter is defined in 3GPP TS 48.008.

### 7.6.6.16 Iu-Currently Used Codec

This parameter indicates the codec used at the Iu interface before handover.

### 7.6.6.17 Iu-Supported Codecs List

This parameter indicates the codecs supported by the UE and by MSC-A and the associated modes in priority order (the first entry being the highest priority codec). MSC-B uses this information to select the associated transcoder resources.

#### 7.6.6.17A lu-Available Codecs List

This parameter indicates the codecs available at the Iu interface in MSC-B and the associated modes. MSC-A uses this information to decide whether a change to a different codec at the Iu interface is possible.

#### 7.6.6.18 lu-Selected Codec

When sent by MSC-B, this parameter indicates the codec selected by MSC-B for the Iu interface. When sent by MSC-A, this parameter indicates the codec to be used by MSC-B at the Iu interface.

### 7.6.6.19 RAB Configuration Indicator

This parameter indicates by its presence that MSC-A (or MSC-B in case of subsequent handover) has generated the RAB parameters according to the preferred codec (first entry in the Iu-Supported Codecs List).

#### 7.6.6.20 UESBI-lu

This parameter refers to the UESBI-Iu (UE Specific Behaviour Information over the Iu interface) information element defined in 3GPP TS 25.413.

### 7.6.6.21 Alternative Channel Type

This parameter refers to the Channel Type information element defined in 3GPP TS 48.008 [49] for the alternative radio access bearer. This parameter is used for SCUDIF calls (see 3GPP TS 23.172 [126]).

## 7.6.7 Authentication parameters

### 7.6.7.1 Authentication set list

This parameter represents a list of sets of authentication parameters for a given subscriber.

The list either contains Authentication Triplets (Rand, Sres, Kc) or Authentication Quintuplets (Rand, Xres, Ck, Ik, Autn). If the list contains Authentication Quintuplets, the order of sequence in this list is chronological, the first quintuplet in the list is the oldest one.

#### 7.6.7.2 Rand

This parameter represents a random number used for authentication.

#### 7.6.7.3 Sres

This parameter represents the response to an authentication request.

#### 7.6.7.4 Kc

This parameter refers to a key used for ciphering purposes.

#### 7.6.7.5 Xres

This parameter represents the response to an UMTS authentication request.

#### 7.6.7.5A Ck

This parameter refers to a key used for UMTS ciphering purposes.

### 7.6.7.5B lk

This parameter refers to the Integrity Key.

#### 7.6.7.5C Autn

This parameter refers to the Authentication Token.

#### 7.6.7.6 Cksn

This parameter refers to a ciphering key sequence number.

### 7.6.7.6A Ksi

This parameter refers to a key set identifier.

#### 7.6.7.6B Auts

This parameter refers to the resynchronisation token.

### 7.6.7.7 Ciphering mode

This parameter refers to the ciphering mode which is associated with a radio channel. It may take values as follows:

- no encryption;
- identification of specific ciphering algorithm.

### 7.6.7.8 Current Security Context

This parameter represents a list of security context parameters for a given subscriber.

The list either contains GSM Security Context data (Kc, Cksn) or UMTS Security Context Data (Ck, Ik, Ksi).

### 7.6.7.9 Failure cause

This parameter refers to an authentication failure which has occurred. It may take values as follows:

- wrong user response;

wrong network signature.

#### 7.6.7.10 Re-attempt

It indicates whether the failure ocurred in a normal authentication attempt or in an authentication reattempt (there was a previous unsuccessful authentication).

### 7.6.7.11 Access Type

It indicates whether the authentication procedure was initiated due to a call, an emergency call, a location updating, a supplementary service procedure, a short message transfer, a GPRS attach procedure, a routing area updating, a service request, a MS initiated Detach in GPRS, a PDP context activation or a PDP context deactivation procedure.

## 7.6.8 Short message parameters

### 7.6.8.1 SM-RP-DA

This parameter represents the destination address used by the short message service relay sub-layer protocol. It can be either of the following:

-	IMSI	(see clause 7.6.2.1);
-	LMSI	(see clause 7.6.2.16);
-	MS-ISDN	(see clause 7.6.2.17);
-	roaming number	(see clause 7.6.2.19);
-	service centre address	(see clause 7.6.2.27).

### 7.6.8.2 SM-RP-OA

This parameter refers to the originating address used by the short message service relay sub-layer protocol. It can be either of the following:

```
- MS-ISDN (see clause 7.6.2.17);
- service centre address (see clause 7.6.2.27).
```

#### 7.6.8.3 MWD status

This parameter indicates whether or not the address of the originator service centre is already contained in the Message Waiting Data file. In addition, it contains the status of the Memory Capacity Exceeded Flag (MCEF), the status of the Mobile subscriber Not Reachable Flag (MNRF) and the status of the Mobile station Not Reachable for GPRS flag (MNRG).

### 7.6.8.4 SM-RP-UI

This parameter represents the user data field carried by the short message service relay sub-layer protocol.

### 7.6.8.5 SM-RP-PRI

This parameter is used to indicate whether or not delivery of the short message shall be attempted when a service centre address is already contained in the Message Waiting Data file.

### 7.6.8.6 SM Delivery Outcome

This parameter indicates the cause for setting the message waiting data. It can take one of the following values:

- Absent subscriber;

- MS memory capacity exceeded;
- Successful transfer.

### 7.6.8.7 More Messages To Send

This parameter is used to indicate whether or not the service centre has more short messages to send.

#### 7.6.8.8 Alert Reason

This parameter is used to indicate the reason why the service centre is alerted. It can take one of the following values:

- MS present;
- Memory Available.

### 7.6.8.9 Absent Subscriber Diagnostic SM

This parameter is used to indicate the reason why the subscriber is absent. For the values for this parameter see 3GPP TS 23.040.

#### 7.6.8.10 Alert Reason Indicator

This parameter indicates that the alert reason is sent to the HLR due to GPRS activity.

#### 7.6.8.10A Additional Alert Reason Indicator

This parameter indicates that the alert reason is sent to the HLR due to IMS activity.

### 7.6.8.11 Additional SM Delivery Outcome

This parameter is used to indicate the GPRS delivery outcome in case a combination between delivery outcome for GPRS and non-GPRS are sent to the HLR.

### 7.6.8.12 Additional Absent Subscriber Diagnostic SM

This parameter indicates the reason of the additional SM Delivery Outcome.

### 7.6.8.13 Delivery Outcome Indicator

This parameter indicates that the delivery outcome sent to the HLR is for GPRS.

#### 7.6.8.14 GPRS Node Indicator

This parameter indicates that the Network Node Number sent by the HLR is the SGSN number.

## 7.6.8.15 GPRS Support Indicator

This parameter indicates that the SMS-GMSC supports GPRS specific procedure of combine delivery of Short Message via MSC and/or via the SGSN.

### 7.6.8.16 SM-RP-MTI

This parameter represents the RP-Message Type Indicator of the Short Message. It is used to distinguish a SM sent to the mobile station in order to acknowledge an MO-SM initiated by the mobile from a normal MT-SM. This parameter is formatted according to the formatting rules of address fields as described in 3GPP TS 23.040.

#### 7.6.8.17 SM-RP-SMEA

This parameter represents the RP-Originating SME-address of the Short Message Entity that has originated the SM. This parameter is used by the short message service relay sub-layer protocol and is formatted according to the formatting rules of address fields as described in 3GPP TS 23.040.

### 7.6.8.18 IP-SM-GW SM Delivery Outcome

This parameter is used to indicate the delivery outcome for the IMS domain.

### 7.6.8.19 IP-SM-GW Absent Subscriber Diagnostic SM

This parameter indicates the reason of the IP-SM-GW SM Delivery Outcome.

#### 7.6.8.20 IP-SM-GW Indicator

This parameter indicates indicates by its presence that sm-deliveryOutcome is for delivery via IMS.

## 7.6.9 Access and signalling system related parameters

### 7.6.9.1 AN-apdu

This parameter includes one or two concatenated complete 3GPP TS 25.413 or 3GPP TS 48.006 [48] messages, as described in 3GPP TS 23.009 and 3GPP TS 29.010. The access network protocol ID indicates that the message or messages are according to either 3GPP TS 48.006 [48] or 3GPP TS 25.413. For the coding of the messages see 3GPP TS 25.413, 3GPP TS 48.006 [48] and 3GPP TS 48.008 [49].

### 7.6.9.2 CM service type

This parameter identifies the service category being requested by the subscriber:

- mobile originating call;
- emergency call establishment;
- short message service;
- mobile originating call re-establishment;
- mobile terminating call;
- SS request;
- Voice group call set-up;
- Voice broadcast set-up.

#### 7.6.9.3 Access connection status

This parameter represents the following access connection status information:

- RR-connection status (established/not established);
- ciphering mode (on/off);
- authentication status (authenticated/not authenticated).

### 7.6.9.4 External Signal Information

This parameter contains concatenated information elements (including tag and length) which are defined by a common protocol version, preceded by the associated protocol ID. It is used to transport information of the indicated protocol via MAP interfaces.

### 7.6.9.5 Access signalling information

This parameter refers to any set of information elements imported from 3GPP TS 24.008 [35].

### 7.6.9.6 Location update type

This parameter refers to the location update type (normal, periodic or IMSI attach) contained in the 3GPP TS 24.008 [35] LOCATION REGISTRATION REQUEST message.

#### 7.6.9.7 Protocol ID

This parameter refers to the protocol to which the coding of the content of the associated External Signal Information conforms.

The following values are defined:

- 04.08;
- 08.06;
- ETS 300 102-1.

This value indicates the protocol defined by ETS 300 102-1 (EDSS1).

### 7.6.9.8 Network signal information

This parameter is transported as external signal information. The protocol ID shall be set to "ETS 300 102-1".

The network signal information may include the following information elements as defined in 3GPP TS 29.007 [56]:

- ISDN BC; the tag and length are defined by ETS 300 102-1.

For the content, see 3GPP TS 29.007 [56].

- HLC; the tag and length are defined by ETS 300 102-1.

For the content, see 3GPP TS 29.007 [56].

- LLC; the tag and length are defined by ETS 300 102-1.

For the content, see 3GPP TS 29.007 [56].

They are contained in the Signal Information parameter according to figure 7.6/1 (irrespective of the order):




Figure 7.6/1: Network signal information parameter

### 7.6.9.8A Network signal information 2

This parameter is transported as additional external signal information for SCUDIF calls, described in 3GPP TS 23.172 [126]. The protocol ID and possibly included information elements are identical to Network Signal Information, defined in 7.6.9.8, "Network signal information".

#### 7.6.9.9 Call Info

This parameter is transported as external signal information. The protocol ID shall be set to "3GPP TS 24.008 [35]".

The Call Info includes the set of information elements from the original SETUP message and is imported from 3GPP TS 24.008 [35].

### 7.6.9.10 Additional signal info

This parameter is transported as external signal information. The protocol ID shall be set to "ETS 300 356".

The additional signal information may include the following information elements:

- Calling Party Number as defined by ETS 300 356.
- Generic Number as defined by ETS 300 356.

They are contained in the Signal Information parameter according to figure 7.6/2 (irrespective of the order):




Figure 7.6/2: Additional signal information parameter

## 7.6.10 System operations parameters

### 7.6.10.1 Network resources

This parameter refers to a class or type of network resource:

- PLMN;
- HLR:
- VLR (current or previous);
- MSC (controlling or current);
- EIR;
- radio sub-system.

#### 7.6.10.2 Trace reference

This parameter represents a reference associated with a GSM only tracing request as defined in 3GPP TS 52.008 [61]. The parameter is managed by OMC/EM.

#### 7.6.10.2A Trace reference 2

This parameter represents a reference associated with a tracing request as defined in 3GPP TS 32.421 [131] and 3GPP TS 32.422 [132]. The parameter is managed by EM.

### 7.6.10.3 Trace type

This parameter identifies the type of trace for GSM only tracing request. Trace types are fully defined in 3GPP TS 52.008 [61]. If the activation of the tracing is requested only for UMTS, then this parameter shall contain value "No MSC Trace" for MSC Record Type and value "No BSS Trace" for BSS Record Type.

#### 7.6.10.4 Additional network resources

This parameter refers to a class or type of network resource:

- SGSN;
- GGSN;
- GMLC;
- gsmSCF;
- NPLR;
- AuC.

#### 7.6.10.5 Trace depth list

This parameter identifies the list of depths of trace per network element. See 3GPP TS 32.422 [132].

### 7.6.10.6 Trace NE type list

This parameter identifies the list of network elements to be traced. See 3GPP TS 32.422 [132].

### 7.6.10.7 Trace interface list

This parameter identifies the list of interfaces or protocols per network element to be traced. See 3GPP TS 32.422 [132].

#### 7.6.10.8 Trace event list

This parameter identifies the list of events per network element, which trigger a Trace Recording Session. See 3GPP TS 32.422 [132].

### 7.6.10.9 Trace support indicator

This parameter indicates that UMTS trace parameters are supported in the VLR or in the SGSN.

### 7.6.10.10 Trace Propagation List

This parameter indicates UMTS trace propagation parameters sent from one MSC to the other MSC in the signalling for inter MSC handover/relocation. See 3GPP TS 32.422 [132].

#### 7.6.11 Location Service Parameters

### 7.6.11.1 Age of Location Estimate

This parameter indicates how long ago the location estimate was obtained.

### 7.6.11.2 Deferred MT-LR Response Indicator

This parameter shows that this is a response to a deferred mt-lr request.

#### 7.6.11.3 Deferred MT-LR Data

This parameter is used to report the deferred location event type, the location information and reason why the serving node aborted monitoring the event to the GMLC. The termination cause mt-lrRestart shall be used to trigger the GMLC to restart the location procedure in all the cases where the sending node detects that the location procedure cannot be successfully performed anymore by the sending node and that it could be successfully performed by another node (as for example when. Cancel Location or Send Identification has been received). The location information shall be included only if the termination cause is mt-lrRestart. The network node number contained in the location information refers to the node where the MS/UE has moved to and shall be included if available, like in case Send Identification has been received.

#### 7.6.11.4 LCS Client ID

This parameter provides information related to the identity of an LCS client.

#### 7.6.11.5 LCS Event

This parameter identifies an event associated with the triggering of a location estimate.

7.6.11.6 Void

### 7.6.11.7 LCS Priority

This parameter gives the priority of the location request.

### 7.6.11.8 LCS QoS

This parameter defines the Quality of Service (QoS) for any location request. It is composed of the following elements.

1) Response Time

Indicates the category of response time – 'low delay' or 'delay tolerant'.

2) Horizontal Accuracy

Indicates the required horizontal accuracy of the location estimate.

3) Vertical Coordinate

Indicates if a vertical coordinate is required (in addition to horizontal coordinates).

4) Vertical Accuracy

Indicates the required vertical accuracy of the location estimate (inclusion is optional).

5) Velocity Request

Indicates that velocity should be returned if available (inclusion is optional).

### 7.6.11.9 CS LCS Not Supported by UE

This parameter is used by the VLR to indicate to the HLR that the UE does not support neither UE Based nor UE Assisted positioning methods for Circuit Switched Location Services. VLR defines the presence of this parameter on the basis of the Classmark 3 information.

### 7.6.11.10 PS LCS Not Supported by UE

This parameter is used by the SGSN to indicate to the HLR that the UE does not support neither UE Based nor UE Assisted positioning methods for Packet Switched Location Services. SGSN defines the presence of this parameter on the basis of the UE capability information and the access technology supported by the SGSN.

#### 7.6.11.11 Location Estimate

This parameter gives an estimate of the location of an MS in universal coordinates and the accuracy of the estimate. The estimate is expressed in terms of the geographical shapes defined by 3GPP TS 23.032. and is composed of the type of shape plus the encoding of the shape itself. Any type of shape defined in 3GPP TS 23.032 can be filled in in the Location Estimate parameter, but only the encoding of the following shapes shall be carried by Location Estimate:

- Ellipsoid point with uncertainty circle
- Ellipsoid point with uncertainty ellipse
- Ellipsoid point with altitude and uncertainty ellipsoid
- Ellipsoid arc
- Ellipsoid point

The encoding for the remaining types of shape, defined in the 3GPP TS 23.032, shall be filled in in the Additional Location Estimate parameter.

### 7.6.11.11A GERAN Positioning Data

This parameter provides positioning data associated with a successful or unsuccessful location attempt for a target MS described in 3GPP TS 49.031 [59a].

### 7.6.11.11B UTRAN Positioning Data

This parameter provides positioning data associated with a successful location attempt for a target MS as described in 3GPP TS 25.413 [120]. It contains the positioningDataDiscriminator and positioningDataSet parts of the RANAP PositionData element only.

### 7.6.11.11C GERAN GANSS Positioning Data

This parameter provides GANSS positioning data associated with a successful or unsuccessful location attempt for a target MS as described in 3GPP TS 49.031 [59a] if GANSS has been used.

### 7.6.11.11D UTRAN GANSS Positioning Data

This parameter provides GANSS positioning data associated with a successful location attempt for a target MS as described in 3GPP TS 25.413 [120] if GANSS has been used. It contains the GANSS-PositioningDataSet part of the RANAP PositionData element only.

### 7.6.11.12 Location Type

This parameter indicates the type of location estimate required by the LCS client. Possible location estimate types include:

- current location;
- current or last known location;
- initial location for an emergency services call;
- deferred location event type;
- notification verification only.

#### 7.6.11.13 NA-ESRD

This parameter only applies to location for an emergency services call in North America and gives the North American Emergency Services Routing Digits.

#### 7.6.11.14 NA-ESRK

This parameter only applies to location for an emergency services call in North America and gives the North American Emergency Services Routing Key.

### 7.6.11.15 LCS Service Type Id

This parameter defines the LCS Service Type of the current positioning request. The possible values are defined in 3GPP TS 22.071 [123]

### 7.6.11.16 Privacy Override

This parameter indicates if MS privacy is overridden by the LCS client when the GMLC and VMSC/SGSN for an MT-LR are in the same country.

### 7.6.11.17 Supported LCS Capability Sets

This parameter indicates which capability sets of LCS are supported in the VLR or SGSN.

### 7.6.11.18 LCS Codeword

This parameter contains the codeword associated to current positioning request as described in 3GPP TS 23.271 [26a].

### 7.6.11.19 NA-ESRK Request

This parameter allows the MSC to indicate that it requires the GMLC to allocate a NA-ESRK based on the target MS location estimate. This parameter only applies to emergency services calls in North America.

### 7.6.11.20 Supported GAD Shapes

This parameter indicates which of the shapes defined in 3GPP TS 23.032 are supported. If the parameter is not provided then the receiving node shall assume that the sending entity supports the following shapes:

- Ellipsoid point with uncertainty circle
- Ellipsoid point with uncertainty ellipse
- Ellipsoid point with altitude and uncertainty ellipsoid
- Ellipsoid arc
- Ellipsoid point

#### 7.6.11.21 Additional Location Estimate

This parameter gives an estimate of the location of an MS/UE in universal coordinates and the accuracy of the estimate. This parameter allows the location estimate to be expressed in any of the geographical shapes defined in 3GPP TS 23.032

#### 7.6.11.22 Cell ld Or SAI

For GERAN access, this parameter contains the Global Cell Identifier for the cell that the subscriber is currently attached to. For UTRAN access, this parameter contains the Service Area Identifier for the cell that the subscriber is currently attached to.

#### 7.6.11.23 LCS-Reference Number

This parameter represents a reference between a request and a responce of a deferred mt-lr procedure as described in 3GPP TS 23.271 [26a].

### 7.6.11.24 LCS Privacy Check

This parameter refers to the requested privacy check related actions (call/session unrelated and/or call/session related) from MSC or SGSN provided by H-GMLC. Possible requested actions are:

- positioning allowed without notifying the UE user;
- positioning allowed with notification to the UE user;
- positioning requires notification and verification by the UE user; positioning is allowed only if granted by the UE user or if there is no response to the notification;
- positioning requires notification and verification by the UE user; positioning is allowed only if granted by the UE user;
- positioning not allowed.

### 7.6.11.25 Additional LCS Capability Sets

This parameter indicates which capability sets of LCS are supported in the VLR or SGSN.

#### 7.6.11.26 Area Event Info

This parameter defines the requested deferred MT-LR area event information. The parameter consists of area definition, type of area event, occurrence info and minimum interval time.

### 7.6.11.27 Velocity Estimate

This parameter gives an estimate of the velocity of an MS and the accuracy of the estimate. The estimate is expressed in terms of speed and bearing as defined by 3GPP TS 23.032 [122], and is composed of the velocity terms plus the

encoding of the velocity itself. Only the encoding of the following velocity definitions shall be carried by the Velocity Estimate:

- Horizontal Velocity
- Horizontal with Vertical Velocity
- Horizontal Velocity with Uncertainty
- Horizontal with Vertical Velocity and Uncertainty

### 7.6.11.28 Accuracy Fulfilment Indicator

This parameter indicates the fulfilled accuracy of the positioning procedure. For details see 3GPP TS 23.271 [26a].

#### 7.6.11.29 MO-LR Short Circuit Indicator

This parameter indicates whether MO-LR short circuit feature is permitted. For details see 3GPP TS 23.271 [26a].

### 7.6.11.30 Reporting PLMN List

This parameter provides a list of PLMNs in which subsequent periodic MO-LR TTTP requests will be made. For details see 3GPP TS 23.271 [26a].

#### 7.6.11.31 Periodic LDR information

This parameter refers to the periodic reporting interval and reporting amount of the deferred periodic location. For details see 3GPP TS 23.271 [26a].

#### 7.6.11.32 Sequence Number

This parameter refers to the number of the periodic location reports completed. The sequence number would be set to 1 in the first location report and increment by 1 for each new report. When the number reaches the reporting amount value, the H-GMLC (for a periodic MT-LR or a periodic MO-LR transfer to third party) will know the procedure is complete. For details see 3GPP TS 23.271 [26a].

### 7.6.12 Void

## 7.7 Representation of a list of a basic parameter in serviceprimitives

In some service-primitives several instances of a basic parameter of clause 7.6 are required. In the service descriptions such cases will be represented as



in the tables where ParameterName refers to one of the parameters defined in clause 7.6. This corresponds to the following construction rule:



Figure 7.7/1: Construction of Lists

# 8 Mobility services

## 8.1 Location management services

### 8.1.1 Void

8.1.1.1 Void

8.1.1.2 Void

8.1.1.3 Void

## 8.1.2 MAP\_UPDATE\_LOCATION service

### 8.1.2.1 Definition

This service is used by the VLR to update the location information stored in the HLR.

The MAP\_UPDATE\_LOCATION service is a confirmed service using the service primitives given in table 8.1/2.

### 8.1.2.2 Service primitives

Table 8.1/2: MAP\_UPDATE\_LOCATION

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
MSC Address	M	M(=)		
VLR number	M	M(=)		
LMSI	U	C(=)		
Supported CAMEL Phases	С	C(=)		
SoLSA Support Indicator	С	C(=)		
IST Support Indicator	С	C(=)		
Super-Charger Supported in Serving Network Entity	С	C(=)		
Long FTN Supported	С	C(=)		
Supported LCS Capability Sets	С	C(=)		
Offered CAMEL 4 CSIs	С	C(=)		
Inform Previous Network Entity	С	C(=)		
CS LCS Not Supported by UE	С	C(=)		
V-GMLC Address	U	C(=)		
IMEISV	С	C(=)		
Skip Subscriber Data Update	U	C(=)		
Supported RAT Types Indicator	U	C(=)		
ADD Capability			U	C(=)
HLR number			С	C(=)
User error			С	C(=)
Provider error				0

### 8.1.2.3 Parameter definitions and use

#### Invoke Id

See definition in clause 7.6.1.

### <u>IMSI</u>

See definition in clause 7.6.2.

#### MSC Address

See definition for MSC number in clause 7.6.2. The MSC address is used for short message delivery only and for each incoming call set-up attempt the MSRN will be requested from the VLR.

#### VLR number

See definition in clause 7.6.2.

#### **LMSI**

See definition in clause 7.6.2. It is an operator option to provide the LMSI from the VLR; it is mandatory for the HLR to support the LMSI handling procedures.

#### Supported CAMEL Phases

This parameter indicates which phases of CAMEL are supported. Must be present if a CAMEL phase different from phase 1 is supported. Otherwise may be absent.

#### HLR number

See definition in clause 7.6.2. The presence of this parameter is mandatory in case of successful HLR updating.

#### **SoLSA Support Indicator**

This parameter is used by the VLR to indicate to the HLR in the Update Location indication that SoLSA is supported. If this parameter is not included in the Update Location indication and the Subscriber is marked as only allowed to roam in Subscribed LSAs, then the HLR shall reject the roaming and indicate to the VLR that roaming is not allowed to that Subscriber in the VLR.

This SoLSA Support Indicator shall be stored by the HLR per VLR where there are Subscribers roaming. If a Subscriber is marked as only allowed to roam in Subscribed LSAs while roaming in a VLR and no SoLSA Support indicator is stored for that VLR, the location status of that Subscriber shall be set to Restricted.

#### **IST Support Indicator**

This parameter is used to indicate to the HLR that the VMSC supports basic IST functionality, that is, the VMSC is able to terminate the Subscriber Call Activity that originated the IST Alert when it receives the IST alert response indicating that the call(s) shall be terminated. If this parameter is not included in the Update Location indication and the Subscriber is marked as an IST Subscriber, then the HLR may limit the service for the subscriber (by inducing an Operator Determined barring of Roaming, Incoming or Outgoing calls), or allow service assuming the associated risk of not having the basic IST mechanism available.

This parameter can also indicate that the VMSC supports the IST Command service, including the ability to terminate all calls being carried for the identified subscriber by using the IMSI as a key. If this additional capability is not included in the Update Location indication and the HLR supports the IST Command capability, then the HLR may limit the service for the subscriber (by inducing an Operator Determined barring of Roaming, Incoming or Outgoing calls), or allow service assuming the associated risk of not having the IST Command mechanism available.

### Long FTN Supported

This parameter indicates that the VLR supports Long Forwarded-to Numbers.

#### Super-Charger Supported in Serving Network Entity

This parameter is used by the VLR to indicate to the HLR that the VLR supports the Super-Charger functionality and whether subscription data has been retained by the VLR. If subscription data has been retained by the VLR the age indicator shall be included. Otherwise the VLR shall indicate that subscriber data is required.

If this parameter is absent then the VLR does not support the Super-Charger functionality.

#### Supported LCS Capability Sets

This parameter indicates, if present, the capability sets of LCS which are supported. If the parameter is sent but no capability set is marked as supported then the VLR does not support LCS at all.

If this parameter is absent then the VLR may support at most LCS capability set 1, that is LCS Release98 or Release99 version.

#### Offered CAMEL 4 CSIs

This parameter indicates the CAMEL phase 4 CSIs offered in the VMSC/VLR (see clause 7.6.3.36D).

## **Inform Previous Network Entity**

This parameter is used by the VLR to ask the HLR to inform the previous network entity about the update by sending the previous network entity a Cancel Location message. It is used in case Super-Charger is supported in the network and the serving network entity has not been able to inform the previous network entity that MS has moved, that is if it has not sent Send Identification to the previous serving entity.

## CS LCS Not Supported by UE

See definition in clause 7.6.11.

#### V-GMLC address

See definition in clause 7.6.2.

## **IMEISV**

For definition of the parameter see clause 7.6.2. For the use of this parameter see 3GPP TS 23.012. IMEISV shall be present if ADD function is supported and a new IMEISV is to be notified to the HLR (The functional requirements for the presence of IMEISV due to ADD are described in 3GPP TS 22.101 clause 7.4).

## Skip Subscriber Data Update

The presence of the parameter is optional and if present it indicates that the service is solely used to inform the HLR about change of IMEISV. The parameter is used to optimise signalling load during Location Update procedure.

# Supported RAT Types Indicator

This parameter indicates, if present, which access technologies (e.g. GERAN and / or UTRAN) are served by the MSC/VLR (see clause 7.6.3)

# **ADD Capability**

This parameter indicates, if present, the support of ADD function by the HLR.

#### User error

In case of unsuccessful updating, an error cause shall be returned by the HLR. The following error causes defined in clause 7.6.1 may be used, depending on the nature of the fault:

- unknown subscriber;
- roaming not allowed;

This cause will be sent if the MS is not allowed to roam into the PLMN indicated by the VLR number. The cause is qualified by the roaming restriction reason "PLMN Not Allowed", "Supported RAT Types Not Allowed" or "Operator Determined Barring". If no qualification is received (HLR with MAP Version 1), "PLMN Not Allowed" is taken as default.

- system failure;
- unexpected data value.

#### Provider error

For definition of provider errors see clause 7.6.1.

# 8.1.3 MAP\_CANCEL\_LOCATION service

# 8.1.3.1 Definition

This service is used between HLR and VLR to delete a subscriber record from the VLR. It may be invoked automatically when an MS moves from one VLR area to another, to remove the subscriber record from the old VLR, or by the HLR operator to enforce a location updating from the VLR to the HLR, e.g. on withdrawal of a subscription.

Also this service is used between HLR and SGSN to delete a subscriber record from the SGSN. It may be invoked automatically when an MS moves from one SGSN area to another, to remove the subscriber record from the old SGSN, or by the HLR operator to enforce a location updating from the SGSN to the HLR.

The MAP\_CANCEL\_LOCATION service is a confirmed service using the primitives defined in table 8.1/3.

# 8.1.3.2 Service primitives

Table 8.1/3: MAP\_CANCEL\_LOCATION

Parameter name	Request	Indication	Response	Confirm
Invoke Id	М	M(=)	M(=)	M(=)
IMSI	М	M(=)		
LMSI	С	C(=)		
Cancellation Type	С	C(=)		
User error			C	C(=)
Provider error				0

# 8.1.3.3 Parameter definitions and use

#### Invoke Id

See definition in clause 7.6.1.

#### **IMSI**

See definition in clause 7.6.2.

# **LMSI**

See definition in clause 7.6.2. The LMSI shall be included if it has been received from VLR. LMSI is not applicable between SGSN and HLR.

Value 0000 0000 can be used to indicate that the LMSI is not in use.

# Cancellation Type

See definition in clause 7.6.3. The presence of this parameter is mandatory when the Cancel Location is sent to the SGSN. The parameter may also be sent during an inter-VLR location update. If the VLR receives this parameter and does not understand it, the VLR shall ignore it and should by default assume an Update procedure.

#### User error

If the cancellation fails, an error cause is to be returned by the VLR or by the SGSN. One of the following error causes defined in clause 7.6.1 shall be used:

- unexpected data value;
- data missing.

## Provider error

For definition of provider errors see clause 7.6.1.

# 8.1.4 MAP\_SEND\_IDENTIFICATION service

# 8.1.4.1 Definition

The MAP\_SEND\_IDENTIFICATION service is used between a VLR and a previous VLR to retrieve IMSI and authentication data for a subscriber registering afresh in that VLR.

It may also be used to send the MSC number from a VLR to a previous VLR.

The MAP\_SEND\_IDENTIFICATION service is a confirmed service using the service primitives defined in table 8.1/4.

# 8.1.4.2 Service primitives

Table 8.1/4: MAP\_SEND\_IDENTIFICATION

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
TMSI	M	M(=)		
Number of requested vectors	M	M(=)		
Segmentation prohibited indicator	С	C(=)		
MSC Number	U	C(=)		
Previous Location Area Id	U	C(=)		
Hop Counter	U	C (=)		
IMSI			С	C(=)
Authentication set			U	C(=)
Current Security Context			U	C(=)
User error			С	C(=)
Provider error				0

#### 8.1.4.3 Parameter definitions and use

# Invoke Id

See definition in clause 7.6.1.

#### **TMSI**

See definition in clause 7.6.2.

If multiple service requests are present in a dialogue then this parameter shall be present in every service request.

#### Number of requested vectors

A number indicating how many authentication vectors the new VLR is prepared to receive. The previous VLR shall not return more vectors than indicated by this parameter.

This parameter shall be present in the first (or only) request of the dialogue. If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one

# Segmentation prohibited indicator

This parameter indicates if the new VLR or SGSN allows segmentation of the response at MAP user level.

This parameter may be present only in the first request of the dialogue.

# **IMSI**

See definition in clause 7.6.2. The IMSI is to be returned if the service succeeds.

If multiple service requests are present in a dialogue and the service succeeds then this parameter shall not be present in any service response other than the first one

# MSC Number

This is the ISDN number assigned to the MSC currently serving the MS.

#### Previous Location Area Id

See definition in clause 7.6.2. Together with the TMSI the Previous Location Area Id can be used to derive the IMSI.

#### Authentication set

See definition in clause 7.6.7. If the service succeeds a list of up to five authentication sets is returned, if there are any available.

## **Current Security Context**

See definition in clause 7.6.7. If the service succeeds, a list of either GSM or UMTS Security Context parameters can be returned.

#### Hop Counter

For the use of this parameter see 3GPP TS 23.012 [23].

#### User error

This parameter is mandatory if the service fails. The following error cause defined in clause 7.6.1 may be used, depending on the nature of the fault:

- unidentified subscriber.

# Provider error

For definition of provider errors see clause 7.6.1.

8.1.5 Vo	old
----------	-----

8.1.5.1 Void

8.1.5.2 Void

8.1.5.3 Void

# 8.1.6 MAP\_PURGE\_MS service

#### 8.1.6.1 Definition

This service is used between the VLR and the HLR to cause the HLR to mark its data for an MS so that any request for routing information for a mobile terminated call or a mobile terminated short message will be treated as if the MS is not reachable. It is invoked when the subscriber record for the MS is to be deleted in the VLR, either by MMI interaction or automatically, e.g. because the MS has been inactive for several days. This service shall not be used if both the VLR and HLR support the Super-Charger functionality.

Also this service is used between the SGSN and the HLR to cause the HLR to mark its data for an MS so that any request for routing information for a mobile terminated short message or a network requested PDP-context activation will be treated as if the MS is not reachable. It is invoked when the subscriber record for the MS is to be deleted in the SGSN, either by MMI interaction or automatically, e.g. because the MS has been inactive for several days. This service shall not be used if both the SGSN and HLR support the Super-Charger functionality.

The MAP\_PURGE\_MS service is a confirmed service using the primitives defined in table 8.1/6.

# 8.1.6.2 Service primitives

Table 8.1/6: MAP PURGE MS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
VLR number	С	C(=)		
Freeze TMSI			С	C(=)
Freeze P-TMSI			С	C(=)
SGSN number	С	C(=)		
User error			С	C(=)
Provider error				0

# 8.1.6.3 Parameter definitions and use

# Invoke ID

See definition in clause 7.6.1.

#### <u>IMSI</u>

See definition in clause 7.6.2.

#### VLR number

Shall be present if the sender is VLR. See definition in clause 7.6.2.

# SGSN number

Shall be present if the sender is SGSN. See definition in clause 7.6.2.

# Freeze TMSI

This parameter is sent to the VLR to indicate that the TMSI has to be frozen. It shall be present if the received VLR number matches the stored VLR number.

#### Freeze P-TMSI

This parameter is sent to the SGSN to indicate that the P-TMSI has to be frozen. It shall be present if the received SGSN number matches the stored SGSN number.

#### User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

# Provider error

See definition of provider errors in clause 7.6.1.

# 8.1.7 MAP\_UPDATE\_GPRS\_LOCATION service

# 8.1.7.1 Definition

This service is used by the SGSN to update the location information stored in the HLR.

The MAP\_UPDATE\_GPRS\_LOCATION service is a confirmed service using the service primitives given in table 8.1/7.

# 8.1.7.2 Service primitives

Table 8.1/7: MAP\_UPDATE\_GPRS\_LOCATION

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
SGSN number	M	M(=)		
SGSN address	M	M(=)		
Supported CAMEL Phases	С	C(=)		
SoLSA Support Indicator	С	C(=)		
Super-Charger Supported in Serving Network Entity	С	C(=)		
GPRS enhancements support indicator	С	C(=)		
Supported LCS Capability Sets	С	C(=)		
Offered CAMEL 4 CSIs	С	C(=)		
Inform Previous Network Entity	С	C(=)		
PS LCS Not Supported by UE	С	C(=)		
V-GMLC Address	U	C(=)		
Call barring support indicator	С	C(=)		
IMEISV	С	C(=)		
Skip Subscriber Data Update	U	C(=)		
Supported RAT Types Indicator	U	C(=)		
ADD Capability			U	C(=)
HLR number			С	C(=)
User error			С	C(=)
Provider error				0

# 8.1.7.3 Parameter definitions and use

## Invoke Id

See definition in clause 7.6.1.

**IMSI** 

See definition in clause 7.6.2.

SGSN number

See definition in clause 7.6.2.

SGSN address

See definition in clause 7.6.2.

## Supported CAMEL Phases

This parameter indicates which phases of CAMEL are supported. <u>The SGSN can only support CAMEL phase 3 or greater.</u>

# **SoLSA Support Indicator**

This parameter is used by the SGSN to indicate to the HLR in the Update GPRS Location indication that SoLSA is supported. If this parameter is not included in the Update GPRS Location indication and the Subscriber is marked as only allowed to roam in Subscribed LSAs, then the HLR shall reject the roaming and indicate to the SGSN that roaming is not allowed to that Subscriber in the SGSN.

This SoLSA Support Indicator shall be stored by the HLR per SGSN where there are Subscribers roaming. If a Subscriber is marked as only allowed to roam in Subscribed LSAs while roaming in a SGSN and no SoLSA Support indicator is stored for that SGSN, the location status of that Subscriber has to be set to Restricted.

# Super-Charger Supported in Serving Network Entity

This parameter is used by the SGSN to indicate to the HLR that the SGSN supports the Super-Charger functionality and whether subscription data has been retained by the SGSN. If subscription data has been retained by the SGSN the age indicator shall be included. Otherwise the SGSN shall indicate that subscriber data is required.

If this parameter is absent then the SGSN does not support the Super-Charger functionality.

# GPRS enhancements support indicator

This parameter is used by the SGSN to indicate to the HLR in the Update GPRS Location indication that GPRS enhancements are supported. If this parameter is included in the Update GPRS Location indication the HLR may send the extension QoS parameter in the PDP contexts to the SGSN. The HLR may send the extension-2 QoS and the extension-3 QoS parameters with the extension QoS parameter.

#### HLR number

See definition in clause 7.6.2. The presence of this parameter is mandatory in case of successful HLR updating.

# Supported LCS Capability Sets

This parameter indicates, if present, the capability sets of LCS which are supported. If the parameter is sent but no capability set is marked as supported then the SGSN does not support LCS at all.

The SGSN is not allowed to indicate support for LCS capability set 1.

If this parameter is absent then the SGSN does not support LCS at all.

#### Offered CAMEL 4 CSIs

This parameter indicates the CAMEL phase 4 CSIs offered in the SGSN (see clause 7.6.3.36D).

#### Inform Previous Network Entity

This parameter is used by the SGSN to ask the HLR to inform the previous network entity about the update by sending the previous network entity a Cancel Location message. It is used in case Super-Charger is supported in the network and the serving network entity has not been able to inform the previous network entity that MS has moved, that is if it has not sent SGSN Context Request to the previous serving entity.

#### PS LCS Not Supported by UE

See definition in clause 7.6.11.

## V-GMLC address

See definition in clause 7.6.2.

#### Call Barring support indicator

See definition in clause 7.6.3.92.

#### **IMEISV**

For definition of the parameter see clause 7.6.2. For the use of this parameter see 3GPP TS 23.060. IMEISV shall be present if ADD function is supported and the IMEISV is new in SGSN (The functional requirements for the presence of IMEISV due to ADD are described in 3GPP TS 22.101 clause 7.4).

# Skip Subscriber Data Update

The presence of the parameter is optional and if present it indicates that the service is solely used to inform the HLR about change of IMEISV. The parameter is used to optimise signalling load during Location Update procedure.

# Supported RAT Types Indicator

This parameter indicates, if present, which access technologies (e.g. GERAN and/or UTRAN) are served by the SGSN (see clause 7.6.3)

# **ADD Capability**

This parameter indicates, if present, the support of ADD function by the HLR.

## User error

In case of unsuccessful updating, an error cause shall be returned by the HLR. The following error causes defined in clause 7.6.1 may be used, depending on the nature of the fault:

- unknown subscriber;
- roaming not allowed.

This cause will be sent if the MS is not allowed to roam into the PLMN indicated by the SGSN number. The cause is qualified by the roaming restriction reason "PLMN Not Allowed", "Supported RAT Types Not Allowed" or "Operator Determined Barring".

- system failure;
- unexpected data value.

The diagnostic in the Unknown Subscriber may indicate 'Imsi Unknown' or 'Gprs Subscription Unknown'.

#### Provider error

For definition of provider errors see clause 7.6.1.

# 8.1.8 MAP-NOTE-MM-EVENT

#### 8.1.8.1 Definition

This service is used between the VLR and the gsmSCF or between the SGSN and the gsmSCF when a mobility management event for a subscriber has been processed successfully, that subscriber is provisioned with M-CSI or MG-CSI and the relevant mobility management event is marked for reporting.

This service is also used between the VLR and the Presence Network Agent or between the SGSN and the Presence Network Agent to notify the Presence Network Agent when a mobility management event for a subscriber has been processed successfully, that subscriber is provisioned with M-CSI or MG-CSI and the relevant mobility management event is marked for reporting (see 3GPP TS 23.141 [128]).

# 8.1.8.2 Service primitives

The service primitives are shown in table 8.1/8.

Table 8.1/8: MAP\_NOTE\_MM\_EVENT parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	М	M(=)	M(=)	M(=)
Event Met	М	M(=)		
Service Key	М	M(=)		
IMSI	М	M(=)		
Basic MSISDN	М	M(=)		
Location Information for GPRS	С	C(=)		
Location Information	С	C(=)		
LSA Identity	С	C(=)		
Supported CAMEL Phases	М	M(=)		
Offered CAMEL 4	С	C(=)		
Functionalities				
User error			С	C(=)
Provider error				0

# 8.1.8.3 Parameter use

#### Event Met

This parameter indicates the mobility management event that has lead to the notification. It shall have one of the following values for a mobility management event reported by the VLR:

- Location update in the same VLR service area;
- Location update to another VLR service area;
- IMSI attach;
- MS initiated IMSI detach (explicit detach);
- Network initiated IMSI detach (implicit detach).

It shall have one of the following values for a mobility management event reported by the SGSN:

- Routeing area update in the same SGSN service area;
- Routeing area update to another SGSN service area;
- GPRS attach;
- MS initiated GPRS detach;
- Network initiated GPRS detach;
- Network initiated transfer to the "not reachable for paging" state.

#### Service Key

See clause 7.6.x.

## <u>IMSI</u>

See clause 7.6.x.

#### **Basic MSISDN**

See clause 7.6.x.

# **Location Information**

See clause 7.6.2.30. This information shall be sent when the event is reported by a VLR, if available.

#### Location Information for GPRS

See clause 7.6.2.30a. This information shall be sent when the event is reported by an SGSN, if available.

# **LSA** Identity

See clause 7.6.x. This information shall be sent, if available.

#### Supported CAMEL Phases

See clause 7.6.x. This information shall always be sent.

# Offered CAMEL 4 Functionalities

This parameter indicates the CAMEL phase 4 functionalities offered by the sending entity, VMSC/VLR or SGSN (see clause 7.6.3.36G).

# User error

This parameter is sent by the receiving entity when an error is detected. It shall have one of the following values:

- Data Missing;

- Unexpected Data Value;
- Unknown Subscriber;
- MM-EventNotSupported.

#### Provider error

This is defined in clause 7.6.1.

# 8.2 Paging and search

# 8.2.1 MAP\_PAGE service

# 8.2.1.1 Definition

This service is used between VLR and MSC to initiate paging of an MS for mobile terminated short message or unstructured SS notification.

The MAP\_PAGE service is a confirmed service using the primitives from table 8.2/1.

# 8.2.1.2 Service primitives

Table 8.2/1: MAP\_PAGE

Parameter name	Request	Indication	Response	Confirm
Invoke Id	М	M(=)	M(=)	M(=)
IMSI	М	M(=)		
Stored location area Id	M	M(=)		
TMSI	U	C(=)		
User error			С	C(=)
Provider error				0

# 8.2.1.3 Parameter definitions and use

## Invoke Id

See definition in clause 7.6.1.

## **IMSI**

See definition in clause 7.6.2. The IMSI is used to define the paging subgroup. If the TMSI is not supplied, paging on the radio path uses the IMSI as an identifier.

#### Stored location area Id

See definition in clause 7.6.2.

# **TMSI**

See definition in clause 7.6.2. The TMSI is included if paging on the radio channel is to use the TMSI as an identifier.

#### User error

The following error causes defined in clause 7.6.1 may be sent by the user in case of a paging error, depending on the failure reason:

- absent subscriber;
- unknown location area;
- busy subscriber;

- system failure;
- this corresponds to the case where there is no call associated with the MAP\_PAGE service, i.e. if the call has been released but the dialogue to the VLR has not been aborted;
- unexpected data value.

#### Provider error

See definition in clause 7.6.1.

# 8.2.2 MAP\_SEARCH\_FOR\_MS service

# 8.2.2.1 Definition

This service is used between VLR and MSC to initiate paging of an MS in all location areas of that VLR. It is used if the VLR does not hold location area information confirmed by radio contact.

The MAP\_SEARCH\_FOR\_MS service is a confirmed service using the primitives from table 8.2/2.

# 8.2.2.2 Service primitives

Table 8.2/2: MAP\_SEARCH\_FOR\_MS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	М	M(=)	M(=)	M(=)
IMSI	М	M(=)		
Current location area Id			С	C(=)
User error			С	C(=)
Provider error				0

# 8.2.2.3 Parameter definitions and use

#### Invoke Id

See definition in clause 7.6.1.

#### **IMSI**

See definition in clause 7.6.2. The IMSI is used to identify the subscriber when paging on the radio path.

# Current location area Id

See definition in clause 7.6.2. In case of successful outcome of the service, i.e. if the MS responds to paging, the Location Area Id of the area in which the MS responded is given in the response.

#### User error

The following error causes defined in clause 7.6.1 shall be sent by the user if the search procedure fails, depending on the failure reason:

- absent subscriber;

this error cause is returned by the MSC if the MS does not respond to the paging request;

- system failure;
- this corresponds to the case where there is no call associated with the MAP\_SEARCH\_FOR\_MS service, i.e. if the call has been released but the dialogue to the VLR has not been aborted;
- busy subscriber;
- unexpected data value.

#### Provider error

See definition in clause 7.6.1.

# 8.3 Access management services

# 8.3.1 MAP\_PROCESS\_ACCESS\_REQUEST service

# 8.3.1.1 Definition

This service is used between MSC and VLR to initiate processing of an MS access to the network, e.g. for mobile originated short message submission or after being paged by the network.

The MAP\_PROCESS\_ACCESS\_REQUEST service is a confirmed service using the primitives from table 8.3/1.

# 8.3.1.2 Service primitives

Table 8.3/1: MAP\_PROCESS\_ACCESS\_REQUEST

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
CM service type	M	M(=)		
Access connection status	M	M(=)		
Current Location Area Id	M	M(=)		
Serving cell Id	M	M(=)		
TMSI	С	C(=)		
Cksn	С	C(=)		
IMSI	С	C(=)	С	C(=)
IMEI	С	C(=)	С	C(=)
MSISDN			U	C(=)
User error			С	C(=)
Provider error				Ö

# 8.3.1.3 Parameter definitions and use

# Invoke Id

See definition in clause 7.6.1.

## CM service type

See definition in clause 7.6.9.

## Access connection status

See definition in clause 7.6.9.

# Current Location Area Id

See definition in clause 7.6.2. This parameter is used to update the VLR in case of previous VLR failure.

# Serving cell Id

See definition in clause 7.6.2.

#### **TMSI**

See definition in clause 7.6.2. Either TMSI or IMSI as received from the MS are included in the Request/Indication, but one shall be present. In case of CM Service Type "Emergency Call Establishment", the IMEI may replace IMSI/TMSI.

# Cksn

See definition in clause 7.6.7. In case of access with TMSI, the Cksn shall be present.

#### **IMSI**

See definition in clause 7.6.2. Either TMSI or IMSI as received from the MS are included in the Request/Indication, but one shall be present. In case of CM Service Type "Emergency Call Establishment", the IMEI may replace IMSI/TMSI.

In the Response/Confirmation, the IMSI is to be sent in case of successful outcome of the service. In case of CM Service Type "Emergency Call Establishment", IMEI may replace IMSI.

#### **IMEI**

See definition in clause 7.6.2. The IMEI may replace IMSI/TMSI in the Request/Indication and IMSI in the Response/Confirmation only in case the CM Service Type indicates "Emergency Call Establishment".

#### **MSISDN**

See definition in clause 7.6.2. The MSISDN is included in case of successful outcome of the service as an operator option, e.g. if it is needed at the MSC for charging purposes in case of call forwarding.

#### User error

One of the following error causes defined in clause 7.6.1 shall be sent by the user if the access request fails, depending on the failure reason:

- unidentified subscriber;
- illegal subscriber;

this error is sent if a correlated authentication procedure has not authenticated the subscriber;

- illegal equipment;

this error is sent if an IMEI check failed, i.e. the IMEI is blacklisted or not white-listed;

- roaming not allowed;
- this cause is used after VLR restart if the subscriber has no subscription for the current location area, e.g. due to regional subscription. The cause will be qualified by "location area not allowed" or "national roaming not allowed", respectively;
- unknown location area;
- system failure;
- unexpected data value.

## Provider error

For definition of provider errors see clause 7.6.1.

# 8.4 Handover services

It should be noted that the handover services used on the B-interface have not been updated for Release 99. The B-interface is not fully operational specified. It is strongly recommended not to implement the B-interface as an external interface.

# 8.4.1 MAP\_PREPARE\_HANDOVER service

# 8.4.1.1 Definition

This service is used between MSC-A and MSC-B (E-interface) when a call is to be handed over or relocated from MSC-A to MSC-B.

The MAP\_PREPARE\_HANDOVER service is a confirmed service using the primitives from table 8.4/1.

# 8.4.1.2 Service primitives

Table 8.4/1: MAP\_PREPARE\_HANDOVER

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Target Cell Id	С	C(=)		
Target RNC Id	С	C(=)		
HO-NumberNotRequired	С	C(=)		
IMSI	С	C(=)		
Integrity Protection Information	С	C(=)		
Encryption Information	С	C(=)		
Radio Resource Information	С	C(=)		
AN-APDU	С	C(=)	С	C(=)
Allowed GSM Algorithms	С	C(=)		
Allowed UMTS Algorithms	С	C(=)		
Radio Resource List	С	C(=)		
RAB ID	С	C(=)		
GERAN Classmark	С	C(=)		
BSSMAP Service Handover	С	C(=)		
BSSMAP Service Handover	С	C(=)		
List				
RANAP Service Handover	С	C(=)		
Iu-Currently Used Codec	С	C(=)		
Iu-Supported Codecs List	С	C(=)		
RAB Configuration Indicator	С	C(=)		
ASCI Call Reference	С	C(=)		
UESBI-lu	С	C(=)		
IMEISV	С	C(=)		
Alternative Channel Type	С	C(=)		
Trace_Propagation_List	С	C(=)		
Handover Number			С	C(=)
Relocation Number List			С	C(=)
Multicall Bearer Information			С	C(=)
Multiple Bearer Requested	С	C(=)		
Multiple Bearer Not Supported			С	C(=)
Selected UMTS Algorithms			С	C(=)
Chosen Radio Resource			С	C(=)
Information				
lu-Selected Codec			С	C(=)
lu-Available Codecs List			С	C(=)
User error			С	C(=)
Provider error				0

# 8.4.1.3 Parameter use

#### Invoke Id

For definition of this parameter see clause 7.6.1.

# Target Cell Id

For definition of this parameter see clause 7.6.2. This parameter is only included if the service is not in an ongoing transaction. This parameter shall also be excluded if the service is a part of the Inter-MSC SRNS Relocation procedure or the inter-system handover GSM to UMTS procedure described in 3GPP TS 23.009.

# Target RNC Id

For definition of this parameter see clause 7.6.2. This parameter shall be included if the service is a part of the Inter-MSC SRNS Relocation procedure or the inter-system handover GSM to UMTS procedure described in 3GPP TS 23.009.

#### **HO-Number Not Required**

For definition of this parameter see clause 7.6.6.

#### **IMSI**

For definition of this parameter see clause 7.6.2. This UMTS parameter shall be included if:

- available and
- if the access network protocol is BSSAP and
- there is an indication that the MS also supports UMTS.

#### **Integrity Protection Information**

For definition of this parameter see clause 7.6.6. This UMTS parameter shall be included if available and if the access network protocol is BSSAP.

#### **Encryption Information**

For definition of this parameter see clause 7.6.6. This UMTS parameter shall be included if available and if the access network protocol is BSSAP.

#### Radio Resource Information

For definition of this parameter see clause 7.6.6. This GSM parameter shall be included if the access network protocol is RANAP and there is an indication that the UE also supports GSM. If the parameter Radio Resource List is sent, the parameter Radio Resource Information shall not be sent.

## AN-APDU

For definition of this parameter see clause 7.6.9.

## Allowed GSM Algorithms

For definition of this parameter see clause 7.6.6. This parameters includes allowed GSM algorithms. This GSM parameter shall be included if:

- the service is a part of the Inter-MSC SRNS Relocation procedure and
- Ciphering or Security Mode Setting procedure has been performed.and
- there is an indication that the UE also supports GSM.

#### Allowed UMTS Algorithms

For definition of this parameter see clause 7.6.6. This UMTS parameter shall be included if all of the following conditions apply:

- access network protocol is BSSAP and
- Integrity Protection Information and Encryption Information are not available and

Ciphering or Security Mode Setting procedure has been performed.

#### Radio Resource List

For definition of this parameter see clause 7.6.6. This parameter shall be included if the access network protocol is RANAP and there is an indication that the UE also supports GSM. This parameter shall be sent when MSC-A requests multiple bearers to MSC-B. If the parameter Radio Resource Information is sent , the parameter Radio Resource List shall not be sent.

# RAB ID

For definition of this parameter see subclause 7.6.2. This parameter shall be included when MSC-A supports multiple bearers and access network protocol is BSSAP and the RAB ID has a value other than 1.

#### **GERAN Classmark**

For definition of this parameter see subclause 7.6.6 This parameter shall be included if available.

#### **BSSMAP Service Handover**

For definition of this parameter see clause 7.6.6. It shall be present if it is available and the access network protocol is RANAP. If the parameter BSSMAP Service Handover List is sent, the parameter BSSMAP Service Handover shall not be sent.

#### **BSSMAP Service Handover List**

For definition of this parameter see clause 7.6.6. It shall be present if it is available and the access network protocol is RANAP. This parameter shall be sent when MSC-A requests multiple bearers to MSC-B. If the parameter BSSMAP Service Handover is sent, the parameter BSSMAP Service Handover List shall not be sent.

#### **RANAP Service Handover**

For definition of this parameter see clause 7.6.6. It shall be present if it is available and the access network protocol is BSSAP.

# **Iu-Currently Used Codec**

For definition of this parameter see subclause 7.6.6. This parameter shall be included if the handover is requested for a speech bearer and the MS is in UMTS or GERAN Iu-mode access. This parameter shall not be included if the Iu-Supported Codecs List is not included.

#### **Iu-Supported Codecs List**

For definition of this parameter see subclause 7.6.6. This parameter shall be included by MSC-A, if the handover is requested for a speech bearer.

#### **RAB Configuration Indicator**

For definition of this parameter see subclause 7.6.6. This parameter may be included if the handover is requested for a speech bearer and MSC-A knows by means of configuration information that MSC-B supports the use of the Iu-Supported Codecs List parameter. This parameter shall not be included if the Iu-Supported Codecs List is not included.

# ASCI Call Reference

This parameter contains either the broadcast call reference or group call reference. It shall be included if a subscriber is undergoing handover during a VGCS or VBS call, where MSC-B already has a Bearer established, so that MSC-B can determine the Group or Broadcast Call to which it shall attach the subscriber, see 3GPP TS 48.008 [49].

#### UESBI-Iu

For definition of this parameter see clause 7.6.6. It shall be present if it is available and the access network protocol is BSSAP.

#### **IMEISV**

For definition of the parameter see clause 7.6.2. This parameter is used for Management based Trace Activation (see 3GPP TS 32.422) and shall be present, if available.

# Alternative Channel Type

For definition of this parameter see clause 7.6.6 It shall be present for a SCUDIF call if the access network protocol is BSSAP.

# **Trace Propagation List**

See definition in clause 7.6.10. This parameter shall be included when MSC-A requests trace invocation.

## Handover Number

For definition of this parameter see clause 7.6.2. This parameter shall be returned at handover, unless the parameter HO-NumberNotRequired is sent. If the parameter Handover Number is returned, the parameter Relocation Number List shall not be returned.

#### Relocation Number List

For definition of this parameter see clause 7.6.2. This parameter shall be returned at relocation, unless the parameter HO-NumberNotRequired is sent. If the parameter Relocation Number List is returned, the parameter Handover Number shall not be returned.

#### **Multicall Bearer Information**

For a definition of this parameter see clause 7.6.2. This parameter shall be returned at relocation in the case that MSC-B supports multiple bearers.

# Multiple Bearer Requested

For a definition of this parameter see clause 7.6.2. This parameter shall be sent when MSC-A requests multiple bearers to MSC-B.

# Multiple Bearer Not Supported

For a definition of this parameter see clause 7.6.2. This parameter shall be returned at relocation when MSC-B receives Multiple Bearer Requested parameter and MSC-B does not support multiple bearers.

#### Selected UMTS Algorithms

For definition of this parameter see clause 7.6.6. This parameters includes the UMTS integrity and optionally encryption algorithms selected by RNC under the control of MSC-B. This UMTS parameter shall be included if the service is a part of the inter MSC inter system handover from GSM to UMTS.

# Chosen Radio Resource Information

For definition of this parameter see clause 7.6.6. This parameter shall be returned at relocation if the encapsulated PDU is RANAP RAB Assignment Response and MS is in GSM access.

# **Iu-Selected Codec**

For definition of this parameter see subclause 7.6.6. This parameter shall be included if an Iu-Supported Codecs List was received in the service request and MSC-B supports the selection of codec based on the Iu-Supported Codecs List and the target radio access network is connected to MSC-B via the Iu interface, even if the Iu-Selected Codec is equal to the Iu-Currently Used Codec received in the service request. This parameter shall not be included if the Iu-Supported Codecs List was not received in the service request.

## **Iu-Available Codecs List**

For definition of this parameter see subclause 7.6.6. This parameter shall be included by an MSC-B supporting TrFO, if the Iu-Supported Codecs List was included by MSC-A and the target radio access is UMTS or GERAN Iu-mode.

#### User error

For definition of this parameter see clause 7.6.1. The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- No handover number available.
- Target cell outside group call area;
- System failure.
- Unexpected data value.
- Data Missing.

#### Provider error

See definition of provider errors in clause 7.6.1.

# 8.4.2 MAP\_SEND\_END\_SIGNAL service

#### 8.4.2.1 Definition

This service is used between MSC-B and MSC-A (E-interface) indicating that the radio path has been established by MSC-B to the MS. MSC-A retains then the main control of the call until it clears.

The response is used by MSC-A to inform MSC-B that all resources for the call can be released in MSC-B, either because the call has been released in MSC-A or because the call has been successfully handed over or relocated from MSC-B to another MSC.

The MAP\_SEND\_END\_SIGNAL service is a confirmed service using the primitives from table 8.4/2.

# 8.4.2.2 Service primitives

Table 8.4/2: MAP\_SEND\_END\_SIGNAL

Parameter name	Request	Indication	Response	Confirm
Invoke Id	М	M(=)	M(=)	M(=)
AN-APDU	M	M(=)		
Provider error				0

# 8.4.2.3 Parameter use

# Invoke Id

For definition of this parameter see clause 7.6.1.

# AN-APDU

For definition of this parameter see clause 7.6.9.

## Provider error

For definition of this parameter see clause 7.6.1.

# 8.4.3 MAP\_PROCESS\_ACCESS\_SIGNALLING service

# 8.4.3.1 Definition

This service is used between MSC-B and MSC-A (E-interface) to pass information received on the A-interface or Iuinterface in MSC-B to MSC-A.

The MAP\_PROCESS\_ACCESS\_SIGNALLING service is a non-confirmed service using the primitives from table 8.4/3.

# 8.4.3.2 Service primitives

Table 8.4/3: MAP\_PROCESS\_ACCESS\_SIGNALLING

Parameter name	Request	Indication
Invoke Id	M	M(=)
AN-APDU	M	M(=)
Selected GSM Algorithm	С	C(=)
Selected UMTS Algorithms	С	C(=)
Chosen Radio Resource	С	C(=)
Information		\ \frac{1}{2}
Selected RAB id	С	C(=)

lu-Selected Codec	С	C(=)
lu-Available Codecs List	С	C(=)

# 8.4.3.3 Parameter use

#### Invoke Id

For definition of this parameter see clause 7.6.1.

# AN-APDU

For definition of this parameter see clause 7.6.9.

# Selected GSM algorithm

For definition of this parameter see clause 7.6.6. This parameter shall be present if the encapsulated PDU is Security Mode Complete and MS is in GSM access.

#### Selected UMTS Algorithms

For definition of this parameter see clause 7.6.6. This parameters includes the UMTS integrity and optionally encryption algorithms selected by RNC under the control of MSC-B. This UMTS parameter shall be included if the encapsulated PDU is BSSMAP Cipher Mode Complete and the MS is in UMTS, or an interystem handover to UMTS is performed in MSC-B, or in the case of intra MSC-B intra UMTS relocation.

#### Chosen Radio Resource Information

For definition of this parameter see clause 7.6.6. This parameter shall be sent if the encapsulated PDU is RANAP RAB Assignment Response and MS is in GSM access.

#### Selected RAB ID

The selected radio access bearer that was kept at subsequent intra-MSC handover from UMTS to GSM after multiple bearers were used.

## **Iu-Selected Codec**

For definition of this parameter see subclause 7.6.6. This parameter shall be included

- if MSC-B changes the selected codec and the MS is in UMTS or GERAN Iu-mode access;
- if intersystem handover to UMTS or GERAN Iu-mode is performed in MSC-B; or
- if MSC-B received a Forward Access Signalling service request including an Iu-Supported Codecs List and the MS is in UMTS or GERAN Iu-mode access.

This parameter shall not be included if the Iu-Supported Codecs List was not received either in the Prepare Handover service request or in the Forward Access Signalling service request.

#### Iu-Available Codecs List

For definition of this parameter see subclause 7.6.6. This parameter shall be included by an MSC-B supporting TrFO

- if the Iu-Available Codecs List has changed in MSC-B;
- if intersystem handover to UMTS or GERAN Iu-mode is performed in MSC-B; or
- if MSC-B received a Forward Access Signalling service request including an Iu-Supported Codecs List and the MS is in UMTS or GERAN Iu-mode access.

# 8.4.4 MAP\_FORWARD\_ACCESS\_SIGNALLING service

# 8.4.4.1 Definition

This service is used between MSC-A and MSC-B (E-interface) to pass information to be forwarded to the A-interface or Iu-interface of MSC-B.

The MAP\_FORWARD\_ACCESS\_SIGNALLING service is a non-confirmed service using the primitives from table 8.4/4.

# 8.4.4.2 Service primitives

Table 8.4/4: MAP\_FORWARD\_ACCESS\_SIGNALLING

Parameter name	Request	Indication
Invoke Id	М	M(=)
Integrity Protection Information	С	C(=)
Encryption Information	С	C(=)
Key Status	С	C(=)
AN-APDU	M	M(=)
Allowed GSM Algorithms	С	C(=)
Allowed UMTS Algorithms	С	C(=)
Radio Resource Information	С	C(=)
Radio Resource List	С	C(=)
BSSMAP Service Handover	С	C(=)
BSSMAP Service Handover List	С	C(=)
RANAP Service Handover	С	C(=)
lu-Currently Used Codec	С	C(=)
lu-Supported Codecs List	С	C(=)
RAB Configuration Indicator	С	C(=)
lu-Selected Codec	С	C(=)
Alternative Channel Type	С	C(=)
Trace Propagation List	С	C(=)

#### 8.4.4.3 Parameter use

For the definition and use of all parameters and errors, see clause 7.6.1.

#### Invoke Id

For definition of this parameter see clause 7.6.1.

# **Integrity Protection Information**

For definition of this parameter see clause 7.6.6. This UMTS parameter shall be included if available and if the encapsulated PDU is BSSMAP Cipher Mode Command.

# **Encryption Information**

For definition of this parameter see clause 7.6.6. This UMTS parameter shall be included if available and if the encapsulated PDU is BSSMAP Cipher Mode Command.

# Key Status

For definition of this parameter see clause 7.6.6. This UMTS parameter shall be included if available and if the encapsulated PDU is BSSMAP Cipher Mode Command.

# AN-APDU

For definition of this parameter see clause 7.6.9.

#### Allowed GSM Algorithms

This parameters includes allowed GSM algorithms. This GSM parameter shall be included if the encapsulated PDU is RANAP Security Mode Command and there is an indication that the UE also supports GSM.

#### Allowed UMTS Algorithms

For definition of this parameter see clause 7.6.6. This UMTS parameter shall be included if Integrity Protection Information and Encryption Information are not available and the encapsulated PDU is BSSMAP Cipher Mode Command.

#### Radio Resource Information

For definition of this parameter see clause 7.6.6. This parameter shall be sent if the encapsulated PDU is RANAP RAB Assignment Request. If the parameter Radio Resource List is sent, the parameter Radio Resource Information shall not be sent.

#### Radio Resource List

For definition of this parameter see clause 7.6.6. This parameter shall be sent if the encapsulated PDU is RANAP RAB Assignment Request and MSC-A requests modification of multiple bearers. If the parameter Radio Resource Information is sent, the parameter Radio Resource List shall not be sent.

#### **BSSMAP Service Handover**

For definition of this parameter see clause 7.6.6. It shall be present if it is available and the encapsulated PDU is RANAP RAB Assignment Request. If the parameter BSSMAP Service Handover List is sent, the parameter BSSMAP Service Handover shall not be sent.

#### **BSSMAP Service Handover List**

For definition of this parameter see clause 7.6.6. It shall be present if it is available and the encapsulated PDU is RANAP RAB Assignment Request and MSC-A requests modification of multiple bearers. If the parameter BSSMAP Service Handover is sent, the parameter BSSMAP Service Handover List shall not be sent.

## **RANAP Service Handover**

For definition of this parameter see clause 7.6.6.. It shall be present if it is available and the encapsulated PDU is BSSMAP Assignment Request.

#### **Iu-Currently Used Codec**

For definition of this parameter see subclause 7.6.6. This parameter shall be included if the encapsulated PDU is a RANAP RAB Assignment Request or BSSMAP Assignment Request for a speech bearer and the MS is in UMTS or GERAN Iu-mode access. This parameter shall not be included if the Iu-Supported Codecs List is not included.

# **Iu-Supported Codecs List**

For definition of this parameter see subclause 7.6.6. This parameter shall be included if the encapsulated PDU is a RANAP RAB Assignment Request or BSSMAP Assignment Request and

- a new bearer is allocated for speech;
- an existing bearer is modified from data to speech; or
- for an existing speech bearer the order of priority in the Iu-Supported Codecs List needs to be modified.

This parameter shall not be included if the Iu-Selected Codec is included.

#### **RAB** Configuration Indicator

For definition of this parameter see subclause 7.6.6. This parameter may be included if the encapsulated PDU is a RANAP RAB Assignment Request for a speech bearer, and MSC-A knows by means of configuration information that MSC-B supports the use of the Iu-Supported Codecs List parameter. This parameter shall not be included if the Iu-Supported Codecs List is not included.

#### **Iu-Selected Codec**

For definition of this parameter see subclause 7.6.6. This parameter shall be included if

- the encapsulated PDU is a RANAP RAB Assignment Request or BSSMAP Assignment Request for an existing speech bearer; and
- the MS is in UMTS or GERAN Iu-mode access; and
- an Iu-Available Codecs List was received by MSC-A for this speech bearer before, either in the Prepare Handover service response or in the Process Access Signalling service request.

This parameter shall not be included if the Iu-Supported Codecs List is included.

# Alternative Channel Type

For definition of this parameter see clause 7.6.6. This parameter shall be present for a SCUDIF call if the encapsulated PDU is BSSMAP Assignment Request.

# **Trace Propagation List**

See definition in clause 7.6.10. This parameter shall be included when MSC-A requests trace invocation.

# 8.4.5 MAP\_PREPARE\_SUBSEQUENT\_HANDOVER service

# 8.4.5.1 Definition

This service is used between MSC-B and MSC-A (E-interface) to inform MSC-A that it has been decided that a handover or relocation to either MSC-A or a third MSC (MSC-B') is required.

The MAP\_PREPARE\_SUBSEQUENT\_HANDOVER service is a confirmed service using the primitives from table 8.4/5.

# 8.4.5.2 Service primitives

Table 8.4/5: MAP\_PREPARE\_SUBSEQUENT\_HANDOVER

Parameter name	Request	Indication	Response	Confirm
Invoke Id	М	M(=)	M(=)	M(=)
Target Cell Id	С	C(=)		
Target RNC Id	С	C(=)		
Target MSC Number	M	M(=)		
Selected RAB ID	С	C(=)		
GERAN Classmark	С	C(=)		
RAB Configuration Indicator	С	C(=)		
AN-APDU	М	M(=)	С	C(=)
User error			С	C(=)
Provider error				0

# 8.4.5.3 Parameter use

## Invoke Id

For definition of this parameter see clause 7.6.1.

#### Target Cell Id

For definition of this parameter see clause 7.6.2. This parameter shall be excluded if the service is a part of the Inter-MSC SRNS Relocation procedure or the inter-system handover GSM to UMTS procedure described in 3GPP TS 23.009.

# Target RNC Id

For definition of this parameter see clause 7.6.2. This parameter shall be included if the service is a part of the Inter-MSC SRNS Relocation procedure or the inter-system handover GSM to UMTS procedure described in 3GPP TS 23.009.

#### Target MSC Number

For definition of this parameter see clause 7.6.2.

## Selected RAB ID

For definition of this parameter see clause 7.6.2.

#### **GERAN Classmark**

For definition of this parameter see subclause 7.6.6 This parameter shall be included if available.

#### **RAB Configuration Indicator**

For definition of this parameter see subclause 7.6.6. This parameter may be included if the call is a speech call and MSC-B knows by means of configuration information that MSC-B' (and MSC-A) supports the use of the Iu-Supported Codecs List parameter.

#### AN-APDU

For definition of this parameter see clause 7.6.9.

#### User error

For definition of this parameter see clause 7.6.1. The following error causes defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unknown MSC;
- Subsequent handover failure;
- Unexpected data value;
- Data Missing.

#### Provider error

For definition of this parameter see clause 7.6.1.

# 8.4.6 MAP\_ALLOCATE\_HANDOVER\_NUMBER service

# 8.4.6.1 Definition

This service is used between MSC and VLR (B-interface) to request a handover number.

The MAP\_ALLOCATE\_HANDOVER\_NUMBER service is a confirmed service using the primitives from table 8.4/6.

# 8.4.6.2 Service primitives

Table 8.4/6: MAP\_ALLOCATE\_HANDOVER\_NUMBER

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
User error			С	C(=)
Provider error				0

# 8.4.6.3 Parameter use

# Invoke Id

For definition of this parameter see clause 7.6.1.

#### User error

For definition of this parameter see clause 7.6.1. The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- No handover number available.

#### Provider error

For definition of this parameter see clause 7.6.1.

# 8.4.7 MAP\_SEND\_HANDOVER\_REPORT service

# 8.4.7.1 Definition

This service is used between VLR and MSC-B (B-interface) to transfer the handover number to be forwarded to and used by MSC-A.

The MAP\_SEND\_HANDOVER\_REPORT service is a confirmed service using the primitives from table 8.4/7.

# 8.4.7.2 Service primitives

Table 8.4/7: MAP\_SEND\_HANDOVER\_REPORT

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Handover Number	M	M(=)		
Linked Id	M	M(=)		
Provider error				0

# 8.4.7.3 Parameter use

## Invoke Id

For definition of this parameter see clause 7.6.1.

#### Handover Number

For definition of this parameter see clause 7.6.2.

# Linked Id

For definition of this parameter see clause 7.6.1. This service is linked with MAP\_ALLOCATE\_HANDOVER\_NUMBER.

### Provider error

For definition of this parameter see clause 7.6.1.

# 8.5 Authentication management services

# 8.5.1 MAP AUTHENTICATE service

The MAP\_AUTHENTICATE service is used on the MAP B interface. This interface is not fully operational specified. It is strongly recommended not to implement the B-interface as an external interface.

# 8.5.1.1 Definition

This service is used between the VLR and the MSC when the VLR receives a MAP service indication from the MSC concerning a location registration, call set-up, operation on a supplementary service or a request from the MSC to initiate authentication.

The service is a confirmed service and consists of four service primitives.

# 8.5.1.2 Service primitives

The service primitives are shown in table 8.5/1.

Table 8.5/1: MAP AUTHENTICATE parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
RAND	M	M(=)		
CKSN	M	M(=)		
SRES			M	M(=)
Provider error				0

# 8.5.1.3 Parameter use

#### Invoke id

See clause 7.6.1 for the use of this parameter.

#### **RAND**

See clause 7.6.7 for the use of this parameter.

# **CKSN**

See clause 7.6.7 for the use of this parameter.

#### **SRES**

See clause 7.6.7 for the use of this parameter.

## Provider error

See clause 7.6.1 for the use of this parameter.

# 8.5.2 MAP SEND AUTHENTICATION INFO service

# 8.5.2.1 Definition

This service is used between the VLR and the HLR for the VLR to retrieve authentication information from the HLR. The VLR requests up to five authentication vectors.

Also this service is used between the SGSN and the HLR for the SGSN to retrieve authentication information from the HLR. The SGSN requests up to five authentication vectors.

Also this service is used between the BSF and the HLR for the BSF to retrieve authentication information from the HLR. The BSF shall only request one authentication vector at a time.

If the user is a UMTS subscriber, the HLR shall return authentication quintuplets. If the user is a GSM subscriber, the HLR shall return authentication triplets.

If the HLR cannot provide the VLR, the SGSN or the BSF with triplets, an empty response is returned. The VLR, the SGSN or the BSF may then re-use old authentication triplets, except where this is forbidden under the conditions specified in 3GPP TS 43.020 [24].

If the HLR cannot provide the VLR, the SGSN or the BSF with quintuplets, an empty response is returned. The VLR, the SGSN or the BSF shall not re-use old authentication quintuplets.

If the VLR, the SGSN or the BSF receives a MAP\_SEND\_AUTHENTICATION\_INFO response containing a User Error parameter as part of the handling of an authentication procedure, the authentication procedure in the VLR, the SGSN or the BSF shall fail.

Security related network functions are further described in 3GPP TS 43.020 [24] and 3GPP TS 33.200.

The service is a confirmed service and consists of four service primitives.

# 8.5.2.2 Service primitives

The service primitives are shown in table 8.5/2.

Table 8.5/2: MAP\_SEND\_AUTHENTICATION\_INFO parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	М	M(=)	M(=)	M(=)
IMSI	С	C(=)		
Number of requested vectors	С	C(=)		
Requesting node type	С	C(=)		
Re-synchronisation Info	С	C(=)		
Segmentation prohibited indicator	С	C (=)		
Immediate response preferred indicator	U	C (=)		
Requesting PLMN ID	С	C(=)		
AuthenticationSetList			С	C(=)
User error			С	C(=)
Provider error				0

# 8.5.2.3 Parameter use

# Invoke id

See clause 7.6.1 for the use of this parameter.

# <u>IMSI</u>

See clause 7.6.2 for the use of this parameter.

This parameter shall be present in the first (or only) request of the dialogue. If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one.

#### Number of requested vectors

A number indicating how many authentication vectors the VLR, the SGSN or the BSF is prepared to receive. The HLR shall not return more vectors than indicated by this parameter.

This parameter shall be present in the first (or only) request of the dialogue. If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one.

#### Requesting node type

The type of the requesting node (SGSN, VLR, or BSF).

This parameter shall be present in the first (or only) request of the dialogue. If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one.

#### Re-synchronisation Info

For definition and use of this parameter see 3GPP TS 33.200.

If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one..

#### Segmentation prohibited indicator

This parameter indicates if the VLR or SGSN allows segmentation of the response at MAP user level.

This parameter may be present only in the first request of the dialogue.

#### Immediate response preferred indicator

This parameter indicates that one of the requested authentication vectors is requested for immediate use in the VLR, the SGSN or the BSF. It may be used by the HLR together with the number of requested vectors and the number of vectors stored in the HLR to determine the number of vectors to be obtained from the AuC. It shall be ignored if the number of available vectors is greater than the number of requested vectors.

If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one.

# Requesting PLMN ID

The PLMN-ID of the requesting node. See3GPP TS 23.003.

This parameter shall be present in the first (or only) request of the dialogue. If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one.

#### <u>AuthenticationSetList</u>

A set of one to five authentication vectors are transferred from the HLR to the VLR, from the HLR to the SGSN or from the HLR to the BSF, if the outcome of the service was successful.

#### User error

One of the following error causes defined in clause 7.6.1 shall be sent by the user in case of unsuccessful outcome of the service, depending on the respective failure reason:

- unknown subscriber;
- unexpected data value;
- system failure;
- data missing.

## Provider error

See clause 7.6.1 for the use of this parameter.

# 8.5.3 MAP\_AUTHENTICATION\_FAILURE\_REPORT service

# 8.5.3.1 Definition

This service is used between the VLR and the HLR or between the SGSN or HLR for reporting of authentication failures.

# 8.5.3.2 Service primitives

The service primitives are shown in table 8.5/3.

Table 8.5/3: MAP AUTHENTICATION FAILURE REPORT parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	М	M(=)	M(=)	M(=)
IMSI	М	M(=)		
Failure cause	М	M(=)		
Re-attempt	М	M(=)		
Access Type	М	M(=)		
Rand	М	M(=)		

VLR number	С	C(=)		
SGSN number	С	C(=)		
User error			С	C(=)
Provider error				0

# 8.5.3.3 Parameter use

# Invoke id

See clause 7.6.1 for the use of this parameter.

# <u>IMSI</u>

See clause 7.6.2 for the use of this parameter.

#### Failure Cause

See clause 7.6.7 for use of this parameter.

#### Re-attempt

See clause 7.6.7 for use of this parameter.

# Access Type

See clause 7.6.7 for use of this parameter.

#### Rand

This parameter identifies the specific AV that failed authentication.

See clause 7.6.7 for use of this parameter.

# VLR number

Shall be present if the sender is VLR. See definition in clause 7.6.2.

# SGSN number

Shall be present if the sender is SGSN. See definition in clause 7.6.2.

## User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- Unknown Subscriber;
- System Failure;
- Unexpected Data Value.

# Provider error

These are defined in clause 7.6.

# 8.6 Security management services

# 8.6.1 MAP\_SET\_CIPHERING\_MODE service

# 8.6.1.1 Definitions

This service is used between the VLR and the MSC to set the ciphering mode and to start ciphering if applicable. It is called when another service requires that information is to be sent on the radio path in encrypted form.

The service is a non-confirmed service and consists of two service primitives.

# 8.6.1.2 Service primitives

The service primitives are shown in table 8.6/1.

Table 8.6/1: MAP SET CIPHERING MODE parameters

Parameter name	Request	Indication
Invoke id	M	M(=)
Ciphering mode	M	M(=)
Kc	С	C(=)

#### 8.6.1.3 Parameter use

#### Invoke id

See clause 7.6.1 for the use of this parameter.

# Ciphering mode

See clause 7.6.7 for the use of this parameter.

Kc

The Kc parameter should be included when the ciphering mode parameter indicates that ciphering must be performed.

# 8.7 International mobile equipment identities management services

# 8.7.1 MAP\_CHECK\_IMEI service

# 8.7.1.1 Definition

This service is used between the VLR and the MSC and between the MSC and the EIR and between the SGSN and EIR to request check of IMEI. If the IMEI is not available in the MSC or in the SGSN, it is requested from the MS and transferred to the EIR in the service request.

This service may also be used to request the BMUEF from the EIR.

The service is a confirmed service and consists of four service primitives.

# 8.7.1.2 Service primitives

The service primitives are shown in table 8.7/1.

Table 8.7/1: MAP\_CHECK\_IMEI parameters

Parameter name   Request   Indication   Response   Confirm
--

Invoke id	M	M(=)	M(=)	M(=)
IMEI	С	C(=)	С	C(=)
IMEISV	С	C(=)	C(=)	C(=)
Requested	M	M(=)		
Equipment Info				
Equipment status			С	C(=)
BMUEF			С	C(=)
User error			C	C(=)
Provider error				0

# 8.7.1.3 Parameter use

## Invoke id

See clause 7.6.1 for the use of this parameter.

#### Requested Equipment Info

This parameter indicates whether Equipment Status or BMUEF or both is requested.

#### **IMEI**

See clause 7.6.2 for the use of this parameter. The parameter shall not be included in the service request between the VLR and the MSC, but one of IMEI and IMEISV is mandatory in the service request from the MSC to the EIR and from the SGSN to the EIR. It is not included in the service response from the EIR to the MSC or to the SGSN, but one of IMEI and IMEISV is mandatory in the service response from the MSC to the VLR on successful outcome.

#### **IMEISV**

See clause 7.6.2 for the use of this parameter. IMEISV shall be present if BMUEF is requested.

# Equipment status

See clause 7.6.3 for the use of this parameter. This parameter is sent by the responder in case of successful outcome of the service if Equipment status was requested.

### **BMUEF**

See clause 7.6.4 for the use of this parameter. This parameter is sent by the responder in case of successful outcome of the service if BMUEF was requested.

#### User error

One of the following error causes defined in clause 7.6.1 shall be sent by the user in case of unsuccessful outcome of the service, depending on the respective failure reason:

- unknown equipment;
  - this error is returned by the responder when the IMEI is not known in the EIR;
- system failure;
- unexpected data value.

#### Provider error

See clause 7.6.1 for the use of this parameter.

# 8.7.2 MAP\_OBTAIN\_IMEI service

# 8.7.2.1 Definition

This service is used between the VLR and the MSC to request the IMEI. If the IMEI is not available in the MSC, it is requested from the MS.

The service is a confirmed service and consists of four service primitives.

# 8.7.2.2 Service primitives

The service primitives are shown in table 8.7/2.

Table 8.7/2: MAP\_OBTAIN\_IMEI parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMEI			С	C(=)
User error			С	C(=)
Provider error				0

## 8.7.2.3 Parameter use

#### Invoke id

See clause 7.6.1 for the use of this parameter.

#### **IMEI**

See clause 7.6.2 for the use of this parameter. The parameter is included in the service response from the MSC to the VLR on successful outcome of the service.

#### User error

If the service fails, the VLR sends the user error System Failure (see clause 7.6.1) to the MSC.

## Provider error

See clause 7.6.1 for the use of this parameter.

# 8.8 Subscriber management services

# 8.8.1 MAP-INSERT-SUBSCRIBER-DATA service

# 8.8.1.1 Definition

This service is used by an HLR to update a VLR with certain subscriber data in the following occasions:

- the operator has changed the subscription of one or more supplementary services, basic services or data of a subscriber. Note that in case of withdrawal of a Basic or Supplementary service this primitive shall not be used;
- the operator has applied, changed or removed Operator Determined Barring;
- the subscriber has changed data concerning one or more supplementary services by using a subscriber procedure;
- the HLR provides the VLR with subscriber parameters at location updating of a subscriber or at restoration. In this case, this service is used to indicate explicitly that a supplementary service is not provisioned, if the supplementary service specification requires it. The only supplementary services which have this requirement are the CLIR and COLR services. Network access mode is provided only in restoration. If the Super-Charger functionality is supported the HLR may not need to provide the VLR with subscriber parameters at location updating of a subscriber. See TS 23.116.

Also this service is used by an HLR to update an SGSN with certain subscriber data in the following occasions:

- if the GPRS subscription has changed;
- if the network access mode is changed;
- the operator has applied, changed or removed Operator Determined Barring;

- the subscriber has changed data concerning one or more supplementary services by using a subscriber procedure;
- the HLR provides the SGSN with subscriber parameters at GPRS location updating of a subscriber. If the Super-Charger functionality is supported the HLR may not need to provide the SGSN with subscriber parameters. See 3GPP TS 23.116.

It is a confirmed service and consists of the primitives shown in table 8.8/1.

# 8.8.1.2 Service primitives

Table 8.8/1: MAP-INSERT-SUBSCRIBER-DATA

Parameter name	Request	Indication	Response	Confirm
Invoke Id	М	M(=)	M(=)	M(=)
IMSI	С	C(=)		
MSISDN	C	C(=)		
Category	С	C(=)		
Subscriber Status	С	C(=)		
Bearer service List	С	C(=)	С	C(=)
Teleservice List	C C C C C C C C C C C C	C(=)	С	C(=)
Forwarding information List	С	C(=)		
Call barring information List	С	C(=)		
CUG information List	С	C(=)		
SS-Data List	С	C(=)		
eMLPP Subscription Data	С	C(=)		
MC-Subscription Data	С	C(=)		
Operator Determined Barring General data	С	C(=)	С	C(=)
Operator Determined Barring HPLMN data	С	C(=)		
Roaming Restriction Due To Unsupported	С	C(=)		
Feature				
Regional Subscription Data	С	C(=)		
VLR CAMEL Subscription Info	С	C(=)		
Voice Broadcast Data	C C C	C(=)		
Voice Group Call Data	С	C(=)		
Network access mode	С	C(=)		
GPRS Subscription Data	С	C(=)		
Roaming Restricted In SGSN Due To	С	C(=)		
Unsupported Feature				
North American Equal Access preferred Carrier	U	C(=)		
Id List				
SGSN CAMEL Subscription Info	C C	C(=)		
LSA Information	С	C(=)		
IST Alert Timer	С	C(=)		
SS-Code List			С	C(=)
LMU Identifier	С	C(=)		
LCS Information	С	C(=)		
CS Allocation/Retention priority	C C C C	C(=)		
Super-Charger Supported In HLR	С	C(=)		
Subscribed Charging Characteristics	С	C(=)		
Access Restriction Data	С	C(=)		
Regional Subscription Response			С	C(=)
Supported CAMEL Phases			C	C (=)
Offered CAMEL 4 CSIs			C	C (=)
User error			U	C(=)
Provider error				0

# 8.8.1.3 Parameter use

All parameters are described in clause 7.6. The following clarifications are applicable:

# Network access mode

This parameter defines if the subscriber has access to MSC/VLR and/or to SGSN. This parameter is used by SGSN and MSC/VLR. In VLR, the parameter is used only as part of Restore Data Procedure and the parameter is not stored in the

VLR. This parameter shall always be sent to the SGSN as part of the GPRS subscriber data at GPRS location updating. It shall be sent to the SGSN if it is changed as a result of administrative action.

#### **IMSI**

It is only included if the service is not used in an ongoing transaction (e.g. location updating). This parameter is used by the VLR and the SGSN.

## **MSISDN**

It is included either at location updating or when it is changed. The MSISDN sent shall be the basic MSISDN. This parameter is used by the VLR and the SGSN.

#### Category

It is included either at location updating or when it is changed. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

# Subscriber Status

It is included either at location updating or when it is changed.

To apply, remove or update Operator Determined Barring Categories the Subscriber Status is set to Operator Determined Barring. In this case ODB General Data shall also be present. If the Operator Determined Barring applies and the subscriber is registered in the HPLMN and HPLMN specific Operator Determined Barring applies then ODB HPLMN Specific Data shall also be present.

To remove all Operator Determined Barring Categories the Subscriber Status shall be set to "Service Granted". This parameter is used by the VLR and the SGSN.

#### Bearer service List

A list of Extensible Bearer service parameters (Extensible Bearer service is defined in clause 7.6). An Extensible Bearer service parameter must be the code for an individual Bearer service, except in the cases described below.

The codes for the Bearer service groups "allAlternateSpeech-DataCDA" and "allAlternateSpeech-DataCDS" shall, if applicable, be sent from the HLR to the VLR as a pair. The codes for the Bearer service groups "allSpeechFollowedByDataCDA" and "allSpeechFollowedByDataCDS" shall, if applicable, be sent from the HLR to the VLR as a pair.

If it is included in the Request/Indication, it includes either all Extensible Bearer services subscribed (at location updating or at restoration) or only the ones added (at subscriber data modification).

If the VLR receives an Indication containing any Extensible Bearer service parameters which it does not support/allocate it returns them in the response to the HLR and discards the unsupported Extensible Bearer services (no error is sent back), except in the cases described below.

If the VLR receives the codes for the Bearer service groups "allSpeechFollowedByDataCDA" and "allSpeechFollowedByDataCDS" and supports one or more of the circuit-switched synchronous or asynchronous data rates specified for simple data bearer services, it shall accept the bearer service codes, and not return them in the response to the HLR. If the VLR does not support any of the circuit-switched synchronous or asynchronous data rates specified for simple data bearer services, and receives the pair of codes for "allAlternateSpeech-DataCDA" and "allAlternateSpeech-DataCDS" or the pair of codes for "allSpeechFollowedByDataCDA" and "allSpeechFollowedByDataCDS", it shall reject the pair of codes by returning them in the response to the HLR. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

# Teleservice List

A list of Extensible Teleservice parameters (Extensible Teleservice is defined in clause 7.6). An Extensible Teleservice parameter must be the code for an individual Teleservice.

If it is included in the Request/Indication, it contains either all Extensible Teleservices subscribed (at location updating or at restoration) or the ones added (at subscriber data modification). Only the Extensible Teleservices that are relevant to the node at which the message is received should be included in the Teleservice List.

If the VLR or the SGSN receives an Indication containing any Extensible Teleservice parameters which it does not support/allocate it returns them in the response to the HLR and discards the unsupported Extensible Teleservices (no error is sent back). This parameter is used by the VLR and the SGSN.

#### Forwarding information List

A list of Extensible Forwarding information parameters (Extensible Forwarding information is defined in clause 7.6). It includes Call Forwarding services either at location updating or at restoration or when they are changed. Each Extensible Forwarding information parameter shall be treated independently of all other parameters in the primitive.

The Extensible Forwarding information shall include the SS-Code for an individual call forwarding supplementary service. The Extensible Forwarding information shall contain one or more Extensible Forwarding Features (Extensible Forwarding Feature is defined in clause 7.6).

The Extensible Forwarding Feature may include an Extensible Basic Service Group. This shall be interpreted according to the rules in clause 8.8.1.4.

The Extensible Forwarding Feature shall contain an Extensible SS-Status parameter.

If the Extensible SS-Status indicates that call forwarding is registered then (except for call forwarding unconditional) the Extensible Forwarding Feature shall contain a number to define the forwarded-to destination and, if available, the forwarded-to subaddress. In other states the forwarded-to number and, if applicable, the forwarded-to subaddress shall not be included. For call forwarding unconditional the forwarded-to number and, if applicable, the forwarded-to subaddress shall not be included. If the VLR does not receive a forwarded-to subaddress then it shall assume that a forwarded-to subaddress has not been registered.

The Extensible Forwarding Feature shall contain the extensible forwarding options (except for call forwarding unconditional where the extensible forwarding options shall not be included). Bits 3 and 4 of the extensible forwarding options shall be ignored by the VLR, and may be set to any value by the HLR.

For call forwarding on no reply: If the extensible SS-Status indicates that call forwarding is registered then the Extensible Forwarding Feature shall contain an extensible no reply condition timer. In other states the no reply condition timer shall not be included.

For call forwarding services other than call forwarding on no reply: The Extensible Forwarding Feature shall not contain a no reply condition timer.

If the VLR receives an Indication containing any Call Forwarding service codes which it does not support/allocate it returns them to the HLR in the parameter SS-Code List and discards the unsupported Call Forwarding service codes (no error is sent back). This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

# Call barring information List

A list of Extensible Call barring information parameters (Extensible Call barring information is defined in clause 7.6). It includes Call Barring services either at location updating or at restoration or when they are changed. Each Extensible Call barring information parameter shall be treated independently of all other parameters in the primitive.

The Extensible Call barring information shall include the SS-Code for an individual call barring supplementary service. The Extensible Call barring information shall contain one or more Extensible Call Barring Features (Extensible Call Barring Feature is defined in clause 7.6).

The Extensible Call Barring Feature may include an Extensible Basic Service Group. This shall be interpreted according to the rules in clause 8.8.1.4.

The Extensible Call Barring Feature shall contain an extensible SS-Status parameter.

If the VLR or the SGSN receives an Indication containing any Extensible Call Barring service codes which it does not support/allocate it returns them to the HLR in the parameter SS-Code List and discards the unsupported Extensible Call Barring service codes (no error is sent back).

# **CUG** information List

A list of CUG information list parameters (CUG information is defined in clause 7.6). It includes CUG information either at location updating or at restoration or when it is changed.

At location updating, restoration or when there is a change in CUG data, the HLR shall include the complete CUG-SubscriptionList and, if there are options per basic group, it shall also include the complete CUG-FeatureList. If there are not options per extensible basic service group the CUG-FeatureList shall not be included.

In any dialogue, the first insertSubscriberData message which contains CUG information shall include a non-empty CUG-SubscriptionList.

When the VLR receives CUG data it shall replace the stored CUG data with the received data set.

If CUG-FeatureList is omitted in the Insert Subscriber Data operation VLR shall interpret that no options per extensible basic service group exist, and then it shall apply the default values i.e. no outgoing access, no incoming access, no preferential CUG exists.

If CUG-Feature is received without preferential CUG, the VLR shall interpret that no preferential CUG applies.

If the VLR detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value.

Note that data consistency between CUG subscription data and CUG feature data is the responsibility of the HLR.

If the VLR does not support the CUG service it returns its code to the HLR in the parameter SS-Code List and discards the received information (no error is sent back). This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

# SS-Data List

A list of Extensible SS-Data parameters (Extensible SS-Data is defined in clause 7.6). It is sent for any other supplementary service than Call Forwarding, Call Barring, CUG and eMLPP either at location updating or at restoration or when they are changed. Each SS-Data parameter shall be treated independently of all other parameters in the primitive.

The Extensible SS-Data shall include the SS-Code for an individual supplementary service.

The Extensible SS-Data shall contain an Extensible SS-Status parameter and any subscription options that are applicable to the service defined by the SS-Code.

The SS-Data may include a Basic Service Group List. This shall be interpreted according to the rules in clause 8.8.1.4.

If the VLR receives an Indication containing any supplementary service codes which it does not support/allocate it returns them to the HLR in the parameter SS-Code List and therefore discards the unsupported service codes received (no error is sent back).

This parameter is used by the SGSN only for LCS. If the SGSN receives an Indication containing any LCS related supplementary service codes which it does not support/allocate it returns them to the HLR in the parameter SS-Code List and therefore discards the unsupported service codes received (no error is sent back). SS-codes not related to the supported LCS capability set shall be discarded.

#### Operator Determined Barring General data

If it is included in a Request/Indication, it includes all the Operator Determined Barring categories that may be applied to a subscriber registered in any PLMN. This parameter is only included in a Request/Indication when the parameter Subscriber Status is set to the value Operator Determined Barring. Note that all General Operator Determined Barring Categories shall be set to their actual status.

If the VLR or the SGSN receives an Indication containing Operator Determined Barring General Data which shows that the subscriber is subject to barring not supported / not allocated by the VLR or by the SGSN, it returns Operator Determined Barring General Data in the response to the HLR to show the barring categories which are not supported / not allocated by the VLR or by the SGSN. This parameter is used by the VLR and the SGSN.

## Operator Determined Barring HPLMN data

It includes all the Operator Determined Barring categories that may be applied only to a subscriber registered in the HPLMN. Therefore, it shall only be transferred to the VLR or to the SGSN when the subscriber is roaming into the HPLMN and when the parameter Subscriber Status is set to the value Operator Determined Barring. Note that all HPLMN Operator Determined Barring Categories shall be set to their actual status.

If Subscriber Status is set to the value Operator Determined Barring and no Operator Determined Barring HPLMN data is present then the VLR or the SGSN shall not apply any HPLMN specific ODB services to the subscriber. This parameter is used by the VLR and the SGSN.

#### eMLPP Subscription Data

If included in the Insert Subscriber Data request this parameter defines the priorities the subscriber might apply for a call (as defined in clause 7.6). It contains both subparameters of eMLPP.

If the VLR does not support the eMLPP service it returns its code to the HLR in the parameter SS-Code List and therefore discards the received information (no error is sent back).

eMLPP subscription data that have been stored previously in a subscriber data record in the VLR are completely replaced by the new eMLPP subscription data received in a MAP\_INSERT\_SUBSCRIBER\_DATA during either an Update Location or Restore Data procedure or a stand alone Insert Subscriber data procedure. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

## MC Subscription Data

If included in the Insert Subscriber Data request, this parameter provides the MC Subscription Data as defined in clause 7.6.

If the VLR does not support the MC service, it returns its code to the HLR in the parameter SS-Code List and therefore discards the received information (no error is sent back).

MC subscription data that have been stored previously in a subscriber data record in the VLR are completely replaced by the new MC subscription data received in a MAP\_INSERT\_SUBSCRIBER\_DATA during either an Update Location or Restore Data procedure or a stand alone Insert Subscriber data procedure. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

# Roaming Restriction Due To Unsupported Feature

The HLR may decide to include this parameter in the request if certain services or features are indicated as not supported by the MSC/VLR (e.g. Advice of Charge Charging Level).

If this parameter is sent to the VLR the MSC area is restricted by the HLR and the VLR. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

#### Regional Subscription Data

If included in the Insert Subscriber Data request this parameter defines the subscriber's subscription area for the addressed VLR or for the addressed SGSN (as defined in clause 7.6). It contains the complete list of up to 10 Zone Codes that apply to a subscriber in the currently visited PLMN. The HLR shall send only those Zone Codes which are stored against the CC and NDC of the VLR or the CC and NDC of the SGSN to be updated.

NOTE: Support of this parameter is a network operator option and it will not be sent to networks which do not support Regional Subscription.

Regional subscription data that have been stored previously in a subscriber data record in the VLR or in the SGSN are completely replaced by the regional subscription data received in an Insert Subscriber Data indication during either an Update Location or Restore Data procedure or a stand alone Insert Subscriber data procedure.

After the regional subscription data are inserted the VLR or the SGSN shall derive whether its location areas are allowed or not. If the whole MSC or SGSN area is restricted it will be reported to HLR by returning the Regional Subscription Response.

The VLR or the SGSN returns a Regional Subscription Response indicating that a problem with the Zone Code has been detected in one of the following cases:

- Too Many Zone Codes: more than 10 Zone Codes are to be stored in the VLR or in the SGSN.
- Regional Subscription Not Supported by the VLR or the SGSN.
- Zone Codes Conflict: the VLR or the SGSN detects that the zone codes indicate conflicting service permission for a location area.

Zone codes which have no mapping to location areas shall be ignored.

If a sequence of MAP\_INSERT\_SUBSCRIBER\_DATA services is used during a dialogue, Regional Subscription Data shall be accepted only in one service. Regional Subscription Data received in a subsequent service shall be rejected with the error Unexpected Data Value.

If Regional Subscription Data are not included in any MAP\_INSERT\_SUBSCRIBER\_DATA service, there is no restriction of roaming due to Regional Subscription. This parameter is used by the VLR and the SGSN.

### Voice Broadcast Data

This parameter contains a list of group id's a user might have subscribed to; (VBS-Data is defined in clause 7.6). It includes VBS information either at location updating or at restoration or when it is changed.

At location updating, restoration or when there is a change in VBS data, the HLR shall include the complete VBS-Data.

When the VLR receives VBS-Data within a dialogue it shall replace the stored VBS-data with the received data set. All subsequent VBS-data received within this dialogue shall be interpreted as add-on data.

If VBS-data is omitted in the Insert Subscriber Data operation the VLR shall keep the previously stored VBS data.

If the VLR detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

#### Voice Group Call Data

This parameter contains a list of group id's a user might have subscribed to; see clause 7.6.

At location updating, restoration or when there is a change in VGCS data, the HLR shall include the complete VGCS-Data.

When the VLR receives VGCS-Data within a dialogue it shall replace the stored VGCS-Data with the received data set. All VGCS-Data received within this dialogue shall be interpreted as add-on data.

If VBCS-Data is omitted in the Insert Subscriber Data operation the VLR shall keep the previously stored VGCS-Data.

If the VLR detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it

### North American Equal Access preferred Carrier Id List

A list of the preferred carrier identity codes that are subscribed to.

When the VLR receives this parameter from the HLR, it shall replace the previously stored preferred carrier identity codes with the received ones. It is not possible to delete all the preferred carrier identity codes from the VLR using this service. To delete all the preferred carrier identity codes from the VLR, the HLR shall use the MAP\_CANCEL\_LOCATION service.

## **LSA Information**

If included in the ISD request, this parameter contains a list of localised service area identities a user might have subscribed to together with the priority, the preferential access indicator, the active mode support indicator and active mode indication of each localised service area; see clause 7.6. The access right outside these localised service areas is also indicated. In all cases mentioned below, the LSA information shall only include LSA Data applicable to the VPLMN where the Subscriber is located. The VLR number, received in the MAP-UPDATE\_LOCATION primitive, or the SGSN number, received in the MAP\_UPDATE\_GPRS\_LOCATION primitive, can be used, alongside data stored in the HLR, to determine the LSA Data applicable to the VPLMN.

At restoration, location updating or GPRS location updating the HLR shall include the complete set of applicable LSA Information.

When there is a change in LSA data the HLR shall include at least the new and/or modified LSA data.

When there is a change in the access right outside the localised service areas the HLR shall include the LSA only access indicator.

When the SGSN or the VLR receives LSA information within a dialogue it shall check if the received data has to be considered as the entire LSA information. If so, it shall replace the stored LSA information with the received data set, otherwise it shall replace the data only for the modified LSA data (if any) and/or access right, and add the new LSA data (if any) to the stored LSA Information.

If the entire LSA information is received, it shall always include the LSA only access indicator value together with the LSA data applicable for the PLMN (if any).

If LSA Information is omitted in the Insert Subscriber Data operation the SGSN or the VLR shall keep the previously stored LSA Information.

If the SGSN or the VLR detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value. This parameter is used by the VLR and the SGSN.

### **IST Alert Timer**

This parameter contains the IST Alert timer value that must be used to inform the HLR about the call activities that the subscriber performs.

At Location Updating, restoration, or when there is a change in the IST data defined for the Subscriber, the HLR shall include the IST Alert timer.

# LMU Identifier

This parameter indicates the presence of an LMU. This parameter is used only by the VLR and shall be ignored if received by an SGSN.

#### **LCS Information**

This parameter provides the following LCS related information for an MS subscriber:

- list of GMLCs in the HPLMN;
- privacy exception list;
- MO-LR list.

At restoration and location updating, the HLR shall include the complete LCS data of the subscriber.

When there is a change in LCS subscriber data the HLR shall include at least the new and/or modified LCS data. LCS data that is not modified need not be included.

The VLR/SGSN shall keep any previously stored LCS Information that is not included in an Insert Subscriber Data operation.

If the VLR/SGSN detects that there is overlapping in the LCS information received within a dialogue, it shall send the error Unexpected Data Value. However, if the VLR receives the LCS code in both the LCS Information and the SS-Data List, then the VLR shall not interpret this as overlapping data.

## Super-Charger Supported In HLR

This parameter is used by the HLR to indicate support for the Super-Charger functionality. If this parameter is present it shall include an indication of the age of the subscription data stored in the HLR.

If this parameter is absent then the HLR does not support the Super-Charger functionality.

# SS-Code List

The list of SS-Code parameters for the services that are provided to a subscriber but are not supported/allocated by the VLR/SGSN (SS-Code is defined in clause 7.6). The list can only include individual SS-Codes that were sent in the service request. For the VLR, this list can also include SS-Codes for the eMLPP and/or CUG services if the above mentioned conditions, as described in eMLPP Subscription Data and/or CUG information List, are met (that is, eMLPP Subscription Data and/or CUG information List are received).

### Regional Subscription Response

If included in the response this parameter indicates one of:

- MSC Area Restricted entirely because of regional subscription;
- SGSN Area Restricted entirely because of regional subscription;
- Too Many Zone Codes to be inserted;
- Zone Codes Conflict;
- Regional Subscription not Supported by the VLR or by the SGSN.

If the VLR determines after insertion of Regional Subscription Data that the entire MSC area is restricted, the VLR shall respond with a Regional Subscription Response indicating MSC Area Restricted. Otherwise MSC Area Restricted is not sent. The HLR shall check whether the current MSC area is no longer restricted.

If the SGSN determines after insertion of Regional Subscription Data that the entire SGSN area is restricted, the SGSN shall respond with a Regional Subscription Response indicating SGSN Area Restricted. Otherwise SGSN Area Restricted is not sent. The HLR shall check whether the current SGSN area is no longer restricted. This parameter is used by the VLR and by the SGSN.

# VLR CAMEL Subscription Info

This parameter is sent for subscribers who have CAMEL services which are invoked in the MSC.

- In CAMEL phase 1, this parameter contains only the O-CSI.
- In CAMEL Phase 2, this parameter may contain O-CSI, SS-CSI and TIF-CSI. In CAMEL Phase 2 and onwards, TDP-Criteria for O-CSI may be associated with O-CSI.
- In CAMEL Phase 3, this parameter may contain O-CSI, D-CSI, SS-CSI, VT-CSI, MO-SMS-CSI, M-CSI and TIF-CSI. In CAMEL Phase 3 and onwards, TDP-Criteria for VT-CSI may be associated with VT-CSI.
  - In CAMEL Phase 4, this parameter may contain O-CSI, D-CSI, SS-CSI, VT-CSI, MO-SMS-CSI, MT-SMS-CSI, M-CSI and TIF-CSI. In CAMEL Phase 4, TDP-Criteria for MT-SMS-CSI may be associated with MT-SMS-CSI.

The VLR CAMEL Subscription Info is sent at location updating or when any information in the applicable CAMEL Subscription Info in the HLR has been changed.

At location updating, the complete set of VLR CAMEL Subscription Info is sent in one dialogue.

When CAMEL Subscription Information is changed in the HLR and changed data have to be sent to the VLR, then:

- for CAMEL Phase 1 and CAMEL Phase 2, the complete set of VLR CAMEL Subscription Info is sent in one dialogue;
- for CAMEL Phase 3 or higher, one or more specific elements of VLR CAMEL Subscription Info are sent in one dialogue.

When the VLR receives a specific element of VLR CAMEL Subscription Info, it shall overwrite the corresponding specific element of VLR CAMEL Subscription Info (if any) which it has stored for that subscriber.

For CAMEL Phase 1 and CAMEL Phase 2, the VLR CAMEL Subscription Info consists of any one or more of:

O-CSI (irrespective of the value of the 'CAMEL Capability Handling' inside O-CSI),TDP-Criteria for O-CSI,SS-CSI and TIF-CSI.

(The complete set of above shall be sent even if only one CSI has changed in case of stand alone ISD. The omitted elements of above list will be withdrawn in the VLR.)

From CAMEL phase 3 onwards, the specific elements of VLR CAMEL Subscription Info which may be sent are:

O-CSI (irrespective of the value of the 'CAMEL Capability Handling' inside O-CSI), TDP criteria for O-CSI, SS-CSI and TIF-CSI;

(The complete set of above shall be sent even if only one CSI has changed in case of stand alone ISD. The omitted elements of above list will be withdrawn in the VLR.)

- D-CSI;
- VT-CSI;
- TDP-Criteria for VT-CSI:
- MO-SMS-CSI;
- MT-SMS-CSI;
- TDP-Criteria for MT-SMS-CSI:
- M-CSI.

If the VLR CAMEL Subscription Info is omitted in the Insert Subscriber Data operation the VLR shall keep the previously stored VLR CAMEL Subscription Info. Within one dialogue subsequent received data are interpreted as add-on data. If the VLR detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

The VLR CAMEL Subscription Info may contain the TIF-CSI (Translation Information Flag) for CAMEL Phase 2 and higher. See 3GPP TS 23.072 for the use of this parameter and the conditions for its presence.

### Supported CAMEL Phases

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078. This parameter is used by the VLR and SGSN.

A VLR or SGSN not supporting any CAMEL Phase may omit this parameter.

## **GPRS Subscription Data**

This parameter contains a list of PDP-contexts a user has subscribed to; see clause 7.6.

At GPRS location updating the HLR shall include the complete GPRS Subscription Data.

When there is a change in GPRS subscriber data the HLR shall include only the new and/or modified PDP contexts.

When the SGSN receives GPRS Subscription Data within a dialogue it shall check if the received data has to be considered as the entire GPRS subscription data. If so, it shall replace the stored GPRS Subscription Data with the received data set, otherwise it shall replace the data only for the modified PDP contexts (if any) and add the new PDP contexts (if any) to the stored GPRS Subscription Data.

If GPRS Subscription Data is omitted in the Insert Subscriber Data operation the SGSN shall keep the previously stored GPRS Subscription Data.

If the SGSN detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value. This parameter is used only by the SGSN and if the VLR receives this parameter it shall ignore it

# SGSN CAMEL Subscription Info

The SGSN CAMEL Subscription Info is sent at GPRS location updating or when any information in the applicable SGSN CAMEL Subscription Info in the HLR has been changed.

- In CAMEL Phase 3, this parameter may contain one or both of GPRS-CSI and MO-SMS-CSI.
- In CAMEL Phase 4, this parameter may contain GPRS-CSI, MO-SMS-CSI and MT-SMS-CSI and TDP-Criteria for MT-SMS-CSI.

At GPRS location updating the complete set of SGSN CAMEL Subscription Info is sent.

When CAMEL Subscription Information is changed in the HLR and changed data have to be sent to the SGSN, then one or more specific elements of SGSN CAMEL Subscription Info are sent in one dialogue.

When the SGSN receives a specific element of SGSN CAMEL Subscription Info, it shall overwrite the corresponding specific element of SGSN CAMEL Subscription Info (if any) which it has stored for that subscriber.

The specific elements of SGSN CAMEL Subscription Info which may be sent are:

- MO-SMS-CSI;
- MT-SMS-CSI:
- TDP-Criteria for MT-SMS-CSI;
- GPRS-CSI;
- MC-CSI.

This parameter is used only by the SGSN and if the VLR receives this parameter it shall ignore it.

# Roaming Restricted In SGSN Due To Unsupported Feature

The HLR may decide to include this parameter in the request if certain services or features are indicated as not supported by the SGSN. This parameter is used only by the SGSN and if the VLR receives this parameter it shall ignore it.

### CS Allocation/Retention priority

The CS Allocation/Retention priority is used only for Circuit Switched (CS). This parameter specifies relative importance to compare with other bearers about allocation and retention of bearer. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

### Offered CAMEL 4 CSIs

This parameter indicates the CAMEL phase 4 CSIs offered in the VMSC/VLR or SGSN (see clause 7.6.3.36D).

# **Subscribed Charging Characteristics**

This parameter refers to the Subscribed Charging Characteristics as defined in 3GPP TS 32.251.

For a detailed description of the use of the parameter, see 3GPP TS 32.251.

This parameter is used only by the SGSN and if the VLR receives this parameter it shall ignore it.

### Access Restriction Data

This parameter indicates the allowed RAT according to subscription data. (see clause 7.6.3.96)

If the VLR/SGSN supports the Access Restriction feature but does not receive the Access Restriction Data parameter from the HLR at location updating or restoration, the VLR/SGSN shall assume that the subscriber's profile does not have any restrictions enabled.

For a detailed description of the use of the parameter, see 3GPP TS 23.012[23] for CS domain and 3GPP TS 23.060[104] for PS domain.

# User error

Only one of the following values is applicable:

- Unidentified subscriber;
- Data missing;
- Unexpected data value.

# 8.8.1.4 Basic service information related to supplementary services

A number of parameters that relate to supplementary services can be qualified by a Basic Service Group (or a Basic Service Group List). This clause explains how this information is to be interpreted. Supplementary service parameters to which this clause is applicable only apply to the basic service groups described in this clause, and only those basic service groups shall be overwritten at the VLR or the SGSN.

The Basic Service Group (or Basic Service Group List) is optional.

If present the Basic Service Group (or each element of the Basic Service Group List) shall be one of:

- an Elementary Basic Service Group for which the supplementary service is applicable to at least one basic service in the group and for which the subscriber has a subscription to at least one basic service in the group;
- the group "All Teleservices" provided that the service is applicable to at least one teleservice and that the subscriber has a subscription to at least one teleservice which is in the same Elementary Basic Service Group as a teleservice to which the service is applicable;
- the group "All Bearer Services" provided that the service is applicable to at least one bearer service and that the subscriber has a subscription to at least one bearer service which is in the same Elementary Basic Service Group as a basic service to which the service is applicable.

If the Basic Service Group (or Basic Service Group List) is not present then the parameter shall apply to all Basic Service Groups.

If the basic service information is not a single Elementary Basic Service Group then the parameter shall be taken as applying individually to all the Elementary Basic Service Groups for which:

- the supplementary service is applicable to at least one basic service in the Basic Service Group; and
- the subscriber has a subscription to at least one basic service in the Basic Service Group.

The VLR and the SGSN are not required to store supplementary services data for Basic Service Groups which are not supported at the VLR or the SGSN respectively.

# 8.8.2 MAP-DELETE-SUBSCRIBER-DATA service

# 8.8.2.1 Definition

This service is used by an HLR to remove certain subscriber data from a VLR or SGSN if the subscription of one or more supplementary services or basic services is withdrawn. Note that this service is not used in case of erasure or deactivation of supplementary services.

This service is also used by an HLR to remove GPRS subscription data from an SGSN.

It is a confirmed service and consists of the primitives shown in table 8.8/2.

# 8.8.2.2 Service primitives

Table 8.8/2: MAP-DELETE-SUBSCRIBER-DATA

Parameter name	Request	Indication	Response	Confirm
Invoke Id	М	M(=)	M(=)	M(=)
IMSI	M	M(=)		
Basic service List	С	C(=)		
SS-Code List	С	C(=)		
Roaming Restriction Due To				
Unsupported Feature	С	C(=)		
Camel Subscription Info Withdraw	С	C(=)		
Specific CSI Withdraw	С	C(=)		
Regional Subscription Data	С	C(=)		
VBS Group Indication	С	C(=)		
VGCS Group Indication	С	C(=)		
GPRS Subscription Data Withdraw	С	C(=)		

Roaming Restricted In SGSN Due To	С	C(=)		
Unsupported Feature				
LSA Information Withdraw	С	C(=)		
IST Information Withdraw	С	C(=)		
Regional Subscription Response			С	C(=)
GMLC List Withdraw	С	C(=)		
Subscribed Charging Characteristics	С	C(=)		
Withdraw				
User error			С	C(=)
Provider error				Ö

# 8.8.2.3 Parameter use

All parameters are described in clause 7.6. The following clarifications are applicable:

### Basic service List

A list of Extensible Basic service parameters (Extensible Basic service is defined in clause 7.6). It is used when one, several or all basic services are to be withdrawn from the subscriber. If the VLR or the SGSN receives a value for an Extensible Basic Service which it does not support, it shall ignore that value. This parameter is used by the VLR and by the SGSN.

### SS-Code List

A list of SS-Code parameters (SS-Code is defined in clause 7.6). It is used when several or all supplementary services are to be withdrawn from the subscriber.

There are three possible options:

- deletion of basic service(s);
  - The parameter Basic service List is only included.
- deletion of supplementary service(s);
  - The parameter SS-Code List is only included.
- deletion of basic and supplementary services;
  - Both Basic service List and SS-Code List are included.

This parameter is used by the VLR and SGSN for Call Barring and LCS. Otherwise, this parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

### Roaming Restriction Due To Unsupported Feature

This parameter is used if Roaming Restriction Due To Unsupported Feature is deleted from the subscriber data. This may occur if unsupported features or services are removed from the subscriber data in the HLR.

If this parameter is sent the VLR shall check if the current Location Area is possibly allowed now. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

### **CAMEL Subscription Info Withdraw**

This parameter is used to indicate that CAMEL Subscription Info shall be deleted from the VLR or from the SGSN. All CAMEL Subscription Info for the subscriber shall be deleted. This parameter is used by the VLR and by the SGSN. This parameter should not be sent in the same message as the Specific CSI Withdraw parameter.

# Specific CSI Withdraw

This parameter is used to indicate that one or more specific elements of CAMEL Subscription Info shall be deleted from the VLR or from the SGSN.

The specific elements of CAMEL Subscription Info which may be withdrawn are:

- O-CSI with TDP criteria for O-CSI;

- SS-CSI;
- TIF-CSI;
- D-CSI:
- VT-CSI with TDP criteria for VT-CSI;
- MO-SMS-CSI;
- MT-SMS-CSI with TDP-Criteria for MT-SMS-CSI;
- M-CSI;
- MG-CSI;
- GPRS-CSI.

This parameter is used by the VLR and by the SGSN. It shall not be sent to VLRs that do not support CAMEL phase 3 or higher. This parameter should not be sent in the same message as the CAMEL Subscription Info Withdraw parameter.

# Regional Subscription Identifier

Contains one single Zone Code (as defined in clause 7.6) and is used if all Zone Codes shall be deleted from the subscriber data. When all the Zone Codes are deleted, the VLR or the SGSN shall check for its location areas whether they are allowed or not. If the whole MSC area is restricted, VLR will report it to HLR by returning the Regional Subscription Response "MSC Area Restricted". If the whole SGSN area is restricted, SGSN will report it to HLR by returning the Regional Subscription Response "SGSN Area Restricted".

The binary coding of the Zone Code value received in a Delete Subscriber Data request shall not be checked by the VLR or by the SGSN.

Note that support of this parameter is a network operator option and it shall not be sent to networks which do not support Regional Subscription.

If Regional Subscription is not supported by the VLR or by the SGSN, the request for deletion of Zone Codes is refused by sending the Regional Subscription Response "Regional Subscription Not Supported" to the HLR.

If no Zone Codes are stored in the respective subscriber data record, the request for deleting all Zone Code information shall be ignored and no Regional Subscription Response shall be returned. This parameter is used by the VLR and by the SGSN.

### **VBS** Group Indication

Contains an indication (flag) which is used if all Group Ids shall be deleted from the subscriber data for the Voice Broadcast teleservice.

If VBS is not supported in the VLR or no Group Ids are stored for VBS in the respective subscriber record, the request for deletion of all Group Ids shall be ignored. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

## **VGCS Group Indication**

Contains an indication (flag) which is used if all Group Id's shall be deleted from the subscriber data for the Voice Group Call teleservice. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

If VGCS is not supported in the VLR or no Group Ids are stored for VGCS in the respective subscriber record, the request for deletion of all Group Ids shall be ignored.

### **GPRS Subscription Data Withdraw**

This parameter is used to indicate whether all GPRS Subscription Data for the subscriber shall be deleted or if only a subset of the stored GPRS Subscription Data for the subscriber shall be deleted. In the latter case only those PDP contexts whose identifiers are included in the subsequent identifier list will be deleted. This parameter is used only by the SGSN and if the VLR receives this parameter it shall ignore it.

# Roaming Restricted In SGSN Due To Unsupported Feature

This parameter is used if Roaming Restricted In SGSN Due To Unsupported Feature is deleted from the GPRS subscriber data. This may occur if unsupported features or services are removed from the GPRS subscriber data in the HLR.

If this parameter is sent the SGSN shall check if the current Location Area is possibly allowed now. This parameter is used only by the SGSN and if the VLR receives this parameter it shall ignore it.

### LSA Information Withdraw

This parameter is used to indicate whether all LSA Information for the subscriber shall be deleted or if only a subset of the stored LSA Information for the subscriber shall be deleted. In the latter case only the LSA data whose LSA identities are included in the subsequent LSA data list will be deleted. This parameter is used by the VLR and the SGSN.

### IST Information Withdraw

This parameter is used to indicate that the IST condition has been removed for the subscriber. See 3GPP TS 43.035 for the use of this parameter.

### Regional Subscription Response

If included in the Delete Subscriber Data response this parameter indicates one of:

- MSC Area Restricted;
- SGSN Area Restricted;
- Regional Subscription Not Supported.

This parameter is used by the VLR and by the SGSN.

## **GMLC List Withdraw**

This parameter indicates that the subscriber's LCS GMLC List shall be deleted from the VLR or SGSN.

### Subscribed Charging Characteristics Withdraw

This parameter indicates that the Subscribed Charging Characteristics shall be replaced with a local default value in the SGSN (see 3GPP TS 32.251).

This parameter is used only by the SGSN and if the VLR receives this parameter it shall ignore it.

### <u>User error</u>

Only one of the following values is applicable:

- Unidentified subscriber;
- Data missing;
- Unexpected data value.

# 8.9 Identity management services

# 8.9.1 MAP-PROVIDE-IMSI service

# 8.9.1.1 Definition

This service is used by a VLR in order to get, via the MSC, the IMSI of a subscriber (e.g. when a subscriber has identified itself with a TMSI not allocated to any subscriber in the VLR).

It is a confirmed service and consists of the primitives shown in table 8.9/1.

# 8.9.1.2 Service primitives

Table 8.9/1: MAP-PROVIDE-IMSI

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI			С	C(=)
User error			С	C(=)
Provider error				0

### 8.9.1.3 Parameter use

All parameters are described in clause 7.6. The following clarifications are applicable:

#### **IMSI**

This parameter is received when the request is successfully carried out. It contains the requested IMSI.

### User error

Only one of the following values is applicable:

- Absent subscriber.

# 8.9.2 MAP-FORWARD-NEW-TMSI service

# 8.9.2.1 Definition

This service is used by a VLR to allocate, via MSC, a new TMSI to a subscriber during an ongoing transaction (e.g. call set-up, location updating or supplementary services operation).

It is a confirmed service and consists of the primitives shown in table 8.9/2.

# 8.9.2.2 Service primitives

Table 8.9/2: MAP-FORWARD-NEW-TMSI

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
TMSI	M	M(=)		
Provider error				0

# 8.9.2.3 Parameter use

The parameter TMSI is described in clause 7.6.

# 8.10 Fault recovery services

# 8.10.1 MAP\_RESET service

# 8.10.1.1 Definition

This service is used by the HLR, after a restart, to indicate to a list of VLRs or SGSNs that a failure occurred.

The MAP\_RESET service is a non-confirmed service using the service primitives defined in table 8.10/1.

# 8.10.1.2 Service primitives

Table 8.10/1: MAP\_RESET

Parameter name	Request	Indication
Invoke Id	M	M(=)
HLR number	M	M(=)
HLR Id LIST	U	C(=)

### 8.10.1.3 Parameter definition and use

#### Invoke Id

See definition in clause 7.6.1.

### HLR number

See definition in clause 7.6.2.

# **HLR Id LIST**

The HLR Id List is a list of HLR Ids. If the parameter is present in the indication, the VLR or SGSN may base the retrieval of subscribers to be restored on their IMSI: the subscribers affected by the reset are those whose IMSI leading digits are equal to one of these numbers. If the parameter is absent, subscribers to be restored are those for which the OriginatingEntityNumber received at location updating time matches the equivalent parameter of the Reset Indication.

# 8.10.2 MAP\_FORWARD\_CHECK\_SS\_INDICATION service

# 8.10.2.1 Definition

This service may be used by an HLR as an implementation option, to indicate to a mobile subscriber that supplementary services parameters may have been altered, e.g. due to a restart. If received from the HLR, the VLR shall forward this indication to the MSC, which in turn forwards it to the MS. The HLR only sends this indication after successful completion of the subscriber data retrieval from HLR to VLR that ran embedded in a MAP\_UPDATE\_LOCATION procedure.

The MAP\_FORWARD\_CHECK\_SS\_INDICATION service is a non-confirmed service using the service primitives defined in table 8.10/2.

# 8.10.2.2 Service primitives

Table 8.10/2: MAP\_FORWARD\_CHECK\_SS\_INDICATION

Parameter name	Request	Indication
Invoke Id	М	M(=)

### 8.10.2.3 Parameter definition and use

### Invoke Id

See definition in clause 7.6.1.

# 8.10.3 MAP\_RESTORE\_DATA service

# 8.10.3.1 Definition

This service is invoked by the VLR on receipt of a MAP\_PROVIDE\_ROAMING\_NUMBER indication for an unknown IMSI, or for a known IMSI with the indicator "Confirmed by HLR" set to "Not confirmed". The service is

used to update the LMSI in the HLR, if provided, and to request the HLR to send all data to the VLR that are to be stored in the subscriber's IMSI record.

The MAP\_RESTORE\_DATA service is a confirmed service using the service primitives defined in table 8.10/3.

# 8.10.3.2 Service primitives

Table 8.10/3: MAP RESTORE DATA

Parameter name	Request	Indication	Response	Confirm
Invoke Id	М	M(=)	M(=)	M(=)
IMSI	М	M(=)		
LMSI	U	C(=)		
Supported CAMEL phases	C	C(=)		
SoLSA Support Indicator	C	C(=)		
IST Support Indicator	С	C(=)		
Super-Charger Supported in	С	C(=)		
Serving Network Entity				
Long FTN Supported	С	C(=)		
Supported LCS Capability	С	C(=)		
Sets				
Offered CAMEL 4 CSIs	C	C(=)		
HLR number			С	C(=)
MS Not Reachable Flag			С	C(=)
User error			С	C(=)
Provider error				0

# 8.10.3.3 Parameter definitions and use

### Invoke Id

See definition in clause 7.6.1.

### **IMSI**

See definition in clause 7.6.2.

### **LMSI**

See definition in clause 7.6.2. It is an operator option to provide the LMSI from the VLR; it is mandatory for the HLR to support the LMSI handling procedures.

### Supported CAMEL Phases

This parameter indicates which phases of CAMEL are supported. Must be present if a CAMEL phase different from phase 1 is supported. Otherwise may be absent.

### SoLSA Support Indicator

This parameter is used by the VLR to indicate to the HLR in the Restore Data indication that SoLSA is supported. If this parameter is not included in the Restore Data indication then the HLR shall not perform any specific error handling.

This SoLSA Support Indicator shall be stored by the HLR per VLR where there are Subscribers roaming. If a Subscriber is marked as only allowed to roam in Subscribed LSAs while roaming in a VLR and no SoLSA Support indicator is stored for that VLR, the location status of that Subscriber shall be set to Restricted.

### **IST Support Indicator**

This parameter is used to indicate to the HLR that the VMSC supports basic IST functionality, that is, the VMSC is able to terminate the Subscriber Call Activity that originated the IST Alert when it receives the IST alert response indicating that the call(s) shall be terminated. If this parameter is not included in the Restore Data indication and the Subscriber is marked as an IST Subscriber, then the HLR may limit the service for the subscriber (by inducing an Operator Determined barring of Outgoing calls), or allow service assuming the associated risk of not having the basic IST mechanism available.

This parameter can also indicate that the VMSC supports the IST Command service, including the ability to terminate all calls being carried for the identified subscriber by using the IMSI as a key. If this additional capability is not included in the Restore Data indication and the HLR supports the IST Command capability, then the HLR may limit the service for the subscriber (by inducing an Operator Determined barring of Outgoing calls), or allow service assuming the associated risk of not having the IST Command mechanism available.

### Long FTN Supported

This parameter indicates that the VLR supports Long Forwarded-to Numbers.

### Super-Charger Supported in Serving Network Entity

This parameter is used by the VLR to indicate to the HLR that the VLR supports the Super-Charger functionality and that subscriber data is required.

If this parameter is absent then the VLR does not support the Super-Charger functionality.

# Supported LCS Capability Sets

This parameter indicates, if present, the capability sets of LCS which are supported. If the parameter is sent but no capability set is marked as supported then the VLR does not support LCS at all.

If this parameter is absent then the VLR may support at most LCS capability set 1, that is LCS Release98 or Release99 version.

#### Offered CAMEL 4 CSIs

This parameter indicates the CAMEL phase 4 CSIs offered in the VMSC/VLR (see clause 7.6.3.36D).

### HLR number

See definition in clause 7.6.2. The presence of this parameter is mandatory in case of successful outcome of the service.

## MS Not Reachable Flag

See definition in clause 7.6.8. This parameter shall be present in case of successful outcome of the service, if the "MS Not Reachable flag" was set in the HLR.

### <u>User error</u>

In case of unsuccessful outcome of the service, an error cause shall be returned by the HLR. The following error causes defined in clause 7.6.1 may be used, depending on the nature of the fault:

- unknown subscriber;
- system failure;
- unexpected data value;
- data missing.

## Provider error

For definition of provider errors see clause 7.6.1.

# 8.11 Subscriber Information services

# 8.11.1 MAP-ANY-TIME-INTERROGATION service

# 8.11.1.1 Definition

This service is used by the gsmSCF, to request information (e.g. subscriber state and location) from the HLR or the GMLC at any time. This service may also be used by the gsmSCF to request the Mobile Number Portability (MNP) information from the NPLR.

This service is also used by the Presence Network Agent to request information, (e.g. subscriber state and location) about the subscriber (associated with a presentity) from the HLR at any time (see 3GPP TS 23.141 [128]).

When this service is used to the HLR, the subscriber state or location may be requested.

When this service is used to the GMLC, only the location may be requested.

When this service is used to the NPLR, only the MNP information may be requested.

The MAP-ANY-TIME-INTERROGATION service is a confirmed service using the service primitives defined in table 8.11/1.

# 8.11.1.2 Service primitives

Table 8.11/1: Any\_Time\_Interrogation

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
Requested Info	M	M(=)		
Requested domain	С	C(=)		
MNP Requested Info	С	C(=)		
gsmSCF-Address	M	M(=)		
IMSI	С	C(=)		
MSISDN	С	C(=)		
Location Information			С	C(=)
Location Information for GPRS			С	C(=)
Subscriber State			С	C(=)
PS Subscriber State			С	C(=)
IMEI			С	C(=)
MS Classmark 2			С	C(=)
GPRS MS Class			С	C(=)
MNP info Result			С	C(=)
User error			C	C(=)
Provider error				0

# 8.11.1.3 Parameter definition and use

All parameters are described in clause 7.6. The use of these parameters and the requirements for their presence are specified in 3GPP TS 23.018 [97] and 3GPP TS 23.078 [98].

The HLR or GMLC may be able to use the value of the parameter gsmSCF-address to screen a MAP\_Any\_Time\_Interrogation indication.

The use of the parameters and the requirements for their presence are specified in 3GPP TS 23.078.

# User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- System Failure;
- Any Time Interrogation Not Allowed;
- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

### Provider error

These are defined in clause 7.6.1.

# 8.11.2 MAP-PROVIDE-SUBSCRIBER-INFO service

# 8.11.2.1 Definition

This service is used to request information (e.g. subscriber state and location) from the VLR or SGSN at any time.

The MAP-PROVIDE-SUBSCRIBER-INFO service is a confirmed service using the primitives defined in table 8.11/2.

# 8.11.2.2 Service primitives

Table 8.11/2: Provide\_Subscriber\_Information

Parameter name	Request	Indication	Response	Confirm
Invoke id	М	M(=)	M(=)	M(=)
Requested Info	М	M(=)		
IMSI	М	M(=)		
LMSI	U	0		
Location Information			С	C(=)
Location Information for GPRS			O	C(=)
Subscriber State			С	C(=)
PS Subscriber State			С	C(=)
IMEI			С	C(=)
MS Classmark 2			С	C(=)
GPRS MS Class			С	C(=)
User error			С	C(=)
Provider error				0

# 8.11.2.3 Parameter definition and use

All parameters are defined in clause 7.6. The use of these parameters and the requirements for their presence are specified in 3GPP TS 23.018 [97] and 3GPP TS 23.078 [98].

# User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Data Missing;
- Unexpected Data Value.

#### Provider error

These are defined in clause 7.6.1.

# 8.11.3 MAP-ANY-TIME-SUBSCRIPTION-INTERROGATION service

# 8.11.3.1 Definition

This service is used by the gsmSCF, to request subscription information (e.g. call forwarding supplementary service data or CSI) from the HLR at any time. In an IP Multimedia Core Network, an IM-SSF can take on the role of a gsmSCF for this service.

# 8.11.3.2 Service primitives

Table 8.11/3: Any\_Time\_Subscription\_Interrogation

Parameter name	Request	Indication	Response	Confirm
----------------	---------	------------	----------	---------

Invoke id	M	M(=)	M(=)	M(=)
Requested Subscription Info	M	M(=)		
GsmSCF-Address	M	M(=)		
IMSI	С	C(=)		
MSISDN	С	C(=)		
Long FTN Supported	С	C(=)		
Call Forwarding Data			С	C(=)
Call Barring Data			С	C(=)
ODB Info			С	C(=)
CAMEL Subscription Info			С	C(=)
Supported CAMEL phases in VLR			С	C(=)
Supported CAMEL phases in SGSN			С	C(=)
Offered CAMEL 4 CSIs in VLR			С	C(=)
Offered CAMEL 4 CSIs in SGSN			С	C(=)
MSISDN-BS-List			С	C(=)
User error			С	C(=)
Provider error				0

### 8.11.3.3 Parameter definition and use

All parameters are described in clause 7.6.

The HLR may be able to use the value of the parameter gsmSCF-address to screen a MAP\_Any\_Time\_Subscription\_Interrogation indication. The gsmSCF-address shall contain the IM-SSF address when the IM-SSF takes the role of the gsmSCF.

The use of the parameters and the requirements for their presence are specified in 3GPP TS 23.078 and 3GPP TS 23.278.

### <u>User error</u>

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Unexpected Data Value;
- Unknown Subscriber;
- BearerServiceNotProvisioned;
- TeleserviceNotProvisioned;
- CallBarred;
- IllegalSS-Operation;
- SS-NotAvailable;
- InformationNotAvailable;
- Any Time Subscription Interrogation Not Allowed;
- Data Missing.

# Provider error

These are defined in clause 7.6.1.

# 8.11.4 MAP-ANY-TIME-MODIFICATION service

# 8.11.4.1 Definition

This service is used by the gsmSCF, to modify information of the HLR at any time.

This service is also used by the Presence Network Agent to activate or deactivate reporting of mobility management events (associated with a presentity) from the VLR or SGSN (see 3GPP TS 23.141 [128]).

This service is also used by external Short Message Gateway (IP-SM-GW) for updating the IP-SM-GW Number stored in the HLR.

# 8.11.4.2 Service primitives

Table 8.11/4: Any\_Time\_Modification

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
gsmSCF-Address	M	M(=)		
Subscriber Identity	M	M(=)		
Modification request for ODB data	С	C(=)		
Modification request for SS information	С	C(=)		
Modification request for CSI	С	C(=)		
Long FTN Supported	С	C(=)		
Modification request for IP-SM-GW data	С	C(=)		
Ext Forwarding information-for-CSE			С	C(=)
Ext Call barring information-for-CSE			С	C(=)
ODB Info			С	C(=)
CAMEL subscription info			С	C(=)
User error			С	C(=)
Provider error				0

# 8.11.4.3 Parameter definition and use

All parameters are described in clause 7.6.

The HLR may be able to use the value of the parameter gsmSCF-address to screen a MAP\_Any\_Time\_Modification indication.

The use of parameters other than described below and the requirements for their presence are specified in 3GPP TS 23.078 [98] and 3GPP TS 23.278 [125].

### gsmSCF-Address

This parameter indicates the address of the interrogating gsmSCF. The gsmSCF Address shall be in international E.164 format. If the service is used by IP-SM-GW, the parameter contains the address of the IP-SM-GW. See also 3GPP TS 23.078 [98] and 3GPP TS 23.278 [125].

### Modification request for IP-SM-GW data

This parameter is used by the external IP-SM-GW for updating the IP-SM-GW Number stored in the HLR. If this parameter is present then other modification requests shall not be present.

## User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Any Time Modification Not Allowed;
- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber;
- Bearer service not provisioned;

This error is returned only if not even a subset of the requested bearer service group has been subscribed to;

Teleservice not provisioned;

This error is returned only if not even a subset of the requested teleservice group has been subscribed to;

- Call Barred;
- Illegal SS operation;
- SS error status;
- SS incompatibility;
- SS subscription violation;
- Information Not Available.

### Provider error

These are defined in clause 7.6.1.

# 8.11.5 MAP-NOTE-SUBSCRIBER-DATA-MODIFIED service

# 8.11.5.1 Definition

This service is used by the HLR to inform the gsmSCF that subscriber data have been modified. In an IP Multimedia Core Network, an IM-SSF can take on the role of a gsmSCF for this service.

# 8.11.5.2 Service primitives

Table 8.11/5: Note\_Subscriber\_Data\_Modified

Parameter name	Request	Indication	Response	Confirm
Invoke id	М	M(=)	M(=)	M(=)
IMSI	М	M(=)		
MSISDN	М	M(=)		
Ext Forwarding	С	C(=)		
information-for-CSE				
Ext Call barring	С	C(=)		
information-for-CSE				
ODB Info	С	C(=)		
CAMEL subscription	С	C(=)		
info				
All Information Sent	С	C(=)		
User error			С	C(=)
Provider error				0

# 8.11.5.3 Parameter definition and use

# Invoke id

See clause 7.6.1 for the use of this parameter.

# **IMSI**

See clause 7.6.2 for the use of this parameter.

### **MSISDN**

See clause 7.6.2 for the use of this parameter. In an IP Multimedia Core Network, if no MSISDN is available, the HLR shall populate this parameter with a dummy MSISDN.

# **Ext Forwarding information-for-CSE**

See clause 7.6.3 for the use of this parameter. The use of this parameter and the requirements for their presence are specified in 3GPP TS 23.078.

## Ext Call barring information-for-CSE

See clause 7.6.3 for the use of this parameter. The use of this parameter and the requirements for their presence are specified in 3GPP TS 23.078.

### **ODB** Info

See clause 7.6.3 for the use of this parameter. The use of this parameter and the requirements for their presence are specified in 3GPP TS 23.078.

### **CAMEL** subscription info

See clause 7.6.3 for the use of this parameter. The use of this parameter and the requirements for their presence are specified in 3GPP TS 23.078 and 3GPP TS 23.278.

### **All Information Sent**

This parameter is set when the HLR has sent all information to gsmSCF.

#### User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

### Provider error

These are defined in clause 7.6.1.

The use of the parameters and the requirements for their presence are specified in 3GPP TS 23.078 and 3GPP TS 23.278.

# 9 Operation and maintenance services

# 9.1 Subscriber tracing services

# 9.1.1 MAP-ACTIVATE-TRACE-MODE service

### 9.1.1.1 Definition

This service is used between the HLR and the VLR to activate subscriber tracing in the VLR.

Also this service is used between the HLR and the SGSN to activate subscriber tracing in the SGSN.

The MAP-ACTIVATE-TRACE-MODE service is a confirmed service using the primitives from table 9.1/1.

# 9.1.1.2 Service primitives

Table 9.1/1: MAP-ACTIVATE-TRACE-MODE

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	С	C(=)		
Trace reference	M	M(=)		

Trace type	M	M(=)		
Trace reference 2	С	C(=)		
Trace depth list	С	C(=)		
Trace NE type list	С	C(=)		
Trace interface list	С	C(=)		
Trace event list	С	C(=)		
Trace support			С	C(=)
indicator				
OMC Id	U	C(=)		
User error			С	C(=)
Provider error				0

# 9.1.1.3 Parameter use

# Invoke id

See definition in clause 7.6.1.

#### **IMSI**

See definition in clause 7.6.2. The IMSI is a mandatory parameter in a stand-alone operation.

### Trace reference

See definition in clause 7.6.10. This parameter contains trace reference for GSM only tracing request.

# Trace type

See definition in clause 7.6.10. This parameter contains trace type for GSM only tracing request.

# OMC Id

See definition in clause 7.6.2. The use of this parameter is an operator option.

### Trace reference 2

See definition in clause 7.6.10. This parameter shall be used for UMTS trace activation.

# Trace depth list

See definition in clause 7.6.10. This parameter shall be used for UMTS trace activation.

### Trace NE type list

See definition in clause 7.6.10. This parameter shall be used for UMTS trace activation.

# Trace interface list

See definition in clause 7.6.10. This parameter shall be used for UMTS trace activation.

### Trace event list

See definition in clause 7.6.10. This parameter shall be used for UMTS trace activation.

# Trace support indicator

See definition in clause 7.6.10. This parameter shall be used for UMTS trace activation.

# User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unidentified Subscriber;
- Facility Not Supported;
- Tracing Buffer Full;

- System Failure;
- Unexpected Data Value;
- Data missing.

### Provider error

For definition of provider errors see clause 7.6.1.

# 9.1.2 MAP-DEACTIVATE-TRACE-MODE service

# 9.1.2.1 Definition

This service is used between the VLR and the HLR for deactivating subscriber tracing in the VLR.

Also this service is used between the SGSN and the HLR for deactivating subscriber tracing in the SGSN.

The MAP-DEACTIVATE-TRACE-MODE service is a confirmed service using the primitives from table 9.1/2.

# 9.1.2.2 Service primitives

Table 9.1/2: MAP-DEACTIVATE-TRACE-MODE

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	С	C(=)		
Trace reference	M	M(=)		
Trace reference 2	С	C(=)		
User error			С	C(=)
Provider error				0

# 9.1.2.3 Parameter use

# Invoke id

See definition in clause 7.6.1.

# **IMSI**

See definition in clause 7.6.2. The IMSI is a mandatory parameter in a stand-alone operation.

# Trace reference

See definition in clause 7.6.10.

# Trace reference 2

See definition in clause 7.6.10. This parameter shall be used for UMTS trace activation.

### User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unidentified Subscriber;
- Facility Not Supported;
- System Failure;
- Unexpected Data Value;
- Data missing.

### Provider error

For definition of provider errors see clause 7.6.1.

# 9.1.3 MAP-TRACE-SUBSCRIBER-ACTIVITY service

# 9.1.3.1 Definition

This service is used between the VLR and the MSC to activate the subscriber tracing in the MSC.

The MAP-TRACE-SUBSCRIBER-ACTIVITY service is a non-confirmed service using the primitives from table 9.1/3.

# 9.1.3.2 Service primitives

Table 9.1/3: MAP-TRACE-SUBSCRIBER-ACTIVITY

Parameter name	Request	Indication
Invoke id	М	M(=)
IMSI	С	C(=)
Trace reference	М	M(=)
Trace type	M	M(=)
OMC Id	U	C(=)

# 9.1.3.3 Parameter use

# Invoke id

See definition in clause 7.6.1.

# **IMSI**

See definition in clause 7.6.2. The controlling MSC shall provide either the IMSI or the IMEI to the servicing MSC.

# Trace reference

See definition in clause 7.6.10.

#### Trace type

See definition in clause 7.6.10.

# OMC Id

See definition in clause 7.6.2. The use of this parameter is an operator option.

# 9.2 Other operation and maintenance services

# 9.2.1 MAP-SEND-IMSI service

# 9.2.1.1 Definition

This service is used by a VLR in order to fetch the IMSI of a subscriber in case of some Operation & Maintenance procedure where subscriber data are needed in the Visited PLMN and MSISDN is the only subscriber's identity known.

It is a confirmed service and consists of the primitives shown in table 9.2/1.

# 9.2.1.2 Service primitives

Table 9.2/1: MAP-SEND-IMSI

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
MSISDN	M	M(=)		
IMSI		, ,	С	C(=)
User error			С	C(=)
Provider error				Ò

# 9.2.1.3 Parameter use

All parameters are described in clause 7.6. The following clarifications are applicable.

# User error

Only one of the following values is applicable:

- Unknown subscriber;
- Unexpected data value;
- Data missing.

# 10 Call handling services

# 10.1 MAP\_SEND\_ROUTING\_INFORMATION service

# 10.1.1 Definition

This service is used between the Gateway MSC and the HLR. The service is invoked by the Gateway MSC to perform the interrogation of the HLR in order to route a call towards the called MS.

This is a confirmed service using the primitives listed in table 10.1/1.

This service is also used between the GMSC and the NPLR and between the gsmSCF and the HLR.

# 10.1.2 Service primitives

Table 10.1/1: MAP\_SEND\_ROUTING\_INFORMATION parameters

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Interrogation Type	M	M(=)		
GMSC or gsmSCF Address	M	M(=)		
MSISDN	M	M(=)	С	C(=)
OR Interrogation	С	C(=)		
OR Capability	С	C(=)		
CUG Interlock	С	C(=)	С	C(=)
CUG Outgoing Access	C C	C(=)	С	C(=)
Number of Forwarding	С	C(=)		
Network Signal Info	С	C(=)		
Supported CAMEL Phases	С	C(=)	С	C(=)
Suppress T-CSI	С	C(=)		
Offered CAMEL 4 CSIs	С	C(=)		
Suppression of Announcement	С	C(=)		
Call Reference Number	С	C(=)		
Forwarding Reason	С	C(=)		
Basic Service Group	С	C(=)		

Parameter name	Request	Indication	Response	Confirm
Basic Service Group 2	С	C(=)		
Alerting Pattern	С	C(=)		
CCBS Call	С	C(=)		
Supported CCBS Phase	С	C(=)		
Additional Signal Info	С	C(=)		
IST Support Indicator	С	C(=)		
Pre-paging supported	C C	C(=)		
Call Diversion Treatment Indicator	С	C(=)		
Long FTN Supported	С	C(=)		
Suppress VT-CSI	C C	C(=)		
Suppress Incoming Call Barring	C	C(=)		
SuppressMTSS	C	C(=)		
gsmSCF Initiated Call	C C	C(=)		
Network Signal Info 2	Ċ	C(=)		
MT Roaming Retry Supported	Ŭ	C(=)		
IMSI		<b>O</b> (-)	С	C(=)
MSRN			Č	C(=)
Forwarding Data			Č	C(=)
Forwarding Interrogation Required			Č	C(=)
VMSC address			Č	C(=)
ReleaseResourcesSupported			Č	C(=)
GMSC Camel Subscription Info			Ċ	C(=)
Location Information			C C	C(=)
Subscriber State			Č	C(=)
Basic Service Code			C	C(=)
CUG Subscription Flag			Č	C(=)
North American Equal Access preferred			Ü	C(=)
Carrier Id				- ( )
User error			С	C(=)
SS-List			Ü	C(=)
CCBS Target			Ċ	C(=)
Keep CCBS Call Indicator			C	C(=)
IST Alert Timer			C	C(=)
Number Portability Status			U	C(=)
Supported CAMEL Phases in VMSC			С	, ,
Offered CAMEL 4 CSIs in VMSC			C C	C(=)
MSRN 2			С	C(=)
Forwarding Data 2			C C	C(=)
SS-List 2			С	C(=)
Basic Service Code 2			С	C(=)
Allowed Services			С	C(=)
Unavailability Cause			С	C(=)
Provider error				ò
GSM Bearer Capability			U	C (=)

# 10.1.3 Parameter use

See clause 7.6 for a definition of the parameters used in addition to the following. Note that:

- a conditional parameter whose use is defined only in 3GPP TS 23.078 shall be absent if the sending entity does not support CAMEL;
- a conditional parameter whose use is defined only in 3GPP TS 23.079 [99] shall be absent if the sending entity does not support optimal routeing;
- a conditional parameter whose use is defined only in 3GPP TS 23.078 & 3GPP TS 23.079 [99] shall be absent if the sending entity supports neither CAMEL nor optimal routeing.

# Interrogation Type

See 3GPP TS 23.079 [99] for the use of this parameter.

### GMSC or gsmSCF address

The E.164 address of the GMSC or the gsmSCF. This parameter contains the gsmSCF address if the gsmSCF iniated call parameter is present, otherwise it is the GMSC address.

### **MSISDN**

This is the Mobile Subscriber ISDN number assigned to the called subscriber. In the Request & Indication it is the number received by the GMSC in the ISUP IAM. If the call is to be forwarded and the HLR supports determination of the redirecting number, the HLR inserts the basic MSISDN in the Response.

See 3GPP TS 23.066 [108] for the use of this parameter and the conditions for its presence in the response.

### **OR** Interrogation

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

# **OR** Capability

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

### **CUG Interlock**

See 3GPP TS 23.018 [97] for the use of this parameter and the conditions for its presence.

# **CUG Outgoing Access**

See 3GPP TS 23.018 [97] for the use of this parameter and the conditions for its presence.

### Number of Forwarding

See 3GPP TS 23.018 [97] for the use of this parameter and the conditions for its presence.

### Network Signal Info

See 3GPP TS 23.018 [97] for the conditions for the presence of the components of this parameter.

# Supported CAMEL Phases

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

### **T-CSI Suppression**

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

## Offered CAMEL 4 CSIs

This parameter indicates the CAMEL phase 4 CSIs offered in the GMSC/VLR (see clause 7.6.3.36D).

### Suppression Of Announcement

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

## Call Reference Number

The use of this parameter and the conditions for its presence are specified in 3GPP TS 23.078 [98] and 3GPP TS 23.079 [99].

# Forwarding Reason

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

### **Basic Service Group**

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

# Basic Service Group 2

See 3GPP TS 23.079[99] for the use of this parameter and the conditions for its presence.

### **Alerting Pattern**

See 3GPP TS 23.018 [97] and 3GPP TS 23.078 [98] for the use of this parameter and the conditions for its presence.

### CCBS Call

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

### Supported CCBS Phase

This parameter indicates by its presence that CCBS is supported and the phase of CCBS which is supported.

### Additional Signal Info

See 3GPP TS 23.081 [27] for the conditions for the presence of the components of this parameter.

### **IST Support Indicator**

This parameter is used to indicate to the HLR that the GMSC supports basic IST functionality, that is, the GMSC is able to terminate the subscriber call activity that originated the IST Alert when it receives the IST Alert response indicating that the call(s) shall be terminated. If this parameter is not included in the Send Routing Information indication and the subscriber is marked as an IST subscriber, then the HLR may limit the service for the call (by barring the incoming call if it is not subject to forwarding, or suppressing Call Forwarding from the GMSC), or allow the call assuming the associated risk of not having the basic IST mechanism available.

This parameter can also indicate that the GMSC supports the IST Command, including the ability to terminate all calls being carried for the identified subscriber by using the IMSI as a key. If this additional capability is not included in the Send Routing Information indication and the subscriber is marked as an IST subscriber, then the HLR may limit the service for the subscriber (by barring the incoming calls if they are not subject to forwarding, or suppressing Call Forwarding from the GMSC), or allow the incoming calls assuming the associated risk of not having the IST Command mechanism available.

### Pre-paging supported

See 3GPP TS 23.018 for the use of this parameter and the conditions for its presence.

### Call Diversion Treatment Indicator

This parameter indicates whether or not call diversion is allowed.

## Network Signal Info 2

See 3GPP TS 23.172 [126] for the conditions for the presence of the components of this parameter.

# MT Roaming Retry Supported

See 3GPP TS 23.018 [97] and 3GPP TS 23.012 [23] for the use of this parameter and the conditions for its presence.

# **IMSI**

See 3GPP TS 23.018 [97] and 3GPP TS 23.066 [108] for the use of this parameter and the conditions for its presence.

#### **MSRN**

See 3GPP TS 23.018 [97], 3GPP TS 23.066 [108] and 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence. If the NPLR returns only the MSISDN-number without Routeing Number to the GMSC, the MSISDN-number shall be returned as MSRN.

# Forwarding Data

This parameter includes a number to define the forwarded-to destination, the forwarding reason and the forwarding options Notification to calling party and Redirecting presentation, and can include the forwarded-to subaddress. See 3GPP TS 23.018 [97] and 3GPP TS 23.079 [99] for the conditions for the presence of its components.

### Forwarding Interrogation Required

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

### Long FTN Supported

This parameter indicates that the GMSC supports Long Forwarded-to Numbers.

### Suppress VT-CSI

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

### Suppress Incoming Call Barring

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

### gsmSCF Initiated Call

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

### **SuppressMTSS**

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

### VMSC address

See 3GPP TS 23.079 [99] and 3GPP TS 23.078 [98] for the use of this parameter and the conditions for its presence. In addition this parameter shall be present if the ReleaseResourcesSupported parameter is present.

# Release Resources Supported

This parameter indicates by its presence that the MAP\_RELEASE\_RESOURCES service is supported at the VMSC. It shall be present if so indicated by the VMSC with MAP\_PROVIDE\_ROAMING\_NUMBER confirm.

### **GMSC CAMEL Subscription Info**

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

# **Location Information**

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

### Subscriber State

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

### **CUG Subscription Flag**

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

# North American Equal Access preferred Carrier Id

This parameter is returned to indicate the preferred carrier identity to be used to set-up the call (i.e. forwarding the call or establishing the roaming leg).

# SS-List

This parameter includes SS-codes and will be returned as an operator option. The HLR shall not send PLMN-specific SS-codes across PLMN boundaries. However if the GMSC receives PLMN-specific SS-codes from a foreign PLMN's HLR the GMSC may ignore it. If the GMSC attempts to process the PLMN- specific SS- codes, this may lead to unpredictable behaviour but the GMSC shall continue call processing.

### **Basic Service Code**

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

If the CAMEL service is not involved, this parameter includes the basic service code and will be returned as an operator option. The HLR shall not send a PLMN-specific Basic Service Code across PLMN boundaries. However if the GMSC receives a PLMN-specific Basic Service Code from a foreign PLMN's HLR the GMSC may ignore it. If the GMSC attempts to process the PLMN specific Basic Service codes, this may lead to unpredictable behaviour but the GMSC shall continue call processing.

### **CCBS Target**

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

### Keep CCBS Call Indicator

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

### **IST Alert Timer**

It includes the IST Alert timer value that must be used to inform the HLR about the call activities that the subscriber performs. This parameter is only sent to the GMSC in response to a Send Routing Information request which indicates the the GMSC supports IST.

# **Number Portability Status**

This parameter indicates the number portability status of the subscriber. This parameter may be present if the sender of SRIack is NPLR.

### Supported CAMEL Phases in VMSC

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

### Offered CAMEL 4 CSIs in VMSC

This parameter is defined in clause 7.6.3.36F.

### MSRN 2

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.172 [126].

### Forwarding Data 2

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.172 [126].

### SS-List 2

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.172 [126].

# Basic Service Code 2

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.172 [126].

### Allowed Services

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.172 [126].

# **Unavailability Cause**

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.172 [126].

### User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Unknown Subscriber;

The diagnostic for the Unknown Subscriber error may indicate 'NPDB Mismatch'.

- Number changed:
- Call Barred;

This error will indicate that either incoming calls are barred for this MS or that calls are barred due to Operator Determined Barring (see 3GPP TS 22.041 [8] for a definition of this network feature);

- CUG Reject;

The value of this error cause will indicate the reason for CUG Reject;

- Bearer Service Not Provisioned:
- Teleservice Not Provisioned;

A subscription check has been performed and the call has not passed the check due to incompatibility with regard to the requested service. Depending on the nature of the incompatibility, either of these messages will be returned:

- Facility Not Supported;
- Absent Subscriber;

This indicates that the location of the MS is not known (either the station is not registered and there is no location information available or the Provide Roaming Number procedure fails due to IMSI detached flag being set), or the GMSC requested forwarding information with a forwarding reason of not reachable, and the call forwarding on MS not reachable service is not active;

- Busy Subscriber;

This indicates that Call Forwarding on Busy was not active for the specified basic service group when the GMSC requested forwarding information with a forwarding reason of busy;

The error may also indicate that the subscriber is busy due to an outstanding CCBS recall. In the error data it may then be specified that CCBS is possible for the busy encountered call;

No Subscriber Reply;

This indicates that Call Forwarding on No Reply was not active for the specified basic service group when the GMSC requested forwarding information with a forwarding reason of no reply;

- OR Not Allowed:

This indicates that the HLR is not prepared to accept an OR interrogation from the GMSC, or that calls to the specified subscriber are not allowed to be optimally routed;

- Forwarding Violation;
- System Failure;
- Data Missing;
- Unexpected Data Value.

See clause 7.6 for a definition of these errors.

### Provider error

These are defined in clause 7.6.

# **GSM** Bearer Capability

This information is passed according to the rules specified in 3GPP TS 29.007 [56]. There may be two GSM Bearer Capabilities supplied.

# 10.2 MAP\_PROVIDE\_ROAMING\_NUMBER service

# 10.2.1 Definition

This service is used between the HLR and VLR. The service is invoked by the HLR to request a VLR to send back a roaming number to enable the HLR to instruct the GMSC to route an incoming call to the called MS.

This is a confirmed service which uses the primitives described in table 10.2/1.

# 10.2.2 Service primitives

Table 10.2/1: MAP\_PROVIDE\_ROAMING\_NUMBER parameters

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
MSC Number	M	M(=)		
MSISDN	U	C(=)		
LMSI	С	C(=)		
GSM Bearer Capability	С	C(=)		
Network Signal Info	С	C(=)		
Suppression Of Announcement	С	C(=)		
Call Reference Number	С	C(=)		
GMSC Address	С	C(=)		
OR Interrogation	С	C(=)		
OR Not Supported in GMSC	С	C(=)		
Alerting Pattern	С	C(=)		
CCBS Call	С	C(=)		
Supported CAMEL Phases in	С	C(=)		
interrogating node				
Additional Signal Info	С	C(=)		
Pre-paging supported	С	C(=)		
Long FTN Supported	С	C(=)		
Suppress VT-CSI	С	C(=)		
Offered CAMEL 4 CSIs in	С	C(=)		
interrogating node				
MT Roaming Retry Supported	U	C(=)		
Roaming Number			С	C(=)
ReleaseResourcesSupported			U	C(=)
User error			С	C(=)
Provider error				0

# 10.2.3 Parameter use

See clause 7.6 for a definition of the parameters used, in addition to the following. Note that:

- a conditional parameter whose use is defined only in 3GPP TS 23.078 [98] shall be absent if the sending entity does not support CAMEL;
- a conditional parameter whose use is defined only in 3GPP TS 23.079 [99] shall be absent if the sending entity does not support optimal routeing;
- a conditional parameter whose use is defined only in 3GPP TS 23.078 [98] & 3GPP TS 23.079 [99] shall be absent if the sending entity supports neither CAMEL nor optimal routeing.

# <u>IMSI</u>

This is the IMSI of the called Subscriber.

### MSC Number

This is the ISDN number assigned to the MSC currently serving the MS. The MSC number will have been stored in the HLR as provided at location updating.

#### <u>MSISDN</u>

See 3GPP TS 23.018 [97] for the use of this parameter and the conditions for its presence.

### **LMSI**

See 3GPP TS 23.018 [97] for the use of this parameter and the conditions for its presence.

# **GSM** Bearer Capability

See 3GPP TS 23.018 [97] for the use of this parameter and the conditions for its presence.

This information is passed according to the rules specified in TS 3GPP TS 29.007 [56].

There may be two GSM Bearer Capabilities supplied.

### Network Signal Info

See 3GPP TS 23.018 [97] for the conditions for the presence of the components of this parameter.

### **Suppression Of Announcement**

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078 [98].

### Call Reference Number

The use of this parameter and the conditions for its presence are specified in 3GPP TS 23.078 [98] and 3GPP TS 23.079 [99].

### **GMSC Address**

The use of this parameter and the conditions for its presence are specified in 3GPP TS 23.078 [98] and 3GPP TS 23.079 [99].

### **OR** Interrogation

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

# OR Not Supported in GMSC

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

# Supported CAMEL Phases in interrogating node

This parameter is defined in clause 7.6.3.36I. Alerting Pattern

See 3GPP TS 23.078 [98] for the use of this parameter and the conditions for its presence.

### CCBS Call

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

### Additional Signal Info

See 3GPP TS 23.081 [27] for the conditions for the presence of the components of this parameter.

# Pre-paging supported

See 3GPP TS 23.018 for the use of this parameter and the conditions for its presence.

### Long FTN supported

See 3GPP TS 23.082 for the use of this parameter and the conditions for its presence.

# Suppress VT-CSI

See 3GPP TS 23.078 for the use of this parameter and the conditions for its presence.

# Offered CAMEL 4 CSIs in interrogating node

This parameter is defined in clause 7.6.3.36E.

# MT Roaming Retry Supported

See 3GPP TS 23.018 [97] and 3GPP TS 23.012 [23] for the use of this parameter and the conditions for its presence.

# Roaming Number

See 3GPP TS 23.018 [97] for the use of this parameter and the conditions for its presence.

# ReleaseResourcesSupported

This parameter indicates by its presence that the MAP\_RELEASE\_RESOURCES service is supported at the VMSC.

### User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Absent Subscriber;

This error will be returned if the IMSI detach flag is set.

- No Roaming Number Available;
- OR Not Allowed;

This indicates that the MAP\_PROVIDE\_ROAMING\_NUMBER indication included the OR interrogation indicator, but the VLR does not support optimal routeing.

- Facility Not Supported;
- System Failure;
- Data Missing;
- Unexpected Data Value.

See clause 7.6 for a definition of these reasons.

### Provider error

These are defined in clause 7.6.

# 10.3 MAP\_RESUME\_CALL\_HANDLING service

# 10.3.1 Definition

This service is used between the terminating VMSC and the GMSC. The service is invoked by the terminating VMSC to request the GMSC to resume handling the call and forward it to the specified destination.

This is a confirmed service which uses the Primitives listed in table 10.3/1.

# 10.3.2 Service primitives

Table 10.3/1: MAP\_RESUME\_CALL\_HANDLING parameters

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Call Reference Number	С	C(=)		
Basic Service Group	С	C(=)		
Basic Service Group 2	С	C(=)		
IMSI	С	C(=)		
Forwarding Data	С	C(=)		
CUG Interlock	С	C(=)		
CUG Outgoing Access	С	C(=)		
O-CSI	С	C(=)		
D-CSI	С	C(=)		
CCBS Target	С	C(=)		
UU Data	С	C(=)		
UUS CF Interaction	С	C(=)		
All Information Sent	С	C(=)		
MSISDN	С	C(=)		
MT Roaming Retry	U	C(=)		
User error			С	C(=)

Provider error		0

# 10.3.3 Parameter use

Information received in subsequent segment of a segmented dialogue shall not overwrite information received in an earlier segment.

See clause 7.6 for a definition of the parameters used, in addition to the following.

### Call Reference Number

See 3GPP TS 23.079 [99] for the use of this parameter. This parameter shall be present in the first segment of the dialogue.

# **Basic Service Group**

See 3GPP TS 23.079 [99] for the use of this parameter. This parameter shall be present in the first segment of the dialogue.

### Basic Service Group 2

See 3GPP TS 23.079[99] for the use of this parameter. If this parameter is present, it shall be in the first segment of the dialogue.

### **IMSI**

This is the IMSI of the forwarding Subscriber. This parameter shall be present in the first segment of the dialogue.

# Forwarding Data

This parameter includes a number to define the forwarded-to destination, the forwarding reason and the forwarding options Notification to calling party and Redirecting presentation, and can include the forwarded-to subaddress. See 3GPP TS 23.079 [99] for the conditions for the presence of its components. This parameter shall be present in a first segment of the dialogue.

# CUG Interlock

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

### **CUG Outgoing Access**

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

# O-CSI

See 3GPP TS 23.078 for the use of this parameter and the conditions for its presence.

For CAMEL phases 1 & 2, the O-CSI shall contain only one set of O-BCSM TDP data.

### D-CSI

The Dialled Services-CSI.

See 3GPP TS 23.078 for the use of this parameter and the conditions for its presence.

### **CCBS Target**

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

#### UU Data

See 3GPP TS 23.087 for the use of this parameter and the conditions for its presence.

### **UUS CF Interaction**

See 3GPP TS 23.087 for the use of this parameter and the conditions for its presence.

### **All Information Sent**

This parameter is set when the VMSC has sent all information to GMSC.

# MT Roaming Retry

See 3GPP TS 23.018 [97], 3GPP TS 23.012 [23] and 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence. When this parameter is present, only the Call Reference Number and All Information Sent IEs shall be present; the other IEs shall be ignored by the GMSC if received.

### **MSISDN**

This parameter is the basic MSISDN of the forwarding subscriber. It shall be present if the VMSC supports determination of the redirecting number.

### User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Optimal Routeing not allowed;
- Forwarding failed;
- Unexpected Data Value;
- Data Missing.

### Provider error

These are defined in clause 7.6.

# 10.4 MAP\_PREPARE\_GROUP\_CALL service

# 10.4.1 Definition

This service is used by the Anchor\_MSC to inform the Relay\_MSC about a group call set-up.

The MAP\_PREPARE\_GROUP\_CALL service is a confirmed service using the service primitives given in table 10.4/1.

# 10.4.2 Service primitives

Table 10.4/1: MAP\_PREPARE\_GROUP\_CALL service

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Teleservice	М	M(=)		
ASCI Call Reference	М	M(=)		
Ciphering Algorithm	М	M(=)		
Group Key Number VK-Id	С	C(=)		
VSTK Key	С	C(=)		
VSTK-RAND	С	C(=)		
Priority	С	C(=)		
CODEC-Information	М	M(=)		
Uplink Free Indicator	М	M(=)		
Group Call Number			M	M(=)
User Error			С	C(=)
Provider Error				0

# 10.4.3 Parameter definitions and use

### Invoke Id

See definition in clause 7.6.1.

### <u>Teleservice</u>

Voice Broadcast Service or Voice Group Call Service.

### **ASCI Call Reference**

Broadcast call reference or group call reference. This item is used to access the VBS-GCR or VGCS-GCR within the Relay MSC.

## Ciphering Algorithm

The ciphering algorithm to be used for the group call.

### Group Key Number VK-Id

This Group Key Number has to be broadcast and is used by the mobile station to derive the key for ciphering on the radio interface (see 3GPP TS 43.020 [24]). Values 2 to 15 are reserved for future use.

Shall be present if the ciphering applies.

### **VSTK**

The VGCS/VBS Short Term Key is used to derive the key for ciphering on the radio interface (see 3GPP TS 43.020 [24]).

Shall be present if the ciphering applies.

## **VSTK-RAND**

This random number has to be broadcast and is used by the mobile station to derive the group key for ciphering on the radio interface (see 3GPP TS 43.020 [24]).

Shall be present if the ciphering applies.

### **Priority**

Default priority level related to the call if eMLPP applies.

# **CODEC-Information**

Information on the codecs allowed for this call.

# **Uplink Free Indicator**

A flag indicating whether the call is initiated from a dispatcher.

### Group Call Number

This temporary allocated E.164 number is used for routing the call from the Anchor MSC to the Relay MSC.

### **User Error**

For definition of this parameter see clause 7.6.1 The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- No Group Call Number available;
- System Failure;
- Unexpected Data Value.

### Provider Error

See definition of provider error in clause 7.6.1.

# 10.5 MAP PROCESS GROUP CALL SIGNALLING service

# 10.5.1 Definitions

This service is used between Relay MSC and Anchor MSC for transmission of Group Call notifications.

The MAP\_PROCESS\_GROUP\_CALL\_SIGNALLING service is a non-confirmed service using the service primitives given in table 10.5/1.

# 10.5.2 Service primitives

Table 10.5/1: MAP\_PROCESS\_GROUP\_CALL\_SIGNALLING service

Parameter name	Request	Indication
Invoke Id	M	M(=)
Uplink Request	С	C(=)
Uplink Release Indication	С	C(=)
Release Group Call	С	C(=)
Talker Priority	С	C(=)
Additional Info	С	C(=)
Emergency Mode Reset Command Flag	С	C(=)

# 10.5.3 Parameter definitions and use

### Invoke Id

See definition in clause 7.6.1

# <u>Uplink Request</u>

This information element indicates to the anchor MSC that a service subscriber roaming in the relay MSC area requests access to the uplink.

# **Uplink Release Indication**

This information element if included by the Relay MSC indicates to the Anchor MSC that the uplink has become free.

# Release Group Call

This information element if included by the Relay MSC indicates to the Anchor MSC that the service subscriber who has initiated the call and who currently has access to the uplink terminates the call.

### **Talker Priority**

For the definition and use of this parameter see 3GPP TS 43.068 [100]

# Additional Info

For the definition and use of this parameter see 3GPP TS 43.068 [100]

### **Emergency Mode Reset Command Flag**

For the definition and use of this parameter see 3GPP TS 43.068 [100]

# 10.6 MAP\_FORWARD\_GROUP\_CALL\_SIGNALLING service

### 10.6.1 Definitions

This service is used between Anchor MSC and Relay MSC for transmission of Group Call notifications.

The MAP\_FORWARD\_GROUP\_CALL\_SIGNALLING service is a non-confirmed service using the service primitives given in table 10.6/1.

# 10.6.2 Service primitives

Table 10.6/1: MAP\_FORWARD\_GROUP\_CALL\_SIGNALLING service

Parameter name	Request	Indication
Invoke Id	М	M(=)
IMSI	С	C(=)
Uplink Request	С	C(=)
Acknowledgement		
Uplink Release Indication	С	C(=)
Uplink Reject Command	С	C(=)
Uplink Seized Command	С	C(=)
Uplink Release Command	С	C(=)
State Attributes	С	C(=)
Talker Priority	С	C(=)
Additional Info	С	C(=)
Emergency Mode Reset	С	C(=)
Command Flag		
SM RP UI	С	C(=)

# 10.6.3 Parameter definitions and use

### **IMSI**

Identity of the service subscriber who has established the call and who is allowed to terminate the call.

#### Invoke Id

See definition in clause 7.6.1.

### **Uplink Request Acknowledgement**

This information element is used for positive acknowledgement of an uplink request.

#### Uplink Release Indication

This information element if included by the Anchor MSC indicates to the Relay MSC that the uplink has become free.

### **Uplink Reject Command**

This information element is used for negative acknowledgement of an uplink request.

#### **Uplink Seized Command**

This information element if included by the Anchor MSC indicates to the Relay MSC that the uplink is no longer free.

#### Uplink Release Command

This information element if included by the Anchor MSC indicates to the Relay MSC that the uplink which is granted to a MS in the relay MSC area shall be released.

#### State Attributes

This information element is used to allow service logic running in an Anchor MSC to mute a VGCS talker even when the talker is served on a Relay MSC. The IE is used to build a GCC message that provides a mechanism to induce the VGCS talker terminal to mute/unmute the downlink at the Anchor MSC, as defined in 3GPP TS 44.068.

#### **Talker Priority**

For the definition and use of this parameter see 3GPP TS 43.068 [100]

#### Additional Info

For the definition and use of this parameter see 3GPP TS 43.068 [100]

### **Emergency Mode Reset Command Flag**

For the definition and use of this parameter see 3GPP TS 43.068 [100]

#### SM RP UI

See definition in clause 7.6.8. The short message transfer protocol data unit received from the Service Centre is inserted in this parameter.

# 10.7 MAP\_SEND\_GROUP\_CALL\_END\_SIGNAL service

### 10.7.1 Definitions

This service is used between the Relay MSC and the Anchor MSC. When the VGCS/ VBS calling service subscriber is in the Relay MSC area the MAP\_SEND\_GROUP\_CALL\_END\_SIGNAL indicates that at least the downlink channel in the originating cell is established. For all other VGCS/ VBS call set-up scenarios (i.e. calling service subscriber in Anchor MSC area, calling service subscriber in other Relay MSC area, dispatcher originated call) the MAP\_SEND\_GROUP\_CALL\_END\_SIGNAL indicates that at least the downlink channel in any one cell within the VGCS/ VBS call area in the Relay MSC is established. The response is used by the Anchor MSC to inform the Relay MSC that all resources for the call can be released in the Relay MSC because the call has been released in the Anchor MSC.

The MAP\_SEND\_GROUP\_CALL\_END\_SIGNAL service is a confirmed service using the service primitives given in table 10.7/1.

# 10.7.2 Service primitives

Table 10.7/1: MAP\_SEND\_GROUP\_CALL\_END\_SIGNAL service

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	С	C(=)		
Talker Priority	С	C(=)		
Additional Info	С	C(=)		
Provider Error				0

#### 10.7.3 Parameter definitions and use

#### Invoke Id

See definition in clause 7.6.1

### IMSI

Identity of the service subscriber who has established the call and who is allowed to terminate the call.

Shall be present if the call was established by a service subscriber roaming in the relay MSC area.

#### **Talker Priority**

For the definition and use of this parameter see 3GPP TS 43.068 [100]

#### Additional Info

For the definition and use of this parameter see 3GPP TS 43.068 [100]

#### Provider Error

See definition of provider error in clause 7.6.1.

# 10.7A MAP\_SEND\_GROUP\_CALL\_INFO service

# 10.7A.1 Definitions

This service is used in a RANflex configuration (see 3GPP TS 23.236 [133]) between the subscriber's visited MSC and group call serving MSC of the subscriber's location area.

The MAP\_SEND\_GROUP\_CALL\_INFO service is a confirmed service using the service primitives given in table 10.7A/1.

# 10.7A.2 Service primitives

Table 10.7A/1: MAP\_SEND\_GROUP\_CALL\_INFO service

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Requested Info	M	M(=)		
Teleservice	M	M(=)		
Cell Id	С	C(=)		
Group Id	M	M(=)		
IMSI	С	C(=)	С	C(=)
Talker Priority	С	C(=)		
Additional Info	С	C(=)	С	C(=)
TMSI	С	C(=)		
CKSN	С	C(=)		
Anchor MSC Address			С	C(=)
ASCI Call Reference			С	C(=)
Additional Subscriptions			С	C(=)
Kc			С	C(=)
User Error			С	C(=)
Provider Error				0

# 10.7A.3 Parameter definitions and use

#### Invoke Id

See definition in clause 7.6.1

### Requested Info

For the definition and use of this parameter see 3GPP TS 43.068 [100]

#### **Teleservice**

Voice Broadcast Service or Voice Group Call Service.

### Cell Id

Identity of the initiating service subscriber's current cell.

#### Group Id

For the definition and use of this parameter see 3GPP TS 43.068 [100] and 3GPP TS 43.069 [101]

#### **IMSI**

If sent in the request: Identity of the service subscriber who has established the call and who is allowed to terminate the call.

If sent in the response: Identity of the uplink requesting service subscriber.

#### **Talker Priority**

For the definition and use of this parameter see 3GPP TS 43.068 [100]

#### Additional Info

For the definition and use of this parameter see 3GPP TS 43.068 [100]

#### **TMSI**

See definition in clause 7.6.2.

#### **CKSN**

See clause 7.6.7 for the use of this parameter.

#### Anchor MSC Address

For the definition and use of this parameter see 3GPP TS 43.068 [100] and 3GPP TS 43.069 [101]

#### **ASCI Call Reference**

For the definition and use of this parameter see 3GPP TS 43.068 [100] and 3GPP TS 43.069 [101]

#### **Additional Subscriptions**

For the definition and use of this parameter see 3GPP TS 43.068 [100]

#### Kc

See clause 7.6.7 for the use of this parameter.

#### User Error

For definition of this parameter see clause 7.6.1 The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- System Failure;
- Unexpected Data Value;
- Data Missing
- TeleserviceNotProvisioned:
- Unknown Subscriber;
- Ongoing Call.

#### Provider Error

See definition of provider error in clause 7.6.1.

# 10.8 Void

# 10.9 Void

# 10.10 MAP\_SET\_REPORTING\_STATE service

### 10.10.1 Definition

This service is used between the HLR and the VLR to set the reporting state for a requested service. It is a confirmed service using the service primitives shown in table 10.10/1.

# 10.10.2 Service primitives

Table 10.10/1: MAP\_SET\_REPORTING\_STATE parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	М	M(=)	M(=)	M(=)
IMSI	С	C(=)		
LMSI	С	C(=)		
CCBS Monitoring	С	C(=)		
CCBS Subscriber Status			С	C(=)
User error			С	C(=)
Provider error				0

# 10.10.3 Parameter use

See clause 7.6 for a definition of the parameters used, in addition to the following.

#### **IMSI**

The IMSI is a mandatory parameter if the service is used as the only one in a dialogue.

### **CCBS Monitoring**

This parameter indicates whether monitoring for CCBS shall be started or stopped. If it indicates that monitoring shall be started this service corresponds to the message 'Start Reporting' in 3GPP TS 23.093 [107]; if it indicates that monitoring shall be stopped this service corresponds to the message 'Stop Reporting' in 3GPP TS 23.093 [107].

#### **CCBS Subscriber Status**

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

### <u>User error</u>

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- System Failure;
- Unidentified Subscriber;
- Unexpected Data Value;
- Data Missing;
- Resource Limitation;
- Facility Not Supported.

NOTE: This error is reserved for future use.

#### Provider error

These are defined in clause 7.6.

# 10.11 MAP\_STATUS\_REPORT service

# 10.11.1 Definition

This service is used by the VLR to report an event or call outcome to the HLR. It is a confirmed service using the service primitives shown in table 10.11/1.

# 10.11.2 Service primitives

Table 10.11/1: MAP\_STATUS\_REPORT parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	М	M(=)	M(=)	M(=)
IMSI	М	M(=)		
CCBS Subscriber Status	С	C(=)		
Monitoring Mode	С	C(=)		
Call Outcome	С	C(=)		
User error			С	C(=)
Provider error				0

### 10.11.3 Parameter use

See clause 7.6 for a definition of the parameters used, in addition to the following.

#### **CCBS Subscriber Status**

If this parameter is present without Monitoring Mode and Call Outcome this service corresponds to the message 'Event Report' in 3GPP TS 23.093 [107]. See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

# **Monitoring Mode**

If this parameter is present with CCBS Call Outcome this service corresponds to the message 'CCBS Call Report' in 3GPP TS 23.093 [107]. See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

### Call Outcome

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

#### User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- Unknown Subscriber;
- System Failure;
- Unexpected Data Value;
- Data Missing.

#### Provider error

These are defined in clause 7.6.

# 10.12 MAP REMOTE USER FREE service

# 10.12.1 Definition

This service is used between the HLR and the VLR to report that the B subscriber is now idle and that the A subscriber can be notified. It is a confirmed service using the service primitives shown in table 10.12/1.

# 10.12.2 Service primitives

Table 10.12/1: MAP\_REMOTE\_USER\_FREE parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	М	M(=)	M(=)	M(=)
IMSI	M	M(=)		
Call Info	M	M(=)		
CCBS Feature	M	M(=)		
Translated B Number	M	M(=)		
Replace B Number	С	C(=)		
Alerting Pattern	С	C(=)		
RUF Outcome			С	C(=)
User error			С	C(=)
Provider error				0

# 10.12.3 Parameter use

See clause 7.6 for a definition of the parameters used, in addition to the following.

#### Call Info

See 3GPP TS 23.093 [107] for the use of this parameter.

#### **CCBS** Feature

See 3GPP TS 23.093 [107] for the conditions for the presence of the parameters included in the CCBS feature.

#### Translated B Number

See 3GPP TS 23.093 [107] for the use of this parameter.

#### Replace B Number

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

#### **Alerting Pattern**

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

#### **RUF Outcome**

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

#### User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- Unexpected Data Value;
- Data Missing;
- Incompatible Terminal;

- This error is returned by the responder when the terminal used for CCBS activation is not compatible with the terminal used for the CCBS recall. For details refer to 3GPP TS 24.008 [35];
- Absent Subscriber (IMSI Detach; Restricted Area; No Page Response);
- System Failure;
- Busy Subscriber (CCBS Busy).

#### Provider error

These are defined in clause 7.6.

# 10.13 MAP\_IST\_ALERT service

#### 10.13.1 Definition

This service is used between the MSC (Visited MSC or Gateway MSC) and the HLR, to report that the IST timer running for a call for the Subscriber has expired. It is a confirmed service using the service primitives shown in table 10.13/1.

# 10.13.2 Service primitives

Table 10.13/1: MAP\_IST\_ALERT parameters

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	М	M(=)		
IST Alert Timer			С	C(=)
IST Information Withdraw			С	C(=)
Call termination Indicator			С	C(=)
User error			С	C(=)
Provider error				Ö

### 10.13.3 Parameter use

All parameters are described in clause 7.6. The following clarifications are applicable:

#### **IST Alert Timer**

If included in the IST Alert response, it includes the new IST Alert timer value that must be used to inform the HLR about the call activities that the subscriber performs.

#### **IST Information Withdraw**

If included in the IST Alert response, this parameter is used to indicate that the IST condition has been removed for the subscriber. When the MSC receives this parameter, IST control for that call shall be terminated.

#### Call termination Indicator

If included in the IST Alert response, this parameter is used to indicate whether the MSC shall terminate the call activity that had previously triggered the IST Alert procedure, or it shall also release all other call activities for the specified subscriber (outgoing call activities if the IST Alert is initiated by the VMSC, or incoming call activities if the IST Alert is initiated by the GMSC). Release of all other call activities is possible only if the MSC has the capability to link the call activities for the Subscriber by using the IMSI as key.

#### User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- System Failure;

- Unexpected Data Value;
- Resource Limitation;
- Facility Not Supported;
- Unknown Subscriber.

# 10.14 MAP IST COMMAND service

# 10.14.1 Definition

This service is used by the HLR to instruct the MSC (Visited MSC or Gateway MSC) to terminate ongoing call activities for a specific subscriber. It is a confirmed service using the service primitives shown in table 10.14/1.

# 10.14.2 Service primitives

Table 10.14/1: MAP\_IST\_COMMAND parameters

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
User error			С	C(=)
Provider error				0

# 10.14.3 Parameter use

All parameters are described in clause 7.6. The following clarifications are applicable:

#### <u>User error</u>

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- System Failure;
- Unexpected Data Value;
- Resource Limitation;
- Facility Not Supported;
- Unknown Subscriber.

# 10.15 MAP\_RELEASE\_RESOURCES service

### 10.15.1 Definition

This service is used between the GMSC and the terminating VMSC. The service is invoked by the GMSC to request the VMSC to release the resources associated with the specified MSRN.

This is a confirmed service which uses the Primitives listed in table 10.15/1.

# 10.15.2 Service primitives

Table 10.15/1: MAP\_RELEASE\_RESOURCES parameters

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
MSRN	M	M(=)		

User error		С	C(=)
Provider error			0

# 10.15.3 Parameter use

#### **MSRN**

See 3GPP TS 23.018 [97] for the use of this parameter.

#### User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- System Failure;
- Unexpected Data Value;

#### Provider error

These are defined in clause 7.6.

# 11 Supplementary services related services

# 11.1 MAP\_REGISTER\_SS service

# 11.1.1 Definition

This service is used between the MSC and the VLR and between the VLR and the HLR to register data related to a supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and uses the service primitives shown in table 11.1./1.

# 11.1.2 Service primitives

Table 11.1/1: MAP\_REGISTER\_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
Basic service	С	C(=)		
Forwarded-to number with subaddress	С	C(=)		
No reply condition time	С	C(=)		
EMLPP default priority	С	C(=)	С	C(=)
Long FTN Supported	С	C(=)		
NbrUser	С	C(=)	С	C(=)
Forwarding information			С	C(=)
User error			С	C(=)
Provider error				0

# 11.1.3 Parameter use

#### Invoke id

See clause 7.6.1 for the use of this parameter.

#### SS-Code

This parameter indicates the supplementary service which the mobile subscriber wants to register.

#### Basic service

This parameter indicates for which basic service group the supplementary service is to be registered. If it is not included, the registration request applies to all basic services.

#### Forwarded-to number with subaddress

This parameter is obligatory if the registration applies to one or more call forwarding supplementary services. It can optionally include a sub-address.

#### No reply condition time

This parameter is included if the registration applies to the Call Forwarding on No Reply supplementary service (or a superset of this service) and the mobile subscriber supplies a value for this time.

#### EMLPP default priority

This parameter is sent by the initiator to register the eMLPP default priority level and is returned by the responder at successful outcome of the service.

#### Long FTN Supported

This parameter indicates that the mobile station supports Long Forwarded-to Numbers.

#### NbrUser

This parameter is sent by the initiator to register the MC maximum number of user defined circuit switched bearers to be used.

#### Forwarding information

This parameter is returned by the responder at successful outcome of the service, if the registration request concerned one or a group of Call Forwarding supplementary services.

### User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- System failure;
- Data missing;
- Unexpected data value;
- Call Barred;
- Bearer service not provisioned;
- This error is returned only if not even a subset of the requested bearer service group has been subscribed to;
- Teleservice not provisioned;

This error is returned only if not even a subset of the requested teleservice group has been subscribed to;

- Illegal SS operation;
- SS error status;
- SS incompatibility.

#### Provider error

See clause 7.6.1 for the use of this parameter.

# 11.2 MAP\_ERASE\_SS service

# 11.2.1 Definition

This service is used between the MSC and the VLR and between the VLR and the HLR to erase data related to a supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and uses the service primitives shown in table 11.2/1.

# 11.2.2 Service primitives

Table 11.2/1: MAP\_ERASE\_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
Basic service	С	C(=)		
Forwarding information			С	C(=)
User error			С	C(=)
Provider error				0

# 11.2.3 Parameter use

#### Invoke id

See clause 7.6.1 for the use of this parameter.

#### SS-Code

This parameter indicates the supplementary service which the mobile subscriber wants to erase.

# Basic service

This parameter indicates for which basic service group the supplementary service should be erased. If it is not included, the erasure request applies to all basic services.

### Forwarding information

This parameter is returned by the responder at successful outcome of the service, if the erasure request concerned one or a group of Call Forwarding supplementary services.

### <u>User error</u>

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in clause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Bearer service not provisioned;

This error is returned only if not even a subset of the requested bearer service group has been subscribed to;

Teleservice not provisioned;

This error is returned only if not even a subset of the requested teleservice group has been subscribed to;

- Call Barred;
- Illegal SS operation;

SS error status.

#### Provider error

See clause 7.6.1 for the use of this parameter.

# 11.3 MAP ACTIVATE SS service

### 11.3.1 Definition

This service is used between the MSC and the VLR and between the VLR and the HLR to activate a supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and uses the service primitives shown in table 11.3/1.

# 11.3.2 Service primitives

Table 11.3/1: MAP\_ACTIVATE\_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
Long FTN Supported	С	C(=)		
Basic service	С	C(=)		
Forwarding information			С	C(=)
Call barring information			С	C(=)
SS-Data			С	C(=)
User error			С	C(=)
Provider error				0

# 11.3.3 Parameter use

#### Invoke id

See clause 7.6.1 for the use of this parameter.

#### SS-Code

This parameter indicates the supplementary service which the mobile subscriber wants to activate.

### Basic service

This parameter indicates for which basic service groups the requested supplementary service(s) should be activated. If it is not included, the activation request applies to all basic services.

### Forwarding information

This parameter is returned by the responder at successful outcome of the service, if the activation request concerned Call Forwarding.

### Long FTN Supported

This parameter indicates that the mobile station supports Long Forwarded-to Numbers.

#### Call barring information

This parameter is returned by the responder at successful outcome of the service, if the activation request concerned Call Barring.

#### SS-Data

This parameter is returned by the responder at successful outcome of the service, if the activation request concerned for example Call Waiting.

#### User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in clause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Bearer service not provisioned;
- This error is returned only if not even a subset of the requested bearer service group has been subscribed to.
- Teleservice not provisioned;
- This error is returned only if not even a subset of the requested teleservice group has been subscribed to.
- Call Barred;
- Illegal SS operation;
- SS error status;
- SS subscription violation;
- SS incompatibility;
- Negative PW check;
- Number Of PW Attempts Violation.

#### Provider error

See clause 7.6.1 for the use of this parameter.

# 11.4 MAP DEACTIVATE SS service

### 11.4.1 Definitions

This service is used between the MSC and the VLR and between the VLR and the HLR to deactivate a supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and uses the service primitives shown in table 11.4/1.

# 11.4.2 Service primitives

Table 11.4/1: MAP\_DEACTIVATE\_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
Basic service	С	C(=)		
Forwarding information			С	C(=)
Call barring information			С	C(=)
SS-Data			С	C(=)
User error			С	C(=)
Provider error				0

#### 11.4.3 Parameter use

#### Invoke id

See clause 7.6.1 for the use of this parameter.

#### SS-Code

This parameter indicates the supplementary service which the mobile subscriber wants to deactivate.

#### Basic service

This parameter indicates for which basic service group the requested supplementary service(s) should be deactivated. If it is not included the deactivation request applies to all basic services.

#### Forwarding information

This parameter is returned by the responder at successful outcome of the service, if the deactivation request concerned one or a group of Call Forwarding supplementary services.

#### Call barring information

This parameter is returned by the responder at successful outcome of the service, if the activation request concerned one or a group of Call Barring supplementary services.

#### SS-Data

This parameter is returned by the responder at successful outcome of the service, for example if the deactivation request concerned the Call Waiting supplementary service.

#### User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in clause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Bearer service not provisioned;

This error is returned only if not even a subset of the requested bearer service group has been subscribed to;

- Teleservice not provisioned;

This error is returned only if not even a subset of the requested teleservice group has been subscribed to;

- Call Barred:
- Illegal SS operation;
- SS error status;
- SS subscription violation;
- Negative PW check;
- Number Of PW Attempts Violation.

#### Provider error

See clause 7.6.1 for the use of this parameter.

# 11.5 MAP\_INTERROGATE\_SS service

# 11.5.1 Definitions

This service is used between the MSC and the VLR and between the VLR and the HLR to retrieve information related to a supplementary service. The VLR will relay the message to the HLR if necessary.

The service is a confirmed service and consists of four service primitives.

# 11.5.2 Service primitives

The service primitives are shown in table 11.5/1.

Table 11.5/1: MAP\_INTERROGATE\_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
Basic service	С	C(=)		
Long FTN Supported	С	C(=)		
SS-Status			С	C(=)
Basic service Group LIST			С	C(=)
Forwarding feature LIST			С	C(=)
CLI restriction Info			С	C(=)
EMLPP Info			С	C(=)
MC Information			С	C(=)
CCBS Feature LIST			С	C(=)
User error			С	C(=)
Provider error				0

# 11.5.3 Parameter use

For additional information on parameter use refer to the GSM 04.8x and 04.9x-series of technical specifications.

#### Invoke id

See clause 7.6.1 for the use of this parameter.

# SS-Code

The mobile subscriber can only interrogate a single supplementary service per service request.

#### Basic service

This parameter indicates for which basic service group the given supplementary service is interrogated. If it is not included, the interrogation request applies to all basic services.

#### SS-Status

This parameter is included by the responder if:

- the interrogated supplementary service can only be subscribed for all applicable basic services simultaneously; or
- the interrogated supplementary service is not active for any of the interrogated basic services, or
- the interrogation was for the CCBS supplementary service and no CCBS request is active or the service is not provisioned.

#### Basic service group LIST

This parameter LIST is used to include one or a series of basic service groups for which the interrogated supplementary service is active. If the interrogated supplementary service is not active for any of the interrogated (and provisioned) basic service groups, the SS-Status parameter is returned.

#### Long FTN Supported

This parameter indicates that the mobile station supports Long Forwarded-to Numbers.

#### Forwarding feature LIST

The forwarding feature parameter is described in clause 7.6.4. A list of one or more forwarding features is returned by the responder when the interrogation request applied to Call Forwarding supplementary service.

If no basic service code parameter is provided within this sequence, the forwarding feature parameter applies to all provisioned basic services.

#### **CLI** restriction Info

The CLI-RestrictionInfo parameter is returned by the responder when the interrogation request applies to the CLIR supplementary service.

#### **EMLPP Info**

The eMLPP info (maximum entitled priority and default priority) is returned by the responder if the interrogation request applies to the eMLPP supplementary service.

#### MC Information

The MC information (NbrSB, NbrUser and NbrSN) is returned by the responder if the interrogation request applies to the MC supplementary service. For a definition of these 3 components, refer to 3GPP TS 23.135 and 3GPP TS 24.135.

#### **CCBS Feature LIST**

The CCBS feature parameter is described in clause 7.6. A list of one or more CCBS features is returned by the responder when the interrogation request applied to the CCBS supplementary service. See 3GPP TS 23.093 [107] for the conditions for the presence of the parameters included in the CCBS feature.

#### User error

This error is sent by the responder upon unsuccessful outcome of the interrogation service, and then takes one of the following values, defined in clause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Bearer Service not provisioned;

This error is returned only if not even a subset of the interrogated bearer services are provided;

- Teleservice not provisioned;

This error is returned only if not even a subset of the interrogated teleservices are provided;

- Call Barred;
- Illegal SS operation;
- SS not available.

#### Provider error

See clause 7.6.1 for the use of this parameter.

# 11.6 Void

# 11.7 MAP\_REGISTER\_PASSWORD service

# 11.7.1 Definitions

This service is used between the MSC and the VLR and between the VLR and the HLR if the mobile subscriber requests to register a new password. The VLR will relay the message to the HLR.

The service is a confirmed service and consists of four service primitives.

# 11.7.2 Service primitives

The service primitives are shown in table 11.7/1.

Table 11.7/1: MAP\_REGISTER\_PASSWORD parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
New password			С	C(=)
User error			С	C(=)
Provider error				Ö

# 11.7.3 Parameter use

### Invoke id

See clause 7.6.1 for the use of this parameter.

#### SS-Code

This parameter indicates for which supplementary service(s) the password should be registered.

### New Password

See clause 7.6.4 for the use of this parameter.

#### User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in clause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Call Barred;
- SS subscription violation;
- Password registration failure;
- Negative PW check;
- Number Of PW Attempts Violation.

#### Provider error

See clause 7.6.1 for the use of this parameter.

# 11.8 MAP\_GET\_PASSWORD service

### 11.8.1 Definitions

This service is used between the HLR and the VLR and between the VLR and the MSC when the HLR receives a request from the mobile subscriber for an operation on a supplementary service which requires a password from the subscriber. The VLR will relay the message to the MSC.

The service is a confirmed service and uses the service primitives shown in table 11.8/1.

# 11.8.2 Service primitives

Table 11.8/1: MAP\_GET\_PASSWORD parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
Linked id	С	C(=)		
Guidance info	M	M(=)		
Current password			M	M(=)
Provider error				Ö

### 11.8.3 Parameter use

#### Invoke id

See clause 7.6.1 for the use of this parameter.

#### Linked Id

See clause 7.6.1 for the use of this parameter. If the MAP\_GET\_PASSWORD service is used in conjunction with the MAP\_REGISTER\_PASSWORD service, this parameter must be present; otherwise it must be absent.

#### Guidance info

See clause 7.6.4 for the use of this parameter.

#### Current password

See clause 7.6.4 for the use of this parameter.

#### Provider error

See clause 7.6.1 for the use of this parameter.

# 11.9 MAP\_PROCESS\_UNSTRUCTURED\_SS\_REQUEST service

# 11.9.1 Definitions

This service is used between the MSC and the VLR, between the VLR and the HLR, between the HLR and gsmSCF and between the HLR and HLR to relay information in order to allow unstructured supplementary service operation.

The MAP\_PROCESS\_UNSTRUCTURED\_SS\_REQUEST service is a confirmed service using the primitives from table 11.9/1.

# 11.9.2 Service primitives

Table 11.9/1: MAP\_PROCESS\_UNSTRUCTURED\_SS\_REQUEST parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
USSD Data Coding Scheme	M	M(=)	С	C(=)
USSD String	M	M(=)	С	C(=)
MSISDN	С	C(=)		
User error			С	C(=)
Provider error				0

#### 11.9.3 Parameter use

#### Invoke id

See clause 7.6.1 for the use of this parameter.

#### **USSD Data Coding Scheme**

See clause 7.6.4 for the use of this parameter. The presence of the parameter in the response is dependent on the unstructured supplementary service application. If this parameter is present, then the USSD String parameter has to be present.

#### **USSD String**

See clause 7.6.1 for the use of this parameter. The presence of the parameter in the response is dependent on the unstructured supplementary service application. If this parameter is present, then the USSD Data Coding Scheme parameter has to be present.

#### **MSISDN**

The subscriber"s basic MSISDN.

See definition in clause 7.6.2. For Follow Me when the service request is sent from the HLR of the A subscriber, the parameter shall contain the MSISDN of the A subscriber, see 3GPP TS 23.094 [129]. For other purposes the MSISDN may be included as an operator option, e.g. to allow addressing the subscriber"s data in the gsmSCF with the MSISDN.

#### User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- System failure;
- Data missing;
- Unexpected data value;

This error is returned by the responder if it is not able to deal with the contents of the USSD string.

- Call Barred;
- Unknown Alphabet.

#### Provider error

See clause 7.6.1 for the use of this parameter.

# 11.10 MAP\_UNSTRUCTURED\_SS\_REQUEST service

# 11.10.1 Definitions

This service is used between the gsmSCF and the HLR, the HLR and the VLR and between the VLR and the MSC when the invoking entity requires information from the mobile user, in connection with unstructured supplementary service handling.

The MAP\_UNSTRUCTURED\_SS\_REQUEST service is a confirmed service using the primitives from table 11.10/1.

# 11.10.2 Service primitives

Table 11.10/1: MAP\_UNSTRUCTURED\_SS\_REQUEST parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
USSD Data Coding Scheme	M	M(=)	С	C(=)
USSD String	M	M(=)	С	C(=)
Alerting Pattern	С	C(=)		
User error			С	C(=)
Provider error				0

# 11.10.3 Parameter use

#### Invoke id

See clause 7.6.1 for the use of this parameter.

#### **USSD Data Coding Scheme**

See clause 7.6.4 for the use of this parameter. The presence of the parameter in the response is dependent on the mobile user's MMI input. If this parameter is present, then the USSD String parameter has to be present.

#### **USSD String**

See clause 7.6.1 for the use of this parameter. The presence of the parameter in the response is dependent on the mobile user's MMI input. If this parameter is present, then the USSD Data Coding Scheme parameter has to be present.

# Alerting Pattern

See clause 7.6.3 for the use of this parameter.

#### User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- System failure;
- Data missing;
- Unexpected data value;

This error is returned by the responder if it is not able to deal with the contents of the USSD string;

- Absent Subscriber:
- Illegal Subscriber;

This error indicates that delivery of the unstructured supplementary service data failed because the MS failed authentication;

- Illegal Equipment;
- USSD Busy;
- Unknown Alphabet.

#### Provider error

See clause 7.6.1 for the use of this parameter.

# 11.11 MAP\_UNSTRUCTURED\_SS\_NOTIFY service

### 11.11.1 Definitions

This service is used between the gsmSCF and the HLR, the HLR and the VLR and between the VLR and the MSC when the invoking entity requires a notification to be sent to the mobile user, in connection with unstructured supplementary services handling.

The MAP\_UNSTRUCTURED\_SS\_NOTIFY service is a confirmed service using the primitives from table 11.11/1.

# 11.11.2 Service primitives

Table 11.11/1: MAP\_UNSTRUCTURED\_SS\_NOTIFY parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
USSD Data Coding Scheme	M	M(=)		
USSD String	M	M(=)		
Alerting Pattern	С	C(=)		
User error			С	C(=)
Provider error				0

# 11.11.3 Parameter use

#### Invoke id

See clause 7.6.1 for the use of this parameter.

### **USSD Data Coding Scheme:**

See clause 7.6.4 for the use of this parameter.

#### **USSD String:**

See clause 7.6.1 for the use of this parameter.

#### Alerting Pattern

See clause 7.6.3 for the use of this parameter.

#### User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- System failure;
- Data missing;
- Unexpected data value;

This error is returned by the responder if it is not able to deal with the contents of the USSD string.

- Absent Subscriber;
- Illegal Subscriber;

This error indicates that delivery of the unstructured supplementary service data failed because the MS failed authentication.

- Illegal Equipment;
- USSD Busy;

- Unknown Alphabet.

#### Provider error

See clause 7.6.1 for the use of this parameter.

# 11.12 MAP SS INVOCATION NOTIFY

### 11.12.1 Definition

This service is used between the MSC and the gsmSCF when the subscriber invokes one of the following supplementary services; Call Deflection (CD), Explicit Call Transfer (ECT) or Multi Party (MPTY).

This service is used between the HLR and the gsmSCF when the subscriber invokes the CCBS supplementary service.

# 11.12.2 Service primitives

The service primitives are shown in table 11.12/1.

Table 11.12/1: SS\_INVOCATION\_NOTIFY parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	М	M(=)	M(=)	M(=)
MSISDN	М	M(=)		
IMSI	М	M(=)		
SS- event	М	M(=)		
SS- event data	С	C(=)		
B-subscriber Number	С	C(=)		
CCBS Request State	С	C(=)		
User error			С	C(=)
Provider error				0

### 11.12.3 Parameter use

All parameters are described in clause 7.6. The use of these parameters and the requirements for their presence are specified in 3GPP TS 23.078.

### User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

#### Provider error

This is defined in clause 7.6.1.

# 11.13 MAP REGISTER CC ENTRY service

### 11.13.1 Definition

This service is used between the MSC and the VLR and between the VLR and the HLR to register data for a requested call completion supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and uses the service primitives shown in table 11.13/1.

# 11.13.2 Service primitives

Table 11.13/1: MAP\_REGISTER\_CC\_ENTRY parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS Code	M	M(=)		
CCBS Feature	С	C(=)	С	C(=)
Translated B number	С	C(=)		
Service Indicator	С	C(=)		
Call Info	С	C(=)		
Network Signal Info	С	C(=)		
User error			С	C(=)
Provider error				0

### 11.13.3 Parameter use

See clause 7.6 for a definition of the parameters used, in addition to the following.

#### SS-Code

This parameter indicates the call completion supplementary service for which the mobile subscriber wants to register an entry.

#### **CCBS** Feature

See 3GPP TS 23.093 [107] for the conditions for the presence of the parameters included in the CCBS feature.

#### Translated B Number

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

#### Service Indicator

This parameter corresponds to the parameters 'Presentation Indicator' and 'CAMEL Invoked' in 3GPP TS 23.093 [107]. It indicates which services have been invoked for the original call (e.g. CLIR, CAMEL). See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

#### Call Info

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

#### Network Signal Info

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

#### User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in clause 7.6.1:

- System failure;
- Data missing;
- Unexpected data value;
- Call Barred;
- Illegal SS operation;
- SS error status;
- SS incompatibility.

- Short Term Denial;
- Long Term Denial;
- Facility Not Supported;

NOTE: This error is reserved for future use.

Private Extensions shall not be sent with these user errors for this operation.

#### Provider error

See clause 7.6.1 for the use of this parameter.

# 11.14 MAP\_ERASE\_CC\_ENTRY service

### 11.14.1 Definition

This service is used between the MSC and the VLR and between the VLR and the HLR to erase data related to a call completion supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and uses the service primitives shown in table 11.14/1.

# 11.14.2 Service primitives

Table 11.14/1: MAP\_ERASE\_CC\_ENTRY parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)	C(=)	C(=)
CCBS Index	С	C(=)		
SS-Status			С	C(=)
User error			С	C(=)
Provider error				0

### 11.14.3 Parameter use

See clause 7.6 for a definition of the parameters used, in addition to the following.

#### SS-Code

This parameter indicates the call completion supplementary service for which the mobile subscriber wants to erase an entry/entries.

#### **CCBS Index**

See 3GPP TS 23.093 [107] for the use of this parameter and the condition for its presence.

#### SS-Status

Depending on the outcome of the service request this parameter may indicate either provisioned and active or not provisioned.

#### User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in clause 7.6.1:

- System failure;
- Data Missing;

- Unexpected data value;
- Call Barred;
- Illegal SS operation;
- SS error status.

Private Extensions shall not be sent with these user errors for this operation.

#### Provider error

See clause 7.6.1 for the use of this parameter.

# 12 Short message service management services

# 12.1 MAP-SEND-ROUTING-INFO-FOR-SM service

# 12.1.1 Definition

This service is used between the gateway MSC and the HLR to retrieve the routing information needed for routing the short message to the servicing MSC or SGSN. This service is also used between the gateway MSC and SMS Router, and SMS Router and HLR in order to enforce routing of the SM delivery via the HPLMN of the receiving MS. This service is also used between HLR and IP-SM-GW, and between IP-SM-GW and HLR in order to allow MT-SM delivery via the IMS.

The MAP-SEND-ROUTING-INFO-FOR-SM is a confirmed service using the primitives from table 12.1/1.

# 12.1.2 Service primitives

Table 12.1/1: MAP-SEND-ROUTING-INFO-FOR-SM

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
MSISDN	M	M(=)		
SM-RP-PRI	M	M(=)		
Service Centre Address	M	M(=)		
SM-RP-MTI	С	C(=)		
SM-RP-SMEA	С	C(=)		
GPRS Support Indicator	С	C(=)		
IMSI			С	C(=)
Network Node Number			С	C(=)
LMSI			С	C(=)
GPRS Node Indicator			С	C(=)
Additional Number			С	C(=)
User error			С	C(=)
Provider error				0

# 12.1.3 Parameter use

Invoke id

See definition in clause 7.6.1.

**MSISDN** 

See definition in clause 7.6.2.

SM-RP-PRI

See definition in clause 7.6.8.

#### Service Centre Address

See definition in clause 7.6.2.

#### SM-RP-MTI

See definition in clause 7.6.8. This parameter shall be present when the feature « SM filtering by the HPLMN » is supported by the SMS-GMSC and when the equivalent parameter is received from the short message service relay sublayer protocol.

#### SM-RP-SMEA

See definition in clause 7.6.8. This parameter shall be present when the feature « SM filtering by the HPLMN » is supported by the SMS-GMSC and when the equivalent parameter is received from the short message service relay sublayer protocol.

#### **GPRS Support Indicator**

See definition in clause 7.6.8. The presence of this parameter is mandatory if the SMS-GMSC supports receiving of the two numbers from the HLR.

#### **IMSI**

See definition in clause 7.6.2. If enforcement of routing an SM via the HPLMN of the receiving MS is deployed, this parameter contains an MT Correlation ID instead of an IMSI when the service is used between SMS-GMSC and SMS Router (see 3GPP TS 23.040 [26] for more information).

The presence of this parameter is mandatory in a successful case.

#### Network Node Number

See definition in clause 7.6.2. This parameter is provided in a successful response.

#### **LMSI**

See definition in clause 7.6.2. It is an operator option to provide this parameter from the VLR; it is mandatory for the HLR to include the LMSI in a successful response, if the VLR has used the LMSI.

#### **GPRS** Node Indicator

See definition in clause 7.6.8. The presence of this parameter is mandatory if only the SGSN number is sent in the Network Node Number.

#### Additional Number

See definition in clause 7.6.2. This parameter is provided in a successful response.

#### User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unknown subscriber;
- Call Barred;
- Teleservice Not Provisioned;
- Absent Subscriber\_SM;
- Facility Not Supported;
- System failure;
- Unexpected Data Value;
- Data missing.

#### Provider error

For definition of provider errors see clause 7.6.1.

# 12.2 MAP-MO-FORWARD-SHORT-MESSAGE service

# 12.2.1 Definition

This service is used between the serving MSC or the SGSN and the SMS Interworking MSC to forward mobile originated short messages.

The MAP-MO-FORWARD-SHORT-MESSAGE service is a confirmed service using the service primitives given in table 12.2/1.

# 12.2.2 Service primitives

Table 12.2/1: MAP-MO-FORWARD-SHORT-MESSAGE

Parameter name	Request	Indication	Response	Confirm
Invoke Id	М	M(=)	M(=)	M(=)
SM RP DA	М	M(=)		
SM RP OA	М	M(=)		
SM RP UI	М	M(=)	С	C(=)
IMSI	С	C(=)		
User error		, ,	С	C(=)
Provider error				0

# 12.2.3 Parameter use

#### Invoke id

See definition in clause 7.6.1.

#### **SM RP DA**

See definition in clause 7.6.8.

In the mobile originated SM transfer this parameter contains the Service Centre address received from the mobile station.

#### **SM RP OA**

See definition in clause 7.6.8.

The MSISDN received from the VLR or from the SGSN is inserted in this parameter in the mobile originated SM transfer.

#### SM RP UI

See definition in clause 7.6.8. The short message transfer protocol data unit received from the Service Centre is inserted in this parameter.

#### **IMSI**

See definition in clause 7.6.2.1. The IMSI of the originating subscriber is inserted in this parameter in the mobile originated SM transfer.

This parameter shall be included if the sending entity, whether MSC or SGSN, supports mobile number portability.

#### User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Facility Not Supported;
- System Failure;
- SM Delivery Failure;
  - The reason of the SM Delivery Failure can be one of the following in the mobile originated SM:
    - unknown Service Centre address;
    - Service Centre congestion;
    - invalid Short Message Entity address;
    - subscriber not Service Centre subscriber;
    - protocol error.
- Unexpected Data Value

#### Provider error

For definition of provider errors see clause 7.6.1.

# 12.3 MAP-REPORT-SM-DELIVERY-STATUS service

# 12.3.1 Definition

This service is used between the gateway MSC and the HLR or the external Short Message Gateway (IP-SM-GW) and the HLR. The MAP-REPORT-SM-DELIVERY-STATUS service is used to set the Message Waiting Data into the HLR or to inform the HLR of successful SM transfer after polling. This service is invoked by the gateway MSC or the external Short Message Gateway (IP-SM-GW).

The MAP-REPORT-SM-DELIVERY-STATUS service is a confirmed service using the service primitives given in table 12.3/1.

# 12.3.2 Service primitives

Table 12.3/1: MAP-REPORT-SM-DELIVERY-STATUS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
MSISDN	М	M(=)		
Service Centre Address	М	M(=)		
SM Delivery Outcome	М	M(=)		
Absent Subscriber Diagnostic SM	С	C(=)		
GPRS Support Indicator	С	C(=)		
Delivery Outcome Indicator	С	C(=)		
Additional SM Delivery Outcome	С	C(=)		
Additional Absent Subscriber Diagnostic SM	С	C(=)		
IP-SM-GW-Indicator	С	C(=)		
IP-SM-GW SM Delivery Outcome	С	C(=)		
IP-SM-GW Absent Subscriber Diagnostic SM	С	C(=)		
MSIsdn-Alert			С	C(=)
User error			С	C(=)
Provider error				Ö

### 12.3.3 Parameter use

#### Invoke id

See definition in clause 7.6.1.

#### **MSISDN**

See definition in clause 7.6.2.

# Service Centre Address

See definition in clause 7.6.2.

#### **SM** Delivery Outcome

See definition in clause 7.6.8. This parameter indicates the status of the mobile terminated SM delivery.

#### Absent Subscriber Diagnostic SM

See definition in clause 7.6.8.

### **GPRS Support Indicator**

See definition in clause 7.6.8. The presence of this parameter is mandatory if the SMS-GMSC supports handling of two delivery outcomes.

#### **Delivery Outcome Indicator**

See definition in clause 7.6.8.

#### Additional SM Delivery Outcome

See definition in clause 7.6.8.

#### Additional Absent Subscriber Diagnostic SM

See definition in clause 7.6.8.

#### **IP-SM-GW Indicator**

See definition in clause 7.6.8.

#### IP-SM-GW SM Delivery Outcome

See definition in clause 7.6.8.

# IP-SM-GW Absent Subscriber Diagnostic SM

See definition in clause 7.6.8.

#### MSIsdn-Alert

See definition in clause 7.6.2. This parameter shall be present in case of unsuccessful delivery, when the MSISDN received in the operation is different from the stored MSIsdn-Alert; the stored MSIsdn-Alert is the value that is returned to the gateway MSC.

#### User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unknown Subscriber;
- Message Waiting List Full;
- Unexpected Data Value;
- Data missing.

#### Provider error

For definition of provider errors see clause 7.6.1.

# 12.4 MAP-READY-FOR-SM service

# 12.4.1 Definition

This service is used between the MSC and VLR as well as between the VLR and the HLR. The MSC initiates this service if a subscriber indicates memory available situation. The VLR uses the service to indicate this to the HLR.

The VLR initiates this service if a subscriber, whose message waiting flag is active in the VLR, has radio contact in the MSC.

Also this service is used between the SGSN and the HLR. The SGSN initiates this service if a subscriber indicates memory available situation. The SGSN uses the service to indicate this to the HLR.

The SGSN initiates this service if a subscriber, whose message waiting flag is active in the SGSN, has radio contact in the GPRS.

The MAP-READY-FOR-SM service is a confirmed service using the primitives from table 12.4/1.

# 12.4.2 Service primitives

Table 12.4/1: MAP-READY-FOR-SM

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	С	C(=)		
TMSI	С	C(=)		
Alert Reason	М	M(=)		
Alert Reason Indicator	С	C(=)		
Additional Alert Reason Indicator	С	C(=)		
User error			С	C(=)
Provider error	•			0

# 12.4.3 Parameter use

#### Invoke id

See definition in clause 7.6.1.

#### **IMSI**

See definition in clause 7.6.2. The IMSI is used always between the VLR and the HLR and between the SGSN and the HLR. Between the MSC and the VLR the identification can be either IMSI or TMSI.

#### **TMSI**

See definition in clause 7.6.2. The identification can be either IMSI or TMSI between MSC and VLR.

### Alert Reason

See definition in clause 7.6.8. This parameter indicates if the mobile subscriber is present or the MS has memory available.

#### Alert Reason Indicator

See definition in clause 7.6.8.

#### Additional Alert Reason Indicator

See definition in clause 7.6.8.

### User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unknown Subscriber;
- Facility Not Supported;
- System Failure;
- Unexpected Data Value;
- Data missing.

#### Provider error

For definition of provider errors see clause 7.6.1.

# 12.5 MAP-ALERT-SERVICE-CENTRE service

# 12.5.1 Definition

This service is used between the HLR and the interworking MSC. The HLR initiates this service, if the HLR detects that a subscriber, whose MSISDN is in the Message Waiting Data file, is active or the MS has memory available.

The MAP-ALERT-SERVICE-CENTRE service is a confirmed service using the primitives from table 12.5/1.

# 12.5.2 Service primitives

Table 12.5/1: MAP-ALERT-SERVICE-CENTRE

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
MSIsdn-Alert	M	M(=)		
Service Centre Address	M	M(=)		
User error			С	C(=)
Provider error				0

# 12.5.3 Parameter use

#### Invoke id

See definition in clause 7.6.1.

### MSIsdn-Alert

See definition in clause 7.6.2. The provided MSISDN shall be the one which is stored in the Message Waiting Data file.

#### Service Centre Address

See definition in clause 7.6.2.

#### User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- System Failure;
- Unexpected Data Value;
- Data missing.

#### Provider error

For definition of provider errors see clause 7.6.1.

# 12.6 MAP-INFORM-SERVICE-CENTRE service

# 12.6.1 Definition

This service is used between the HLR and the gateway MSC (transiting an SMS Router, if present) to inform the Service Centre which MSISDN number is stored in the Message Waiting Data file. If the stored MSISDN number is not the same as the one received from the gateway MSC in the MAP-SEND-ROUTING-INFO-FOR-SM service primitive the stored MSISDN number is included in the message.

Additionally the status of MCEF, MNRF and MNRG flags and the inclusion of the particular Service Centre address in the Message Waiting Data list is informed to the gateway MSC when appropriate.

If the HLR has stored a single MNRR, the value is included in the Absent Subscriber Diagnostic SM parameter.

If the HLR has stored a second MNRR, the value of the MNRR for the MSC is included in the Absent Subscriber Diagnostic SM parameter and the value of the MNRR for the SGSN is included in the Additional Absent Subscriber Diagnostic SM parameter.

The MAP-INFORM-SERVICE-CENTRE service is a non-confirmed service using the primitives from table 12.6/1.

# 12.6.2 Service primitives

Table 12.6/1: MAP-INFORM-SERVICE-CENTRE

Parameter name	Request	Indication
Invoke Id	M	M(=)
MSIsdn-Alert	С	C(=)
MWD Status	С	C(=)
Absent Subscriber Diagnostic SM	С	C(=)
Additional Absent Subscriber Diagnostic SM	С	C(=)

# 12.6.3 Parameter use

#### Invoke id

See definition in clause 7.6.1.

#### MSIsdn-Alert

See definition in clause 7.6.2. This parameter refers to the MSISDN stored in a Message Waiting Data file in the HLR.

#### MWD Status

See definition in clause 7.6.8. This parameter indicates the status of the MCEF, MNRF and MNRG flags and the status of the particular SC address presence in the Message Waiting Data list.

### Absent Subscriber Diagnostic SM

See definition in clause 7.6.8.

#### Additional Absent Subscriber Diagnostic SM

See definition in clause 7.6.8.

# 12.7 MAP-SEND-INFO-FOR-MT-SMS service

### 12.7.1 Definition

This service is used between the MSC and the VLR. The service is invoked by the MSC receiving a mobile terminated short message to request subscriber related information from the VLR.

The MAP-SEND-INFO-FOR-MT-SMS service is a confirmed service using the primitives from table 12.7/1.

# 12.7.2 Service primitives

Table 12.7/1: MAP-SEND-INFO-FOR-MT-SMS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
SM RP DA	M	M(=)		
IMSI	С	C(=)		
MSISDN			С	C(=)
User error			С	C(=)
Provider error				0

# 12.7.3 Parameter use

#### Invoke id

See definition in clause 7.6.1.

### SM RP DA

See definition in clause 7.6.8. This parameter shall contain either an IMSI or an LMSI.

# **IMSI**

See definition in clause 7.6.2. This parameter shall be present if the SM RP DA parameter contains an LMSI; otherwise it shall be absent.

#### **MSISDN**

See definition in clause 7.6.2.

#### User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unknown subscriber;
- Unidentified Subscriber;
- Absent subscriber;
- Unexpected Data Value;
- Data Missing;
- Illegal subscriber;
- Illegal equipment;
- Subscriber busy for MT SMS;
- System Failure.

### Provider error

For definition of provider errors see clause 7.6.1.

# 12.8 MAP-SEND-INFO-FOR-MO-SMS service

# 12.8.1 Definition

This service is used between the MSC and the VLR. The service is invoked by the MSC which has to handle a mobile originated short message request to request the subscriber related information from the VLR.

The MAP-SEND-INFO-FOR-MO-SMS service is a confirmed service using the primitives from table 12.8/1.

# 12.8.2 Service primitives

Table 12.8/1: MAP-SEND-INFO-FOR-MO-SMS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Service Centre Address	M	M(=)		
MSISDN			С	C(=)
User error			С	C(=)
Provider error				0

# 12.8.3 Parameter use

#### Invoke id

See definition in clause 7.6.1.

# Service Centre Address

See definition in clause 7.6.2.

#### **MSISDN**

See definition in clause 7.6.2.

#### User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Teleservice Not Provisioned;
- Call Barred;
- Unexpected Data Value;
- Data Missing.

#### Provider error

For definition of provider errors see clause 7.6.1.

# 12.9 MAP-MT-FORWARD-SHORT-MESSAGE service

# 12.9.1 Definition

This service is used between the gateway MSC and the serving MSC or the SGSN (transiting an SMS Router, if present) to forward mobile terminated short messages.

The MAP-MT-FORWARD-SHORT-MESSAGE service is a confirmed service using the service primitives given in table 12.9/1.

# 12.9.2 Service primitives

Table 12.9/1: MAP-MT-FORWARD-SHORT-MESSAGE

Parameter name	Request	Indication	Response	Confirm
Invoke Id	М	M(=)	M(=)	M(=)
SM RP DA	M	M(=)		
SM RP OA	M	M(=)		
SM RP UI	M	M(=)	С	C(=)
More Messages To Send	С	C(=)		
User error			С	C(=)
Provider error				0

# 12.9.3 Parameter use

#### Invoke id

See definition in clause 7.6.1.

#### **SM RP DA**

See definition in clause 7.6.8. This parameter can contain either an IMSI or a LMSI. The use of the LMSI is an operator option. The LMSI can be provided if it is received from the HLR. The IMSI is used if the use of the LMSI is not available.

This parameter is omitted in the mobile terminated subsequent SM transfers.

#### **SM RP OA**

See definition in clause 7.6.8. The Service Centre address received from the originating Service Centre is inserted in this parameter.

This parameter is omitted in the mobile terminated subsequent SM transfers.

#### SM RP UI

See definition in clause 7.6.8. The short message transfer protocol data unit received from the Service Centre is inserted in this parameter. A short message transfer protocol data unit may also be inserted in this parameter in the message delivery acknowledgement from the MSC or from the SGSN to the Service Centre.

### More Messages To Send

See definition in clause 7.6.8. The information from the MMS indication received from the Service Centre is inserted in this parameter.

### User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unidentified subscriber;
- Absent Subscriber\_SM;
- Subscriber busy for MT SMS;
- Facility Not Supported;
- Illegal Subscriber indicates that delivery of the mobile terminated short message failed because the mobile station failed authentication;

- Illegal equipment indicates that delivery of the mobile terminated short message failed because an IMEI check failed, i.e. the IMEI was blacklisted or not white-listed;
- System Failure;
- SM Delivery Failure:
  - The reason of the SM Delivery Failure can be one of the following in the mobile terminated SM:
    - memory capacity exceeded in the mobile equipment;
    - protocol error;
    - mobile equipment does not support the mobile terminated short message service.
- Unexpected Data Value;
- Data Missing.

#### Provider error

For definition of provider errors see clause 7.6.1.

## 12.10 MAP-MT-FORWARD-SM-FOR-VGCS service

## 12.10.1 Definition

This service is used between the SMS gateway MSC and the Group Call Anchor MSC to forward mobile terminated short messages into an ongoing voice group call.

The MAP-MT-FORWARD-SM-FOR-VGCS service is a confirmed service using the service primitives given in table 12.10/1.

## 12.10.2 Service primitives

Table 12.10/1: MAP-MT-FORWARD-SM-VGCS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
ASCI Call Reference	M	M(=)		
SM RP OA	M	M(=)		
SM RP UI	M	M(=)	С	C(=)
Dispatcher List			С	C(=)
Ongoing Call Indicator			С	C(=)
User error			С	C(=)
Provider error				0

## 12.10.3 Parameter use

## Invoke id

See definition in clause 7.6.1.

#### ASCI Call Reference

Group call reference. This item is used to access the VGCS-GCR within the Anchor\_MSC.

#### SM RP OA

See definition in clause 7.6.8. The Service Centre address received from the originating Service Centre is inserted in this parameter.

## **SM RP UI**

See definition in clause 7.6.8. The short message transfer protocol data unit received from the Service Centre is inserted in this parameter. A short message transfer protocol data unit may also be inserted in this parameter in the message delivery acknowledgement from the MSC to the Service Centre.

## Dispatcher List

A list of identities (international E.164 phone numbers) identifying the dispatchers of the VGCS call. It shall be present if received from the GCR; otherwise shall be absent.

#### Ongoing Call Indicator

Indicates by its presence that the VGCS call is ongoing.

## User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- System Failure;
- Unexpected Data Value.

#### Provider error

For definition of provider errors see clause 7.6.1.

# 13 Network-Requested PDP Context Activation services

# 13.1 MAP\_SEND\_ROUTING\_INFO\_FOR\_GPRS service

## 13.1.1 Definition

This service is used by the GGSN to request GPRS routing information from the HLR.

## 13.1.2 Service primitives

Table 13.1/1: MAP\_SEND\_ROUTING\_INFO\_FOR\_GPRS

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
GGSN address	С	C(=)	С	C(=)
GGSN number	M	M(=)		
SGSN address			С	C(=)
Mobile Not Reachable Reason			С	C(=)
User error			С	C(=)
Provider error				0

## 13.1.3 Parameter definition and use

#### Invoke Id

See definition in clause 7.6.1.

## <u>IMSI</u>

See definition in clause 7.6.2.

#### GGSN address

This parameter shall be present if the protocol-converting GSN is used between the GGSN and the HLR.

#### GGSN number

See definition in clause 7.6.2.

## SGSN address

This parameter shall be present if the outcome of the Send Routing Info For GPRS request to the GPRS application process in the HLR is positive.

### Mobile Not Reachable Reason

This parameter shall be present if the outcome of the Send Routing Info For GPRS request to the GPRS application process in the HLR is positive and the MNRG flag in the HLR is set. See definition in clause 7.6.3.51.

#### User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Absent Subscriber;
- System Failure;
- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

The diagnostic in the Unknown Subscriber may indicate 'Imsi Unknown' or 'Gprs Subscription Unknown'.

Call Barred;

This error will indicate that the received PDP PDUs in the GGSN shall be barred for this MS due to Operator Determined Barring. (The CallBarringCause must be the operatorBarring.)

#### Provider error

These are defined in clause 7.6.1.

# 13.2 MAP\_FAILURE\_REPORT service

## 13.2.1 Definition

This service is used by the GGSN to inform the HLR that network requested PDP-context activation has failed.

## 13.2.2 Service primitives

Table 13.2/1: MAP\_FAILURE\_REPORT

Parameter name	Request	Indication	Response	Confirm
Invoke id	М	M(=)	M(=)	M(=)
IMSI	M	M(=)		
GGSN address	С	C(=)	С	C(=)
GGSN number	M	M(=)		
User error			С	C(=)
Provider error				0

## 13.2.3 Parameter definition and use

## Invoke Id

See definition in clause 7.6.1.

#### **IMSI**

See definition in clause 7.6.2.

## GGSN address

This parameter shall be present if the protocol-converting GSN is used between the GGSN and the HLR.

## GGSN number

See definition in clause 7.6.2.

#### User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- System Failure;
- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

## Provider error

These are defined in clause 7.6.1.

# 13.3 MAP\_NOTE\_MS\_PRESENT\_FOR\_GPRS service

## 13.3.1 Definition

This service is used by the HLR to inform the GGSN that the MS is present for GPRS again.

# 13.3.2 Service primitives

Table 13.3/1: MAP\_NOTE\_MS\_PRESENT\_FOR\_GPRS

Parameter name	Request	Indication	Response	Confirm
Invoke id	М	M(=)	M(=)	M(=)
IMSI	M	M(=)		
GGSN address	С	C(=)		
SGSN address	M	M(=)		
User error			С	C(=)
Provider error				0

## 13.3.3 Parameter definition and use

## Invoke Id

See definition in clause 7.6.1.

## **IMSI**

See definition in clause 7.6.2.

#### GGSN address

This parameter shall be present if the protocol-converting GSN is used between the GGSN and the HLR.

## SGSN address

See definition in clause 7.6.2.

#### User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- System Failure;
- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

## Provider error

These are defined in clause 7.6.1.

# 13A Location Service Management Services

## 13A.1 MAP-SEND-ROUTING-INFO-FOR-LCS Service

## 13A.1.1 Definition

This service is used between the GMLC and the HLR to retrieve the routing information needed for routing a location service request to the servicing VMSC or SGSN. The MAP-SEND-ROUTING-INFO-FOR-LCS is a confirmed service using the primitives from table 13A.1/1.

## 13A.1.2 Service Primitives

Table 13A.1/1: MAP-SEND-ROUTING-INFO-FOR-LCS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	М	M(=)	M(=)	M(=)
MLC Number	М	M(=)		
MSISDN	C	C(=)	С	C(=)
IMSI	С	C(=)	С	C(=)
LMSI			С	C(=)
Network Node Number			С	C(=)
GPRS Node Indicator			С	C(=)
Additional Number			С	C(=)
Supported LCS Capability			С	C(=)
Sets				
Additional LCS Capability			С	C(=)
Sets				
V-GMLC Address			U	C(=)
Additional V-GMLC Address			U	C(=)
H-GMLC Address			С	C(=)
PPR Address			U	C(=)
User error			С	C(=)
Provider error				0

## 13A.1.3 Parameter Use

Invoke id

See definition in clause 7.6.1.

MLC Number

See definition in clause 7.6.2.

#### **MSISDN**

See definition in clause 7.6.2. The request shall carry either the IMSI or MSISDN. The response shall carry whichever of these was not included in the request (see 3GPP TS 23.271 for details).

#### **IMSI**

See definition in clause 7.6.2.

#### **LMSI**

See definition in clause 7.6.2. It is an operator option to provide this parameter from the VLR; it is mandatory for the HLR to include the LMSI in a successful response, if the VLR has used the LMSI.

#### Network Node Number

See definition in clause 7.6.2. This parameter is provided in a successful response. If the Network Node Number and Additional Number are received in the GMLC, the Network Node Number is used in preference to the Additional Number.

#### **GPRS** Node Indicator

See definition in clause 7.6.8. The presence of this parameter is mandatory only if the SGSN number is sent in the Network Node Number.

#### Additional Number

See definition in clause 7.6.2. This parameter is provided in a successful response. If the Network Node Number and Additional Number are received in the GMLC, the Network Node Number is used in preference to the Additional Number

#### Supported LCS Capability Sets

See definition in clause 7.6.11. This parameter indicates the LCS capability of the serving node that is indicated by the Network Node Number. This parameter is provided only if LCS capability sets are available in HLR and Network Node Number is present in this message.

## Additional LCS Capability Sets

See definition in clause 7.6.11. This parameter indicates the LCS capability of the serving node that is indicated by the Additional Number. This parameter is provided only if LCS capability sets are available in HLR and Additional Number is present in this message.

#### V-GMLC address

See definition in clause 7.6.2. This parameter indicates the V-GMLC address of the serving node that is indicated by the Network Node Number.

#### Additional V-GMLC address

See definition in clause 7.6.2. This parameter indicates the V-GMLC address of the serving node that is indicated by the Additional Number. This parameter is provided only if additional LCS capability sets are available in HLR and Additional Number is present in this message.

#### H-GMLC address

See definition in clause 7.6.2. The requirements for its presence are specified in 3GPP TS 23.271 [26a].

## PPR address

See definition in clause 7.6.2.

User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unknown subscriber;
- Absent Subscriber;
- Facility Not Supported;
- System failure;
- Unexpected Data Value;
- Data missing;
- Unauthorised requesting network.

Provider error

For definition of provider errors see clause 7.6.1.

## 13A.2 MAP-PROVIDE-SUBSCRIBER-LOCATION Service

## 13A.2.1 Definition

This service is used by a GMLC to request the location of a target MS from the visited MSC or SGSN at any time. This is a confirmed service using the primitives from table 13A.2/1.

## 13A.2.2 Service Primitives

Table 13A.2/1: Provide\_Subscriber\_Location

Parameter name	Request	Indication	Response	Confirm
Invoke id	М	M(=)	M(=)	M(=)
Location Type	M	M(=)		
MLC Number	M	M(=)		
LCS Client ID	М	M(=)		
Privacy Override	U	C(=)		
IMSI	С	C(=)		
MSISDN	С	C(=)		
LMSI	С	C(=)		
LCS Priority	С	C(=)		
LCS QoS	С	C(=)		
IMEI	U	C(=)		
Supported GAD Shapes	С	C(=)		
LCS-Reference Number	С	C(=)		
LCS Codeword	С	C(=)		
LCS Service Type Id	С	C(=)		
LCS Privacy Check	С	C(=)		
Area Event Info	С	C(=)		
H-GMLC Address	С	C(=)		
Reporting PLMN List	С	C(=)		
PeriodicLDRInfo	С	C(=)		
MO-LR Short Circuit	С	C(=)	С	C(=)
Indicator				
Location Estimate			M	M(=)
GERAN Positioning Data			С	C(=)
UTRAN Positioning Data			С	C(=)

GERAN GANSS	С	C(=)
Positioning Data		
UTRAN GANSS	С	C(=)
Positioning Data		
Age of Location Estimate	С	C(=)
Additional Location	С	C(=)
Estimate		
Deferred MT-LR	С	C(=)
Response Indicator		
Cell Id Or SAI	С	C(=)
Accuracy Fulfilment	С	C(=)
Indicator		
User error	С	C(=)
Provider error		Ö

## 13A.2.3 Parameter Definition and Use

All parameters are defined in clause 7.6. The use of these parameters and the requirements for their presence are specified in 3GPP TS 23.271 [26a].

#### **Location Type**

This parameter identifies the type of location information requested.

#### MLC Number

This is the E.164 number of the requesting GMLC.

#### LCS Client ID

This parameter provides information related to the identity of an LCS client.

## Privacy Override

This parameter indicates if MS privacy is overridden by the LCS client when the GMLC and VMSC or SGSN for an MT-LR are in the same country.

#### **IMSI**

The IMSI is provided to identify the target MS. At least one of the IMSI or MSISDN is mandatory.

#### **MSISDN**

The MSISDN is provided to identify the target MS. At least one of the IMSI or MSISDN is mandatory.

## **LMSI**

The LMSI shall be provided if previously supplied by the HLR. This parameter is only used in the case of the MT-LR for CS domain.

#### LCS Priority

This parameter indicates the priority of the location request.

## LCS QoS

This parameter indicates the required quality of service in terms of response time and accuracy.

## **IMEI**

The requirements for its presence are specified in 3GPP TS 23.271 [26a].

### Supported GAD Shapes

This parameter indicates which of the shapes defined in 3GPP TS 23.032 [122] are supported.

#### LCS-Reference Number

This parameter shall be included if a deferred MT-LR procedure is performed for a UE available event, an area event or a periodic positioning event.

#### LCS Codeword

See definition in clause 7.6.11.18. The requirements for its presence are specified in 3GPP TS 23.271 [26a].

#### LCS Service Type Id

See definition in clause 7.6.11.15. The requirements for its presence are specified in 3GPP TS 23.271 [26a].

#### LCS Privacy Check

See definition in clause 7.6.11. The requirements for its and its components presence are specified in 3GPP TS 23.271 [26a].

#### Area Event Info

See definition in clause 7.6.11. The parameter shall be included if a deferred MT-LR procedure is performed for an area event.

#### H-GMLC address

See definition in clause 7.6.2. The parameter shall be included if a deferred MT-LR procedure is performed for a UE available event, an area event or a periodic positioning event.

#### Location Estimate

This parameter provides the location estimate if this is encoded in one of the supported geographical shapes. Otherwise this parameter shall consist of one octet, which shall be discarded by the receiving node.

#### **GERAN Positioning Data**

This parameter indicates the usage of each positioning method that was attempted to determine the location estimate either successfully or unsuccessfully. If Positioning Data received from the RAN contains no Positioning Methods, Positioning Data is excluded from the MAP message. It may be included in the message only if the access network is GERAN, see 3GPP TS 23.271 [26a].

#### **UTRAN** Positioning Data

This parameter indicates the usage of each positioning method that was successfully attempted to determine the location estimate. If Position Data received from the RAN contains no Positioning Methods, UTRAN Positioning Data is excluded from the MAP message. It may be included in the message only if the access network is UTRAN, see 3GPP TS 23.271 [26a].

#### **GERAN GANSS Positioning Data**

This parameter indicates the usage of each GANSS positioning method that was attempted to determine the location estimate either successfully or unsuccessfully. If GANSS Positioning Data received from the RAN contains no GANSS method, GERAN GANSS Positioning Data is excluded from the MAP message. It may be included in the message only if the access network is GERAN, see 3GPP TS 23.271 [26a].

#### **UTRAN GANSS Positioning Data**

This parameter indicates the usage of each GANSS positioning method that was successfully attempted to determine the location estimate. If Position Data received from the RAN contains no GANSS Positioning Data Set, UTRAN GANSS Positioning Data is excluded from the MAP message. It may be included in the message only if the access network is UTRAN, see 3GPP TS 23.271 [26a].

## Age of Location Estimate

This parameter indicates how long ago the location estimate was obtained.

## Additional Location Estimate

This parameter provides the location estimate when not provided by the Location Estimate parameter. It may be sent only if the parameter Supported GAD Shapes has been received in the Provide Subscriber Location indication and the shape to be included is supported by the GMLC.

#### Deferred MT-LR Response Indicator

See definition in clause 7.6.11.2.

## Cell Id Or SAI

For GERAN access, this parameter indicates Global Cell Identifier of the cell that the served subscriber is currently attached to. For UTRAN access, this parameter contains the Service Area Identifier for the cell that the subscriber is currently attached to. This parameter is included only for North American Emergency Calls as described in 3GPP TS 23.271 [26a].

## Accuracy Fulfilment Indicator

See definition in clause 7.6.11.28.

### MO-LR Short Circuit Indicator

This parameter indicates whether MO-LR Short Circuit is permitted for periodic location.

#### Reporting PLMN List

This parameter indicates a list of PLMNs in which subsequent periodic MO-LR TTTP requests will be made.

### Periodic LDR information

This parameter indicates the reporting amount and reporting interval of deferred periodic location.

#### User error

This parameter is sent by the responder when the location request has failed or cannot proceed and if present, takes one of the following values defined in clause 7.6.1.

- System Failure;
- Data Missing;
- Unexpected Data Value;
- Facility Not Supported;
- Unidentified Subscriber;
- Illegal Subscriber;
- Illegal Equipment;
- Absent Subscriber (diagnostic information may also be provided);
- Unauthorised requesting network;
- Unauthorised LCS Client with detailed reason;
- Position method failure with detailed reason.

#### Provider error

These are defined in clause 7.6.1.

# 13A.3 MAP-SUBSCRIBER-LOCATION-REPORT Service

## 13A.3.1 Definition

This service is used by a VMSC or SGSN to provide the location of a target MS to a GMLC when a request for location is either implicitly administered or made at some earlier time. This is a confirmed service using the primitives from table 13A.3/1.

## 13A.3.2 Service Primitives

Table 13A.3/1: Subscriber\_Location\_Report

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
LCS Event	M	M(=)		
LCS Client ID	М	M(=)		
Network Node Number	М	M(=)		
IMSI	С	C(=)		
MSISDN	С	C(=)		
NA-ESRD	С	C(=)	С	C(=)
NA-ESRK	С	C(=)	С	C(=)
IMEI	U	C(=)		
Location Estimate	С	C(=)		
GERAN Positioning Data	С	C(=)		
UTRAN Positioning Data	С	C(=)		
GERAN GANSS Positioning	С	C(=) C(=)		
Data				
UTRAN GANSS Positioning	С	C(=)		
Data				
Age of Location Estimate	С	C(=)		
LMSI	U	C(=)		
GPRS Node Indicator	С	C(=)		
Additional Location Estimate	С	C(=)		
Deferred MT-LR Data	С	C(=)		
LCS-Reference Number	С	C(=)	С	C(=)
NA-ESRK Request	С	C(=)		
Cell Id Or SAI	С	C(=)		
H-GMLC Address	С	C(=)	С	C(=)
LCS Service Type Id	С	C(=)		
Pseudonym Indicator	С	C(=)		
Accuracy Fulfilment	С	C(=)		
Indicator				
Sequence Number	С	C(=)		
Periodic LDR Info	C C	C(=)		
MO-LR Short Circuit	С	C(=)	С	C(=)
Indicator				
Reporting PLMN List			С	C(=)
User error			С	C(=)
Provider error				0

## 13A.3.3 Parameter Definition and Use

All parameters are defined in clause 7.6. The use of these parameters and the requirements for their presence are specified in. 3GPP TS 23.271 [26a].

## LCS Event

This parameter indicates the event that triggered the Subscriber Location Report.

## LCS Client ID

This parameter provides information related to the identity of the recipient LCS client.

#### Network Node Number

See definition in clause 7.6.2. This parameter provides the address of the sending node.

#### **IMSI**

The IMSI shall be provided if available to the VMSC or SGSN.

#### **MSISDN**

The MSISDN shall be provided if available to the VMSC or SGSN.

### NA-ESRD

If the target MS has originated an emergency service call in North America, the NA-ESRD shall be provided by the VMSC if available.

If the target MS has originated an emergency service call in North America and NA-ESRK Request is included in Subscriber\_Location\_Report-Arg, an NA-ESRK or NA-ESRD, but not both, may also be included in the response to the MSC, see 3GPP TS 23.271 [26a].

#### **NA-ESRK**

If the target MS has originated an emergency service call in North America, the NA-ESRK shall be provided by the VMSC if assigned.

If the target MS has originated an emergency service call in North America and NA-ESRK Request is included in Subscriber\_Location\_Report-Arg, an NA-ESRK or NA-ESRD, but not both, may also be included in the response to the MSC, see 3GPP TS 23.271 [26a].

#### **IMEI**

The requirements for its presence are specified in 3GPP TS 23.271 [26a].

## **Location Estimate**

This parameter provides the location estimate. The absence of this parameter implies that a location estimate was not available or could not be successfully obtained. If the obtained location estimate is not encoded in one of the supported geographical shapes then this parameter shall consist of one octet, which shall be discarded by the receiving node.

#### **GERAN Positioning Data**

This parameter indicates the usage of each positioning method that was attempted to determine the location estimate either successfully or unsuccessfully. If Positioning Data received from the RAN contains no Positioning Methods, Positioning Data is excluded from the MAP message. It may be included in the message only if the access network is GERAN, see 3GPP TS 23.271 [26a].

#### **UTRAN Positioning Data**

This parameter indicates the usage of each positioning method that was successfullyattempted to determine the location estimate. If Position Data received from the RAN contains no Positioning Methods, UTRAN Positioning Data is excluded from the MAP message. It may be included in the message only if the access network is UTRAN, see 3GPP TS 23.271 [26a].

#### **GERAN GANSS Positioning Data**

This parameter indicates the usage of each GANSS positioning method that was attempted to determine the location estimate either successfully or unsuccessfully. If GANSS Positioning Data received from the RAN contains no GANSS method, GERAN GANSS Positioning Data is excluded from the MAP message. It may be included in the message only if the access network is GERAN, see 3GPP TS 23.271 [26a].

#### **UTRAN GANSS Positioning Data**

This parameter indicates the usage of each GANSS positioning method that was successfully attempted to determine the location estimate. If Position Data received from the RAN contains no GANSS Positioning Data Set, UTRAN GANSS

Positioning Data is excluded from the MAP message. It may be included in the message only if the access network is UTRAN, see 3GPP TS 23.271 [26a].

#### Age of Location Estimate

This parameter indicates how long ago the location estimate was obtained.

#### **LMSI**

The LMSI may be provided if assigned by the VLR.

#### **GPRS** Node Indicator

See definition in clause 7.6.8. This presence of this parameter is mandatory only if the SGSN number is sent in the Network Node Number.

#### Additional Location Estimate

This parameter provides the location estimate when not provided by the Location Estimate parameter...

#### Deferred MT-LR Data

See definition in clause 7.6.11.3.

#### **LCS-Reference Number**

This parameter shall be included if the Subscriber Location Report is the response to a deferred MT location request.

## NA-ESRK Request

If the target MS has originated an emergency service call in North America, NA-ESRK Request may be included to indicate that the MSC is able to accept NA-ESRK in the Response message, see section 7.6.11.19.

#### Cell Id Or SAI

For GERAN access, this parameter indicates Global Cell Identifier of the cell that the served subscriber is currently attached to. For UTRAN access, this parameter contains the Service Area Identifier for the cell that the subscriber is currently attached to. This parameter is included only for Emergency Calls as described in 3GPP TS 23.271 [26a].

## **H-GMLC** address

See definition in clause 7.6.2. The parameter shall be included if the Subscriber Location Report is the response to a deferred MT location request for a UE available event, an area event or a periodic positioning event. This parameter shall be included in a Subscriber Location Report response if a deferred MO-LR TTTP procedure is initiated for a periodic positioning event.

## LCS Service Type Id

See definition in clause 7.6.11.15. The requirements for its presence are specified in 3GPP TS 23.271 [26a].

#### Pseudonym Indicator

This parameter indicates by its presence that the pseudonym is required. Refer to 3GPP TS 23.271 [26a].

## Accuracy Fulfilment Indicator

For a mobile terminated periodic LDR, this parameter indicates whether the obtained location estimate satisfies the requested accuracy or not, provided that this indication is obtained from RAN or the UE with the location estimate.

## Periodic LDR Information

This parameter refers to the periodic reporting interval and reporting amount of the deferred periodic location.

#### MO-LR Short Circuit Indicator

This parameter indicates whether MO-LR Short Circuit is permitted for periodic location.

## Reporting PLMN List

This parameter indicates a list of PLMNs in which subsequent periodic MO-LR TTTP requests will be made.

## Sequence Number

This parameter refers to the number of the periodic location reports completed. The sequence number would be set to 1 in the first location report and increment by 1 for each new report. When the number reaches the reporting amount value, the H-GMLC (for a periodic MT-LR or a periodic MO-LR transfer to third party) will know the procedure is complete. For details see 3GPP TS 23.271 [26a].

## User error

This parameter is sent by the responder when the received message contains an error, cannot be forwarded or stored for an LCS client or cannot be accepted for some other reason and if present, takes one of the following values defined in clause 7.6.1.

- System Failure;
- Data Missing;
- Unexpected Data Value;
- Resource Limitation;
- Unknown Subscriber;
- Unauthorised requesting network;
- Unknown or unreachable LCS Client.

## Provider error

These are defined in clause 7.6.1.

230

- 13A.4 Void
- 13A.4.1 Void
- 13A.4.2 Void
- 13A.4.3 Void
- 13A.5 Void
- 13A.5.1 Void
- 13A.5.2 Void
- 13A.5.3 Void
- 13A.6 Void
- 13A.6.1 Void
- 13A.6.2 Void
- 13A.6.3 Void
- 13A.7 Void
- 13A.7.1 Void
- 13A.7.2 Void
- 13A.7.3 Void
- 13A.8 Void
- 13A.8.1 Void
- 13A.8.2 Void
- 13A.8.3 Void
- 13A.9 Void
- 13A.9.1 Void

13A.9.2 Void

13A.9.3 Void

## 14 General

## 14.1 Overview

Clauses 14 to 17 specify the protocol elements to be used to provide the MAP services described in clause 7.

Clause 15 specifies the elements of procedures for the MAP protocol. Clause 16 specifies the mapping onto TC service primitives. Clause 17 specifies the application contexts, operation packages and abstract syntaxes for the MAP protocol as well as the encoding rules to be applied.

# 14.2 Underlying services

The MAP protocol relies on the services provided by the Transaction Capabilities (TC) of Signalling System Number No. 7, as referenced in clause 6.

## 14.3 Model

The MAP Protocol Machine (MAP PM) can be modelled as a collection of service state machines (SSMs) - one per MAP specific service invoked - coordinated by a MAP dialogue control function with its one state machine: MAP dialogue state machine (DSM). There are two types of Service State Machines: Requesting Service State Machines (RSM) and Performing Service State Machines (PSM).

A new invocation of a MAP PM is employed on the receipt of a MAP-OPEN request primitive or a TC-BEGIN indication primitive. Each invocation controls exactly one MAP dialogue. For each MAP specific service invoked during a dialogue, a MAP RSM is created at the requestor's side and a MAP PSM is created at the performer's side.

This modelling is used only to facilitate understanding and the MAP behaviour descriptions and is not intended to suggest any implementation. SDL descriptions are organised according to this model.

How the MAP-service-user and the MAP refer to a MAP dialogue (i.e. a MAP PM invocation) is a local implementation matter.

How TC dialogue identifiers are assigned to a MAP PM invocation is also a local implementation matter.

## 14.4 Conventions

The behaviour of the MAP PM depends on the application-context-name associated with the dialogue. One major difference is that the MAP requests the transfer of the application-context-name by TC only for those contexts which do not belong to the so-called "version one context set".

The "version one context set" is a set of application-contexts which model the behaviour of a MAP V1 implementation according to the latest phase 1 version of GSM 09.02. This set is defined in clause 15.

The procedures described in clause 15 are used when the application-context-name does not refer to a dialogue between an MSC and its VLR. When the application-context-name refers to a dialogue between an MSC and its VLR the MAP PM procedures are a local implementation matter.

# 15 Elements of procedure

# 15.1 Handling of unknown operations

Unknown operations (i.e. a standard operation introduced in a later version of the MAP specification, or a private operation) can be introduced into MAP in a backwards compatible way. This means that the receiver of an unknown operation shall, if the dialogue state allows it, send a TC-REJECT component to the sender of the operation indicating 'unrecognised operation' and continue with the processing of further components or messages exchanged within the dialogue as if the unknown operation had not been received.

The standardised structure of a MAP dialogue shall not be affected by the invocation of unknown operations, i.e. if a dialogue uses only a TC-BEGIN message which is acknowledged by a TC-END message, a TC-CONTINUE message shall not be used to invoke an unknown operation. However the standardised structure of a MAP dialogue may be affected by the rejection of unknown operations, i.e. if a dialogue uses only a TC-BEGIN message which is acknowledged by a TC-END message, a TC-CONTINUE message followed by a TC-END message may be used to carry the rejection of an unknown operation and the response to the standardised operation. The entity which initiated a dialogue whose standardised structure is a TC-BEGIN message which is acknowledged by a TC-END message shall not send any messages in that dialogue after the TC-BEGIN. Note that if the dialogue structure is affected as described in this paragraph the TC-CONTINUE shall include the dialogue portion required to confirm the acceptance of the dialogue.

Unknown operations may be invoked in the following types of message (there is no restriction as to how many unknown operations can be invoked in a message):

- TC-BEGIN: the component to invoke the unknown operation shall follow the component of the standard operation which is included in this message.
- TC-CONTINUE: the component to invoke the unknown operation may be transported as the only component in a stand-alone message or may be grouped with existing operations. In the latter case a specific sequencing of components is not required.
- TC-END: if the component to invoke the unknown operation is grouped with an existing operation a specific sequencing of components is not required

The TC-REJECT component may be sent in the following messages:

- TC-CONTINUE or TC-END: either as the only component of the message or grouped with an existing component. The choice is up to the MAP-Service User.

If the received message contains only unknown operations the MAP-Service User shall send the TC-REJECT components in a TC-CONTINUE message to the peer entity, if the dialogue state allows it.

If the received message contains unknown operations and standard operations and the standardised structure of the dialogue requires the response to the standard operation to be sent within a TC-END message, then the MAP-Service User may send the response to the standard operations and the TC-REJECT components for the unknown operations in a TC-CONTINUE message followed by a TC-END message. Neither a specific distribution of the components to the TC messages nor a specific sequencing of components is required.

Note that the SDL diagrams of clauses 19 - 25 do not show the report to the MAP-Service User about the reception of the unknown operation. This has been done for simplicity of description; the MAP PM may inform the MAP-Service User.

The sender of the unknown operation shall ensure that there is enough room in the used message for the unknown operation.

# 15.2 Dialogue establishment

The establishment of a MAP dialogue involves two MAP-service-users: the dialogue-initiator and the dialogue-responder.

This procedure is driven by the following signals:

- a MAP-OPEN request primitive from the dialogue-initiator;
- a TC-BEGIN indication primitive occurring at the responding side;
- a MAP-OPEN response primitive from the dialogue-responder;
- the first TC-CONTINUE indication primitive occurring at the initiating side;

and under specific conditions:

- a TC-END indication primitive occurring at the initiating side;
- a TC-U-ABORT indication primitive occurring at the initiating side;
- a TC-P-ABORT indication primitive occurring at the initiating side.

One instance of the MAP dialogue state machine runs at the initiating side, and one at the responding side.

## 15.2.1 Behaviour at the initiating side

The behaviour of the MAP dialogue state machine at the initiating side is defined in sheets 1 - 8 of the process MAP\_DSM (figure 15.6/3).

Sheet 3: When the MAP dialogue state machine at the initiating side is waiting for a response from the responding side, a TC-END indication which echoes the AC name which was sent in the TC-BEGIN indicates acceptance of the dialogue.

Sheet 3: If the dialogue opening is accepted, any components included in the TC-END are processed and passed to the MAP-Service User. The dialogue is closed by sending a MAP-CLOSE to the MAP-Service User.

Sheet 3, sheet 4, sheet 5, sheet 6, sheet 7, sheet 8: when a dialogue is terminated, the MAP dialogue state machine terminates all instances of the Requesting\_MAP\_SSM which are active for this dialogue.

Sheet 4: A TC-P-ABORT with an abort parameter Incorrect\_Transaction\_Portion indicates that the responding side does not support a MAP version higher than 1. This triggers a MAP-OPEN confirm indicating that the dialogue is refused, with a refuse reason potential version incompatibility. The MAP-Service User may then decide to retry the dialogue at MAP version 1.

Sheet 8: When the MAP dialogue state machine at the initiating side is waiting for a response from the responding side, a TC-CONTINUE indication which echoes the AC name which was sent in the TC-BEGIN indicates acceptance of the dialogue.

Sheet 8: If the dialogue opening is accepted, any components included in the TC-CONTINUE are processed and passed to the MAP-Service User. The dialogue has then reached the established state.

# 15.2.2 Behaviour at the responding side

The behaviour of the MAP dialogue state machine at the responding side is defined in sheets 0 - 14 of the process MAP\_DSM (figure 15.6/3).

Sheet 9: If no application context information is included in the TC-BEGIN indication, this implies a MAP version 1 dialogue. An explicit application context indicating version 1 is treated as abnormal behaviour.

Sheet 11: The v1 application context name which corresponds to a v1 operation is derived using the information in table 15.2/1.

Table 15.2/1: Mapping of V1 operation codes on to application-context-names

Operation	Application-context-name (note 1)
updateLocation	networkLocUpContext-v1
cancelLocation	locationCancellationContext-v1
provideRoamingNumber	roamingNumberEnquiryContext-v1
insertSubscriberData	subscriberDataMngtContext-v1
deleteSubscriberData	subscriberDataMngtContext-v1
sendParameters	infoRetrievalContext-v1
	networkLocUpContext-v1 (note 2)
beginSubscriberActivity	networkFunctionalSsContext-v1
sendRoutingInfo	locationInfoRetrievalContext-v1
performHandover	handoverControlContext-v1
reset	resetContext-v1
activateTraceMode	tracingContext-v1
deactivateTraceMode	tracingContext-v1
sendRoutingInfoForSM	shortMsgGatewayContext-v1
forwardSM	shortMsgRelayContext-v1
reportSM-deliveryStatus	shortMsgGatewayContext-v1
noteSubscriberPresent	mwdMngtContext-v1
alertServiceCentreWithoutResult	shortMsgAlertContext-v1
checkIMEI	EquipmentMngtContext-v1

NOTE 1: These symbolic names refer to the object identifier value defined in clause 17 and allocated to each application-context used for the MAP.

NOTE 2: The choice between the application contexts is based on the parameters received in the operation.

Sheet 12: If the dialogue is accepted, each component present in the TC-BEGIN is forwarded to an instance of a Performing MAP SSM, by executing the procedure Process Components.

Sheet 13: If the MAP dialogue state machine receives a MAP-OPEN response with a result accepted, it waits for any MAP specific service request or response primitives or a MAP-DELIMITER request.

Sheet 13, sheet 14: When a dialogue is terminated, the MAP dialogue state machine terminates all instances of the Requesting\_MAP\_SSM or Performing\_MAP\_SSM which are active for this dialogue.

Sheet 14: A MAP-DELIMITER request triggers a TC-CONTINUE request to accept the dialogue. The dialogue has then reached the established state.

# 15.3 Dialogue continuation

Once established the dialogue is said to be in a continuation phase. The behaviour of the MAP dialogue state machine in this phase is defined in sheets 15 - 17 of the process MAP\_DSM (figure 15.6/3).

Both MAP users can request the transfer of MAP APDUs until one of them requests the termination of the dialogue.

Normal closure of an established dialogue is shown on sheet 16; abnormal termination is shown on sheet 17.

## 15.4 Load control

If an entity which should respond to a MAP dialogue opening request is overloaded, it uses the AC of the request to determine whether to discard the request.

The priority level allocated to each application-context is described in clause 5, tables 5.1/1, 5.1/2, and 5.1/3.

# 15.5 Procedures for MAP specific services

This clause describes the MAP procedures for MAP specific services. These procedures are driven by the following types of event:

- a MAP specific request or a MAP specific response primitive;

- a component handling primitive from TC.

A Service State Machine is activated when of one of the following signals is received:

- a MAP request primitive, which activates a requesting SSM;
- a TC-INVOKE indication primitive without a linked identifier, which activates a performing SSM.

For component handling primitives there are two types of event:

- events which activate a Service State Machine or which can be related to an existing one;
- events which cannot be related to a Service State Machine.

## 15.5.1 Service invocation

The behaviour of the requesting SSM which handles a service is defined by the SDL for the process Requesting\_MAP\_SSM. The requesting SSM receives a MAP service request from the MAP-Service User via the MAP dialogue state machine and sends a TC-INVOKE request to TCAP. When a confirm is received from TCAP via the MAP dialogue state machine, the requesting SSM forwards a MAP service confirm to the MAP-Service User.

The response to a MAP service invocation may come in the form of a linked request. If the linked request corresponds to a class 4 operation, this is handled by the requesting SSM. If the linked request corresponds to a class 1, 2 or 3 operation, the MAP dialogue state machine sends a notification to the requesting SSM and creates an instance of a performing SSM to handle the linked request. The test "Linked\_Operation\_Allowed" on sheet 3 of the process Requesting\_MAP\_SSM takes the (TRUE) exit if the definition of the parent operation includes the received linked operation as a permitted linked operation; otherwise the test takes the (FALSE) exit.

The mapping of MAP specific services on to remote operations is given in table 16.2/1.

## 15.5.2 Void

## 15.5.3 Service invocation receipt

The behaviour of the performing SSM which handles a service is defined by the SDL for the process Performing\_MAP\_SSM. The performing SSM receives a TC-INVOKE component from TCAP via the MAP dialogue state machine and sends a MAP service indication to the MAP-Service User. When a MAP service response is received from the MAP-Service User via the MAP dialogue state machine, the performing SSM forwards a TC-RESULT or TC-U-ERROR component to TCAP.

## 15.5.4 Void

# 15.5.5 Handling of components received from TC

The procedure Process\_Components shows the handling of components received in a TC-BEGIN, TC-CONTINUE or TC-END message.

Sheet 2: If a linked invoke component corresponds to a class 4 operation, the MAP dialogue state machine sends it to the requesting SSM instance identified by the linked invoke ID. If a linked invoke component corresponds to any other class of operation, the MAP dialogue state machine sends a notification to the requesting SSM instance identified by the linked invoke ID, creates an instance of a performing SSM and sends the invoke component to it.

# 15.6 SDL descriptions

The following SDL specification describes a system which includes three blocks: MAP-user, MAP-provider and TC.

Such a system resides in each network component supporting MAP and communicates with its peers via the lower layers of the signalling network which are part of the environment.

Only the MAP-provider is fully described in this clause. The various types of processes which form the MAP-User block and the TC block are described respectively in clauses 18 to 25 of the present document and in CCITT Recommendation Q.774.

The MAP-Provider block communicates with the MAP\_USER via two channels U1 and U2. Via U1 the MAP-provider receives the MAP request and response primitives. Via U2 it sends the MAP indication and confirm primitives.

The MAP-Provider block communicates with TC via two channels P1 and P2. Via P1 the MAP-Provider sends all the TC request primitives. Via P2 it receives all the TC indication primitives.

The MAP-Provider block is composed of the four following types of process:

- a) MAP\_DSM: This type of process handles a dialogue for transport of MAP messages. There exists one process instance per MAP dialogue.
- b) Load\_Ctrl: This type of process is in charge of load control. There is only one instance of this process in each system.
- c) Requesting\_MAP\_SSM: This type of process handles a MAP service requested during a dialogue. An instance of this process is created by the instance of the MAP\_DSM process for each requested MAP service.
- d) Performing\_MAP\_SSM: This type of process handles a MAP service performed during a dialogue. An instance of this process is created by the instance of the MAP\_DSM process for each MAP service to be performed.

A process MAP\_DSM exchanges external signals with other blocks as well as internal signals with the other processes of the MAP-Provider block. The external signals are either MAP service primitives or TC service primitives.

The signal routes used by the various processes are organised as follows:

- a) A process MAP\_DSM receives and sends events from/to the MAP\_user via signal route User1/User2. These routes use channels U1 and U2 respectively.
- b) A process MAP\_DSM receives and sends events from/to the TCAP via signal route TC1/TC2. These routes use channels P1 and P2 respectively.
- c) A process MAP\_DSM receives and sends events from/to the LOAD\_CTRL process via signal route Load1/Load2. These routes are internal.
- d) A process MAP\_DSM sends events to the Performing\_MAP\_SSM processes via signal route Intern1. This route is internal.
- e) A process MAP\_DSM sends events to the Requesting\_MAP\_SSM processes via signal route Intern2. This route is internal.
- f) A process Performing\_MAP\_SSM sends events to the MAP\_USER via signal route User3. This route uses channel U2.
- g) A process Performing\_MAP\_SSM sends events to the TCAP via signal route TC3. This route uses channel
- h) A process Requesting\_MAP\_SSM sends events to the MAP\_USER via signal route User4. This route uses channel U2.
- i) A process Requesting\_MAP\_SSM sends events to the TCAP via signal route TC4. This route uses channel P1.




Figure 15.6/1: System MAP\_Stack




Figure 15.6/2: Block MAP\_Provider




Figure 15.6/3a: Process MAP\_DSM (sheet 1)




Figure 15.6/3b: Process MAP\_DSM (sheet 2)




Figure 15.6/3c: Process MAP\_DSM (sheet 3)




Figure 15.6/3d: Process MAP\_DSM (sheet 4)




Figure 15.6/3e: Process MAP\_DSM (sheet 5)




Figure 15.6/3f: Process MAP\_DSM (sheet 6)




Figure 15.6/3g: Process MAP\_DSM (sheet 7)




Figure 15.6/3h: Process MAP\_DSM (sheet 8)




Figure 15.6/3i: Process MAP\_DSM (sheet 9)




Figure 15.6/3j: Process MAP\_DSM (sheet 10)




Figure 15.6/3k: Process MAP\_DSM (sheet 11)




Figure 15.6/3I: Process MAP\_DSM (sheet 12)




Figure 15.6/3m: Process MAP\_DSM (sheet 13)




Figure 15.6/3n: Process MAP\_DSM (sheet 14)




Figure 15.6/30: Process MAP\_DSM (sheet 15)




Figure 15.6/3p: Process MAP\_DSM (sheet 16)




Figure 15.6/3q: Process MAP\_DSM (sheet 17)




Figure 15.6/4a: Procedure Process\_Components (sheet 1)




Figure 15.6/4b: Procedure Process\_Components (sheet 2)




Figure 15.6/4c: Procedure Process\_Components (sheet 3)




Figure 15.6/4d: Procedure Process\_Components (sheet 4)




Figure 15.6/4e: Procedure Process\_Components (sheet 5)




Figure 15.6/5: Process Load\_Ctrl




Figure 15.6/6a: Process Requesting\_MAP\_SSM (sheet 1)




Figure 15.6/6b: Process Requesting\_MAP\_SSM (sheet 2)




Figure 15.6/6c: Process Requesting\_MAP\_SSM (sheet 3)




Figure 15.6/6d: Process Requesting\_MAP\_SSM (sheet 4)




Figure 15.6/8a: Process Performing\_MAP\_SSM (sheet 1)




Figure 15.6/8b: Process Performing\_MAP\_SSM (sheet 2)

# 16 Mapping on to TC services

# 16.1 Dialogue control

Dialogue control services are mapped to TC dialogue handling services. The TC-UNI service is not used by the MAP PM

# 16.1.1 Directly mapped parameters

The following parameters of the MAP-OPEN request and indication primitives are directly mapped on to the corresponding parameters of the TC-BEGIN primitives:

- destination address;
- originating address.

# 16.1.2 Use of other parameters of dialogue handling primitives

### 16.1.2.1 Dialogue Id

The value of this parameter is associated with the MAP PM invocation in an implementation dependent manner.

### 16.1.2.2 Application-context-name

The application-context-name parameter of a MAP primitive is mapped to the application-context-name parameter of TC dialogue handling primitives according to the rules described in clause 15.1.

#### 16.1.2.3 User information

The user information parameter of TC dialogue primitives is used to carry the MAP dialogue APDUs.

#### 16.1.2.4 Component present

This parameter is used by the MAP PM as described in CCITT Recommendation Q.771. It is not visible to the MAP user.

#### 16.1.2.5 Termination

The value of this parameter of the TC-END request primitive is set by the MAP PM on the basis of the release method parameter of the MAP-CLOSE request primitive, except when the dialogue state machine is in the state DIALOGUE INITIATED, in which case the Termination parameter shall always indicate "pre-arranged end".

### 16.1.2.6 P-Abort-Cause

Values of the P-abort-cause parameter are mapped to the values of the provider-reason parameter of the MAP-P-ABORT indication primitive according to table 16.1/1, except in the dialogue initiated phase for the "incorrectTransactionPortion" and "noCommonDialoguePortion" values which are mapped to the "potential incompatibility problem" value of the refuse-reason parameter of the MAP-OPEN cnf primitive. The source parameter in the MAP-P-ABORT ind takes the value "TC problem".

# 16.1.2.7 Quality of service

The quality of service of TC request primitives is set by the MAP as shown below.

- Return option: "Return message on error" or "Discard message on error" as required by the network operator;
- Sequence control: "Sequence guaranteed" or "Sequence result not guaranteed" as required by the network operator;
- "Sequence guaranteed" shall be used when a segmented result is to be transferred (e.g. subscriber data in response to SendParameters). It may also be appropriate to use Sequence guaranteed when a series of InsertSubscriberData, ProcessAccessSignalling or ForwardAccessSignalling operations is used.

It is essential that the TC message which indicates acceptance of a dialogue opening request is received by the dialogue initiator before any subsequent message in that dialogue; otherwise the dialogue opening will fail. The dialogue responder shall ensure that this requirement is met by:

- Sending the dialogue acceptance message in a TC-END, if the dialogue structure requires it; or
- Using "Sequence guaranteed", if the dialogue acceptance message is sent in a TC-CONTINUE; or
- Waiting until the dialogue acceptance message has been acknowledged by the dialogue initiator before sending a subsequent message, if the dialogue acceptance message is sent in a TC-CONTINUE.

Table 16.1/1: Mapping of P-Abort cause in TC-P-ABORT indication on to provider-reason in MAP-P-ABORT indication

TC P-Abort cause	MAP provider-reason	
unrecognised message type	provider malfunction	
unrecognised transaction Id	supporting dialogue released	
badlyFormattedTransactionPortion	provider malfunction	
incorrectTransactionPortion	provider malfunction (note)	
resourceLimitation	resource limitation	
abnormalDialogue	provider malfunction	
noCommonDialoguePortion	version incompatibility	
NOTE: Or version incompatibility in the dialogue initiated phase.		

# 16.2 Service specific procedures

Specific services are mapped to TC component handling services.

# 16.2.1 Directly mapped parameters

The Invoke Id parameter of the MAP request and indication primitive is directly mapped on to the Invoke Id parameter of the component handling primitives.

# 16.2.2 Use of other parameters of component handling primitives

### 16.2.2.1 Dialogue Id

The value of this parameter is associated with the MAP PM invocation in an implementation dependent manner.

#### 16.2.2.2 Class

The value of this parameter is set by the MAP PM according to the type of the operation to be invoked.

### 16.2.2.3 Linked Id

When a service response is mapped to a class 4 operation, the value of this parameter is set by the MAP PM and corresponds to the value assigned by the user to the initial service request (i.e. the value of the invoke ID parameter of

the request primitive). Otherwise if such a parameter is included in MAP request/indication primitives it is directly mapped to the linked ID parameter of the associated TC-INVOKE request/indication primitives.

# 16.2.2.4 Operation

When mapping a request primitive on to a Remote Operations PDU (invoke), the MAP PM shall set the operation code according to the mapping described in table 16.2/1.

When mapping a response primitive on to a Remote Operations service, the MAP PM shall set the operation code of the TC-RESULT-L/NL primitive (if required) to the same value as the one received at invocation time.

Table 16.2/1: Mapping of MAP specific services on to MAP operations

MAD CEDVICE	an avation	
MAP-SERVICE	operation	
MAP-ACTIVATE-SS	activateSS	
MAP-ACTIVATE-TRACE-MODE	activateTraceMode	
MAP-ALERT-SERVICE-CENTRE	alertServiceCentre	
MAP-ANY-TIME-INTERROGATION	anyTimeInterrogaton	
MAP_AUTHENTICATION_FAILURE_REPORT	authenticationFailureReport	
MAP-ANY-TIME-MODIFICATION	anyTimeModification	
MAP-ANY-TIME-SUBSCRIPTION-INTERROGATION	anyTimeSubscriptionInterrogation	
MAP-CANCEL-LOCATION	cancelLocation	
MAP-CHECK-IMEI	checkIMEI	
MAP-DEACTIVATE-SS	deactivateSS	
MAP-DEACTIVATE-TRACE-MODE	deactivateTraceMode	
MAP-DELETE-SUBSCRIBER-DATA	deleteSubscriberData	
MAP-ERASE-CC-ENTRY	eraseCC-Entry	
MAP-ERASE-SS	eraseSS	
MAP-FAILURE-REPORT	failureReport	
MAP-FORWARD-ACCESS-SIGNALLING	forwardAccessSignalling	
MAP-FORWARD-CHECK-SS-INDICATION	forwardCheckSsIndication	
MAP-FORWARD-GROUP-CALL-SIGNALLING	forwardGroupCallSignalling	
MAP-MT-FORWARD-SHORT-MESSAGE	mt-forwardSM	
MAP-MO-FORWARD-SHORT-MESSAGE	mo-forwardSM	
MAP-GET-PASSWORD	getPassword	
MAP-INFORM-SERVICE-CENTRE	informServiceCentre	
MAP-INSERT-SUBSCRIBER-DATA	insertSubscriberData	
MAP-INTERROGATE-SS	interrogateSs	
MAP-IST-ALERT	istAlert	
MAP-IST-COMMAND	istCommand	
MAP-NOTE-MS-PRESENT-FOR-GPRS	noteMsPresentForGprs	
MAP-NOTE-SUBSCRIBER-DATA-MODIFIED	noteSubscriberDataModified	
MAP-PREPARE-GROUP-CALL	prepareGroupCall prepareHandover	
MAP-PREPARE-HANDOVER		
MAP-PREPARE-SUBSEQUENT-HANDOVER	prepareSubsequentHandover	
MAP-PROCESS-ACCESS-SIGNALLING	processAccessSignalling	
MAP-PROCESS-GROUP-CALL-SIGNALLING	processGroupCallSignalling	
MAP-PROCESS-UNSTRUCTURED-SS-REQUEST	processUnstructuredSS-Request	
MAP-PROVIDE-ROAMING-NUMBER	provideRoamingNumber	
MAP-PROVIDE-SUBSCRIBER-LOCATION	provideSubscriberLocation	
MAP-PROVIDE-SUBSCRIBER-INFO	provideSubscriberInfo	
MAP-PURGE-MS	purgeMS	
MAP-READY-FOR-SM	readyForSM	
MAP-REGISTER-CC-ENTRY	registerCC-Entry	
MAP-REGISTER-PASSWORD	registerPassword	
MAP-REGISTER-SS	registerSS	
MAP-REMOTE-USER-FREE	remoteUserFree	
MAP-REPORT-SM-DELIVERY-STATUS	reportSmDeliveryStatus	
MAP-RESET	reset	
MAP-RESTORE-DATA	restoreData	
MAP-SEND_GROUP-CALL_END_SIGNAL	sendGroupCallEndSignal	
MAP-SEND-GROUP-CALL-INFO	sendGroupCallInfo	
MAP-SEND-SIGNAL	sendEndSignal	
	1	

MAP-SEND-AUTHENTICATION-INFO	sendAuthenticationInfo
MAP-SEND-IMSI	sendIMSI
MAP-SEND-IDENTIFICATION	sendIdentification
MAP-SEND-ROUTING-INFO-FOR-SM	sendRoutingInfoForSM
MAP-SEND-ROUTING-INFO-FOR-GPRS	sendRoutingInfoForGprs
MAP-SEND-ROUTING-INFO-FOR-LCS	sendRoutingInfoForLCS
MAP-SEND-ROUTING-INFORMATION	sendRoutingInfo
MAP-SET-REPORTING-STATE	setReportingState
MAP-STATUS-REPORT	statusReport
MAP-SUBSCRIBER-LOCATION-REPORT	subscriberLocationReport
MAP-SUPPLEMENTARY-SERVICE-INVOCATION-NOTIFICATION	ss-Invocation-Notification
MAP-UNSTRUCTURED-SS-NOTIFY	unstructuredSS-Notify
MAP-UNSTRUCTURED-SS-REQUEST	unstructuredSS-Request
MAP-UPDATE-GPRS-LOCATION	updateGprsLocation
MAP-UPDATE-LOCATION	updateLocation
MAP-NOTE-MM-EVENT	NoteMM-Event

#### 16.2.2.5 Error

The error parameter in a TC-U-ERROR indication primitive is mapped to the user error parameter in the MAP confirm primitive of the service associated with the operation to which the error is attached.

The user error parameter in MAP response primitives is mapped to the error parameter of the TC-U-ERROR request primitive, except for "initiating-release" and "resource-limitation" which are mapped to the problem code parameter of the TC-U-REJECT request primitive.

#### 16.2.2.6 Parameters

The parameters of MAP specific request and indication primitives are mapped to the argument parameter of TC-INVOKE primitives.

The parameters of MAP specific response and confirm primitives are mapped to the result parameter of TC-RESULT-L primitives, the parameter of TC-U-ERROR primitives or the argument of TC-INVOKE primitives when mapping on linked class 4 operations is used.

#### 16.2.2.7 Time out

The value of this parameter is set by the MAP PM according to the type of operation invoked.

#### 16.2.2.8 Last component

This parameter is used by the MAP PM as described in CCITT Recommendation Q.711. It is not visible from the MAP user.

## 16.2.2.9 Problem code

### 16.2.2.9.1 Mapping to MAP User Error

The following values of the user error parameter are mapped as follows to values of the TC problem code parameter. These values are generated by the MAP user. This mapping is valid from the TC-U-REJECT indication primitive to the MAP confirm service primitive and from the MAP response service primitive to the TC-U-REJECT request primitive.

Table 16.2/2: Mapping of MAP User Error parameter on to TC problem code in TC-U-REJECT primitives

MAP User Error	TC problem code
resource limitation	resource limitation
initiating release	initiating release

# 16.2.2.9.2 Mapping to MAP Provider Error parameter

The following values of the TC problem code parameter of the TC-U-REJECT indication primitive are mapped as follows to values of the MAP Provider Error parameter of the MAP confirm primitive.

Table 16.2/3: Mapping of TC problem code in TC-U-REJECT on to MAP Provider Error parameter

TC problem code	MAP Provider Error
duplicated invoke Id	duplicated invoke id
unrecognised operation	service not supported
mistyped parameter	mistyped parameter

The following values of the problem code parameters of the TC-L-REJECT primitive are mapped to values of the provider error parameter of the MAP confirm primitive as follows.

Table 16.2/4: Mapping of TC problem code in TC-L-REJECT on to MAP Provider Error parameter

TC problem code	MAP Provider Error
return result unexpected	unexpected response from the peer
return error unexpected	unexpected response from the peer

#### 16.2.2.9.3 Mapping to diagnostic parameter

The following values of the problem code parameter of the TC-R-REJECT and TC-U-REJECT primitive are mapped to values of the diagnostic parameter of the MAP-NOTICE indication primitive as follows:

Table 16.2/5: Mapping of TC problem code of TC-R-REJECT and TC-U-REJECT on to diagnostic parameter

TC problem code	MAP diagnostic
General problem	- abnormal event detected by the peer
Invoke problem	
- unrecognised linked ID	- abnormal event detected by the peer
- linked response unexpected	- response rejected by the peer
- unexpected linked operation	- response rejected by the peer
Return result problem	
- unrecognised invoke ID	- response rejected by the peer
- return result unexpected	- response rejected by the peer
- mistyped parameter	- response rejected by the peer
Return error problem	
- unrecognised invoke ID	- response rejected by the peer
- return error unexpected	- response rejected by the peer
- unrecognised error	- response rejected by the peer
- unexpected error	- response rejected by the peer
- mistyped parameter	- response rejected by the peer

The following values of the problem code parameter of the TC-L-REJECT primitive are mapped to values of the diagnostic parameter of the MAP-NOTICE indication primitive as follows.

Table 16.2/6: Mapping of TC problem code of TC-L-REJECT on to diagnostic parameter

TC problem code	MAP diagnostic
General problems	- abnormal event received from the peer
Invoke problem	
- unrecognised linked ID	- abnormal event received from the peer
Return result problem	
- unrecognised invoke ID	- abnormal event received from the peer
Return error problem	
- unrecognised invoke ID	- abnormal event received from the peer

# 17 Abstract syntax of the MAP protocol

# 17.1 General

This clause specifies the Abstract Syntaxes for the Mobile Application Part as well as the associated set of Operations and Errors, using the Abstract Syntax Notation One (ASN.1), defined in ITU-T Recommendations X.680 and X.681 with additions as defined in clause 17.1.4 on Compatibility Considerations and the OPERATION and ERROR external information object classes, defined in ITU-T Recommendation X.880.

The Abstract Syntax is defined for all interfaces specified in clause 4.4 except for the A- and B-interfaces.

The Mobile Application Part protocol is defined by two Abstract Syntaxes:

- one Abstract Syntax which encompass all Operations and Errors identified by the various MAP subsystem numbers.

This Abstract Syntax represents the set of values each of which is a value of the ASN.1 type TCAPMessages. TCMessage as defined in ITU-T Recommendation Q.773 with the component relationconstraint sections resolved by the operation and error codes included in the ASN.1 modules MAP-\*Operations and MAP-Errors. However, only the subset of this abstract syntax which is required by the procedures defined for an entity needs to be supported.

- one Abstract Syntax identified by the OBJECT IDENTIFIER value MAP-DialogueInformation.map-DialogueAS.

This Abstract Syntax represents the set of values each of which is a value of the ASN.1 type MAP-DialogueInformation.MAP-DialoguePDU. Such a value of the ASN.1 single-ASN.1-type element is contained within the user-information element of the TCAPMessages.DialoguePortion ASN.1 type. This Abstract Syntax name is to be used as a direct reference.

# 17.1.1 Encoding rules

The encoding rules which are applicable to the defined Abstract Syntaxes are the Basic Encoding Rules for Abstract Syntax Notation One, defined in ITU-T Recommendation X.690 with the same exceptions as in ITU-T Recommendation Q.773, clause 4 Message Representation.

When the definite form is used for length encoding, a data value of length less than 128 octets must have the length encoded in the short form.

When the long form is employed to code a length, the minimum number of octets shall be used to code the length field.

OCTET STRING values and BIT STRING values must be encoded in a primitive form.

There is no restriction to the use of empty constructors (e.g. an empty SEQUENCE type). That is, the encoding of the content of any data value shall consist of zero, one or more octets.

#### 17.1.2 Use of TC

The mapping of OPERATION and ERROR to TC components is defined in ETS 300 287 (version 2) which is based on ITU-T Recommendation Q.773.

NOTE 1: The class of an operation is not stated explicitly but is specified as well in the ASN.1 operation definition.

Class 1: RESULT and ERROR appear in ASN.1 operation definition.

Class 2: only ERROR appears in ASN.1 operation definition.

Class 3: only RESULT appears in ASN.1 operation definition.

Class 4: both RESULT and ERROR do not appear in ASN.1 operation definition.

The field "ARGUMENT", "PARAMETER" or "RESULT" (for information objects of class OPERATION and ERROR) is always optional from a syntactic point of view. However, except when specifically mentioned with the

ASN.1 comment "-- optional", the "parameter" part of a component has to be considered as mandatory from a semantic point of view.

When an optional element is missing in an invoke component or in an inner data structure while it is required by the context, an error component is returned if specified in the information object associated with the operation; the associated type of error is "DataMissing". This holds also when the entire parameter of an invoke component is missing while it is required by the context.

NOTE 2: When a mandatory element is missing in the parameter or inner data structure of any component, a reject component is returned (if the dialogue still exists). The problem code to be used is "Mistyped parameter".

The Timer Values used in the operation definitions are indicated as ASN.1 comments. The Timer Value Ranges are:

```
s = from 3 seconds to 10 seconds;
```

m = from 15 seconds to 30 seconds;

ml = from 1 minute to 10 minutes;

1 = from 28 hours to 38 hours.

## 17.1.2.1 Use of Global Operation and Error codes defined outside MAP

An entity supporting an application context greater than 2 shall be capable of receiving an operation or error code, within an application context defined in GSM 29.002, encoded as either an Object Identifier (as defined in ITU-T Recommendation X.690) or an integer value (as defined in clause 17.5). Related restrictions regarding the use of Object Identifiers are as follows:

- The length of the Object Identifier shall not exceed 16 octets and the number of components of the Object Identifier shall not exceed 16.
- Object Identifiers shall be used only for operations or errors defined outside of GSM 29.002.
- Global error codes may be sent only in response to a global operation. If a standard operation is received then a global error code shall not be sent in response.

Handling of an unknown operation codes by the receiving entity is defined in clause 15.1.1.

### 17.1.3 Use of information elements defined outside MAP

An information element or a set of information elements (messages) transparently carried in the Mobile Application Part but defined in other recommendations/technical specifications are handled in one of the following ways:

- i) The contents of each information element (without the octets encoding the identifier and the length in the recommendation/technical specification where it is defined unless explicitly stated otherwise) is carried as the value of an ASN.1 type derived from the OCTET STRING data type. Additionally, the internal structure may be explained by means of comments. In case of misalignment the referred to recommendation/technical specification takes precedence.
- ii) The complete information element (including the octets encoding the identifier and the length in the recommendation/technical specification where it is defined) or set of information elements and the identity of the associated protocol are carried as the value of the ExternalSignalInfo data type defined in the present document. Where more than one information element is carried, the information elements are sent contiguously with no filler octets between them.

# 17.1.4 Compatibility considerations

The following ASN.1 modules conform to ITU-T Recommendation X.680 and X.681. An extension marker ("...") is used wherever future protocol extensions are foreseen.

The "..." construct applies only to SEQUENCE and ENUMERATED data types. An entity supporting a version greater than 1 shall not reject an unsupported extension following "..." of that SEQUENCE or ENUMERATED data type. The

Encoding Rules from clause 17.1.1 apply to every element of the whole Transfer Syntax especially to the ASN.1 type EXTERNAL.

The extension container "privateExtensionList" is defined in this specification in order to carry extensions which are defined outside this specification. Private extensions can be defined by, for example, network operators, manufacturers, and regional standardisation bodies.

Private extensions shall:

1) if included in operations of an AC of V2, follow the extension marker and be tagged using PRIVATE tags up to and including 29.

NOTE: This type of extension is in most cases used only within a PLMN.

2) if included in operations of an AC of V3 or higher: be included only in the Private Extension Container that is defined in the specification.

NOTE: This type of extension can be used between PLMNs.

Private extensions shall not be included in v2 supplementary service operations.

Private extensions shall not be included within user error for RegisterCCEntry and EraseCCEntry operations.

PCS extensions shall be included in the PCS Extension Container that is defined in this specification.

In order to improve extensibility, a few error parameters have been defined as a CHOICE between the version 2 description and a SEQUENCE including the version 2 description and an extension container. Operations used in a v2-application-context must consider only the first alternative while operations used in a vn-application-context (n>2) must consider only the second alternative.

# 17.1.5 Structure of the Abstract Syntax of MAP

For each MAP parameter which has to be transferred by a MAP Protocol Data Unit (MAP message), there is a PDU field (an ASN.1 type) which has the same name as the corresponding parameter, except for the differences required by the ASN.1 notation (blanks between words are removed or replaced by hyphen, the first letter of the first word is capital and the first letter of each of the following words ise capitalised, e.g. "no reply condition time" is mapped to "NoReplyConditionTime"). Additionally some words may be abbreviated as follows:

```
bs basic service
ch call handling
      closed user group
cug
ho handover
ic incoming call
id identity
info
      information
mm
      mobility management
lcs location services
ms mobile service
oc outgoing call
om operation & maintenance
pw Password
sm short message service
ss supplementary service
```

The MAP protocol is composed of several ASN.1 modules dealing with either operations, errors, data types, and, if applicable, split into those dealing with mobile services, call handling services, supplementary services and short message services. For operations and errors the code values are given as parameters, in order to allow use of the defined information objects also by other protocols (e.g. 3GPP TS 24.080 [38]). The ASN.1 source lines are preceded by line-numbers at the left margin in order to enable the usage of the cross-reference in annex A.

The module containing the definition of the operation packages for MAP is:

1. MAP-OperationPackages.

The module containing the definition of the application contexts for MAP is:

2. MAP-ApplicationContexts.

The module containing the data types for the Abstract Syntax to be used for TCAPMessages. DialoguePortion for MAP is:

3. MAP-DialogueInformation.

The module containing the supported operations is:

4. MAP-Protocol.

The modules containing all operation definitions for MAP are:

- 5. MAP-MobileServiceOperations;
- 6. MAP-OperationAndMaintenanceOperations;
- 7. MAP-CallHandlingOperations;
- 8. MAP-SupplementaryServiceOperations;
- 9. MAP-ShortMessageServiceOperations;
- 10. MAP-Group-Call-Operations;
- 11. MAP-LocationServiceOperations.

The module containing all error definitions for MAP is:

12. MAP-Errors.

Modules containing all data type definitions for MAP are:

- 13. MAP-MS-DataTypes;
- 14. MAP-OM-DataTypes;
- 15. MAP-CH-DataTypes;
- 16. MAP-SS-DataTypes;
- 17. MAP-SS-Code:
- 18. MAP-SM-DataTypes;
- 19. MAP-ER-DataTypes;
- 20. MAP-CommonDataTypes;
- 21. MAP-TS-Code:
- 22. MAP-BS-Code;
- 23. MAP-ExtensionDataTypes;
- 24. MAP-GR-DataTypes;

25. MAP-LCS-DataTypes.

References are made also to modules defined outside of the present document. They are defined in the technical specification Mobile Services Domain, technical specification Transaction Capability and ITU-T Recommendation X.880 respectively:

MobileDomainDefinitions;

TCAPMessages, DialoguePDUs;

Remote-Operations-Information-Objects.

# 17.1.6 Application Contexts

The following informative table lists the latest versions of the Application Contexts used in this specification, with the operations used by them and, where applicable, whether or not the operation description is exactly the same as for previous versions. Information in 17.6 & 17.7 relates only to the ACs in this table.

AC Name	AC Version	Operations Used	Comments
IocationCancellationContext	v3	cancelLocation	
equipmentMngtContext	V3	checkIMEI	
imsiRetrievalContext	v2	sendIMSI	
infoRetrievalContext	v3	sendAuthenticationInfo	
interVIrInfoRetrievalContext	v3	sendIdentification	
handoverControlContext	v3	prepareHandover forwardAccessSignalling sendEndSignal processAccessSignalling prepareSubsequentHandover	the syntax of this operation has been extended in comparison with release 98 version
mwdMngtContext	v3	readyForSM	
msPurgingContext	v3	purgeMS	
shortMsgAlertContext	v2	alertServiceCentre	
resetContext	v2	reset	
networkUnstructuredSsContext	v2	processUnstructuredSS-Request unstructuredSS-Request unstructuredSS-Notify	
tracingContext	v3	activateTraceMode deactivateTraceMode	
networkFunctionalSsContext	v2	registerSS eraseSS activateSS deactivateSS registerPassword interrogateSS getPassword	
shortMsgMO-RelayContext	v3	mo-forwardSM	
shortMsgMT-RelayContext	v3	mt-forwardSM	
shortMsgMT-VGCS-RelayContext	v3	mt-forwardSM-VGCS	
shortMsgGatewayContext	v3	sendRoutingInfoForSM reportSM-DeliveryStatus InformServiceCentre	the syntax of this operation has been extended in comparison with release 96 version
networkLocUpContext	v3	updateLocation forwardCheckSs-Indication restoreData insertSubscriberData activateTraceMode	the syntax is the same in v1 & v2
gprsLocationUpdateContext	v3	updateGprsLocation insertSubscriberData activateTraceMode	
subscriberDataMngtContext	v3	insertSubscriberData	

AC Name	AC Version	Operations Used	Comments
		deleteSubscriberData	
roamingNumberEnquiryContext	v3	provideRoamingNumber	
locationInfoRetrievalContext	v3	sendRoutingInfo	
gprsNotifyContext	v3	noteMsPresentForGprs	
gprsLocationInfoRetrievalContext	v4	sendRoutingInfoForGprs	
failureReportContext	v3	failureReport	
callControlTransferContext	v4	resumeCallHandling	
subscriberInfoEnquiryContext	v3	provideSubscriberInfo	
anyTimeEnquiryContext	v3	anyTimeInterrogation	
anyTimeInfoHandlingContext	v3	anyTimeSubscriptionInterrogation anyTimeModification	
ss-InvocationNotificationContext	v3	ss-InvocationNotification	
groupCallControlContext	v3	prepareGroupCall processGroupCallSignalling forwardGroupCallSignalling sendGroupCallEndSignal	
reportingContext	v3	setReportingState statusReport remoteUserFree	
callCompletionContext	v3	registerCC-Entry eraseCC-Entry	
istAlertingContext	v3	istAlert	
ServiceTerminationContext	v3	istCommand	
IocationSvcEnquiryContext	v3	provideSubscriberLocation	
		subscriberLocationReport	
IocationSvcGatewayContext	v3	sendRoutingInfoForLCS	
mm-EventReportingContext	v3	noteMM-Event	
subscriber Data Modification Notification Context	v3	noteSubscriberDataModified	
authenticationFailureReportContext	v3	authenticationFailureReport	
resourceManagementContext	v3	releaseResources	
groupCallInfoRetievalContext	V3	sendGroupCallInfo	

NOTE (\*): The syntax of the operations is not the same as in previous versions unless explicitly stated

# 17.2 Operation packages

# 17.2.1 General aspects

This clause describes the operation-packages which are used to build the application-contexts defined in clause 17.3.

Each operation-package is a specification of the roles of a pair of communicating objects (i.e. a pair of MAP-Providers), in terms of operations which they can invoke of each other.

The grouping of operations into one or several packages does not necessarily imply any grouping in terms of Application Service Elements.

The following ASN.1 information object class is used to describe operation-packages in this clause:

```
OPERATION-PACKAGE ::= CLASS {
              OPERATION
                                          OPTIONAL.
     &Both
     &Consumer OPERATION
                                          OPTIONAL,
     &Supplier OPERATION
                                          OPTIONAL,
     &id
              OBJECT IDENTIFIER
                                          UNIQUE OPTIONAL }
WITH SYNTAX {
     [ OPERATIONS
                        &Both 1
     [ CONSUMER INVOKES &Supplier ]
     [ SUPPLIER INVOKES &Consumer ]
                        &id ]
```

Since the application-context definitions provided in clause 17.3 use only an informal description technique, only the type notation is used in the following clauses to define operation-packages.

The following definitions are used throughout this clause (n>=2):

- v1-only operation: An operation which shall be used only in v1 application-contexts;
- vn-only operation: An operation which shall be used only in vn application-contexts;
- v(n-1)-operation: An operation whose specification has not been modified since the MAP v(n-1) specifications or if the modifications are considered as not affecting v(n-1) implementations;
- v(n-1)-equivalent operation: The version of an operation which excludes all the information elements and errors which have been added since the MAP v(n-1) specification;
- vn-only package: An operation package which contains only vn-only operations;
- v(n-1)-package: An operation package which contains only v(n-1)- operations.

The names of vn-packages are suffixed by "-vn" where n>=2.

For each operation package which is not vn-only (n>=2) and which does not include only v(n-1)-operations, there is a v(n-1)-equivalent package. Except when a definition is explicitly provided in the following clauses, the v(n-1)-equivalent package includes the v(n-1)-equivalent operations of the operations which belong to this package.

# 17.2.2 Packages specifications

### 17.2.2.1 Location updating

This operation package includes the operations required for location management procedures between HLR and VLR.

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

#### 17.2.2.2 Location cancellation

This operation package includes the operations required for location cancellation and MS purging procedures between HLR and VLR and between HLR and SGSN.

```
locationCancellationPackage-v3     OPERATION-PACKAGE ::= {
          -- Supplier is VLR or SGSN if Consumer is HLR
          CONSUMER INVOKES {
                cancelLocation}     }
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

# 17.2.2.3 Roaming number enquiry

This operation package includes the operations required for roaming number enquiry procedures between HLR and VLR.

```
roamingNumberEnquiryPackage-v3 OPERATION-PACKAGE ::= {
    -- Supplier is VLR if Consumer is HLR
    CONSUMER INVOKES {
        provideRoamingNumber} }
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

#### 17.2.2.4 Information retrieval

This operation package includes the operation required for the authentication information retrieval procedure between HLR and VLR and between HLR and SGSN.

```
infoRetrievalPackage-v3     OPERATION-PACKAGE ::= {
         -- Supplier is HLR if Consumer is VLR
         -- Supplier is HLR if Consumer is SGSN
         CONSUMER INVOKES {
            sendAuthenticationInfo} }
```

The v2-equivalent package is defined as follows:

```
infoRetrievalPackage-v2     OPERATION-PACKAGE ::= {
         -- Supplier is HLR if Consumer is VLR
         -- Supplier is HLR if Consumer is SGSN
         CONSUMER INVOKES {
            sendAuthenticationInfo} }
```

The v1-equivalent package is defined as follows:

```
infoRetrievalPackage-v1    OPERATION-PACKAGE ::= {
      -- Supplier is HLR or VLR if Consumer is VLR
      -- Supplier is HLR if Consumer is SGSN
      CONSUMER INVOKES {
            sendParameters} }
```

#### 17.2.2.5 Inter-VLR information retrieval

This operation package includes the operations required for inter VLR information retrieval procedures.

```
interVlrInfoRetrievalPackage-v3     OPERATION-PACKAGE ::= {
          -- Supplier is VLR if Consumer is VLR
          CONSUMER INVOKES {
                sendIdentification}     }
```

The v2-equivalent package is defined as follows:

```
interVlrInfoRetrievalPackage-v2    OPERATION-PACKAGE ::= {
          -- Supplier is VLR if Consumer is VLR
          CONSUMER INVOKES {
                sendIdentification} }
```

The v1-equivalent package is : infoRetrievalPackage-v1.

## 17.2.2.6 IMSI retrieval

This operation package includes the operation required for the IMSI retrieval procedure between HLR and VLR.

```
imsiRetrievalPackage-v2     OPERATION-PACKAGE ::= {
         -- Supplier is HLR if Consumer is VLR
          CONSUMER INVOKES {
                sendIMSI}     }
```

This package is v2 only.

#### 17.2.2.7 Call control transfer

This operation package includes the operation required for the call control transfer procedure between VMSC and GMSC.

```
callControlTransferPackage-v4   OPERATION-PACKAGE ::= {
    -- Supplier is GMSC if Consumer is VMSC
    CONSUMER INVOKES {
        resumeCallHandling} }
```

The v3-equivalent package can be determined according to the rules described in clause 17.2.1.

17.2.2.8 Void

17.2.2.9 Void

### 17.2.2.10 Interrogation

This operation package includes the operations required for interrogation procedures between MSC and HLR or NPLR or between HLR and gsmSCF.

```
interrogationPackage-v3     OPERATION-PACKAGE ::= {
         -- Supplier is HLR or NPLR if Consumer is MSC
         -- Supplier is HLR if Consumer is gsmSCF
         CONSUMER INVOKES {
            sendRoutingInfo} }
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

#### 17.2.2.11 Void

#### 17.2.2.12 Handover Control

This operation package includes the operations required for handover procedures between MSCs.

```
handoverControlPackage-v3 OPERATION-PACKAGE ::= {
    -- Supplier is MSCB if Consumer is MSCA
    CONSUMER INVOKES {
        prepareHandover |
        forwardAccessSignalling}
    SUPPLIER INVOKES {
        sendEndSignal |
        processAccessSignalling |
        prepareSubsequentHandover} }
```

The v2-equivalent package can be determined according to the rules described in clause 17.2.1.

The v1-equivalent package is defined as follows.

```
handoverControlPackage-v1 OPERATION-PACKAGE ::= {
    -- Supplier is MSCB if Consumer is MSCA
    CONSUMER INVOKES {
        performHandover |
        forwardAccessSignalling |
        traceSubscriberActivity}
    SUPPLIER INVOKES {
        sendEndSignal |
        noteInternalHandover |
        processAccessSignalling |
        performSubsequentHandover} }
```

# 17.2.2.13 Subscriber Data management stand alone

This operation package includes the operations required for stand alone subscriber data management procedures between HLR and VLR or between HLR and SGSN.

```
subscriberDataMngtStandAlonePackage-v3    OPERATION-PACKAGE ::= {
          -- Supplier is VLR or SGSN if Consumer is HLR
          CONSUMER INVOKES {
            insertSubscriberData |
            deleteSubscriberData} }
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

# 17.2.2.14 Equipment management

This operation package includes the operations required for equipment management procedures between EIR and MSC or between EIR and SGSN.

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

## 17.2.2.15 Subscriber data management

This operation package includes the operations required for subscriber data management procedures between HLR and VLR or between HLR and SGSN.

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

# 17.2.2.16 Location register restart

This operation package includes the operations required for location register restart procedures between HLR and VLR or between HLR and SGSN.

The v1-equivalent package can be determined according to the rules described in clause 17.2.1.

# 17.2.2.17 Tracing stand-alone

This operation package includes the operations required for stand alone tracing procedures between HLR and VLR or between HLR and SGSN.

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

# 17.2.2.18 Functional SS handling

This operation package includes the operations required for functional supplementary services procedures between VLR and HLR.

The v1-equivalent package can be determined according to the rules described in clause 17.2.1.

### 17.2.2.19 Tracing

This operation package includes the operations required for tracing procedures between HLR and VLR or between HLR and SGSN.

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

### 17.2.2.20 Binding

This operation package includes the operation required to initialise a supplementary service procedure between VLR and HLR or between gsmSCF and HLR.

```
bindingPackage-v1 OPERATION-PACKAGE ::= {
    -- Supplier is HLR if Consumer is VLR
    -- Supplier is gsmSCF if Consumer is HLR
    CONSUMER INVOKES {
        beginSubscriberActivity} }
```

This package is v1 only.

# 17.2.2.21 Unstructured SS handling

This operation package includes the operations required for unstructured supplementary services procedures between VLR and HLR, between the HLR and the gsmSCF, and between HLR and HLR.

The v1-equivalent package is defined as follows:

```
unstructuredSsPackage-v1 OPERATION-PACKAGE ::= {
    -- Supplier is HLR if Consumer is VLR
    -- Supplier is gsmSCF if Consumer is HLR
    CONSUMER INVOKES {
        processUnstructuredSS-Data} }
```

# 17.2.2.22 MO Short message relay services

This operation package includes the operations required for short message relay service procedures between IWMSC and VMSC or between GMSC and MSC or between SGSN and IWMSC.

```
The v2-equivalent package is defined as follows:

shortMsgRelayPackage-v2 OPERATION-PACKAGE ::= {

-- Supplier is IWMSC if Consumer is MSC

-- Supplier is MSC or SGSN if Consumer is GMSC

-- Supplier is IWMSC if Consumer is SGSN

CONSUMER INVOKES {

forwardSM} }
```

The v1-equivalent package can be determined according to the rules described in clause 17.2.1.

## 17.2.2.23 Short message gateway services

This operation package includes the operations required for short message service gateway procedures between MSC and HLR.

The v2-equivalent package can be determined according to the rules described in clause 17.2.1.

The v1-equivalent package is defined as follows:

#### 17.2.2.24 MT Short message relay services

This operation package includes the operations required for short message relay service procedures between GMSC and MSC or between GMSC and SGSN.

The v2-equivalent package is: shortMsgRelayPackage-v2

#### 17.2.2.25 Void

# 17.2.2.26 Message waiting data management

This operation package includes the operations required for short message waiting data procedures between HLR and VLR, between HLR and SGSN.

The v2-equivalent package can be determined according to the rules described in clause 17.2.1.

The v1-equivalent package is defined as follows:

```
mwdMngtPackage-v1 OPERATION-PACKAGE ::= {
    -- Supplier is HLR if Consumer is VLR
    CONSUMER INVOKES {
        noteSubscriberPresent }
}
```

### 17.2.2.27 Alerting

This operation package includes the operations required for alerting between HLR and IWMSC.

```
alertingPackage-v2 OPERATION-PACKAGE ::= {
    -- Supplier is IWMSC if Consumer is HLR
    CONSUMER INVOKES {
        alertServiceCentre} }
```

The v1-equivalent package is defined as follows.

```
alertingPackage-v1 OPERATION-PACKAGE ::= {
    -- Supplier is IWMSC if Consumer is HLR
    CONSUMER INVOKES {
        alertServiceCentreWithoutResult} }
```

### 17.2.2.28 Data restoration

This operation package includes the operations required for VLR data restoration between HLR and VLR.

```
dataRestorationPackage-v3    OPERATION-PACKAGE ::= {
         -- Supplier is HLR if Consumer is VLR
         CONSUMER INVOKES {
            restoreData}    }
```

The v2-equivalent package can be determined according to the rules described in clause 17.2.1.

The v1-equivalent package is: infoRetrievalPackage-v1

#### 17.2.2.29 Purging

This operation package includes the operations required for purging between HLR and VLR or between HLR and SGSN.

```
purgingPackage-v3      OPERATION-PACKAGE ::= {
            -- Supplier is HLR if Consumer is VLR
            -- Supplier is HLR if Consumer is SGSN
            CONSUMER INVOKES {
                purgeMS}      }
```

The v2-equivalent package can be determined according to the rules described in clause 17.2.1.

# 17.2.2.30 Subscriber information enquiry

This operation package includes the operations required for subscriber information enquiry procedures between HLR and VLR or between HLR and SGSN.

```
subscriberInformationEnquiryPackage-v3     OPERATION-PACKAGE ::= {
          -- Supplier is VLR or SGSN if Consumer is HLR
          CONSUMER INVOKES {
                provideSubscriberInfo} }
```

This package is v3 only.

# 17.2.2.31 Any time information enquiry

This operation package includes the operations required for any time information enquiry procedures between gsmSCF and HLR or between gsmSCF and GMLC or between gsmSCF and NPLR.

```
anyTimeInformationEnquiryPackage-v3 OPERATION-PACKAGE ::= {
    -- Supplier is HLR or GMLC or NPLR if Consumer is gsmSCF
    CONSUMER INVOKES {
        anyTimeInterrogation} }
```

This package is v3 only.

# 17.2.2.32 Group Call Control

This operation package includes the operations required for group call and broadcast call procedures between MSCs.

This package is v3 only.

## 17.2.2.32A Group Call Info Retrieval

This operation package includes the operations required for group call and broadcast call info retrieval between MSCs.

```
groupCallInfoRetrievalPackage-v3 OPERATION-PACKAGE ::= {
    -- Supplier is group call serving MSC if Consumer is visited MSC
    -- Supplier is visited MSC if Consumer is group call serving MSC
    CONSUMER INVOKES {
        sendGroupCallInfo} }
```

This package is v3 only.

17.2.2.33 Void

17.2.2.34 Void

## 17.2.2.35 Gprs location updating

This operation package includes the operations required for the gprs location management procedures between HLR and SGSN.

```
gprsLocationUpdatingPackage-v3 OPERATION-PACKAGE ::= {
    -- Supplier is HLR if Consumer is SGSN
    CONSUMER INVOKES {
        updateGprsLocation} }
```

This package is v3 only.

# 17.2.2.36 Gprs Interrogation

This operation package includes the operations required for interrogation procedures between HLR and GGSN.

```
gprsInterrogationPackage-v4 OPERATION-PACKAGE ::= {
    -- Supplier is HLR if Consumer is GGSN
    CONSUMER INVOKES {
       sendRoutingInfoForGprs} }
```

The v3-equivalent package is defined as follows.

```
gprsInterrogationPackage-v3    OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is GGSN
     CONSUMER INVOKES {
        sendRoutingInfoForGprs} }
```

### 17.2.2.37 Failure reporting

This operation package includes the operations required for failure reporting between HLR and GGSN.

```
failureReportingPackage-v3     OPERATION-PACKAGE ::= {
          -- Supplier is HLR if Consumer is GGSN
          CONSUMER INVOKES {
                failureReport}     }
```

This package is v3 only.

# 17.2.2.38 GPRS notifying

This operation package includes the operations required for notifying that GPRS subscriber is present between HLR and GGSN.

This package is v3 only.

## 17.2.2.39 Supplementary Service invocation notification

This operation package includes the operations required for Supplementary Service invocation notification procedures between the MSC and the gsmSCF and between the HLR and the gsmSCF.

This package is v3 only.

## 17.2.2.40 Set Reporting State

This operation package includes the operation required for procedures between HLR and VLR to set the reporting state.

```
setReportingStatePackage-v3 OPERATION-PACKAGE ::= {
    -- Supplier is VLR if Consumer is HLR
    CONSUMER INVOKES {
        setReportingState} }
```

This package is v3 only.

## 17.2.2.41 Status Report

This operation package includes the operation required for procedures between VLR and HLR to report call results and events.

```
statusReportPackage-v3    OPERATION-PACKAGE ::= {
      -- Supplier is HLR if Consumer is VLR
      CONSUMER INVOKES {
         statusReport} }
```

This package is v3 only.

#### 17.2.2.42 Remote User Free

This operation package includes the operation required by the HLR to indicate to the VLR that the remote user is free.

This package is v3 only.

#### 17.2.2.43 Call Completion

This operation package includes the operations required for procedures between VLR and HLR for subscriber control of call completion services.

```
callCompletionPackage-v3    OPERATION-PACKAGE ::= {
         -- Supplier is HLR if Consumer is VLR
         CONSUMER INVOKES {
            registerCC-Entry |
            eraseCC-Entry} }
```

This package is v3 only.

## 17.2.2.44 Location service gateway services

This operation package includes the operations required for location service gateway procedures between GMLC and HLR.

This package is v3 only.

#### 17.2.2.45 Location service enquiry

This operation package includes the operations required for the location service enquiry procedures between GMLC and MSC and between GMLC and SGSN.

```
locationSvcEnquiryPackage-v3    OPERATION-PACKAGE ::= {
          -- Supplier is MSC or SGSN if Consumer is GMLC
           CONSUMER INVOKES {
                provideSubscriberLocation} }
```

This package is v3 only.

### 17.2.2.45A Location service reporting

This operation package includes the operations required for the location service enquiry procedures between MSC and GMLC and between SGSN and GMLC.

```
locationSvcReportingPackage-v3    OPERATION-PACKAGE ::= {
         -- Supplier is GMLC if Consumer is MSC
         -- Supplier is GMLC if Consumer is SGSN
         CONSUMER INVOKES {
            subscriberLocationReport} }
```

17.2.2.46 Void

17.2.2.47 Void

17.2.2.48 Void

## 17.2.2.49 IST Alerting

This operation package includes the operation required for alerting procedures between the MSC (Visited MSC or Gateway MSC) and HLR.

```
ist-AlertingPackage-v3     OPERATION-PACKAGE ::= {
          -- Supplier is HLR if Consumer is VMSC
          -- Supplier is HLR if Consumer is GMSC
          CONSUMER INVOKES {
               istAlert} }
```

This package is v3 only.

#### 17.2.2.50 Service Termination

This operation package includes the operation required for immediate service termination procedures between the HLR and the Visited MSC or between the HLR and the Gateway MSC.

```
serviceTerminationPackage-v3    OPERATION-PACKAGE ::= {
          -- Supplier is VMSC or GMSC if Consumer is HLR
           CONSUMER INVOKES {
                istCommand}    }
```

This package is v3 only.

## 17.2.2.51 Mobility Management event notification

This operation package includes the operations required for Mobility Management event notification procedures between VLR and gsmSCF.

This package is v3 only.

## 17.2.2.52 Any time information handling

This operation package includes the operations required for any time information handling procedures between gsmSCF and HLR.

This package is v3 only.

### 17.2.2.53 Subscriber Data modification notification

This operation package includes the operations required for Subscriber Data modification notification procedures between HLR and gsmSCF.

This package is v3 only.

#### 17.2.2.54 Authentication Failure Report

This operation package includes the operation required for procedures between VLR and HLR or the SGSN and the HLR for reporting of authentication failures.

```
authenticationFailureReportPackage-v3    OPERATION-PACKAGE ::= {
        -- Supplier is HLR if Consumer is VLR
        -- Supplier is HLR if Consumer is SGSN
        CONSUMER INVOKES {
            authenticationFailureReport} }
```

This package is v3 only.

#### 17.2.2.55 Resource Management

This operation package includes the operation required for procedures between GMSC and VMSC for resource management purpose.

```
resourceManagementPackage-v3     OPERATION-PACKAGE ::= {
          -- Supplier is VMSC if Consumer is GMSC
          CONSUMER INVOKES {
            releaseResources}     }
```

This package is v3 only.

## 17.2.2.56 MT Short message relay VGCS services

This operation package includes the operations required for short message relay service procedures between SMS GMSC and MSC.

This package is v3 only.

## 17.3 Application contexts

## 17.3.1 General aspects

An application-context is assigned for each dialogue established by a MAP-user. In the present document each application-context is assigned a name which is supplied in the MAP-OPEN Req primitive by the MAP-User and transmitted to the peer under certain circumstances.

The following ASN.1 information object class is used to describe the main aspects of application-contexts in the following clauses:

The following definitions are used throughout this clause:

- v1-application-context: An application-context which contains only v1-packages and uses only TC v1 facilities;
- v1 context set: the set of v1-application-contexts defined in the present document.
- vn-application-context (n>=2): An application-context which contains only vn-packages;

The names of v1-application-contexts are suffixed by "-v1" while other names are suffixed by "-vn" where  $n \ge 2$ .

Application-contexts which do not belong to the v1 context set use v2 TC facilities.

The last component of each application-context-name (i.e. the last component of the object identifier value) assigned to an application-context which belongs to the v1 context set indicates explicitly "version1".

For each application-context which does not belong to the "v1 context set" there is a v1-equivalent application context. This is a v1-application-context which includes the v1-equivalents of the packages included in the original context.

Each application-context uses the abstract-syntax associated with the operation-packages it includes and uses the transfer-syntax derived from it by applying the encoding rules defined in clause 17.1.1.

ACs which do not belong to the v1 context set require the support of the abstract-syntax identified by the object identifier value: MAP-DialogueInformation.map-Dialogue-AS defined in clause 17.4.

## 17.3.2 Application context definitions

## 17.3.2.1 Void

#### 17.3.2.2 Location Updating

This application context is used between HLR and VLR for location updating procedures.

```
networkLocUpContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is HLR if Initiator is VLR
    INITIATOR CONSUMER OF {
        locationUpdatingPackage-v3 |
        dataRestorationPackage-v3}
    RESPONDER CONSUMER OF {
        subscriberDataMngtPackage-v3 |
        tracingPackage-v3}
    ID {map-ac networkLocUp(1) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
ID {map-ac networkLocUp(1) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
ID {map-ac networkLocUp(1) version1(1)}
```

#### 17.3.2.3 Location Cancellation

This application context is used between HLR and VLR or between HLR and SGSN for location cancellation procedures. For the HLR - SGSN interface only version 3 of this application context is applicable.

The following application-context-name is assigned to the v2-equivalent application-context:

```
ID map-ac locationCancel(2) version2(2)
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
ID map-ac locationCancel(2) version1(1)
```

#### 17.3.2.4 Roaming number enquiry

This application context is used between HLR and VLR for roaming number enquiry procedures.

```
roamingNumberEnquiryContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is VLR if Initiator is HLR
    INITIATOR CONSUMER OF {
        roamingNumberEnquiryPackage-v3}
    ID {map-ac roamingNbEnquiry(3) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
ID {map-ac roamingNbEnquiry(3) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
ID {map-ac roamingNbEnquiry(3) version1(1)}
```

#### 17.3.2.5 Void

#### 17.3.2.6 Location Information Retrieval

This application-context is used between GMSC and HLR or between GMSC and NPLR or between gsmSCF and HLR when retrieving location information. For the GMSC - NPLR interface version 1, version 2 and version 3 of this application context are applicable.

```
locationInfoRetrievalContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is HLR or NPLR if Initiator is GMSC
    -- Responder is HLR if Initiator is gsmSCF
    INITIATOR CONSUMER OF {
        interrogationPackage-v3}
    ID {map-ac locInfoRetrieval(5) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
ID {map-ac locInfoRetrieval(5) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
ID {map-ac locInfoRetrieval(5) version1(1)}
```

#### 17.3.2.7 Call control transfer

This application context is used for the call control transfer procedure between the VMSC and the GMSC.

```
callControlTransferContext-v4 APPLICATION-CONTEXT ::= {
    -- Responder is GMSC if Initiator is VMSC
    INITIATOR CONSUMER OF {
        callControlTransferPackage-v4}
    ID {map-ac callControlTransfer(6) version4(4)} }
```

The following application-context-name is assigned to the v3-equivalent application-context:

```
ID {map-ac callControlTransfer(6) version3(3)}
```

17.3.2.8 Void

17.3.2.9 Void

17.3.2.10 Void

## 17.3.2.11 Location registers restart

This application context is used between HLR and VLR or between HLR and SGSN for location register restart procedures. For the HLR - SGSN interface version 1 and version 2 of this application context are applicable.

```
resetContext-v2 APPLICATION-CONTEXT ::= {
    -- Responder is VLR or SGSN if Initiator is HLR
    INITIATOR CONSUMER OF {
        resetPackage-v2}
    ID {map-ac reset(10) version2(2)} }
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
ID {map-ac reset(10) version1(1)}
```

#### 17.3.2.12 Handover control

This application context is used for handover procedures between MSCs.

```
handoverControlContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is MSCB if Initiator is MSCA
    INITIATOR CONSUMER OF {
        handoverControlPackage-v3}
    ID {map-ac handoverControl(11) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
ID {map-ac handoverControl(11) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
ID {map-ac handoverControl(11) version1(1)}
```

#### 17.3.2.13 IMSI Retrieval

This application context is used for IMSI retrieval between HLR and VLR.

```
imsiRetrievalContext-v2 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is VLR
     INITIATOR CONSUMER OF {
         imsi-RetrievalPackage-v2}
     ID {map-ac imsiRetrieval(26) version2(2)} }
```

This application-context is v2 only.

## 17.3.2.14 Equipment Management

This application context is used for equipment checking between MSC and EIR or between SGSN and EIR. For the SGSN - EIR interface version 1 and version 2 and version 3 of this application context are applicable:

```
equipmentMngtContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is EIR if Initiator is MSC
    -- Responder is EIR if Initiator is SGSN
    INITIATOR CONSUMER OF {
        equipmentMngtPackage-v3}
    ID {map-ac equipmentMngt(13) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
equipmentMngtContext-v2 APPLICATION-CONTEXT ::= {
    -- Responder is EIR if Initiator is MSC
    -- Responder is EIR if Initiator is SGSN
    INITIATOR CONSUMER OF {
        equipmentMngtPackage-v2}
    ID {map-ac equipmentMngt(13) version2(2)} }
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
ID {map-ac equipmentMngt(13) version1(1)}
```

## 17.3.2.15 Information retrieval

This application context is used for authentication information retrieval between HLR and VLR or between HLR and SGSN. For the HLR - SGSN interface version 1 and version 2 and version 3 of this application context are applicable.

```
infoRetrievalContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is HLR if Initiator is VLR
    -- Responder is HLR if Initiator is SGSN
    INITIATOR CONSUMER OF {
        infoRetrievalPackage-v3}
    ID {map-ac infoRetrieval(14) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
infoRetrievalContext-v2 APPLICATION-CONTEXT ::= {
    -- Responder is HLR if Initiator is VLR
    -- Responder is HLR if Initiator is SGSN
    INITIATOR CONSUMER OF {
        infoRetrievalPackage-v2}
    ID {map-ac infoRetrieval(14) version2(2)} }
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
ID {map-ac infoRetrieval(14) version1(1)}
```

#### 17.3.2.16 Inter-VLR information retrieval

This application context is used for information retrieval between VLRs.

```
interVlrInfoRetrievalContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is VLR if Initiator is VLR
    INITIATOR CONSUMER OF {
        interVlrInfoRetrievalPackage-v3}
    ID {map-ac interVlrInfoRetrieval(15) version3(3)} }
```

The v2-equivalent application-context is:

```
interVlrInfoRetrievalContext-v2 APPLICATION-CONTEXT ::= {
    -- Responder is VLR if Initiator is VLR
    INITIATOR CONSUMER OF {
        interVlrInfoRetrievalPackage-v2}
    ID {map-ac interVlrInfoRetrieval(15) version2(2)} }
```

The v1-equivalent application-context is:

```
ID \{ map-ac infoRetrieval(14) version1(1) \}
```

### 17.3.2.17 Stand Alone Subscriber Data Management

This application context is used for stand alone subscriber data management between HLR and VLR or between HLR and SGSN. For the HLR - SGSN interface only version 3 of this application context is applicable:

```
subscriberDataMngtContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is VLR or SGSN if Initiator is HLR
    INITIATOR CONSUMER OF {
        subscriberDataMngtStandAlonePackage-v3}
    ID {map-ac subscriberDataMngt(16) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
ID {map-ac subscriberDataMngt(16) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
ID {map-ac subscriberDataMngt(16) version1(1)}
```

## 17.3.2.18 Tracing

This application context is used between HLR and VLR or between HLR and SGSN for stand alone tracing control procedures. For the HLR - SGSN interface version 1, version 2 and version 3 of this application context are applicable.

```
tracingContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is VLR or SGSN if Initiator is HLR
    INITIATOR CONSUMER OF {
        tracingStandAlonePackage-v3}
    ID {map-ac tracing(17) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
ID {map-ac tracing(17) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
ID {map-ac tracing(17) version1(1)}
```

## 17.3.2.19 Network functional SS handling

This application context is used for functional-like SS handling procedures between VLR and HLR.

```
networkFunctionalSsContext-v2 APPLICATION-CONTEXT ::= {
    -- Responder is HLR, Initiator is VLR
    INITIATOR CONSUMER OF {
        functionalSsPackage-v2}
    ID {map-ac networkFunctionalSs(18) version2(2)} }
```

The v1-equivalent application-context is defined as follows:

#### 17.3.2.20 Network unstructured SS handling

This application context is used for handling stimuli-like procedures between HLR and VLR, between the HLR and gsmSCF, and between HLR and HLR.

The following application-context-name is assigned to the v1-equivalent application-context:

```
ID {map-ac networkFunctionalSs(18) version1(1)}
```

#### 17.3.2.21 Short Message Gateway

This application context is used for short message gateway procedures.

```
shortMsgGatewayContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is HLR if Initiator is GMSC
    INITIATOR CONSUMER OF {
        shortMsgGatewayPackage-v3}
    ID {map-ac shortMsgGateway(20) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
ID {map-ac shortMsgGateway(20) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
ID {map-ac shortMsgGateway(20) version1(1)}
```

## 17.3.2.22 Mobile originating Short Message Relay

This application context is used between MSC and IWMSC or between SGSN and IWMSC for mobile originating short message relay procedures. For the SGSN - IWMSC interface version 1, version 2 and version 3 of this application context are applicable.

```
shortMsgMO-RelayContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is IWMSC if Initiator is MSC
     -- Responder is IWMSC if Initiator is SGSN
     INITIATOR CONSUMER OF {
               mo-ShortMsgRelayPackage-v3}
        ID {map-ac shortMsgMO-Relay(21) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
ID {map-ac shortMsgMO-Relay(21) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
ID {map-ac shortMsg-Relay(21) version1(1)}
```

#### 17.3.2.23 Void

### 17.3.2.24 Short message alert

This application context is used for short message alerting procedures.

```
shortMsgAlertContext-v2 APPLICATION-CONTEXT ::= {
    -- Responder is IWMSC if Initiator is HLR
    INITIATOR CONSUMER OF {
        alertingPackage-v2}
    ID {map-ac shortMsgAlert(23) version2(2)} }
```

The following application-context-name is symbolically assigned to the v1-equivalent application-context:

```
ID {map-ac shortMsgAlert(23) version1(1)}
```

#### 17.3.2.25 Short message waiting data management

This application context is used between VLR and HLR or between SGSN and HLR for short message waiting data management procedures. For the SGSN - HLR interface only version 3 of this application context is applicable.

```
mwdMngtContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is HLR if Initiator is SGSN
    -- Responder is HLR if Initiator is VLR
    INITIATOR CONSUMER OF {
        mwdMngtPackage-v3}
    ID {map-ac mwdMngt(24) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
ID {map-ac mwdMngt(24) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
ID \{map-ac mwdMngt(24) version1(1)\}
```

## 17.3.2.26 Mobile terminating Short Message Relay

This application context is used between GMSC and MSC or between GMSC and SGSN for mobile terminating short message relay procedures. For the GMSC - SGSN interface version 2 and version 3 of this application context and the equivalent version 1 application context are applicable.

```
shortMsgMT-RelayContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is MSC or SGSN if Initiator is GMSC
     INITIATOR CONSUMER OF {
        mt-ShortMsgRelayPackage-v3}
     ID {map-ac shortMsgMT-Relay(25) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
ID {map-ac shortMsgMT-Relay(25) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
ID {map-ac shortMsg-Relay(21) version1(1)}
```

### 17.3.2.27 MS purging

This application context is used between HLR and VLR or between HLR and SGSN for MS purging procedures. For the SGSN - HLR interface only version 3 of this application context is applicable.

```
msPurgingContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is HLR if Initiator is VLR
    -- Responder is HLR if Initiator is SGSN
    INITIATOR CONSUMER OF {
        purgingPackage-v3}
    ID {map-ac msPurging(27) version3(3)}
}
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
ID {map-ac msPurging(27) version2(2)}
```

#### 17.3.2.28 Subscriber information enquiry

This application context is used between HLR and VLR or between HLR and SGSN for subscriber information enquiry procedures.

```
subscriberInfoEnquiryContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is VLR or SGSN if Initiator is HLR
    INITIATOR CONSUMER OF {
        subscriberInformationEnquiryPackage-v3}
    ID {map-ac subscriberInfoEnquiry(28) version3(3)} }
```

This application-context is v3 only.

#### 17.3.2.29 Any time information enquiry

This application context is used between gsmSCF and HLR or between gsmSCF and GMLC or between gsmSCF and NPLR for any time information enquiry procedures.

```
anyTimeInfoEnquiryContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is HLR or GMLC or NPLR if Initiator is gsmSCF
    INITIATOR CONSUMER OF {
        anyTimeInformationEnquiryPackage-v3}
    ID {map-ac anyTimeInfoEnquiry(29) version3(3)} }
```

## 17.3.2.30 Group Call Control

This application context is used between anchor MSC and relay MSC for group call and broadcast call procedures.

```
groupCallControlContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is relay MSC if Initiator is anchor MSC
     INITIATOR CONSUMER OF {
          groupCallControlPackage-v3}
     ID {map-ac groupCallControl(31) version3(3)} }
```

This application-context is v3 only.

## 17.3.2.30A Group Call Info Retrieval

This application context is used between group call serving MSC and visited MSC for group call and broadcast call procedures.

```
groupCallInfoRetControlContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is group call serving MSC if Initiator is visited MSC
    -- Responder is visited MSC if Initiator is group call serving MSC
    INITIATOR CONSUMER OF {
        groupCallInfoRetrievalPackage-v3}
    ID {map-ac groupCallInfoRetrieval(45) version3(3)} }
```

This application-context is v3 only.

#### 17.3.2.31 Void

## 17.3.2.32 Gprs Location Updating

This application context is used between HLR and SGSN for gprs location updating procedures.

```
gprsLocationUpdateContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is HLR if Initiator is SGSN
    INITIATOR CONSUMER OF {
        gprsLocationUpdatingPackage-v3}
    RESPONDER CONSUMER OF {
        subscriberDataMngtPackage-v3 |
        tracingPackage-v3}
    ID {map-ac gprsLocationUpdate(32) version3(3)} }
```

This application-context is v3 only.

## 17.3.2.33 Gprs Location Information Retreival

This application context is used between HLR and GGSN when retrieving gprs location information.

```
gprsLocationInfoRetrievalContext-v4 APPLICATION-CONTEXT ::= {
    -- Responder is HLR if Initiator is GGSN
    INITIATOR CONSUMER OF {
        gprsInterrogationPackage-v4}
    ID {map-ac gprsLocationInfoRetrieval(33) version4(4)} }
```

The following application-context-name is assigned to the v3-equivalent application-context:

```
ID {map-ac gprsLocationInfoRetrieval(33) version3(3)}
```

## 17.3.2.34 Failure Reporting

This application context is used between HLR and GGSN to inform that network requested PDP-context activation has failed.

```
failureReportContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is HLR if Initiator is GGSN
    INITIATOR CONSUMER OF {
        failureReportingPackage-v3}
    ID {map-ac failureReport(34) version3(3)} }
```

This application-context is v3 only.

## 17.3.2.35 GPRS Notifying

This application context is used between HLR and GGSN for notifying that GPRS subscriber is present again.

```
gprsNotifyContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is GGSN if Initiator is HLR
    INITIATOR CONSUMER OF {
        gprsNotifyingPackage-v3}
    ID {map-ac gprsNotify(35) version3(3)} }
```

This application-context is v3 only.

## 17.3.2.36 Supplementary Service invocation notification

This application context is used between the MSC and the gsmSCF and between the HLR and the gsmSCF for Supplementary Service invocation notification procedures.

```
ss-InvocationNotificationContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is gsmSCF, Initiator is MSC
    -- Responder is gsmSCF, Initiator is HLR
    INITIATOR CONSUMER OF {
        ss-InvocationNotificationPackage-v3}
    ID {map-ac ss-InvocationNotification(36) version3(3)} }
```

This application-context is v3 only.

#### 17.3.2.37 Reporting

This application context is used between HLR and VLR for reporting procedures.

```
reportingContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is VLR if Initiator is HLR
    -- Responder is HLR if Initiator is VLR
    INITIATOR CONSUMER OF {
        setReportingStatePackage-v3 |
            statusReportPackage-v3 |
            remoteUserFreePackage-v3 }
    RESPONDER CONSUMER OF {
            setReportingStatePackage-v3 |
            statusReportPackage-v3 |
            statusReportPackag
```

This application-context is v3 only.

#### 17.3.2.38 Call Completion

This application context is used between VLR and the HLR for subscriber control of call completion services.

```
callCompletionContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is HLR if Initiator is VLR
    INITIATOR CONSUMER OF {
        callCompletionPackage-v3}
    ID {map-ac callCompletion(8) version3(3)} }
```

## 17.3.2.39 Location Service Gateway

This application context is used for location service gateway procedures.

```
locationSvcGatewayContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is HLR if Initiator is GMLC
    INITIATOR CONSUMER OF {
        locationSvcGatewayPackage-v3}
    ID {map-ac locationSvcGateway(37) version3(3)} }
```

## 17.3.2.40 Location Service Enquiry

This application context is used for location service enquiry procedures.

17.3.2.41 Void

17.3.2.42 Void

17.3.2.43 Void

## 17.3.2.44 IST Alerting

This application context is used between MSC (Visited MSC or Gateway MSC) and HLR for alerting services within IST procedures.

```
istAlertingContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is HLR if Initiator is VMSC
    -- Responder is HLR if Initiator is GMSC
    INITIATOR CONSUMER OF {
        ist-AlertingPackage-v3}
    ID {map-ac alerting(4) version3(3)} }
```

This application-context is v3 only.

#### 17.3.2.45 Service Termination

This application context is used between HLR and MSC (Visited MSC or Gateway MSC) for service termination services within IST procedures.

```
serviceTerminationContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is VMSC or GMSC if Initiator is HLR
    INITIATOR CONSUMER OF {
        serviceTerminationPackage-v3}
    ID {map-ac serviceTermination(9) version3(3)} }
```

## 17.3.2.46 Mobility Management event notification

This application context is used between VLR and gsmSCF for Mobility Management event notification procedures.

```
mm-EventReportingContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is gsmSCF, Initiator is VLR
     INITIATOR CONSUMER OF {
         mm-EventReportingPackage-v3}
     ID {map-ac mm-EventReporting(42) version3(3)} }
```

This application-context is v3 only.

## 17.3.2.47 Any time information handling

This application context is used between gsmSCF and HLR for any time information handling procedures.

```
anyTimeInfohandlingContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is HLR if Initiator is gsmSCF
    INITIATOR CONSUMER OF {
        anyTimeInformationHandlingPackage-v3}
    ID {map-ac anyTimeInfoHandling(43) version3(3)} }
```

This application-context is v3 only.

#### 17.3.2.48 Subscriber Data modification notification

This application context is used between HLR and gsmSCF for Subscriber Data modification notification procedures.

```
subscriberDataModificationNotificationContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is gsmSCF, Initiator is HLR
    INITIATOR CONSUMER OF {
        subscriberDataModificationNotificationPackage-v3}
    ID {map-ac subscriberDataModificationNotification(22) version3(3)} }
```

This application-context is v3 only.

#### 17.3.2.49 Authentication Failure Report

This application context is used between VLR and HLR or SGSN and HLR for reporting of authentication failures.

```
authenticationFailureReportContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is HLR if Initiator is VLR
    -- Responder is HLR if Initiator is SGSN
    INITIATOR CONSUMER OF {
        authenticationFailureReportPackage-v3 }
    ID {map-ac authenticationFailureReport(39) version3(3)} }
```

This application-context is v3 only.

## 17.3.2.50 Resource Management

This application context is used between GMSC and VMSC for resource management purpose.

```
resourceManagementContext-v3 APPLICATION-CONTEXT ::= {
    -- Responder is VMSC if Initiator is GMSC
    INITIATOR CONSUMER OF {
        resourceManagementPackage-v3 }
    ID {map-ac resourceManagement(44) version3(3)} }
```

## 17.3.2.51 Mobile terminating Short Message Relay VGCS

This application context is used between SMS-GMSC and MSC for mobile terminating short message relay procedures for VGCS.

```
shortMsgMT-Relay-VGCS-Context-v3 APPLICATION-CONTEXT ::= {
          -- Responder is MSC if Initiator is SMS-GMSC
          INITIATOR CONSUMER OF {
                mt-ShortMsgRelay-VGCS-Package-v3}
          ID {map-ac shortMsgMT-Relay-VGCS(41) version3(3)} }
```

This application-context is v3 only.

## 17.3.3 ASN.1 Module for application-context-names

The following ASN.1 module summarises the application-context-name assigned to MAP application-contexts.

```
MAP-ApplicationContexts {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ApplicationContexts (2) version10 (10)}
DEFINITIONS
::=
BEGIN
-- EXPORTS everything
IMPORTS
   gsm-NetworkId,
   ac-Id
FROM MobileDomainDefinitions {
   itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
   mobileDomainDefinitions (0) version1 (1) }
-- application-context-names
map-ac OBJECT IDENTIFIER ::= {gsm-NetworkId ac-Id}
networkLocUpContext-v3 OBJECT IDENTIFIER ::=
     {map-ac networkLocUp(1) version3(3)}
locationCancellationContext-v3 OBJECT IDENTIFIER ::=
     {map-ac locationCancel(2) version3(3)}
roamingNumberEnquiryContext-v3 OBJECT IDENTIFIER ::=
    {map-ac roamingNbEnquiry(3) version3(3)}
{map-ac authenticationFailureReport(39) version3(3)
locationInfoRetrievalContext-v3     OBJECT IDENTIFIER ::=
     {map-ac locInfoRetrieval(5) version3(3)}
resetContext-v2 OBJECT IDENTIFIER ::=
     {map-ac reset(10) version2(2)}
handoverControlContext-v3 OBJECT IDENTIFIER ::=
     {map-ac handoverControl(11) version3(3)}
equipmentMngtContext-v3 OBJECT IDENTIFIER ::=
     {map-ac equipmentMngt(13) version3(3)}
infoRetrievalContext-v3 OBJECT IDENTIFIER ::=
     {map-ac infoRetrieval(14) version3(3)}
```

interVlrInfoRetrievalContext-v3 OBJECT IDENTIFIER ::=
 {map-ac interVlrInfoRetrieval(15) version3(3)}

```
subscriberDataMngtContext-v3 OBJECT IDENTIFIER ::=
     {map-ac subscriberDataMngt(16) version3(3)}
tracingContext-v3 OBJECT IDENTIFIER ::=
    {map-ac tracing(17) version3(3)}
networkFunctionalSsContext-v2 OBJECT IDENTIFIER ::=
     {map-ac networkFunctionalSs(18) version2(2)}
networkUnstructuredSsContext-v2 OBJECT IDENTIFIER ::=
    {map-ac networkUnstructuredSs(19) version2(2)}
shortMsgGatewayContext-v3 OBJECT IDENTIFIER ::=
     {map-ac shortMsgGateway(20) version3(3)}
shortMsgMO-RelayContext-v3 OBJECT IDENTIFIER ::=
    {map-ac shortMsgMO-Relay(21) version3(3)}
shortMsgAlertContext-v2 OBJECT IDENTIFIER ::=
    {map-ac shortMsgAlert(23) version2(2)}
mwdMngtContext-v3 OBJECT IDENTIFIER ::=
     {map-ac mwdMngt(24) version3(3)}
shortMsgMT-RelayContext-v3 OBJECT IDENTIFIER ::=
    {map-ac shortMsgMT-Relay(25) version3(3)}
shortMsgMT-Relay-VGCS-Context-v3 OBJECT IDENTIFIER ::=
     {map-ac shortMsgMT-Relay-VGCS(41) version3(3)}
imsiRetrievalContext-v2 OBJECT IDENTIFIER ::=
    {map-ac imsiRetrieval(26) version2(2)
msPurgingContext-v3 OBJECT IDENTIFIER ::=
     {map-ac msPurging(27) version3(3)}
subscriberInfoEnquiryContext-v3 OBJECT IDENTIFIER ::=
     {map-ac subscriberInfoEnquiry(28) version3(3)}
anyTimeInfoEnquiryContext-v3 OBJECT IDENTIFIER ::=
     {map-ac anyTimeInfoEnquiry(29) version3(3)}
callControlTransferContext-v4 OBJECT IDENTIFIER ::=
     {map-ac callControlTransfer(6) version4(4)}
ss-InvocationNotificationContext-v3 OBJECT IDENTIFIER ::=
     {map-ac ss-InvocationNotification(36) version3(3)}
{map-ac groupCallControl(31) version3(3)}
groupCallInfoRetrievalContext-v3 OBJECT IDENTIFIER ::=
     {map-ac groupCallInfoRetrieval(45) version3(3)}
gprsLocationUpdateContext-v3 OBJECT IDENTIFIER ::=
    {map-ac gprsLocationUpdate(32) version3(3)}
gprsLocationInfoRetrievalContext-v4 OBJECT IDENTIFIER ::=
     {map-ac gprsLocationInfoRetrieval(33) version4(4)}
failureReportContext-v3 OBJECT IDENTIFIER ::=
     {map-ac failureReport(34) version3(3)}
gprsNotifyContext-v3 OBJECT IDENTIFIER ::=
    {map-ac gprsNotify(35) version3(3)}
reportingContext-v3 OBJECT IDENTIFIER ::=
     {map-ac reporting(7) version3(3)}
callCompletionContext-v3 OBJECT IDENTIFIER ::=
     {map-ac callCompletion(8) version3(3)}
istAlertingContext-v3 OBJECT IDENTIFIER ::=
     {map-ac istAlerting(4) version3(3)}
```

```
serviceTerminationContext-v3 OBJECT IDENTIFIER ::=
    {map-ac immediateTermination(9) version3(3)}
```

- -- The following Object Identifiers are reserved for application-contexts
- ${\mathord{\hspace{1pt}\text{--}}}$  existing in previous versions of the protocol

AC Nome & Version	Object Identifier	
AC Name & Version	Object Identifier	
	man as naturally salls (4)	
networkLocUpContext-v1	map-ac networkLocUp (1)	version1 (1)
networkLocUpContext-v2	map-ac networkLocUp (1)	version2 (2)
locationCancellationContext-v1	map-ac locationCancellation (2)	version1 (1)
locationCancellationContext-v2	map-ac locationCancellation (2)	version2 (2)
roamingNumberEnquiryContext-v1	map-ac roamingNumberEnquiry (3)	version1 (1)
roamingNumberEnquiryContext-v2	map-ac roamingNumberEnquiry (3)	version2 (2)
locationInfoRetrievalContext-v1	map-ac locationInfoRetrieval (5)	version1 (1)
locationInfoRetrievalContext-v2	map-ac locationInfoRetrieval (5)	version2 (2)
resetContext-v1	map-ac reset (10)	version1 (1)
handoverControlContext-v1	map-ac handoverControl (11)	version1 (1)
handoverControlContext-v2	map-ac handoverControl (11)	version2 (2)
sIWFSAllocationContext-v3	map-ac sIWFSAllocation (12)	version3 (3)
equipmentMngtContext-v1	map-ac equipmentMngt (13)	version1 (1)
equipmentMngtContext-v2	map-ac equipmentMngt (13)	version2 (2)
infoRetrievalContext-v1	map-ac infoRetrieval (14)	version1 (1)
infoRetrievalContext-v2	map-ac infoRetrieval (14)	version2 (2)
interVIrInfoRetrievalContext-v2	map-ac interVlrInfoRetrieval (15)	version2 (2)
subscriberDataMngtContext-v1	map-ac subscriberDataMngt (16)	version1 (1)
subscriberDataMngtContext-v2	map-ac subscriberDataMngt (16)	version2 (2)
tracingContext-v1	map-ac tracing (17)	version1 (1)
tracingContext-v2	map-ac tracing (17)	version2 (2)
networkFunctionalSsContext-v1	map-ac networkFunctionalSs (18)	version1 (1)
shortMsgGatewayContext-v1	map-ac shortMsgGateway (20)	version1 (1)
shortMsgGatewayContext-v2	map-ac shortMsgGateway (20)	version2 (2)
shortMsgRelayContext-v1	map-ac shortMsgRelay (21)	version1 (1)
shortMsgAlertContext-v1	map-ac shortMsgAlert (23)	version1 (1)
mwdMngtContext-v1	map-ac mwdMngt (24)	version1 (1)
mwdMngtContext-v2	map-ac mwdMngt (24)	version2 (2)
shortMsgMT-RelayContext-v2	map-ac shortMsgMT-Relay (25)	version2 (2)
msPurgingContext-v2	map-ac msPurging (27)	version2 (2)
callControlTransferContext-v3	map-ac callControlTransferContext (6)	version3 (3)
gprsLocationInfoRetrievalContext-v3	map-ac gprsLocationInfoRetrievalConte	( )
gprscocationimiortethevalcontext-vs	map-ac gpracocationinionethevalconte	VI (22) AELSIOLIS (2)

# 17.4 MAP Dialogue Information

```
MAP-DialogueInformation {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-DialogueInformation (3) version10 (10) }

DEFINITIONS

IMPLICIT TAGS
::=

BEGIN
```

```
EXPORTS
   map-DialogueAS,
   MAP-DialoquePDU
IMPORTS
   gsm-NetworkId,
   as-Id
FROM MobileDomainDefinitions {
   itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
   mobileDomainDefinitions (0) version1 (1) }
   AddressString
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network(1) modules (3) map-CommonDataTypes (18) version10 (10)}
   ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version10 (10)}
;
-- abstract syntax name for MAP-DialoguePDU
map-DialogueAS OBJECT IDENTIFIER ::=
    {gsm-NetworkId as-Id map-DialoguePDU (1) version1 (1)}
MAP-DialoguePDU ::= CHOICE {
    map-open
                                          [0] MAP-OpenInfo,
    map-accept
                                          [1] MAP-AcceptInfo,
    map-close
                                          [2] MAP-CloseInfo,
    map-refuse
                                          [3] MAP-RefuseInfo
    map-userAbort
                                          [4] MAP-UserAbortInfo,
    map-providerAbort
                                          [5] MAP-ProviderAbortInfo}
MAP-OpenInfo ::= SEQUENCE {
    destinationReference
                                          [0] AddressString
                                                                             OPTIONAL,
    originationReference
                                          [1] AddressString
                                                                             OPTIONAL,
     extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL
      - extensionContainer must not be used in version 2
MAP-AcceptInfo ::= SEQUENCE {
     extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL
     -- extensionContainer must not be used in version 2
MAP-CloseInfo ::= SEQUENCE {
     extensionContainer
                                         ExtensionContainer
                                                                             OPTIONAL
     -- extensionContainer must not be used in version 2
MAP-RefuseInfo ::= SEQUENCE {
    reason
              Reason,
     extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
     -- extensionContainer must not be used in version \it 2
     alternativeApplicationContext OBJECT IDENTIFIER
                                                                             OPTIONAL
     -- alternativeApplicationContext must not be used in version 2
Reason ::= ENUMERATED {
    noReasonGiven
                                          (0),
     invalidDestinationReference
                                          (1).
     invalid {\tt Originating Reference}
```

```
ResourceUnavailableReason ::= ENUMERATED {
    shortTermResourceLimitation (0),
    longTermResourceLimitation (1)}
```

```
ProcedureCancellationReason ::= ENUMERATED {
    handoverCancellation (0),
    radioChannelRelease (1),
    networkPathRelease (2),
    callRelease (3),
    associatedProcedureFailure (4),
    tandemDialogueRelease (5),
    remoteOperationsFailure (6)}
```

```
MAP-ProviderAbortReason ::= ENUMERATED {
   abnormalDialogue (0),
   invalidPDU (1)}
```

# 17.5 MAP operation and error codes

```
itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Protocol (4) version10 (10)}
DEFINITIONS
: :=
BEGIN
IMPORTS
  OPERATION
FROM Remote-Operations-Information-Objects {
  joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
  updateLocation,
  cancelLocation.
  purgeMS,
   sendIdentification,
   updateGprsLocation,
  prepareHandover,
   sendEndSignal,
   processAccessSignalling,
   forwardAccessSignalling,
   prepareSubsequentHandover,
   sendAuthenticationInfo,
   authenticationFailureReport,
   checkIMEI,
   insertSubscriberData,
   deleteSubscriberData,
  reset,
   forwardCheckSS-Indication,
   restoreData,
   provideSubscriberInfo,
   anyTimeInterrogation,
   anyTimeSubscriptionInterrogation,
```

```
anyTimeModification,
   sendRoutingInfoForGprs,
   failureReport,
   noteMsPresentForGprs,
   noteMM-Event,
  noteSubscriberDataModified
FROM MAP-MobileServiceOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-MobileServiceOperations (5)
   version10 (10)}
   activateTraceMode,
   deactivateTraceMode,
   sendIMSI
{\tt FROM\ MAP-OperationAndMaintenanceOperations}\ \{
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-OperationAndMaintenanceOperations (6)
   version10 (10)}
   sendRoutingInfo,
  provideRoamingNumber,
   resumeCallHandling,
   setReportingState,
  statusReport,
   remoteUserFree
   ist-Alert,
   ist-Command,
   releaseResources
FROM MAP-CallHandlingOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CallHandlingOperations (7)
   version10 (10)}
  registerSS,
   eraseSS,
   activateSS,
   deactivateSS,
   interrogateSS,
  processUnstructuredSS-Request,
  unstructuredSS-Request,
  unstructuredSS-Notify,
   registerPassword,
  getPassword,
   ss-InvocationNotification,
  registerCC-Entry,
   eraseCC-Entry
FROM MAP-SupplementaryServiceOperations {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SupplementaryServiceOperations (8)
   version10 (10)}
   sendRoutingInfoForSM,
  mo-ForwardSM,
  mt.-ForwardSM.
   reportSM-DeliveryStatus,
   alertServiceCentre,
  informServiceCentre,
  readyForSM,
  mt-ForwardSM-VGCS
FROM MAP-ShortMessageServiceOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ShortMessageServiceOperations (9)
   version10 (10)}
   prepareGroupCall,
   processGroupCallSignalling,
   forwardGroupCallSignalling,
   sendGroupCallEndSignal,
   {\tt sendGroupCallInfo}
FROM MAP-Group-Call-Operations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Group-Call-Operations (22)
   version10 (10)}
```

```
provideSubscriberLocation,
   sendRoutingInfoForLCS,
   subscriberLocationReport
FROM MAP-LocationServiceOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-LocationServiceOperations (24)
   version10 (10)}
Supported-MAP-Operations OPERATION ::= {updateLocation | cancelLocation | purgeMS |
   sendIdentification | updateGprsLocation | prepareHandover | sendEndSignal |
   processAccessSignalling | forwardAccessSignalling | prepareSubsequentHandover
   sendAuthenticationInfo | authenticationFailureReport | checkIMEI | insertSubscriberData | deleteSubscriberData | reset | forwardCheckSS-Indication | restoreData | provideSubscriberInfo |
   anyTimeInterrogation | anyTimeSubscriptionInterrogation | anyTimeModification |
sendRoutingInfoForGprs | failureReport | noteMsPresentForGprs | noteMM-Event |
   noteSubscriberDataModified | activateTraceMode | deactivateTraceMode | sendIMSI
   sendRoutingInfo | provideRoamingNumber | resumeCallHandling | setReportingState | statusReport |
remoteUserFree | ist-Alert |
   ist-Command | registerSS | eraseSS | activateSS | deactivateSS | interrogateSS
   processUnstructuredSS-Request | unstructuredSS-Request | unstructuredSS-Notify
   registerPassword | getPassword | ss-InvocationNotification | registerCC-Entry | eraseCC-Entry |
   sendRoutingInfoForSM | mo-ForwardSM | mt-ForwardSM | reportSM-DeliveryStatus |
   alertServiceCentre | informServiceCentre | readyForSM | prepareGroupCall |
   processGroupCallSignalling | forwardGroupCallSignalling | sendGroupCallEndSignal |
   provideSubscriberLocation | sendRoutingInfoForLCS | subscriberLocationReport |
   releaseResources | mt-ForwardSM-VGCS | sendGroupCallInfo }
```

- -- The following operation codes are reserved for operations
- -- existing in previous versions of the protocol

Operation Name	AC used	Oper. Code
sendParameters	map-ac infoRetrieval (14) version1 (1)	local:9
processUnstructuredSS-Data	map-ac networkFunctionalSs (18) version1 (1)	local:19
performHandover	map-ac handoverControl (11) version1 (1)	local:28
performSubsequentHandover	map-ac handoverControl (11) version1 (1)	local:30
provideSIWFSNumber	map-ac sIWFSAllocation (12) version3 (3)	local:31
siwfs-SignallingModify	map-ac sIWFSAllocation (12) version3 (3)	local:32
noteInternalHandover	map-ac handoverControl (11) version1 (1)	local:35
noteSubscriberPresent	map-ac mwdMngt (24) version1 (1)	local:48
alertServiceCentreWithoutResult	map-ac shortMsgAlert (23) version1 (1)	local:49
traceSubscriberActivity	map-ac handoverControl (11) version1 (1)	local:52
beginSubscriberActivity	map-ac networkFunctionalSs (18) version1 (1)	local:54

- -- The following error codes are reserved for errors
- -- existing in previous versions of the protocol

Error Name	AC used	Error Code	
 unknownBaseStation invalidTargetBaseStation noRadioResourceAvailable	map-ac handoverControl (11) version1 (1) map-ac handoverControl (11) version1 (1) map-ac handoverControl (11) version1 (1)	local:2 local:23 local:24	

# 17.6 MAP operations and errors

## 17.6.1 Mobile Service Operations

```
MAP-MobileServiceOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-MobileServiceOperations (5)
   version10 (10) }

DEFINITIONS
::=
BEGIN
```

```
EXPORTS
```

```
-- location registration operations
  updateLocation,
  cancelLocation,
  purgeMS,
  sendIdentification,
   -- gprs location registration operations
  updateGprsLocation,
   -- subscriber information enquiry operations
  provideSubscriberInfo,
   -- any time information enquiry operations
  anyTimeInterrogation,
   -- any time information handling operations
  anyTimeSubscriptionInterrogation,
  anyTimeModification,
   -- subscriber data modification notification operations
  noteSubscriberDataModified,
   -- handover operations
  prepareHandover,
  sendEndSignal,
  processAccessSignalling,
   forwardAccessSignalling,
  prepareSubsequentHandover,
   -- authentication management operations
  sendAuthenticationInfo,
  authenticationFailureReport,
   -- IMEI management operations
  checkIMEI,
   -- subscriber management operations
  insertSubscriberData,
  deleteSubscriberData,
   -- fault recovery operations
  reset,
  forwardCheckSS-Indication,
  restoreData.
-- gprs location information retrieval operations
  sendRoutingInfoForGprs,
   -- failure reporting operations
  failureReport,
   -- gprs notification operations
  noteMsPresentForGprs,
   -- Mobility Management operations
  noteMM-Event
IMPORTS
  OPERATION
FROM Remote-Operations-Information-Objects {
  joint-iso-itu-t remote-operations(4)
  informationObjects(5) version1(0) }
  systemFailure,
  dataMissing,
  unexpectedDataValue,
  unknownSubscriber,
  unknownMSC,
  unidentifiedSubscriber,
  unknownEquipment,
  roamingNotAllowed,
   ati-NotAllowed,
  noHandoverNumberAvailable,
  subsequentHandoverFailure,
```

311

```
absentSubscriber,
   mm-EventNotSupported,
  atsi-NotAllowed,
   atm-NotAllowed,
  bearerServiceNotProvisioned,
   teleserviceNotProvisioned,
   callBarred,
   illegalSS-Operation,
   ss-ErrorStatus,
   ss-NotAvailable,
   ss-Incompatibility,
   ss-SubscriptionViolation,
   informationNotAvailable,
   targetCellOutsideGroupCallArea
FROM MAP-Errors {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Errors (10) version10 (10)}
   UpdateLocationArg,
   UpdateLocationRes,
   CancelLocationArg,
   CancelLocationRes,
   PurgeMS-Arg,
   PurgeMS-Res,
   SendIdentificationArg,
   SendIdentificationRes,
   UpdateGprsLocationArg,
   UpdateGprsLocationRes,
   PrepareHO-Arg,
   PrepareHO-Res,
   ForwardAccessSignalling-Arg,
   ProcessAccessSignalling-Arg,
   SendEndSignal-Arg,
   SendEndSignal-Res,
   PrepareSubsequentHO-Res,
   PrepareSubsequentHO-Arg,
   SendAuthenticationInfoArg,
   SendAuthenticationInfoRes,
   AuthenticationFailureReportArg,
   AuthenticationFailureReportRes,
   CheckIMEI-Arg,
   CheckIMEI-Res,
   InsertSubscriberDataArg,
   InsertSubscriberDataRes.
   DeleteSubscriberDataArg,
   DeleteSubscriberDataRes,
   ResetArg,
   RestoreDataArg,
   RestoreDataRes.
   ProvideSubscriberInfoArg,
   ProvideSubscriberInfoRes,
   AnyTimeSubscriptionInterrogationArg,
   AnyTimeSubscriptionInterrogationRes,
   AnyTimeModificationArg,
   AnyTimeModificationRes,
   NoteSubscriberDataModifiedArg,
   NoteSubscriberDataModifiedRes,
   AnyTimeInterrogationArg,
   AnyTimeInterrogationRes,
   SendRoutingInfoForGprsArg,
   SendRoutingInfoForGprsRes,
   FailureReportArg,
   FailureReportRes,
  NoteMsPresentForGprsArg,
   NoteMsPresentForGprsRes,
   NoteMM-EventArg,
  NoteMM-EventRes
FROM MAP-MS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-MS-DataTypes (11) version10 (10)}
```

-- location registration operations

```
updateLocation OPERATION ::= {
    ARGUMENT
        UpdateLocationArg
    RESULT
        UpdateLocationRes
    ERRORS {
        systemFailure |
        dataMissing |
        unexpectedDataValue |
        unknownSubscriber |
        roamingNotAllowed}
    CODE local:2 }
```

```
cancelLocation OPERATION ::= {
    ARGUMENT
    CancelLocationArg
    RESULT
    CancelLocationRes
    -- optional
    ERRORS {
        dataMissing |
        unexpectedDataValue}
    CODE local:3 }
```

```
sendIdentification OPERATION ::= {
    ARGUMENT
        SendIdentificationArg
    RESULT
        SendIdentificationRes
    ERRORS {
        dataMissing |
            unidentifiedSubscriber}
    CODE local:55 }
```

-- gprs location registration operations

```
updateGprsLocation OPERATION ::= {
    ARGUMENT
        UpdateGprsLocationArg
    RESULT
        UpdateGprsLocationRes
    ERRORS {
        systemFailure |
        unexpectedDataValue |
        unknownSubscriber |
        roamingNotAllowed}
    CODE local:23 }
```

-- subscriber information enquiry operations

-- any time information enquiry operations

```
anyTimeInterrogation OPERATION ::= {
    ARGUMENT
    AnyTimeInterrogationArg
    RESULT
    AnyTimeInterrogationRes
    ERRORS {
        systemFailure |
            ati-NotAllowed |
            dataMissing |
            unexpectedDataValue |
            unknownSubscriber}
    CODE local:71 }
```

-- any time information handling operations

```
\verb"anyTimeSubscriptionInterrogation" OPERATION ::= \{
                                                                                --Timer m
    ARGUMENT
         AnyTimeSubscriptionInterrogationArg
    RESULT
         AnyTimeSubscriptionInterrogationRes
    ERRORS {
         atsi-NotAllowed |
         dataMissing
         unexpectedDataValue |
         unknownSubscriber
         bearerServiceNotProvisioned |
         teleserviceNotProvisioned |
         callBarred |
         illegalSS-Operation |
         ss-NotAvailable |
         informationNotAvailable}
    CODE local:62 }
```

```
anyTimeModification OPERATION ::= {
                                                                             --Timer m
    ARGUMENT
        AnyTimeModificationArg
    RESULT
        AnyTimeModificationRes
    ERRORS {
        atm-NotAllowed |
         dataMissing
         unexpectedDataValue |
         unknownSubscriber |
         bearerServiceNotProvisioned |
         teleserviceNotProvisioned |
         callBarred |
         illegalSS-Operation
         ss-SubscriptionViolation |
         ss-ErrorStatus
         ss-Incompatibility |
         informationNotAvailable}
    CODE local:65 }
```

-- subscriber data modification notification operations

-- handover operations

```
prepareHandover OPERATION ::= {
          ARGUMENT
          PrepareHO-Arg
     RESULT
          PrepareHO-Res
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          noHandoverNumberAvailable |
          targetCellOutsideGroupCallArea }
     CODE local:68 }
```

```
sendEndSignal OPERATION ::= {
    ARGUMENT
        SendEndSignal-Arg
    RESULT
        SendEndSignal-Res
    CODE local:29 }
--Timer 1
--Timer 1
```

```
processAccessSignalling OPERATION ::= {
          ARGUMENT
          ProcessAccessSignalling-Arg
          CODE local:33 }
```

```
forwardAccessSignalling OPERATION ::= {
    ARGUMENT
    ForwardAccessSignalling-Arg
    CODE local:34 }
```

-- authentication management operations

```
sendAuthenticationInfo OPERATION ::= {
                                                                             --Timer m
    ARGUMENT
         SendAuthenticationInfoArg
         -- optional
         -- within a dialogue sendAuthenticationInfoArg shall not be present in
         -- subsequent invoke components. If received in a subsequent invoke component
         -- it shall be discarded.
    RESULT
         SendAuthenticationInfoRes
         -- optional
    ERRORS {
         systemFailure |
         dataMissing |
         unexpectedDataValue |
         unknownSubscriber}
    CODE local:56 }
```

```
authenticationFailureReport OPERATION ::= {
    ARGUMENT
    AuthenticationFailureReportArg
    RESULT
    AuthenticationFailureReportRes
    -- optional
    ERRORS {
        systemFailure |
        unexpectedDataValue |
        unknownSubscriber}
    CODE local:15 }
```

<sup>--</sup> IMEI management operations

```
checkIMEI OPERATION ::= {
    ARGUMENT
    CheckIMEI-Arg
    RESULT
    CheckIMEI-Res
    ERRORS {
        systemFailure |
        dataMissing |
        unknownEquipment}
    CODE local:43 }
```

-- subscriber management operations

-- fault recovery operations

```
reset OPERATION ::= {
    ARGUMENT
    ResetArg
    CODE local:37 }
```

```
forwardCheckSS-Indication OPERATION ::= {
    CODE local:38 }
```

-- gprs location information retrieval operations

-- failure reporting operations

-- gprs notification operations

```
noteMM-Event OPERATION ::= {
    ARGUMENT
    NoteMM-EventArg
    RESULT
    NoteMM-EventRes
    ERRORS {
    dataMissing |
        unexpectedDataValue |
        unknownSubscriber |
        mm-EventNotSupported}
    CODE local:89 }
```

END

## 17.6.2 Operation and Maintenance Operations

```
MAP-OperationAndMaintenanceOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-OperationAndMaintenanceOperations (6)
   version10 (10)}
DEFINITIONS
BEGIN
EXPORTS
  activateTraceMode,
   deactivateTraceMode,
  sendIMSI
IMPORTS
  OPERATION
FROM Remote-Operations-Information-Objects {
  joint-iso-itu-t remote-operations(4)
  informationObjects(5) version1(0) }
   systemFailure,
   dataMissing,
  unexpectedDataValue,
   facilityNotSupported,
  unknownSubscriber,
  unidentifiedSubscriber,
  tracingBufferFull
FROM MAP-Errors {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Errors (10) version10 (10)}
```

```
ActivateTraceModeArg,
ActivateTraceModeRes,
DeactivateTraceModeRes,
DeactivateTraceModeRes
FROM MAP-OM-DataTypes {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-OM-DataTypes (12) version10 (10) }

ISDN-AddressString,
IMSI
FROM MAP-CommonDataTypes {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-CommonDataTypes (18) version10 (10) }

;
```

```
activateTraceMode OPERATION ::= {
    ARGUMENT
        ActivateTraceModeArg
    RESULT
        ActivateTraceModeRes
        -- optional
    ERRORS {
        systemFailure |
        dataMissing |
        unexpectedDataValue |
        facilityNotSupported |
        unidentifiedSubscriber |
        tracingBufferFull}
    CODE local:50 }
```

```
deactivateTraceMode OPERATION ::= {
    ARGUMENT
    DeactivateTraceModeArg
    RESULT
    DeactivateTraceModeRes
    -- optional
    ERRORS {
        systemFailure |
        dataMissing |
        unexpectedDataValue |
        facilityNotSupported |
        unidentifiedSubscriber}
    CODE local:51 }
```

# 17.6.3 Call Handling Operations

```
MAP-CallHandlingOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CallHandlingOperations (7)
   version10 (10) }

DEFINITIONS

::=

BEGIN

EXPORTS
   sendRoutingInfo,
   provideRoamingNumber,
   resumeCallHandling,
   setReportingState,
   statusReport,
   remoteUserFree,
```

;

```
ist-Alert,
  ist-Command,
  releaseResources
IMPORTS
  OPERATION
FROM Remote-Operations-Information-Objects {
  joint-iso-itu-t remote-operations(4)
  informationObjects(5) version1(0) }
   systemFailure,
  dataMissing,
   unexpectedDataValue,
   facilityNotSupported,
   or-NotAllowed,
  unknownSubscriber,
  numberChanged,
  bearerServiceNotProvisioned,
   teleserviceNotProvisioned,
  noRoamingNumberAvailable,
   absentSubscriber,
  busySubscriber,
   noSubscriberReply,
   callBarred,
   forwardingViolation,
   {\tt forwardingFailed,}
   cug-Reject,
   resourceLimitation,
   incompatibleTerminal,
  unidentifiedSubscriber
FROM MAP-Errors {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Errors (10) version10 (10)}
   SendRoutingInfoArg,
   SendRoutingInfoRes,
  ProvideRoamingNumberArg,
   ProvideRoamingNumberRes,
   ResumeCallHandlingArg,
  ResumeCallHandlingRes,
   SetReportingStateArg,
  SetReportingStateRes,
   StatusReportArg,
   StatusReportRes,
  RemoteUserFreeArg,
  RemoteUserFreeRes,
  IST-AlertArg,
  IST-AlertRes,
   IST-CommandArg,
  IST-CommandRes,
  ReleaseResourcesArg,
  ReleaseResourcesRes
FROM MAP-CH-DataTypes {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CH-DataTypes (13) version10 (10)}
```

```
sendRoutingInfo OPERATION ::= {
                                                                             --Timer m
-- The timer is set to the upper limit of the range if the GMSC supports pre-paging.
    ARGUMENT
         SendRoutingInfoArg
    RESULT
        SendRoutingInfoRes
    ERRORS {
         systemFailure |
         dataMissing
         unexpectedDataValue
         facilityNotSupported |
         or-NotAllowed
         unknownSubscriber |
         numberChanged |
         bearerServiceNotProvisioned |
         teleserviceNotProvisioned |
         absentSubscriber |
         busySubscriber
         noSubscriberReply |
         callBarred
         cug-Reject
         forwardingViolation}
    CODE local:22 }
```

```
provideRoamingNumber OPERATION ::= {
                                                                             --Timer m
 - The timer is set to the upper limit of the range if the HLR supports pre-paging.
    ARGUMENT
         ProvideRoamingNumberArg
    RESULT
         ProvideRoamingNumberRes
    ERRORS {
         systemFailure |
         dataMissing
         unexpectedDataValue |
         facilityNotSupported |
         or-NotAllowed
         absentSubscriber |
         noRoamingNumberAvailable}
     CODE local:4 }
```

```
resumeCallHandling OPERATION ::= {
    ARGUMENT
    ResumeCallHandlingArg
    RESULT
    ResumeCallHandlingRes
    -- optional
    ERRORS {
        forwardingFailed |
            or-NotAllowed |
            unexpectedDataValue |
            dataMissing }
    CODE local:6 }
```

```
setReportingState OPERATION ::= {
    ARGUMENT
        SetReportingStateArg
    RESULT
        SetReportingStateRes
        -- optional
    ERRORS {
        systemFailure |
        unidentifiedSubscriber |
        unexpectedDataValue |
        dataMissing |
        resourceLimitation |
        facilityNotSupported}
    CODE local:73 }
```

```
statusReport OPERATION ::= {
    ARGUMENT
        StatusReportArg
    RESULT
        StatusReportRes
        -- optional
    ERRORS {
        unknownSubscriber |
        systemFailure |
        unexpectedDataValue |
        dataMissing}
    CODE local:74 }
```

```
remoteUserFree OPERATION ::= {
    ARGUMENT
    RemoteUserFreeArg
    RESULT
    RemoteUserFreeRes
    ERRORS {
        unexpectedDataValue |
        dataMissing |
        incompatibleTerminal |
        absentSubscriber |
        systemFailure |
        busySubscriber}
    CODE local:75 }
```

```
ist-Alert OPERATION ::= {
    ARGUMENT
    IST-AlertArg
    RESULT
    IST-AlertRes
    -- optional
    ERRORS {
        unexpectedDataValue |
        resourceLimitation |
        unknownSubscriber |
        systemFailure |
        facilityNotSupported}
    CODE local:87 }
```

```
ist-Command OPERATION::= {
    ARGUMENT
    IST-CommandArg
    RESULT
    IST-CommandRes
    -- optional
    ERRORS {
        unexpectedDataValue |
        resourceLimitation |
        unknownSubscriber |
        systemFailure |
        facilityNotSupported}
    CODE local:88 }
```

# 17.6.4 Supplementary service operations

```
MAP-SupplementaryServiceOperations {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-SupplementaryServiceOperations (8)
  version10 (10) }

DEFINITIONS
::=
```

```
BEGIN
EXPORTS
  registerSS,
  eraseSS,
  activateSS
  deactivateSS,
  interrogateSS,
  processUnstructuredSS-Request,
  unstructuredSS-Request,
  unstructuredSS-Notify,
  registerPassword,
  getPassword,
   ss-InvocationNotification,
  registerCC-Entry,
  eraseCC-Entry
IMPORTS
  OPERATION
FROM Remote-Operations-Information-Objects {
   joint-iso-itu-t remote-operations(4)
  informationObjects(5) version1(0) }
   systemFailure,
   dataMissing,
  unexpectedDataValue,
   unknownSubscriber,
  bearerServiceNotProvisioned,
  teleserviceNotProvisioned,
   callBarred,
   illegalSS-Operation,
   ss-ErrorStatus,
  ss-NotAvailable,
  ss-SubscriptionViolation,
   ss-Incompatibility,
   pw-RegistrationFailure,
  negativePW-Check,
  numberOfPW-AttemptsViolation,
  unknownAlphabet,
  ussd-Busy,
   absentSubscriber,
   illegalSubscriber,
   illegalEquipment,
   shortTermDenial,
  longTermDenial,
   facilityNotSupported
FROM MAP-Errors {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Errors (10) version10 (10)}
  RegisterSS-Arg,
   SS-Info,
   SS-ForBS-Code,
   InterrogateSS-Res,
  USSD-Arg,
  USSD-Res,
   Password,
  GuidanceInfo,
  SS-InvocationNotificationArg,
   SS-InvocationNotificationRes,
   RegisterCC-EntryArg,
  RegisterCC-EntryRes,
  EraseCC-EntryArg,
  EraseCC-EntryRes
FROM MAP-SS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-SS-DataTypes (14) version10 (10)}
  SS-Code
FROM MAP-SS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-SS-Code (15) version10 (10)}
-- supplementary service handling operations
```

```
registerSS OPERATION ::= {
                                                                            --Timer m
    ARGUMENT
        RegisterSS-Arg
    RESULT
        SS-Info
         -- optional
    ERRORS {
         systemFailure |
         dataMissing
         unexpectedDataValue
         bearerServiceNotProvisioned |
         teleserviceNotProvisioned |
         callBarred |
         illegalSS-Operation |
         ss-ErrorStatus
         ss-Incompatibility}
    CODE local:10 }
```

```
eraseSS OPERATION ::= {
                                                                              --Timer m
    ARGUMENT
        SS-ForBS-Code
    RESULT
         SS-Info
         -- optional
    ERRORS {
         systemFailure |
         dataMissing |
         unexpectedDataValue |
         bearerServiceNotProvisioned |
         teleserviceNotProvisioned |
         callBarred |
         illegalSS-Operation |
         ss-ErrorStatus
    CODE local:11 }
```

```
activateSS OPERATION ::= {
                                                                            --Timer m
    ARGUMENT
         SS-ForBS-Code
    RESULT
         SS-Info
         -- optional
    ERRORS {
         systemFailure |
         dataMissing
         unexpectedDataValue
         bearerServiceNotProvisioned |
         teleserviceNotProvisioned |
         callBarred |
         illegalSS-Operation |
         ss-ErrorStatus
         ss-SubscriptionViolation |
         ss-Incompatibility |
         negativePW-Check
         numberOfPW-AttemptsViolation}
    CODE local:12
```

```
deactivateSS OPERATION ::= {
                                                                               --Timer m
    ARGUMENT
         SS-ForBS-Code
    RESULT
         SS-Info
         -- optional
    ERRORS {
         systemFailure
         dataMissing
         unexpectedDataValue
         bearerServiceNotProvisioned |
         teleserviceNotProvisioned |
         callBarred |
         illegalSS-Operation |
         ss-ErrorStatus
         ss-SubscriptionViolation |
         negativePW-Check |
         \verb|numberOfPW-AttemptsViolation|| \\
    CODE local:13 }
```

```
interrogateSS OPERATION ::= {
                                                                             --Timer m
    ARGUMENT
         SS-ForBS-Code
    RESULT
         InterrogateSS-Res
    ERRORS {
         systemFailure |
         dataMissing
         unexpectedDataValue |
         bearerServiceNotProvisioned |
         teleserviceNotProvisioned |
         callBarred |
         illegalSS-Operation |
         ss-NotAvailable}
    CODE local:14 }
```

```
unstructuredSS-Request OPERATION ::= {
                                                                             --Timer ml
    ARGUMENT
         USSD-Arg
    RESULT
         USSD-Res
         -- optional
     ERRORS {
         systemFailure |
         dataMissing |
         unexpectedDataValue |
         absentSubscriber |
         illegalSubscriber |
         illegalEquipment |
         unknownAlphabet |
         ussd-Busy
    CODE local:60
```

```
unstructuredSS-Notify OPERATION ::= {
    ARGUMENT
    USSD-Arg
    RETURN RESULT TRUE
    ERRORS {
        systemFailure |
        dataMissing |
        unexpectedDataValue |
        absentSubscriber |
        illegalSubscriber |
        illegalEquipment |
        unknownAlphabet |
        ussd-Busy}
    CODE local:61 }
```

```
registerPassword OPERATION ::= {
                                                                             --Timer ml
    ARGUMENT
         SS-Code
    RESULT
         Password
    ERRORS {
         systemFailure |
         dataMissing
         unexpectedDataValue |
         callBarred
         ss-SubscriptionViolation |
         pw-RegistrationFailure |
         negativePW-Check
         numberOfPW-AttemptsViolation}
    LINKED {
         getPassword}
    CODE local:17 }
```

```
getPassword OPERATION ::= {
    ARGUMENT
    GuidanceInfo
    RESULT
    Password
    CODE local:18 }
```

```
ss-InvocationNotification OPERATION ::= {
    ARGUMENT
        SS-InvocationNotificationArg
    RESULT
        SS-InvocationNotificationRes
        -- optional
    ERRORS {
        dataMissing |
        unexpectedDataValue |
        unknownSubscriber}
    CODE local:72 }
```

```
registerCC-Entry OPERATION ::= {
                                                                             --Timer m
    ARGUMENT
         RegisterCC-EntryArg
    RESULT
         RegisterCC-EntryRes
    ERRORS {
         systemFailure |
         dataMissing
         unexpectedDataValue
         callBarred |
         illegalSS-Operation |
         ss-ErrorStatus
         ss-Incompatibility |
         shortTermDenial |
         longTermDenial |
         facilityNotSupported}
    CODE local:76
```

END

# 17.6.5 Short message service operations

```
MAP-ShortMessageServiceOperations {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-ShortMessageServiceOperations (9)
  version10 (10) }
```

DEFINITIONS

```
: :=
BEGIN
EXPORTS
  sendRoutingInfoForSM,
  mo-ForwardSM,
  mt-ForwardSM,
  reportSM-DeliveryStatus,
  alertServiceCentre,
  informServiceCentre,
  readyForSM,
  mt-ForwardSM-VGCS
IMPORTS
  OPERATION
FROM Remote-Operations-Information-Objects {
  joint-iso-itu-t remote-operations(4)
  informationObjects(5) version1(0)}
   systemFailure,
   dataMissing,
  unexpectedDataValue,
   facilityNotSupported,
  unknownSubscriber,
   unidentifiedSubscriber,
   illegalSubscriber,
   illegalEquipment,
   teleserviceNotProvisioned,
   callBarred,
   subscriberBusyForMT-SMS,
   sm-DeliveryFailure,
  messageWaitingListFull,
   absentSubscriberSM
FROM MAP-Errors {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-Errors (10) version10 (10)}
  RoutingInfoForSM-Arg,
  RoutingInfoForSM-Res,
   MO-ForwardSM-Arg,
  MO-ForwardSM-Res,
  MT-ForwardSM-Arg,
  MT-ForwardSM-Res,
  ReportSM-DeliveryStatusArg,
   ReportSM-DeliveryStatusRes,
   AlertServiceCentreArg,
   InformServiceCentreArg,
   ReadyForSM-Arg,
  ReadyForSM-Res,
  MT-ForwardSM-VGCS-Arg,
  MT-ForwardSM-VGCS-Res
FROM MAP-SM-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SM-DataTypes (16) version10 (10)}
sendRoutingInfoForSM OPERATION ::= {
                                                                             --Timer m
    ARGUMENT
         RoutingInfoForSM-Arg
    RESULT
         RoutingInfoForSM-Res
    ERRORS {
         systemFailure |
         dataMissing
         unexpectedDataValue |
         facilityNotSupported |
         unknownSubscriber
         teleserviceNotProvisioned |
         callBarred |
         absentSubscriberSM}
    CODE local:45
```

```
mt-ForwardSM OPERATION ::= {
                                                                             --Timer ml
    ARGUMENT
         MT-ForwardSM-Arg
    RESULT
         MT-ForwardSM-Res
         -- optional
    ERRORS {
         systemFailure |
         dataMissing |
         unexpectedDataValue |
         facilityNotSupported |
         unidentifiedSubscriber |
         illegalSubscriber |
         illegalEquipment |
         subscriberBusyForMT-SMS |
         sm-DeliveryFailure |
         absentSubscriberSM}
     CODE local:44 }
```

```
alertServiceCentre OPERATION ::= {
    ARGUMENT
    AlertServiceCentreArg
    RETURN RESULT TRUE
    ERRORS {
        systemFailure |
        dataMissing |
        unexpectedDataValue}
    CODE local:64 }
```

```
informServiceCentre OPERATION ::= {
    ARGUMENT
    InformServiceCentreArg
    CODE local:63 }
```

```
readyForSM    OPERATION ::= {
        ARGUMENT
        ReadyForSM-Arg
        RESULT
        ReadyForSM-Res
        -- optional
        ERRORS {
            dataMissing |
            unexpectedDataValue |
            facilityNotSupported |
            unknownSubscriber}
        CODE local:66 }
```

END

## 17.6.6 Errors

```
MAP-Errors {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Errors (10) version10 (10)}
DEFINITIONS
::=
BEGIN
EXPORTS
   -- generic errors
   systemFailure,
  dataMissing,
  unexpectedDataValue,
   facilityNotSupported,
   incompatibleTerminal,
   resourceLimitation,
   -- identification and numbering errors
  unknownSubscriber,
  numberChanged,
   unknownMSC,
  unidentifiedSubscriber,
  unknownEquipment,
   -- subscription errors
   roamingNotAllowed,
   illegalSubscriber,
   illegalEquipment,
  bearerServiceNotProvisioned,
  teleserviceNotProvisioned,
   -- handover errors
  noHandoverNumberAvailable,
   subsequentHandoverFailure,
  targetCellOutsideGroupCallArea,
   -- operation and maintenance errors
  tracingBufferFull,
   -- call handling errors
   or-NotAllowed,
  noRoamingNumberAvailable,
  busySubscriber,
  noSubscriberReply,
   absentSubscriber,
   callBarred,
   forwardingViolation,
   forwardingFailed,
   cug-Reject,
   -- any time interrogation errors
  ati-NotAllowed,
   -- any time information handling errors
   atsi-NotAllowed,
   atm-NotAllowed,
   informationNotAvailable,
```

```
-- supplementary service errors
   illegalSS-Operation,
   ss-ErrorStatus,
   ss-NotAvailable,
   ss-SubscriptionViolation,
   ss-Incompatibility,
   unknownAlphabet,
  ussd-Busy,
   pw-RegistrationFailure,
   negativePW-Check,
  numberOfPW-AttemptsViolation,
   shortTermDenial,
   longTermDenial,
   -- short message service errors
   subscriberBusyForMT-SMS,
   sm-DeliveryFailure,
  messageWaitingListFull,
   absentSubscriberSM,
   -- Group Call errors
   noGroupCallNumberAvailable,
   ongoingGroupCall,
   -- location service errors
  unauthorizedRequestingNetwork,
   unauthorizedLCSClient,
   positionMethodFailure,
   unknownOrUnreachableLCSClient,
   -- Mobility Management errors
  {\tt mm-EventNotSupported}
;
IMPORTS
FROM Remote-Operations-Information-Objects {joint-iso-itu-t remote-operations(4)
  informationObjects(5) version1(0) }
   SS-Status
FROM MAP-SS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-SS-DataTypes (14) version10 (10)}
   SS-IncompatibilityCause,
   PW-RegistrationFailureCause,
   SM-DeliveryFailureCause,
   SystemFailureParam,
   DataMissingParam,
   UnexpectedDataParam,
   FacilityNotSupParam,
   UnknownSubscriberParam,
   NumberChangedParam,
   UnidentifiedSubParam.
   RoamingNotAllowedParam,
   IllegalSubscriberParam,
   IllegalEquipmentParam,
   BearerServNotProvParam,
   TeleservNotProvParam,
   TracingBufferFullParam,
   NoRoamingNbParam,
   OR-NotAllowedParam,
   AbsentSubscriberParam,
   BusySubscriberParam,
   NoSubscriberReplyParam,
   CallBarredParam,
   ForwardingViolationParam,
   ForwardingFailedParam,
   CUG-RejectParam,
   ATI-NotAllowedParam,
   SubBusyForMT-SMS-Param,
   MessageWaitListFullParam,
   AbsentSubscriberSM-Param,
   ResourceLimitationParam,
   NoGroupCallNbParam,
   IncompatibleTerminalParam,
   ShortTermDenialParam,
```

```
LongTermDenialParam,
   UnauthorizedRequestingNetwork-Param,
   UnauthorizedLCSClient-Param,
   PositionMethodFailure-Param,
   UnknownOrUnreachableLCSClient-Param,
   MM-EventNotSupported-Param,
   ATSI-NotAllowedParam,
   ATM-NotAllowedParam,
   IllegalSS-OperationParam,
   SS-NotAvailableParam,
   SS-SubscriptionViolationParam,
   InformationNotAvailableParam,
   TargetCellOutsideGCA-Param,
   OngoingGroupCallParam
FROM MAP-ER-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ER-DataTypes (17) version10 (10)}
-- generic errors
systemFailure ERROR ::= {
     PARAMETER
         SystemFailureParam
          -- optional
    CODE local:34 }
dataMissing ERROR ::= {
    PARAMETER
         DataMissingParam
         -- optional
          -- DataMissingParam must not be used in version <3
    CODE local:35 }
unexpectedDataValue ERROR ::= {
     PARAMETER
         UnexpectedDataParam
         -- optional
          -- UnexpectedDataParam must not be used in version <3
     CODE local:36 }
facilityNotSupported ERROR ::= {
    PARAMETER
         FacilityNotSupParam
          -- optional
          -- FacilityNotSupParam must not be used in version <3
    CODE local:21 }
incompatibleTerminal ERROR ::= {
    PARAMETER
         IncompatibleTerminalParam
          -- optional
    CODE local:28 }
resourceLimitation ERROR ::= {
    PARAMETER
         ResourceLimitationParam
          -- optional
     CODE local:51 }
-- identification and numbering errors
unknownSubscriber ERROR ::= {
    PARAMETER
         UnknownSubscriberParam
          -- UnknownSubscriberParam must not be used in version <3
    CODE local:1 }
numberChanged ERROR ::= {
    PARAMETER
         NumberChangedParam
          -- optional
     CODE local:44 }
unknownMSC ERROR ::= {
    CODE local:3 }
```

```
unidentifiedSubscriber ERROR ::= {
    PARAMETER
         UnidentifiedSubParam
         -- optional
          -- UunidentifiedSubParam must not be used in version <3
     CODE local:5 }
unknownEquipment ERROR ::= {
    CODE local:7 }
-- subscription errors
roamingNotAllowed ERROR ::= {
    PARAMETER
         RoamingNotAllowedParam
     CODE local:8 }
illegalSubscriber ERROR ::= {
     PARAMETER
         IllegalSubscriberParam
         -- optional
          -- IllegalSubscriberParam must not be used in version <3
     CODE local:9 }
illegalEquipment ERROR ::= {
     PARAMETER
         IllegalEquipmentParam
          -- optional
          -- IllegalEquipmentParam must not be used in version <3
     CODE local:12 }
bearerServiceNotProvisioned ERROR ::= {
    PARAMETER
         BearerServNotProvParam
          -- optional
         -- BearerServNotProvParam must not be used in version <3
     CODE local:10 }
teleserviceNotProvisioned ERROR ::= {
    PARAMETER
         TeleservNotProvParam
         -- optional
          -- TeleservNotProvParam must not be used in version <3
     CODE local:11 }
-- handover errors
noHandoverNumberAvailable ERROR ::= {
    CODE local:25 }
subsequentHandoverFailure ERROR ::= {
    CODE local:26 }
targetCellOutsideGroupCallArea ERROR ::= {
    PARAMETER
         TargetCellOutsideGCA-Param
          -- optional
     CODE local:42 }
-- operation and maintenance errors
tracingBufferFull ERROR : := {
    PARAMETER
         TracingBufferFullParam
          -- optional
    CODE local: 40 }
-- call handling errors
noRoamingNumberAvailable ERROR ::= {
    PARAMETER
       NoRoamingNbParam
         -- optional
    CODE local:39 }
```

```
absentSubscriber ERROR ::= {
    PARAMETER
         AbsentSubscriberParam
         -- optional
         -- AbsentSubscriberParam must not be used in version <3
    CODE local:27 }
busySubscriber ERROR ::= {
    PARAMETER
         BusySubscriberParam
         -- optional
    CODE local:45 }
noSubscriberReply ERROR ::= {
    PARAMETER
        NoSubscriberReplyParam
         -- optional
    CODE local:46 }
callBarred ERROR ::= {
    PARAMETER
        CallBarredParam
         -- optional
    CODE local:13 }
forwardingViolation ERROR ::= {
    PARAMETER
        ForwardingViolationParam
         -- optional
    CODE local:14 }
forwardingFailed ERROR ::= {
    PARAMETER
         ForwardingFailedParam
          -- optional
    CODE local:47 }
cug-Reject ERROR ::= {
    PARAMETER
        CUG-RejectParam
         -- optional
    CODE local:15 }
or-NotAllowed ERROR ::= {
    PARAMETER
         OR-NotAllowedParam
          -- optional
    CODE local:48 }
-- any time interrogation errors
ati-NotAllowed ERROR ::= {
   PARAMETER
         ATI-NotAllowedParam
         -- optional
    CODE local:49 }
 - any time information handling errors
atsi-NotAllowed ERROR ::= {
    PARAMETER
        ATSI-NotAllowedParam
         -- optional
    CODE local:60 }
atm-NotAllowed ERROR ::= {
    PARAMETER
        ATM-NotAllowedParam
          -- optional
    CODE local:61 }
informationNotAvailable ERROR ::= {
    PARAMETER
         InformationNotAvailableParam
         -- optional
    CODE local:62 }
```

-- supplementary service errors

```
illegalSS-Operation ERROR ::= {
    PARAMETER
         IllegalSS-OperationParam
         -- optional
          -- IllegalSS-OperationParam must not be used in version <3
    CODE local:16 }
ss-ErrorStatus ERROR ::= {
    PARAMETER
         SS-Status
         -- optional
    CODE local:17 }
ss-NotAvailable ERROR ::= {
    PARAMETER
         SS-NotAvailableParam
         -- optional
         -- SS-NotAvailableParam must not be used in version <3
    CODE local:18 }
ss-SubscriptionViolation ERROR ::= {
    PARAMETER
        SS-SubscriptionViolationParam
         -- optional
         -- SS-SubscriptionViolationParam must not be used in version <3
    CODE local:19 }
ss-Incompatibility ERROR ::= {
    PARAMETER
        SS-IncompatibilityCause
         -- optional
    CODE local:20 }
unknownAlphabet ERROR ::= {
   CODE local:71 }
ussd-Busy ERROR ::= {
    CODE local:72 }
pw-RegistrationFailure ERROR ::= {
    PARAMETER
         PW-RegistrationFailureCause
    CODE local:37 }
negativePW-Check ERROR ::= {
    CODE local:38 }
numberOfPW-AttemptsViolation ERROR ::= {
    CODE local:43 }
shortTermDenial ERROR ::= {
    PARAMETER
         ShortTermDenialParam
          -- optional
    CODE local:29 }
longTermDenial ERROR ::= {
    PARAMETER
        LongTermDenialParam
          -- optional
    CODE local:30 }
-- short message service errors
subscriberBusyForMT-SMS ERROR ::= {
    PARAMETER
         SubBusyForMT-SMS-Param
         -- optional
    CODE local:31 }
sm-DeliveryFailure ERROR ::= {
    PARAMETER
        SM-DeliveryFailureCause
    CODE local:32 }
```

```
messageWaitingListFull ERROR ::= {
    PARAMETER
        MessageWaitListFullParam
        -- optional
    CODE local:33 }
```

```
absentSubscriberSM ERROR ::= {
    PARAMETER
        AbsentSubscriberSM-Param
        -- optional
    CODE local:6 }
```

-- Group Call errors

```
noGroupCallNumberAvailable ERROR ::= {
    PARAMETER
    NoGroupCallNbParam
    -- optional
    CODE local:50 }
```

```
ongoingGroupCall ERROR ::= {
    PARAMETER
    OngoingGroupCallParam
    -- optional
    CODE local:22 }
```

-- location service errors

```
unauthorizedRequestingNetwork ERROR ::= {
    PARAMETER
    UnauthorizedRequestingNetwork-Param
    -- optional
    CODE local:52 }
```

```
unauthorizedLCSClient ERROR ::= {
    PARAMETER
        UnauthorizedLCSClient-Param
        -- optional
        CODE local:53 }
```

```
positionMethodFailure ERROR ::= {
    PARAMETER
    PositionMethodFailure-Param
    -- optional
    CODE local:54 }
```

```
unknownOrUnreachableLCSClient ERROR ::= {
    PARAMETER
        UnknownOrUnreachableLCSClient-Param
        -- optional
        CODE local:58 }
```

END

## 17.6.7 Group Call operations

```
MAP-Group-Call-Operations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Group-Call-Operations (22)
   version10 (10) }

DEFINITIONS
::=
BEGIN

EXPORTS
   prepareGroupCall,
   sendGroupCallEndSignal,
```

forwardGroupCallSignalling,

```
processGroupCallSignalling,
  sendGroupCallInfo
IMPORTS
  OPERATION
FROM Remote-Operations-Information-Objects {
  joint-iso-itu-t remote-operations(4)
  informationObjects(5) version1(0) }
   systemFailure,
  unexpectedDataValue,
  noGroupCallNumberAvailable,
  ongoingGroupCall,
  unknownSubscriber,
  teleserviceNotProvisioned,
  dataMissing
FROM MAP-Errors
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-Errors (10) version10 (10)}
  PrepareGroupCallArg,
   PrepareGroupCallRes,
   SendGroupCallEndSignalArg,
   SendGroupCallEndSignalRes,
   {\tt ForwardGroupCallSignallingArg,}
  ProcessGroupCallSignallingArg,
   SendGroupCallInfoArg,
  SendGroupCallInfoRes
FROM MAP-GR-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-GR-DataTypes (23) version10 (10)}
prepareGroupCall OPERATION ::= {
                                                                             --Timer m
    ARGUMENT
         PrepareGroupCallArg
    RESULT
    PrepareGroupCallRes
    ERRORS {
         systemFailure |
         noGroupCallNumberAvailable |
         unexpectedDataValue}
    CODE local:39 }
sendGroupCallEndSignal OPERATION ::= {
                                                                             --Timer 1
    ARGUMENT
         SendGroupCallEndSignalArg
    RESULT
         SendGroupCallEndSignalRes
    CODE local:40 }
processGroupCallSignalling OPERATION ::= {
                                                                               --Timer s
    ARGUMENT
         ProcessGroupCallSignallingArg
    CODE local:41
forwardGroupCallSignalling OPERATION ::= {
                                                                               --Timer s
    ARGUMENT
         ForwardGroupCallSignallingArg
    CODE local:42
sendGroupCallInfo OPERATION ::= {
                                                                             --Timer m
    ARGUMENT
         SendGroupCallInfoArg
    RESULT
         SendGroupCallInfoRes
    ERRORS {
         systemFailure
         ongoingGroupCall |
         unexpectedDataValue |
         dataMissing |
         teleserviceNotProvisioned |
         unknownSubscriber}
    CODE local:84 }
```

END

## 17.6.8 Location service operations

```
MAP-LocationServiceOperations {
 123456789
       itu-t identified-organization (4) etsi (0) mobileDomain (0)
       gsm-Network (1) modules (3) map-LocationServiceOperations (24)
       version10 (10)}
    DEFINITIONS
10
   BEGIN
11
12
    EXPORTS
13
       provideSubscriberLocation,
14
       sendRoutingInfoForLCS,
15
       subscriberLocationReport
16
17
   IMPORTS
19
       OPERATION
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
40
41
42
43
   FROM Remote-Operations-Information-Objects {
       joint-iso-itu-t remote-operations(4)
      informationObjects(5) version1(0) }
       systemFailure,
       dataMissing,
       unexpectedDataValue,
       facilityNotSupported,
       unknownSubscriber,
       absentSubscriber.
       unauthorizedRequestingNetwork,
       unauthorizedLCSClient,
       positionMethodFailure,
       resourceLimitation,
       unknownOrUnreachableLCSClient,
       unidentifiedSubscriber,
       illegalEquipment,
       illegalSubscriber
    FROM MAP-Errors {
       itu-t identified-organization (4) etsi (0) mobileDomain (0)
       gsm-Network (1) modules (3) map-Errors (10) version10 (10)}
       RoutingInfoForLCS-Arg,
       RoutingInfoForLCS-Res,
44
45
46
       ProvideSubscriberLocation-Arg,
       ProvideSubscriberLocation-Res,
       SubscriberLocationReport-Arg,
47
       SubscriberLocationReport-Res
    FROM MAP-LCS-DataTypes {
49
50
51
       itu-t identified-organization (4) etsi (0) mobileDomain (0)
       gsm-Network (1) modules (3) map-LCS-DataTypes (25) version10 (10)}
53
54
55
56
57
58
59
   sendRoutingInfoForLCS OPERATION ::= {
                                                                                       --Timer m
         ARGUMENT
              RoutingInfoForLCS-Arg
         RESULT
              RoutingInfoForLCS-Res
         ERRORS {
              systemFailure
60
              dataMissing
61
              unexpectedDataValue |
62
              facilityNotSupported |
63
              unknownSubscriber |
64
              absentSubscriber |
65
              unauthorizedRequestingNetwork }
66
         CODE local:85 }
67
```

```
provideSubscriberLocation OPERATION ::= {
                                                                                           --Timer ml
69
70
71
72
73
74
75
76
77
78
80
81
82
83
84
85
          ARGUMENT
               ProvideSubscriberLocation-Arg
          RESULT
               ProvideSubscriberLocation-Res
          ERRORS {
               systemFailure |
               dataMissing
               unexpectedDataValue |
               facilityNotSupported
               unidentifiedSubscriber
               illegalSubscriber |
               illegalEquipment
               absentSubscriber
               unauthorizedRequestingNetwork |
               unauthorizedLCSClient
               {\tt positionMethodFailure}
          CODE local:83 }
 86
 87
    subscriberLocationReport OPERATION ::= {
                                                                                          --Timer m
 88
               SubscriberLocationReport-Arg
 90
          RESULT
91
92
93
               SubscriberLocationReport-Res
          ERRORS {
               systemFailure |
 94
               dataMissing |
 95
               resourceLimitation |
96
97
98
               unexpectedDataValue |
               unknownSubscriber
               unauthorizedRequestingNetwork |
99
               unknownOrUnreachableLCSClient}
100
          CODE local:86
101
103
     END
```

## 2 17.6.9 Void

# 17.7 MAP constants and data types

# 17.7.1 Mobile Service data types

```
MAP-MS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-MS-DataTypes (11) version10 (10)}
DEFINITIONS
IMPLICIT TAGS
BEGIN
EXPORTS
   -- location registration types
  UpdateLocationArg,
   UpdateLocationRes,
   CancelLocationArg,
   CancelLocationRes,
   PurgeMS-Arg,
   PurgeMS-Res,
   SendIdentificationArg,
   SendIdentificationRes,
   UpdateGprsLocationArg,
   UpdateGprsLocationRes,
   IST-SupportIndicator,
   SupportedLCS-CapabilitySets,
```

```
-- gprs location registration types
  GSN-Address,
  -- handover types
  ForwardAccessSignalling-Arg,
  PrepareHO-Arg,
  PrepareHO-Res,
  PrepareSubsequentHO-Arg,
  PrepareSubsequentHO-Res,
  ProcessAccessSignalling-Arg,
  SendEndSignal-Arg,
  SendEndSignal-Res,
  -- authentication management types
  SendAuthenticationInfoArg,
  SendAuthenticationInfoRes,
  AuthenticationFailureReportArg,
  AuthenticationFailureReportRes,
  -- security management types
  Kc,
  Cksn,
  -- equipment management types
  CheckIMEI-Arg,
  CheckIMEI-Res,
  -- subscriber management types
  InsertSubscriberDataArg,
  InsertSubscriberDataRes,
  LSAIdentity,
  DeleteSubscriberDataArg,
  DeleteSubscriberDataRes,
  Ext-QoS-Subscribed,
  Ext2-QoS-Subscribed,
  Ext3-OoS-Subscribed,
  SubscriberData,
  ODB-Data,
  SubscriberStatus,
  ZoneCodeList,
  maxNumOfZoneCodes,
  O-CSI,
  D-CSI,
  O-BcsmCamelTDPCriteriaList,
  T-BCSM-CAMEL-TDP-CriteriaList,
  SS-CSI.
  ServiceKey,
  DefaultCallHandling,
  CamelCapabilityHandling,
  BasicServiceCriteria,
  SupportedCamelPhases,
  OfferedCamel4CSIs,
  OfferedCamel4Functionalities,
  maxNumOfCamelTDPData,
  CUG-Index,
  CUG-Info,
  CUG-Interlock,
  InterCUG-Restrictions,
  IntraCUG-Options,
  NotificationToMSUser,
  OoS-Subscribed,
  IST-AlertTimerValue,
  T-CSI,
  T-BcsmTriggerDetectionPoint,
  APN,
  AdditionalInfo,
  -- fault recovery types
  ResetArg,
  RestoreDataArg,
  RestoreDataRes,
-- provide subscriber info types
  GeographicalInformation,
  MS-Classmark2,
  GPRSMSClass,
   -- subscriber information enquiry types
```

ProvideSubscriberInfoArg,

```
ProvideSubscriberInfoRes,
   SubscriberInfo,
  LocationInformation,
  LocationInformationGPRS,
   RAIdentity,
   SubscriberState,
   GPRSChargingID,
  MNPInfoRes,
  RouteingNumber,
   -- any time information enquiry types
  AnyTimeInterrogationArg,
  AnyTimeInterrogationRes,
   -- any time information handling types
  AnyTimeSubscriptionInterrogationArg,
   AnyTimeSubscriptionInterrogationRes,
   AnyTimeModificationArg,
   AnyTimeModificationRes,
   -- subscriber data modification notification types
  NoteSubscriberDataModifiedArg,
  NoteSubscriberDataModifiedRes,
   -- gprs location information retrieval types
  SendRoutingInfoForGprsArg,
  SendRoutingInfoForGprsRes,
   -- failure reporting types
   FailureReportArg,
  FailureReportRes,
   -- gprs notification types
  NoteMsPresentForGprsArg,
  NoteMsPresentForGprsRes,
   -- Mobility Management types
  NoteMM-EventArg,
  NoteMM-EventRes,
  NumberPortabilityStatus,
   -- VGCS / VBS types types
  GroupId,
  Long-GroupId,
  AdditionalSubscriptions
IMPORTS
  maxNumOfSS,
  SS-SubscriptionOption,
  SS-List,
  SS-ForBS-Code,
FROM MAP-SS-DataTypes {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-DataTypes (14) version10 (10)}
FROM MAP-SS-Code {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-Code (15) version10 (10)}
  Ext-BearerServiceCode
FROM MAP-BS-Code {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-BS-Code (20) version10 (10)}
  Ext-TeleserviceCode
FROM MAP-TS-Code {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-TS-Code (19) version10 (10)}
  AddressString,
   ISDN-AddressString,
   ISDN-SubaddressString,
   FTN-AddressString,
   AccessNetworkSignalInfo,
   IMSI,
```

```
IMEI,
   TMSI,
  HLR-List,
   LMSI,
   Identity,
   GlobalCellId,
   CellGlobalIdOrServiceAreaIdOrLAI,
   Ext-BasicServiceCode,
  NAEA-PreferredCI,
   EMLPP-Info,
  MC-SS-Info,
   SubscriberIdentity,
  AgeOfLocationInformation,
   LCSClientExternalID,
   LCSClientInternalID,
  Ext-SS-Status,
  LCSServiceTypeID,
  ASCI-CallReference,
   TBCD-STRING,
   LAIFixedLength,
  PLMN-Id
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobile
Domain (0)
   gsm-Network (1) modules (3) map-CommonDataTypes (18) version10 (10)}
  ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version10 (10)}
  AbsentSubscriberDiagnosticSM
FROM MAP-ER-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ER-DataTypes (17) version10 (10)}
  TracePropagationList
FROM MAP-OM-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-OM-DataTypes (12) version10 (10)}
-- location registration types
```

```
UpdateLocationArg ::= SEQUENCE {
    imsi
                                            IMSI,
     msc-Number
                                            [1] ISDN-AddressString,
     vlr-Number
                                            ISDN-AddressString,
                                            [10] LMSI
    lmsi
                                                                                OPTIONAL,
     extensionContainer
                                            ExtensionContainer
                                                                                OPTIONAL,
     vlr-Capability
                                            [6] VLR-Capability
                                                                                OPTIONAL,
     informPreviousNetworkEntity
                                            [11] NULL
                                                                                OPTIONAL.
     cs-LCS-NotSupportedByUE
                                            [12] NULL
                                                                                OPTIONAL,
     v-gmlc-Address
                                            [2] GSN-Address
[13] ADD-Info
                                                                                OPTIONAL,
     add-info
                                                                                OPTIONAL
```

```
{\tt VLR-Capability} \; ::= \; {\tt SEQUENCE} \big\{
     supportedCamelPhases
                                            [0] SupportedCamelPhases
                                                                                 OPTIONAL,
     extensionContainer
                                            ExtensionContainer
                                                                                 OPTIONAL,
     solsaSupportIndicator
                                            [2] NULL
                                                                                 OPTIONAL.
                                            [1] IST-SupportIndicator
     \verb|istSupportIndicator||\\
                                                                                 OPTIONAL,
     superChargerSupportedInServingNetworkEntity
                                                      [3] SuperChargerInfo
                                                                                 OPTIONAL,
                                            [4] NULL
     longFTN-Supported
                                                                                 OPTIONAL,
     supportedLCS-CapabilitySets
                                            [5] SupportedLCS-CapabilitySets
                                                                                 OPTIONAL,
     offeredCamel4CSIs
                                            [6] OfferedCamel4CSIs
                                                                                 OPTIONAL,
     supportedRAT-TypesIndicator
                                            [7] SupportedRAT-Types
                                                                                 OPTIONAL,
     longGroupID-Supported
                                            [8] NULL
                                                                                 OPTIONAL
```

```
SupportedRAT-Types::= BIT STRING {
    utran (0),
    geran (1),
    gan (2),
    i-hspa-evolution (3)} (SIZE (2..8))
    -- exception handling: bits 4 to 7 shall be ignored if received and not understood
```

```
SuperChargerInfo ::= CHOICE {
                                            [0] NULL,
     sendSubscriberData
     subscriberDataStored
                                            [1] AgeIndicator }
AgeIndicator ::= OCTET STRING (SIZE (1..6))
     -- The internal structure of this parameter is implementation specific.
IST-SupportIndicator ::= ENUMERATED {
    basicISTSupported
                                            (0),
     istCommandSupported
                                            (1),
     ...}
-- exception handling:
-- reception of values > 1 shall be mapped to ' istCommandSupported '
SupportedLCS-CapabilitySets ::= BIT STRING {
    lcsCapabilitySet1 (0),
     lcsCapabilitySet2 (1),
     lcsCapabilitySet3 (2),
    lcsCapabilitySet4 (3) ,
lcsCapabilitySet5 (4) } (SIZE (2..16))
-- Core network signalling capability set1 indicates LCS Release98 or Release99 version.
-- Core network signalling capability set2 indicates LCS Release4.
-- Core network signalling capability set3 indicates LCS Release5.
-- Core network signalling capability set4 indicates LCS Release6.
-- Core network signalling capability set5 indicates LCS Release7 or later version.
-- A node shall mark in the BIT STRING all LCS capability sets it supports.
-- If no bit is set then the sending node does not support LCS.
-- If the parameter is not sent by an VLR then the VLR may support at most capability set1.
-- If the parameter is not sent by an SGSN then no support for LCS is assumed.
-- An SGSN is not allowed to indicate support of capability set1.
-- Other bits than listed above shall be discarded.
UpdateLocationRes ::= SEQUENCE {
    hlr-Number
                                           ISDN-AddressString,
     extensionContainer
                                           ExtensionContainer
                                                                                OPTIONAL,
     add-Capability
                                           NULL
                                                                                OPTIONAL }
ADD-Info ::= SEQUENCE {
                                            [0] IMEI,
     imeisv
                                            [1] NULL
     skipSubscriberDataUpdate
                                                                                OPTIONAL.
CancelLocationArg ::= [3] SEQUENCE {
     identity
                                            Identity,
     cancellationType
                                            CancellationType
                                                                                OPTIONAL,
     extensionContainer
                                            ExtensionContainer
                                                                                OPTIONAL,
CancellationType ::= ENUMERATED {
     updateProcedure
                                            (0),
     subscriptionWithdraw
                                            (1),
     -- The HLR shall not send values other than listed above
CancelLocationRes ::= SEQUENCE {
                                                                                OPTIONAL.
     extensionContainer
                                            ExtensionContainer
PurgeMS-Arg ::= [3] SEQUENCE {
     imsi
     vlr-Number
                                            [0] ISDN-AddressString
                                                                                OPTIONAL,
                                            [1] ISDN-AddressString
     sgsn-Number
                                                                                OPTIONAL.
                                                                                OPTIONAL,
     extensionContainer
                                            ExtensionContainer
PurgeMS-Res ::= SEQUENCE {
     freezeTMSI
                                            [0] NULL
                                                                                OPTIONAL,
     freezeP-TMSI
                                            [1] NULL
                                                                                OPTIONAL,
     extensionContainer
                                           ExtensionContainer
                                                                                OPTIONAL,
```

```
SendIdentificationArg ::= SEQUENCE {
                                           TMST.
                                          NumberOfRequestedVectors
     numberOfRequestedVectors
                                                                              OPTIONAL,
     -- within a dialogue numberOfRequestedVectors shall be present in
     -- the first service request and shall not be present in subsequent service requests.
     -- If received in a subsequent service request it shall be discarded.
     segmentationProhibited
                                          NULL
                                                                              OPTIONAL.
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL,
     msc-Number
                                           ISDN-AddressString
                                                                              OPTIONAL,
     previous-LAI
                                           [0] LAIFixedLength
                                                                              OPTIONAL,
     hopCounter
                                           [1] HopCounter
                                                                              OPTIONAL
HopCounter ::= INTEGER (0..3)
SendIdentificationRes ::= [3] SEQUENCE {
     imsi
                                           IMSI
                                                                              OPTIONAL,
     -- IMSI shall be present in the first (or only) service response of a dialogue.
     -- If multiple service requests are present in a dialogue then IMSI
     -- shall not be present in any service response other than the first one.
     authenticationSetList
                                                                              OPTIONAL,
                                          AuthenticationSetList
     {\tt currentSecurityContext}
                                           [2] CurrentSecurityContext
                                                                              OPTIONAL,
     extensionContainer
                                           [3] ExtensionContainer
                                                                              OPTIONAL,
-- authentication management types
AuthenticationSetList ::= CHOICE {
     tripletList
                                           [0] TripletList,
     quintupletList
                                           [1] QuintupletList }
TripletList ::= SEQUENCE SIZE (1..5) OF
                                           AuthenticationTriplet
QuintupletList ::= SEQUENCE SIZE (1..5) OF
                                           AuthenticationQuintuplet
AuthenticationTriplet ::= SEQUENCE {
                                           RAND.
     rand
     sres
                                           SRES,
                                           Kc,
     kc
AuthenticationQuintuplet ::= SEQUENCE {
                                           RAND,
     rand
     xres
                                           XRES.
     ck
                                           CK,
     ik
                                           IK,
                                           AUTN,
     autn
CurrentSecurityContext ::= CHOICE {
     gsm-SecurityContextData
                                           [0] GSM-SecurityContextData,
                                           [1] UMTS-SecurityContextData }
     umts-SecurityContextData
GSM-SecurityContextData ::= SEQUENCE {
                                           Kc,
     cksn
UMTS-SecurityContextData ::= SEQUENCE {
                                           CK,
     ck
     ik
                                           IK.
     ksi
                                           KSI,
RAND ::= OCTET STRING (SIZE (16))
SRES ::= OCTET STRING (SIZE (4))
Kc ::= OCTET STRING (SIZE (8))
XRES ::= OCTET STRING (SIZE (4..16))
CK ::= OCTET STRING (SIZE (16))
```

```
IK ::= OCTET STRING (SIZE (16))
AUTN ::= OCTET STRING (SIZE (16))
AUTS ::= OCTET STRING (SIZE (14))
Cksn ::= OCTET STRING (SIZE (1))
      -- The internal structure is defined in 3GPP TS 24.008
KSI ::= OCTET STRING (SIZE (1))
     -- The internal structure is defined in 3GPP TS 24.008
AuthenticationFailureReportArg ::= SEQUENCE
     imsi
                                           IMSI
     failureCause
                                           FailureCause,
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL,
     re-attempt
                                           BOOLEAN
                                                                              OPTIONAL,
     accessType
                                           AccessType
                                                                              OPTIONAL,
     rand
                                           RAND
                                                                               OPTIONAL,
     vlr-Number
                                           [0] ISDN-AddressString
                                                                              OPTIONAL,
                                               ISDN-AddressString
     sgsn-Number
                                                                              OPTIONAL
                                            [1]
AccessType ::= ENUMERATED {
    call (0),
     emergencyCall (1),
     locationUpdating (2),
     supplementaryService (3),
     shortMessage (4),
     gprsAttach (5),
     routingAreaUpdating (6),
     serviceRequest (7),
     pdpContextActivation (8),
     pdpContextDeactivation (9),
     gprsDetach (10) }
      - exception handling:
     -- received values greater than 10 shall be ignored.
AuthenticationFailureReportRes ::= SEQUENCE {
                                                                              OPTIONAL,
     extensionContainer
                                           ExtensionContainer
FailureCause ::= ENUMERATED {
     wrongUserResponse (0),
     wrongNetworkSignature
-- gprs location registration types
UpdateGprsLocationArg ::= SEQUENCE {
                                           IMSI.
     imsi
     sgsn-Number
                                           ISDN-AddressString,
     sgsn-Address
                                           GSN-Address,
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL,
     sgsn-Capability
                                           [0] SGSN-Capability
                                                                              OPTIONAL.
     informPreviousNetworkEntity
                                           [1] NULL
                                                                              OPTIONAL,
     ps-LCS-NotSupportedByUE
                                           [2]
                                               NULL
                                                                               OPTIONAL,
     v-gmlc-Address
                                           [3] GSN-Address
                                                                              OPTIONAL,
     add-info
                                           [4]
                                               ADD-Info
                                                                              OPTIONAL
SGSN-Capability ::= SEQUENCE{
     {\tt solsaSupportIndicator}
                                           NULL
                                                                              OPTIONAL.
     extensionContainer
                                           [1] ExtensionContainer
                                                                              OPTIONAL,
     superChargerSupportedInServingNetworkEntity
                                                     [2] SuperChargerInfo
                                                                              OPTIONAL ,
     gprsEnhancementsSupportIndicator
                                          [3] NULL
                                                                              OPTIONAL,
     {\tt supportedCamelPhases}
                                           [4] SupportedCamelPhases
                                                                              OPTIONAL,
     supportedLCS-CapabilitySets
                                           [5] SupportedLCS-CapabilitySets
                                                                              OPTIONAL,
     offeredCamel4CSIs
                                           [6] OfferedCamel4CSIs
                                                                              OPTIONAL,
     smsCallBarringSupportIndicator
                                           [7] NULL
                                                                              OPTIONAL,
     supportedRAT-TypesIndicator
                                           [8] SupportedRAT-Types
                                                                              OPTIONAL
GSN-Address ::= OCTET STRING (SIZE (5..17))
```

-- Octets are coded according to TS 3GPP TS 23.003 [17]

-- handover types

```
ForwardAccessSignalling-Arg ::= [3] SEQUENCE {
     an-APDU
                                               AccessNetworkSignalInfo,
     integrityProtectionInfo
                                                [0] IntegrityProtectionInformation OPTIONAL,
                                               [1] EncryptionInformation OPTIONAL,
     encryptionInfo
                                              [2] KeyStatus OPTIONAL,
[4] AllowedGSM-Algorithms OPTIONAL,
[5] AllowedUMTS-Algorithms OPTIONAL,
[6] RadioResourceInformation OPTIONAL,
[6] RadioResourceInformation OPTIONAL,
     kevStatus
     allowedGSM-Algorithms
     allowedUMTS-Algorithms
     radioResourceInformation
     extensionContainer
                                               [3] ExtensionContainer
                                                                                      OPTIONAL,
                                               [7] RadioResourceList
     radioResourceList
                                                                                      OPTIONAL.
     bssmap-ServiceHandover
ranap-ServiceHandover
                                             [9] BSSMAP-ServiceHandover
[8] RANAP-ServiceHandover
                                                                                      OPTIONAL,
                                                                                      OPTIONAL,
     bssmap-ServiceHandoverList
                                               [10] BSSMAP-ServiceHandoverList
                                                                                      OPTIONAL,
     currentlyUsedCodec
                                               [11] Codec
[12] SupportedCodecsList
     iuSupportedCodecsList
                                                                                       OPTIONAL.
                                                                                       OPTIONAL,
     rab-ConfigurationIndicator
                                             [13] NULL
                                                                                       OPTIONAL,
     iuSelectedCodec
                                               [14] Codec
                                                                                       OPTIONAL,
     alternativeChannelType
                                               [15] RadioResourceInformation
                                                                                       OPTIONAL,
                                             [17] TracePropagationList
                                                                                       OPTIONAL 3
     tracePropagationList
```

```
AllowedGSM-Algorithms ::= OCTET STRING (SIZE (1))
-- internal structure is coded as Algorithm identifier octet from
-- Permitted Algorithms defined in 3GPP TS 48.008
-- A node shall mark all GSM algorithms that are allowed in MSC-B
```

```
AllowedUMTS-Algorithms ::= SEQUENCE {
    integrityProtectionAlgorithms [0] PermittedIntegrityProtectionAlgorithms
    OPTIONAL,
    encryptionAlgorithms [1] PermittedEncryptionAlgorithms OPTIONAL,
    extensionContainer [2] ExtensionContainer OPTIONAL,
    ...}
```

```
PermittedIntegrityProtectionAlgorithms ::=

OCTET STRING (SIZE (1..maxPermittedIntegrityProtectionAlgorithmsLength))

-- Octets contain a complete PermittedIntegrityProtectionAlgorithms data type

-- as defined in 3GPP TS 25.413, encoded according to the encoding scheme

-- mandated by 3GPP TS 25.413.

-- Padding bits are included, if needed, in the least significant bits of the

-- last octet of the octet string.
```

#### maxPermittedIntegrityProtectionAlgorithmsLength INTEGER ::= 9

```
PermittedEncryptionAlgorithms ::=

OCTET STRING (SIZE (1..maxPermittedEncryptionAlgorithmsLength))

-- Octets contain a complete PermittedEncryptionAlgorithms data type

-- as defined in 3GPP TS 25.413, encoded according to the encoding scheme

-- mandated by 3GPP TS 25.413

-- Padding bits are included, if needed, in the least significant bits of the

-- last octet of the octet string.
```

#### maxPermittedEncryptionAlgorithmsLength INTEGER ::= 9

```
KeyStatus ::= ENUMERATED {
    old (0),
    new (1),
    ...}
    -- exception handling:
    -- received values in range 2-31 shall be treated as "old"
    -- received values greater than 31 shall be treated as "new"
```

```
PrepareHO-Arg ::= [3] SEQUENCE {
                                          [0] GlobalCellId
    targetCellId
                                                                            OPTIONAL.
                                                                            OPTIONAL,
    ho-NumberNotRequired
                                         NITIT.
    targetRNCId
                                          [1] RNCId
                                                                            OPTIONAL,
                                          [2] AccessNetworkSignalInfo
    an-APDU
                                                                            OPTIONAL,
    multipleBearerRequested
                                          [3] NULL
                                                                            OPTIONAL,
                                         [4] IMSI OPTIONAL,
[5] IntegrityProtectionInformation OPTIONAL,
    imsi
    integrityProtectionInfo
    encryptionInfo
                                         [6] EncryptionInformation
                                                                             OPTIONAL,
    radioResourceInformation
                                         [7] RadioResourceInformation OPTIONAL,
[9] AllowedGSM-Algorithms OPTIONAL,
[10] AllowedUMTS-Algorithms OPTIONAL,
    allowedGSM-Algorithms
    allowedUMTS-Algorithms
    radioResourceList
                                         [11] RadioResourceList
                                                                            OPTIONAL.
    extensionContainer
                                         [8] ExtensionContainer
                                                                           OPTIONAL,
    rab-Id
                                         [12] RAB-Id
                                                                            OPTIONAL.
                                         [13] BSSMAP-ServiceHandover
    bssmap-ServiceHandover
                                                                           OPTIONAL,
     ranap-ServiceHandover
                                         [14] RANAP-ServiceHandover
                                                                            OPTIONAL,
    bssmap-ServiceHandoverList [15] BSSMAP-ServiceHandoverList OPTIONAL,
    asciCallReference
                                         [20] ASCI-CallReference
                                                                            OPTIONAL,
                                         [16] GERAN-Classmark
    geran-classmark
                                                                            OPTIONAL,
     iuCurrentlyUsedCodec
                                         [17] Codec
                                                                            OPTIONAL,
     iuSupportedCodecsList
                                          [18] SupportedCodecsList
                                                                            OPTIONAL,
                                      [19] NULL
    rab-ConfigurationIndicator
                                                                            OPTIONAL.
    uesbi-Iu
                                          [21] UESBI-Iu
                                                                            OPTIONAL.
                                          [22] IMEI
                                                                            OPTIONAL,
    imeisv
    alternativeChannelType
                                [23] RadioResourceInformation OPTIONAL,
                                        [25] TracePropagationList
    tracePropagationList
                                                                           OPTIONAL
```

# BSSMAP-ServiceHandoverList ::= SEQUENCE SIZE (1.. maxNumOfServiceHandovers) OF BSSMAP-ServiceHandoverInfo

```
BSSMAP-ServiceHandoverInfo ::= SEQUENCE {
   bssmap-ServiceHandover BSSMAP-ServiceHandover,
   rab-Id RAB-Id,
   -- RAB Identity is needed to relate the service handovers with the radio access bearers.
   ...}
```

#### maxNumOfServiceHandovers INTEGER ::= 7

```
BSSMAP-ServiceHandover ::= OCTET STRING (SIZE (1))

-- Octets are coded according the Service Handover information element in
-- 3GPP TS 48.008.
```

```
RANAP-ServiceHandover ::= OCTET STRING (SIZE (1))

-- Octet contains a complete Service-Handover data type

-- as defined in 3GPP TS 25.413, encoded according to the encoding scheme

-- mandated by 3GPP TS 25.413

-- Padding bits are included in the least significant bits.
```

```
RadioResourceList ::= SEQUENCE SIZE (1.. maxNumOfRadioResources) OF
RadioResource
```

## maxNumOfRadioResources INTEGER ::= 7

```
PrepareHO-Res ::= [3] SEQUENCE {
    handoverNumber
                                       [0] ISDN-AddressString
                                                                         OPTIONAL,
    relocationNumberList
                                        [1] RelocationNumberList
                                                                         OPTIONAL,
                                       [2] AccessNetworkSignalInfo
    an-APDU
                                                                         OPTIONAL.
    multicallBearerInfo
                                       [3] MulticallBearerInfo
                                                                         OPTIONAL,
    multipleBearerNotSupported
                                       NULL
                                                                         OPTIONAL.
    selectedUMTS-Algorithms
                                       [5] SelectedUMTS-Algorithms
                                                                        OPTIONAL,
    chosenRadioResourceInformation
                                       [6] ChosenRadioResourceInformation OPTIONAL,
                                       [4] ExtensionContainer
    extensionContainer
                                                                        OPTIONAL,
    iuSelectedCodec
                                       [7] Codec
                                                                         OPTIONAL,
    iuAvailableCodecsList
                                       [8] CodecList
                                                                         OPTIONAL
```

```
SelectedUMTS-Algorithms ::= SEQUENCE {
                                          [0] ChosenIntegrityProtectionAlgorithm
[1] ChosenEncryptionAlgorithm OPTION
     integrityProtectionAlgorithm
                                                                                    OPTIONAL.
     encryptionAlgorithm
                                                                             OPTIONAL,
     extensionContainer
                                           [2] ExtensionContainer
                                                                              OPTIONAL,
ChosenIntegrityProtectionAlgorithm ::= OCTET STRING (SIZE (1))
     -- Octet contains a complete IntegrityProtectionAlgorithm data type
     -- as defined in 3GPP TS 25.413, encoded according to the encoding scheme
     -- mandated by 3GPP TS 25.413
     -- Padding bits are included in the least significant bits.
ChosenEncryptionAlgorithm ::= OCTET STRING (SIZE (1))
     -- Octet contains a complete EncryptionAlgorithm data type
     -- as defined in 3GPP TS 25.413, encoded according to the encoding scheme
     -- mandated by 3GPP TS 25.413
     -- Padding bits are included in the least significant bits.
ChosenRadioResourceInformation ::= SEQUENCE {
     chosenChannelInfo
                                           [0] ChosenChannelInfo
                                                                              OPTIONAL,
                                           [1] ChosenSpeechVersion
     chosenSpeechVersion
                                                                              OPTIONAL.
ChosenChannelInfo ::= OCTET STRING (SIZE (1))
     -- Octets are coded according the Chosen Channel information element in 3GPP TS 48.008
ChosenSpeechVersion ::= OCTET STRING (SIZE (1))
     -- Octets are coded according the Speech Version (chosen) information element in 3GPP {
m TS}
     -- 48.008
PrepareSubsequentHO-Arg ::= [3] SEQUENCE {
     targetCellId
                                           [0] GlobalCellId
                                                                              OPTIONAL,
     targetMSC-Number
                                           [1] ISDN-AddressString,
     targetRNCId
                                           [2] RNCId
                                                                              OPTIONAL.
                                           [3] AccessNetworkSignalInfo
     an-APDU
                                                                              OPTIONAL.
     selectedRab-Id
                                           [4] RAB-Id
                                                                              OPTIONAL,
     extensionContainer
                                           [5] ExtensionContainer
                                                                              OPTIONAL,
     geran-classmark
                                           [6] GERAN-Classmark
                                                                              OPTIONAL.
     rab-ConfigurationIndicator
                                           [7] NULL
                                                                              OPTIONAL
PrepareSubsequentHO-Res ::= [3] SEQUENCE {
     an-APDU
                                           AccessNetworkSignalInfo,
     extensionContainer
                                           [0] ExtensionContainer
                                                                              OPTIONAL,
ProcessAccessSignalling-Arg ::= [3] SEQUENCE {
     an-APDU
                                          AccessNetworkSignalInfo.
     selectedUMTS-Algorithms
                                           [1] SelectedUMTS-Algorithms
                                                                              OPTIONAL.
     selectedGSM-Algorithm
                                           [2] SelectedGSM-Algorithm
                                                                              OPTIONAL,
     chosenRadioResourceInformation
                                           [3] ChosenRadioResourceInformation OPTIONAL,
                                                                              OPTIONAL,
     selectedRab-Id
                                           [4] RAB-Id
     extensionContainer
                                           [0] ExtensionContainer
                                                                              OPTIONAL,
     iUSelectedCodec
                                                                              OPTIONAL,
                                           [5] Codec
     iuAvailableCodecsList
                                           [6] CodecList
                                                                              OPTIONAL
SupportedCodecsList ::= SEQUENCE {
    utranCodecList
                                           [0] CodecList
                                                                              OPTIONAL,
    geranCodecList
                                           [1] CodecList
                                                                              OPTIONAL.
                                           [2] ExtensionContainer
     extensionContainer
                                                                              OPTIONAL,
CodecList ::= SEQUENCE {
     codec1
                                           [1] Codec,
     codec2
                                           [2] Codec
                                                                              OPTIONAL,
     codec3
                                           [3] Codec
                                                                              OPTIONAL,
     codec4
                                           [4] Codec
                                                                              OPTIONAL.
     codec5
                                           [5] Codec
                                                                              OPTIONAL,
     codec6
                                           [6] Codec
                                                                              OPTIONAL,
    codec7
                                           [7] Codec
                                                                              OPTIONAL.
     codec8
                                           [8] Codec
                                                                              OPTIONAL.
     extensionContainer
                                           [9] ExtensionContainer
                                                                              OPTIONAL,
```

Codecs are sent in priority order where codec1 has highest priority

```
SelectedGSM-Algorithm ::= OCTET STRING (SIZE (1))

-- internal structure is coded as Algorithm identifier octet from Chosen Encryption
-- Algorithm defined in 3GPP TS 48.008
-- A node shall mark only the selected GSM algorithm
```

```
SendEndSignal-Res ::= SEQUENCE {
    extensionContainer [0] ExtensionContainer OPTIONAL,
    ...}
```

```
RNCId ::= OCTET STRING (SIZE (7))
    -- The internal structure is defined as follows:
    -- octet 1 bits 4321
                                        Mobile Country Code 1st digit
              bits 8765
                                        Mobile Country Code 2nd digit
    -- octet 2 bits 4321
                                        Mobile Country Code 3rd digit
                                       Mobile Network Code 3rd digit
              bits 8765
                                        or filler (1111) for 2 digit MNCs
    -- octet 3 bits 4321
                                        Mobile Network Code 1st digit
               bits 8765
                                        Mobile Network Code 2nd digit
    -- octets 4 and 5
                                        Location Area Code according to 3GPP TS 24.008
                                        RNC Id value according to 3GPP TS 25.413
     -- octets 6 and 7
```

```
RelocationNumberList ::= SEQUENCE SIZE (1..maxNumOfRelocationNumber) OF
RelocationNumber
```

```
MulticallBearerInfo ::= INTEGER (1..maxNumOfRelocationNumber)
```

#### RAB-Id ::= INTEGER (1..maxNrOfRABs)

```
maxNrofRABs INTEGER ::= 255
```

#### maxNumOfRelocationNumber INTEGER ::= 7

```
RadioResourceInformation ::= OCTET STRING (SIZE (3..13))
-- Octets are coded according the Channel Type information element in 3GPP TS 48.008
```

```
IntegrityProtectionInformation ::= OCTET STRING (SIZE (18..maxNumOfIntegrityInfo))
    -- Octets contain a complete IntegrityProtectionInformation data type
    -- as defined in 3GPP TS 25.413, encoded according to the encoding scheme
    -- mandated by 3GPP TS 25.413
    -- Padding bits are included, if needed, in the least significant bits of the
    -- last octet of the octet string.
```

#### maxNumOfIntegrityInfo INTEGER ::= 100

```
EncryptionInformation ::= OCTET STRING (SIZE (18..maxNumOfEncryptionInfo))

-- Octets contain a complete EncryptionInformation data type

-- as defined in 3GPP TS 25.413, encoded according to the encoding scheme

-- mandated by 3GPP TS 25.413

-- Padding bits are included, if needed, in the least significant bits of the

-- last octet of the octet string.
```

## maxNumOfEncryptionInfo INTEGER ::= 100

<sup>--</sup> authentication management types

```
SendAuthenticationInfoArg ::= SEQUENCE {
                                          [0] TMST.
    numberOfRequestedVectors
                                         NumberOfRequestedVectors,
    segmentationProhibited
                                         NULL
                                                                            OPTIONAL,
    immediateResponsePreferred
                                          [1] NULL
                                                                             OPTIONAL,
    re-synchronisationInfo
                                         Re-synchronisationInfo
                                                                            OPTIONAL,
    extensionContainer
                                         [2] ExtensionContainer
                                                                            OPTIONAL,
    requestingNodeType
                                          [3] RequestingNodeType
                                                                            OPTIONAL,
    requestingPLMN-Id
                                          [4] PLMN-Id
                                                                            OPTIONAL
```

```
NumberOfRequestedVectors ::= INTEGER (1..5)
Re-synchronisationInfo ::= SEQUENCE {
                                             RAND,
     rand
     auts
                                             AUTS,
SendAuthenticationInfoRes ::= [3] SEQUENCE {
     authenticationSetList
                                             AuthenticationSetList
                                                                                 OPTIONAL,
     extensionContainer
                                             ExtensionContainer
                                                                                 OPTIONAL,
{\tt RequestingNodeType} \ ::= \ {\tt ENUMERATED} \ \big\{
     vlr (0),
sgsn (1),
     . . . ,
     s-cscf (2),
     bsf (3),
     gan-aaa-server (4),
     wlan-aaa-server (5)
     -- the values 2, 3, 4 and 5 shall not be used on the MAP-D or Gr interfaces
     -- exception handling:
     -- received values in the range (6-15) shall be treated as "vlr"
     -- received values greater than 15 shall be treated as "sgsn"
```

-- equipment management types

```
RequestedEquipmentInfo::= BIT STRING {
    equipmentStatus (0),
    bmuef (1)} (SIZE (2..8))
    -- exception handling: reception of unknown bit assignments in the
    -- RequestedEquipmentInfo data type shall be discarded by the receiver
```

```
UESBI-Iu ::= SEQUENCE {
    uesbi-IuA [0] UESBI-IuA
    uesbi-IuB [1] UESBI-IuB
    OPTIONAL,
    ...}
```

```
UESBI-IUB
-- See 3GPP TS 25.413
::= BIT STRING (SIZE(1..128))
```

```
EquipmentStatus ::= ENUMERATED {
   whiteListed (0),
   blackListed (1),
   greyListed (2)}
```

<sup>--</sup> subscriber management types

```
InsertSubscriberDataArg ::= SEQUENCE {
                                        [0] TMST
                                                                          OPTIONAL.
    imsi
    COMPONENTS OF
                                        SubscriberData,
    extensionContainer
                                        [14] ExtensionContainer
                                                                          OPTIONAL,
    naea-PreferredCI
                                        [15] NAEA-PreferredCI
                                                                         OPTIONAL,
    -- naea-PreferredCI is included at the discretion of the HLR operator.
    gprsSubscriptionData
                                        [16] GPRSSubscriptionData
                                                                          OPTIONAL,
    roamingRestrictedInSgsnDueToUnsupportedFeature [23]
                                                                          NULL
                                                                          OPTIONAL,
                                        [24] NetworkAccessMode
    networkAccessMode
                                                                          OPTIONAL,
                                        [25] LSAInformation
                                                                          OPTIONAL.
    lsaInformation
    lmu-Indicator
                                        [21] NULL
                                                                          OPTIONAL.
    lcsInformation
                                        [22] LCSInformation
                                                                         OPTIONAL,
    istAlertTimer
                                        [26] IST-AlertTimerValue
                                                                         OPTIONAL,
    superChargerSupportedInHLR
                                        [27] AgeIndicator
                                                                         OPTIONAL,
    mc-SS-Info
                                        [28] MC-SS-Info
                                                                         OPTIONAL,
    cs-AllocationRetentionPriority
                                        [29] CS-AllocationRetentionPriority
                                                                              OPTIONAL,
    sqsn-CAMEL-SubscriptionInfo
                                       [17] SGSN-CAMEL-SubscriptionInfo OPTIONAL,
    chargingCharacteristics
                                        [18] ChargingCharacteristics
                                                                         OPTIONAL,
                                        [19] AccessRestrictionData
    accessRestrictionData
                                                                         OPTIONAL
    -- If the Network Access Mode parameter is sent, it shall be present only in
    -- the first sequence if seqmentation is used
```

```
AccessRestrictionData ::= BIT STRING {
    utranNotAllowed (0),
    geranNotAllowed (1),
    ganNotAllowed (2),
    i-hspa-evolutionNotAllowed (3) } (SIZE (2..8))
    -- exception handling:
    -- bits 4 to 7 shall be ignored if received and not understood
```

```
CS-AllocationRetentionPriority ::= OCTET STRING (SIZE (1))

-- This data type encodes each priority level defined in TS 23.107 as the binary value
-- of the priority level.
```

#### IST-AlertTimerValue ::= INTEGER (15..255)

```
LCSInformation ::= SEQUENCE {
    gmlc-List [0]
                                          GMLC-List OPTIONAL,
                                          [1] LCS-PrivacyExceptionList
[2] MOLR-List
    lcs-PrivacyExceptionList
                                                                             OPTIONAL,
    molr-List
                                                                             OPTIONAL.
                                         [3] LCS-PrivacyExceptionList
    add-lcs-PrivacyExceptionList
                                                                            OPTIONAL }
    -- add-lcs-PrivacyExceptionList may be sent only if lcs-PrivacyExceptionList is
    -- present and contains four instances of LCS-PrivacyClass. If the mentioned condition
    -- is not satisfied the receiving node shall discard add-lcs-PrivacyExceptionList.
    -- If an LCS-PrivacyClass is received both in lcs-PrivacyExceptionList and in
    -- add-lcs-PrivacyExceptionList with the same SS-Code, then the error unexpected
    -- data value shall be returned.
```

```
GMLC-List ::= SEQUENCE SIZE (1..maxNumOfGMLC) OF

ISDN-AddressString

-- if segmentation is used, the complete GMLC-List shall be sent in one segment
```

```
maxNumOfGMLC INTEGER ::= 5
```

```
GPRSDataList ::= SEQUENCE SIZE (1..maxNumOfPDP-Contexts) OF
PDP-Context
```

```
maxNumOfPDP-Contexts INTEGER ::= 50
```

```
PDP-Context ::= SEQUENCE {
    pdp-ContextId
                                          Context Id.
    pdp-Type
                                          [16] PDP-Type,
    pdp-Address
                                          [17] PDP-Address
                                                                              OPTIONAL,
     gos-Subscribed
                                           [18] OoS-Subscribed.
     vplmnAddressAllowed
                                          [19] NULL OPTIONAL,
                                          [20] APN,
    apn
    extensionContainer
                                          [21] ExtensionContainer
                                                                             OPTIONAL,
    ext-QoS-Subscribed
                                           [0] Ext-QoS-Subscribed
                                                                             OPTIONAL,
                                          [0] Ext-Qos-subscribed OPTIONAL,
[1] ChargingCharacteristics OPTIONAL,
OPTIONAL,
    pdp-ChargingCharacteristics
     ext2-OoS-Subscribed
                                          [2] Ext2-QoS-Subscribed
     -- ext2-QoS-Subscribed may be present only if ext-QoS-Subscribed is present.
     ext3-QoS-Subscribed
                                         [3] Ext3-QoS-Subscribed
                                                                             OPTIONAL
      - ext3-QoS-Subscribed may be present only if ext2-QoS-Subscribed is present.
```

#### ContextId ::= INTEGER (1..maxNumOfPDP-Contexts)

```
SGSN-CAMEL-SubscriptionInfo ::= SEQUENCE {
     gprs-CSI
                                           [0] GPRS-CSI
                                                                               OPTIONAL,
     mo-sms-CSI
                                           [1] SMS-CSI
                                                                               OPTIONAL,
                                           [2] ExtensionContainer
     extensionContainer
                                                                               OPTIONAL,
     mt-sms-CST
                                           [3] SMS-CSI
                                                                               OPTIONAL.
                                           [4] MT-smsCAMELTDP-CriteriaList
[5] MG-CSI
     mt-smsCAMELTDP-CriteriaList
                                                                               OPTIONAL,
                                                                               OPTIONAL
```

```
GPRS-CSI ::= SEQUENCE {
    gprs-CamelTDPDataList
                                         [0] GPRS-CamelTDPDataList
                                                                            OPTIONAL.
    camelCapabilityHandling
                                         [1] CamelCapabilityHandling
                                                                            OPTIONAL,
    extensionContainer
                                          [2] ExtensionContainer
                                                                            OPTIONAL,
    notificationToCSE
                                          [3] NULL
                                                                            OPTIONAL,
    csi-Active
                                          [4] NULL
                                                                            OPTIONAL,
    notificationToCSE and csi-Active shall not be present when GPRS-CSI is sent to SGSN.
    They may only be included in ATSI/ATM ack/NSDC message.
_ _
    GPRS-CamelTDPData and camelCapabilityHandling shall be present in
    the GPRS-CSI sequence.
    If GPRS-CSI is segmented, gprs-CamelTDPDataList and camelCapabilityHandling shall be
    present in the first segment
```

```
GPRS-CamelTDPDataList ::= SEQUENCE SIZE (1..maxNumOfCamelTDPData) OF
GPRS-CamelTDPData
-- GPRS-CamelTDPDataList shall not contain more than one instance of
-- GPRS-CamelTDPData containing the same value for gprs-TriggerDetectionPoint.
```

```
GPRS-CamelTDPData ::= SEQUENCE {
    gprs-TriggerDetectionPoint [0] GPRS-TriggerDetectionPoint,
    serviceKey [1] ServiceKey,
    gsmSCF-Address [2] ISDN-AddressString,
    defaultSessionHandling [3] DefaultGPRS-Handling,
    extensionContainer [4] ExtensionContainer OPTIONAL,
    ...
}
```

```
DefaultGPRS-Handling ::= ENUMERATED {
    continueTransaction (0) ,
    releaseTransaction (1) ,
    ...}
-- exception handling:
-- reception of values in range 2-31 shall be treated as "continueTransaction"
-- reception of values greater than 31 shall be treated as "releaseTransaction"
```

```
GPRS-TriggerDetectionPoint ::= ENUMERATED {
                                                (1),
     attach
     attachChangeOfPosition
                                                (2),
     pdp-ContextEstablishment
                                                (11),
     pdp-ContextEstablishmentAcknowledgement
                                                (12),
     pdp-ContextChangeOfPosition
                                                (14).
-- exception handling:
-- For GPRS-CamelTDPData sequences containing this parameter with any
-- other value than the ones listed the receiver shall ignore the whole
 -- GPRS-CamelTDPDatasequence.
APN ::= OCTET STRING (SIZE (2..63))
     -- Octets are coded according to TS 3GPP TS 23.003 [17]
PDP-Type ::= OCTET STRING (SIZE (2))
       Octets are coded according to TS 3GPP TS 29.060 [105]
PDP-Address ::= OCTET STRING (SIZE (1..16))
      -- Octets are coded according to TS 3GPP TS 29.060 [105]
     -- The possible size values are:
     -- 1-7 octets X.25 address type
     -- 4 octets IPv4 address type
     -- 16 octets Ipv6 address type
QoS-Subscribed ::= OCTET STRING (SIZE (3))
     -- Octets are coded according to TS 3GPP TS 24.008 [35] Quality of Service Octets
      -- 3-5.
Ext-QoS-Subscribed ::= OCTET STRING (SIZE (1..9))
     -- OCTET 1:
     -- Allocation/Retention Priority (This octet encodes each priority level defined in
            23.107 as the binary value of the priority level, declaration in 29.060)
     -- Octets 2-9 are coded according to 3GPP TS 24.008 [35] Quality of Service Octets
Ext2-QoS-Subscribed ::= OCTET STRING (SIZE (1..3))
     -- Octets 1-3 are coded according to 3GPP TS 24.008 [35] Quality of Service Octets 14-16.
-- If Quality of Service information is structured with 14 octet length, then
     -- Octet 1 is coded according to 3GPP TS 24.008 [35] Quality of Service Octet 14
Ext3-QoS-Subscribed ::= OCTET STRING (SIZE (1..2))
     -- Octets 1-2 are coded according to 3GPP TS 24.008 [35] Quality of Service Octets 17-18.
ChargingCharacteristics ::= OCTET STRING (SIZE (2))
     -- Octets are coded according to 3GPP TS 32.215.
LSAOnlyAccessIndicator ::= ENUMERATED {
     accessOutsideLSAsAllowed (0),
     accessOutsideLSAsRestricted (1) }
LSADataList ::= SEQUENCE SIZE (1..maxNumOfLSAs) OF
maxNumOfLSAs INTEGER ::= 20
LSAData ::= SEQUENCE {
     lsaIdentity
                                           [0] LSAIdentity,
                                           [1] LSAAttributes,
     lsaAttributes
     lsaActiveModeIndicator
                                           [2] NULL
                                                                               OPTIONAL,
     extensionContainer
                                           [3] ExtensionContainer
                                                                               OPTIONAL.
     ...}
LSAInformation ::= SEQUENCE {
     completeDataListIncluded
                                           NULL
                                                                               OPTIONAL,
          -- If segmentation is used, completeDataListIncluded may only be present in the
          -- first segment.
     lsaOnlyAccessIndicator
                                           [1] LSAOnlyAccessIndicator
                                                                               OPTIONAL.
                                                                               OPTIONAL,
     lsaDataList
                                           [2] LSADataList
                                           [3] ExtensionContainer
                                                                               OPTIONAL,
     extensionContainer
```

```
LSAIdentity ::= OCTET STRING (SIZE (3))
    -- Octets are coded according to TS 3GPP TS 23.003 [17]
LSAAttributes ::= OCTET STRING (SIZE (1))
     -- Octets are coded according to TS 3GPP TS 48.008 [49]
SubscriberData ::= SEQUENCE {
    msisdn
                                         [1] ISDN-AddressString
                                                                           OPTIONAL,
     category
                                         [2] Category
                                                                           OPTIONAL,
                                         [3] SubscriberStatus
                                                                          OPTIONAL,
     subscriberStatus
                                         [4] BearerServiceList
    bearerServiceList
                                                                          OPTIONAL,
     -- The exception handling for reception of unsupported / not allocated
     -- bearerServiceCodes is defined in section 8.8.1
     teleserviceList
                                         [6] TeleserviceList
                                                                           OPTIONAL,
     -- The exception handling for reception of unsupported / not allocated
     -- teleserviceCodes is defined in section 8.8.1
     provisionedSS
                                         [7] Ext-SS-InfoList
                                                                           OPTIONAL,
                                         [8] ODB-Data
     odb-Data
                                                                           OPTIONAL,
     roamingRestrictionDueToUnsupportedFeature [9] NULL
                                                                           OPTIONAL,
     regionalSubscriptionData [10] ZoneCodeList
                                                                           OPTIONAL.
                                        [11] VBSDataList
                                                                           OPTIONAL,
     vbsSubscriptionData
                                         [12] VGCSDataList
     vgcsSubscriptionData
                                                                           OPTIONAL,
     vlrCamelSubscriptionInfo
                                        [13] VlrCamelSubscriptionInfo
                                                                          OPTIONAL
Category ::= OCTET STRING (SIZE (1))
     -- The internal structure is defined in ITU-T Rec Q.763.
SubscriberStatus ::= ENUMERATED {
     serviceGranted (0),
    operatorDeterminedBarring (1) }
BearerServiceList ::= SEQUENCE SIZE (1..maxNumOfBearerServices) OF
                                         Ext-BearerServiceCode
maxNumOfBearerServices INTEGER ::= 50
TeleserviceList ::= SEQUENCE SIZE (1..maxNumOfTeleservices) OF
                                         Ext-TeleserviceCode
maxNumOfTeleservices INTEGER ::= 20
ODB-Data ::= SEQUENCE {
    odb-GeneralData
                                         ODB-GeneralData,
     odb-HPLMN-Data
                                         ODB-HPLMN-Data
                                                                           OPTIONAL,
                                                                           OPTIONAL,
     extensionContainer
                                         ExtensionContainer
```

```
ODB-GeneralData ::= BIT STRING {
     alloG-CallsBarred (0),
     internationalOGCallsBarred (1),
     internationalOGCallsNotToHPLMN-CountryBarred (2),
     interzonalOGCallsBarred (6),
     interzonalOGCallsNotToHPLMN-CountryBarred (7),
     interzonalOGCallsAndInternationalOGCallsNotToHPLMN-CountryBarred (8),
    premiumRateInformationOGCallsBarred (3),
    premiumRateEntertainementOGCallsBarred (4),
     ss-AccessBarred (5),
    allECT-Barred (9),
     chargeableECT-Barred (10),
     internationalECT-Barred (11).
     interzonalECT-Barred (12),
     doublyChargeableECT-Barred (13),
    multipleECT-Barred (14),
     allPacketOrientedServicesBarred (15),
    roamerAccessToHPLMN-AP-Barred (16),
roamerAccessToVPLMN-AP-Barred (17),
     roamingOutsidePLMNOG-CallsBarred (18),
     allIC-CallsBarred (19),
     roamingOutsidePLMNIC-CallsBarred (20),
     roamingOutsidePLMNICountryIC-CallsBarred (21),
     roamingOutsidePLMN-Barred (22),
     roamingOutsidePLMN-CountryBarred (23),
     registrationAllCF-Barred (24),
     registrationCFNotToHPLMN-Barred (25),
     registrationInterzonalCF-Barred (26),
    registrationInterzonalCFNotToHPLMN-Barred (27),
    registrationInternationalCF-Barred (28)} (SIZE (15..32))
-- exception handling: reception of unknown bit assignments in the
     -- ODB-GeneralData type shall be treated like unsupported ODB-GeneralData
     -- When the ODB-GeneralData type is removed from the HLR for a given subscriber,
     -- in NoteSubscriberDataModified operation sent toward the gsmSCF
     -- all bits shall be set to 'O'
```

```
ODB-HPLMN-Data ::= BIT STRING {
    plmn-SpecificBarringType1 (0),
    plmn-SpecificBarringType2 (1),
    plmn-SpecificBarringType3 (2),
    plmn-SpecificBarringType4 (3)} (SIZE (4..32))
    -- exception handling: reception of unknown bit assignments in the
    -- ODB-HPLMN-Data type shall be treated like unsupported ODB-HPLMN-Data
    -- When the ODB-HPLMN-Data type is removed from the HLR for a given subscriber,
    -- in NoteSubscriberDataModified operation sent toward the gsmSCF
    -- all bits shall be set to 'O'.
```

```
Ext-SS-InfoList ::= SEQUENCE SIZE (1..maxNumOfSS) OF
Ext-SS-Info
```

```
        Ext-SS-Info ::= CHOICE {
        [0] Ext-ForwInfo,

        forwardingInfo
        [1] Ext-CallBarInfo,

        cug-Info
        [2] CUG-Info,

        ss-Data
        [3] Ext-SS-Data,

        emlpp-Info
        [4] EMLPP-Info}
```

```
Ext-ForwFeature ::= SEQUENCE {
    basicService
                                     Ext-BasicServiceCode
                                                                     OPTIONAL.
                                     [4] Ext-SS-Status,
    ss-Status
    forwardedToNumber
                                    [5] ISDN-AddressString
                                                                     OPTIONAL,
    -- When this data type is sent from an HLR which supports CAMEL Phase 2
    -- to a VLR that supports CAMEL Phase 2 the VLR shall not check the
    -- format of the number
                                     [8] ISDN-SubaddressString OPTIONAL,
[6] Ext-ForwOptions OPTIONAL,
    forwardedToSubaddress
                                     [9] Ext-NoRepCondTime
    forwardingOptions
                                     [6] Ext-ForwOptions
    noReplyConditionTime
                                                                     OPTIONAL,
    extensionContainer
                                                                     OPTIONAL,
    longForwardedToNumber
                                    [10] FTN-AddressString OPTIONAL }
```

```
Ext-ForwOptions ::= OCTET STRING (SIZE (1..5))

-- OCTET 1:

-- bit 8: notification to forwarding party
-- 0 no notification
-- 1 notification
-- bit 7: redirecting presentation
-- 0 no presentation
-- 1 presentation
-- 1 presentation
-- bit 6: notification to calling party
-- 0 no notification
-- 1 notification
-- bit 5: 0 (unused)
-- bits 43: forwarding reason
-- 00 ms not reachable
-- 01 ms busy
-- 10 no reply
-- 11 unconditional
-- bits 21: 00 (unused)
-- OCTETS 2-5: reserved for future use. They shall be discarded if
-- received and not understood.
```

```
Ext-NoRepCondTime ::= INTEGER (1..100)

-- Only values 5-30 are used.

-- Values in the ranges 1-4 and 31-100 are reserved for future use

-- If received:

-- values 1-4 shall be mapped on to value 5

-- values 31-100 shall be mapped on to value 30
```

```
Ext-CallBarFeatureList ::= SEQUENCE SIZE (1..maxNumOfExt-BasicServiceGroups) OF

Ext-CallBarringFeature
```

<pre>Ext-CallBarringFeature ::= SEQUENCE {</pre>		
basicService	Ext-BasicServiceCode	OPTIONAL,
ss-Status	[4] Ext-SS-Status,	
extensionContainer	ExtensionContainer	OPTIONAL,
}		

```
CUG-SubscriptionList ::= SEQUENCE SIZE (0..maxNumOfCUG) OF

CUG-Subscription
```

```
CUG-Subscription ::= SEQUENCE {
     cug-Index CUG-Index,
                                         CUG-Interlock,
     cuq-Interlock
     intraCUG-Options
                                         IntraCUG-Options,
     basicServiceGroupList
                                         Ext-BasicServiceGroupList
                                                                           OPTIONAL,
     extensionContainer
                                         [0] ExtensionContainer
                                                                           OPTIONAL,
CUG-Index ::= INTEGER (0..32767)
     -- The internal structure is defined in ETS 300 138.
CUG-Interlock ::= OCTET STRING (SIZE (4))
IntraCUG-Options ::= ENUMERATED {
    noCUG-Restrictions (0),
     cugIC-CallBarred (1),
     cugOG-CallBarred (2) }
maxNumOfCUG INTEGER ::= 10
CUG-FeatureList ::= SEQUENCE SIZE (1..maxNumOfExt-BasicServiceGroups) OF
                                         CUG-Feature
Ext-BasicServiceGroupList ::= SEQUENCE SIZE (1..maxNumOfExt-BasicServiceGroups) OF
                                         Ext-BasicServiceCode
maxNumOfExt-BasicServiceGroups INTEGER ::= 32
CUG-Feature ::= SEQUENCE {
    basicService
                                         Ext-BasicServiceCode
                                                                           OPTIONAL,
     preferentialCUG-Indicator
                                         CUG-Index OPTIONAL,
     interCUG-Restrictions
                                         InterCUG-Restrictions,
     extensionContainer
                                         ExtensionContainer
                                                                           OPTIONAL,
InterCUG-Restrictions ::= OCTET STRING (SIZE (1))
     -- bits 876543: 000000 (unused)
     -- Exception handling:
     -- bits 876543 shall be ignored if received and not understood
     -- bits 21
     -- 00 CUG only facilities
         01 CUG with outgoing access
        10 CUG with incoming access
         11 CUG with both outgoing and incoming access
Ext-SS-Data ::= SEQUENCE {
     ss-Code
                                         SS-Code,
     ss-Status [4] Ext-SS-Status,
     ss-SubscriptionOption
                                         SS-SubscriptionOption
                                                                           OPTIONAL,
     basicServiceGroupList
                                         Ext-BasicServiceGroupList
                                                                           OPTIONAL,
                                         [5] ExtensionContainer
                                                                           OPTIONAL.
     extensionContainer
LCS-PrivacyExceptionList ::= SEQUENCE SIZE (1..maxNumOfPrivacyClass) OF
                                         LCS-PrivacyClass
```

```
maxNumOfPrivacyClass INTEGER ::= 4
```

```
LCS-PrivacyClass ::= SEQUENCE {
                                         SS-Code,
    ss-Code
    ss-Status
                                         Ext-SS-Status,
                                         [0] NotificationToMSUser
    notificationToMSUser
    -- notificationToMSUser may be sent only for SS-codes callSessionRelated
    -- and callSessionUnrelated. If not received for SS-codes callSessionRelated
    -- and callSessionUnrelated.
    -- the default values according to 3GPP TS 23.271 shall be assumed.
    externalClientList
                                         [1] ExternalClientList
    -- externalClientList may be sent only for SS-code callSessionUnrelated to a
    -- visited node that does not support LCS Release 4 or later versions.
    -- externalClientList may be sent only for SS-codes callSessionUnrelated and
    -- callSessionRelated to a visited node that supports LCS Release 4 or later versions.
                                        [2] PLMNClientList
    plmnClientList
     -- plmnClientList may be sent only for SS-code plmnoperator.
    extensionContainer
                                        [3] ExtensionContainer
                                                                          OPTIONAL,
                                        [4] Ext-ExternalClientList
    ext-externalClientList
                                                                         OPTIONAL.
    -- Ext-externalClientList may be sent only if the visited node supports LCS Release 4 or
    -- later versions, the user did specify more than 5 clients, and White Book SCCP is used.
    serviceTypeList
                                         [5] ServiceTypeList
                                                                           OPTIONAL
     -- serviceTypeList may be sent only for SS-code serviceType and if the visited node
    -- supports LCS Release 5 or later versions.
    -- if segmentation is used, the complete LCS-PrivacyClass shall be sent in one segment
```

```
ExternalClientList ::= SEQUENCE SIZE (0..maxNumOfExternalClient) OF

ExternalClient
```

```
maxNumOfExternalClient INTEGER ::= 5
```

```
PLMNClientList ::= SEQUENCE SIZE (1..maxNumOfPLMNClient) OF
LCSClientInternalID
```

```
maxNumOfPLMNClient INTEGER ::= 5
```

#### maxNumOfExt-ExternalClient INTEGER ::= 35

```
NotificationToMSUser ::= ENUMERATED {
    notifyLocationAllowed (0),
    notifyAndVerify-LocationAllowedIfNoResponse (1),
    notifyAndVerify-LocationNotAllowedIfNoResponse (2),
    ...,
    locationNotAllowed (3) }
-- exception handling:
-- At reception of any other value than the ones listed the receiver shall ignore
-- NotificationToMSUser.
```

```
ServiceTypeList ::= SEQUENCE SIZE (1..maxNumOfServiceType) OF

ServiceType
```

```
maxNumOfServiceType INTEGER ::= 32
```

OPTIONAL,

OPTIONAL,

OPTIONAL

istInformationWithdraw

chargingCharacteristicsWithdraw

specificCSI-Withdraw

```
ServiceType ::= SEQUENCE {
                                          LCSServiceTypeID,
     serviceTvpeIdentitv
     gmlc-Restriction
                                          [0] GMLC-Restriction
                                                                             OPTIONAL,
                                          [1] NotificationToMSUser
     notificationToMSUser
                                                                            OPTIONAL,
     -- If notificationToMSUser is not received, the default value according to
     -- 3GPP TS 23.271 shall be assumed.
     extensionContainer
                                          [2] ExtensionContainer
                                                                             OPTIONAL.
MOLR-List ::= SEQUENCE SIZE (1..maxNumOfMOLR-Class) OF
maxNumOfMOLR-Class INTEGER ::= 3
MOLR-Class ::= SEQUENCE {
     ss-Code
                                          SS-Code.
     ss-Status
                                          Ext-SS-Status,
     extensionContainer
                                          [0] ExtensionContainer
                                                                             OPTIONAL.
ZoneCodeList ::= SEQUENCE SIZE (1..maxNumOfZoneCodes)
ZoneCode ::= OCTET STRING (SIZE (2))
    -- internal structure is defined in TS 3GPP TS 23.003 [17]
maxNumOfZoneCodes INTEGER ::= 10
InsertSubscriberDataRes ::= SEQUENCE {
     teleserviceList
                                          [1] TeleserviceList
                                                                             OPTIONAL,
     bearerServiceList
                                          [2] BearerServiceList
                                                                             OPTIONAL,
                                          [3] SS-List
                                                                             OPTIONAL,
     ss-List
     odb-GeneralData
                                          [4] ODB-GeneralData
                                                                             OPTIONAL,
     {\tt regional Subscription Response}
                                          [5] RegionalSubscriptionResponse
                                                                             OPTIONAL,
     supportedCamelPhases
                                          [6] SupportedCamelPhases
                                                                             OPTIONAL,
     extensionContainer
                                          [7] ExtensionContainer
                                                                             OPTIONAL.
                                          [8] OfferedCamel4CSIs
     offeredCamel4CSIs
                                                                             OPTIONAL }
RegionalSubscriptionResponse ::= ENUMERATED {
                                          (0),
     networkNode-AreaRestricted
     tooManyZoneCodes
                                          (1),
     zoneCodesConflict
                                          (2)
     {\tt regionalSubscNotSupported}
                                           (3)
	exttt{DeleteSubscriberDataArg}:= 	exttt{SEQUENCE} \ ig\{
                                          [0] IMSI,
     imsi
     basicServiceList
                                          [1] BasicServiceList
                                                                             OPTIONAL,
     -- The exception handling for reception of unsupported/not allocated
     -- basicServiceCodes is defined in section 6.8.2
                                          [2] SS-List
                                                                             OPTIONAL.
     ss-List
     roamingRestrictionDueToUnsupportedFeature [4] NULL
                                                                             OPTIONAL,
     regionalSubscriptionIdentifier [5] ZoneCode
                                                                             OPTIONAL,
     vbsGroupIndication
                                          [7] NULL
                                                                             OPTIONAL,
                                          [8] NULL OPTIONAL,
     vqcsGroupIndication
     camelSubscriptionInfoWithdraw
                                          [9] NULL OPTIONAL,
     {\tt extensionContainer}
                                          [6] ExtensionContainer OPTIONAL,
     gprsSubscriptionDataWithdraw
                                          [10] GPRSSubscriptionDataWithdraw OPTIONAL,
     roamingRestrictedInSgsnDueToUnsuppportedFeature [11] NULL
                                                                             OPTIONAL.
     lsaInformationWithdraw
                                          [12] LSAInformationWithdraw
                                                                             OPTIONAL,
     gmlc-ListWithdraw
                                          [13] NULL
                                                                             OPTIONAL,
```

[14] NULL

[16] NULL

[15] SpecificCSI-Withdraw

```
SpecificCSI-Withdraw ::= BIT STRING {
     o-csi (0),
     ss-csi (1),
     tif-csi (2),
     d-csi (3),
     vt-csi (4),
     mo-sms-csi (5),
     m-csi (6),
     gprs-csi (7),
     t-csi (8),
     mt-sms-csi (9),
     mg-csi (10),
     o-IM-CSI (11)
     d-IM-CSI (12),
     vt-IM-CSI (13) } (SIZE(8..32))
-- exception handling:
-- bits 11 to 31 shall be ignored if received by a non-IP Multimedia Core Network entity.
-- bits 0-10 and 14-31 shall be ignored if received by an IP Multimedia Core Network entity.
-- bits 11-13 are only applicable in an IP Multimedia Core Network.
 -- Bit 8 and bits 11-13 are only applicable for the NoteSubscriberDataModified operation.
GPRSSubscriptionDataWithdraw ::= CHOICE {
     allGPRSData
                                          NULL,
     contextIdList
                                          ContextIdList }
ContextIdList ::= SEQUENCE SIZE (1..maxNumOfPDP-Contexts) OF
LSAInformationWithdraw ::= CHOICE {
     allLSAData
                                          NULL,
     lsaIdentityList
                                          LSAIdentityList ]
LSAIdentityList ::= SEQUENCE SIZE (1..maxNumOfLSAs) OF
                                          LSAIdentity
BasicServiceList ::= SEQUENCE SIZE (1..maxNumOfBasicServices) OF
                                          Ext-BasicServiceCode
maxNumOfBasicServices INTEGER ::= 70
DeleteSubscriberDataRes ::= SEQUENCE {
     regionalSubscriptionResponse
                                           [0] RegionalSubscriptionResponse
                                                                              OPTIONAL.
     extensionContainer
                                          ExtensionContainer
                                                                              OPTIONAL,
VlrCamelSubscriptionInfo ::= SEQUENCE {
     o-CSI
                                           [0] O-CSI
                                                                              OPTIONAL.
                                           [1] ExtensionContainer
                                                                              OPTIONAL,
     extensionContainer
     ss-CSI
                                           [2] SS-CSI
                                                                              OPTIONAL,
     o-BcsmCamelTDP-CriteriaList
                                           [4] O-BcsmCamelTDPCriteriaList
                                                                              OPTIONAL,
     tif-CSI
                                           [3] NULL
                                                                              OPTIONAL,
                                           [5] M-CSI
                                                                              OPTIONAL.
     m-CSI
                                           [6] SMS-CSI
     mo-sms-CSI
                                                                              OPTIONAL,
                                                                              OPTIONAL,
     vt-CSI
                                           [7] T-CSI
     t-BCSM-CAMEL-TDP-CriteriaList
                                           [8] T-BCSM-CAMEL-TDP-CriteriaList OPTIONAL,
                                           [9] D-CSI
                                                                              OPTIONAL,
     d-CSI
                                           [10] SMS-CSI
     mt.-sms-CSI
                                                                              OPTIONAL.
     mt-smsCAMELTDP-CriteriaList
                                           [11] MT-smsCAMELTDP-CriteriaList OPTIONAL
MT-smsCAMELTDP-CriteriaList ::= SEQUENCE SIZE (1.. maxNumOfCamelTDPData) OF
    MT-smsCAMELTDP-Criteria
MT-smsCAMELTDP-Criteria ::= SEQUENCE {
     sms-TriggerDetectionPoint
                                          SMS-TriggerDetectionPoint,
                                           [0] TPDU-TypeCriterion
     tpdu-TypeCriterion
                                                                               OPTIONAL,
TPDU-TypeCriterion ::= SEQUENCE SIZE (1..maxNumOfTPDUTypes) OF
     MT-SMS-TPDU-Type
maxNumOfTPDUTypes INTEGER ::= 5
```

```
D-CSI ::= SEOUENCE {
     dp-AnalysedInfoCriteriaList
                                          [0] DP-AnalysedInfoCriteriaList
                                                                             OPTIONAL,
                                          [1] CamelCapabilityHandling
     camelCapabilityHandling
                                                                             OPTIONAL,
     extensionContainer
                                          [2] ExtensionContainer
                                                                             OPTIONAL,
                                          [3] NULL
[4] NULL
    notificationToCSE
                                                                             OPTIONAL.
    csi-Active
                                                                             OPTIONAL,
     ...}
    notificationToCSE and csi-Active shall not be present when D-CSI is sent to VLR/GMSC.
    They may only be included in ATSI/ATM ack/NSDC message.
    {\tt DP-AnalysedInfoCriteria\ and\ } camel{\tt CapabilityHandling\ shall\ be\ present\ in}
    the D-CSI sequence.
    If D-CSI is segmented, then the first segment shall contain dp-AnalysedInfoCriteriaList
    and camelCapabilityHandling. Subsequent segments shall not contain
     camelCapabilityHandling, but may contain dp-AnalysedInfoCriteriaList
```

```
DP-AnalysedInfoCriteriaList ::= SEQUENCE SIZE (1..maxNumOfDP-AnalysedInfoCriteria) OF
DP-AnalysedInfoCriterium
```

#### maxNumOfDP-AnalysedInfoCriteria INTEGER ::= 10

```
maxNumOfCamelSSEvents INTEGER ::= 10
```

```
O-CSI ::= SEQUENCE {
    o-BcsmCamelTDPDataList
                                         O-BcsmCamelTDPDataList,
    extensionContainer
                                         ExtensionContainer
                                                                            OPTIONAL,
    camelCapabilityHandling
                                          [0] CamelCapabilityHandling
                                                                            OPTIONAL,
    notificationToCSE
                                          [1] NULL
                                                                            OPTIONAL,
                                          [2] NULL
                                                                            OPTIONAL)
    csiActive
    notificationtoCSE and csiActive shall not be present when O-CSI is sent to VLR/GMSC.
    They may only be included in ATSI/ATM ack/NSDC message.
    O-CSI shall not be segmented.
O-BcsmCamelTDPDataList ::= SEQUENCE SIZE (1..maxNumOfCamelTDPData) OF
    O-BcsmCamelTDPData
     -- O-BcsmCamelTDPDataList shall not contain more than one instance of
```

```
-- O-BcsmCamelTDPData containing the same value for o-BcsmTriggerDetectionPoint.
-- For CAMEL Phase 2, this means that only one instance of O-BcsmCamelTDPData is allowed
-- with o-BcsmTriggerDetectionPoint being equal to DP2.
```

```
maxNumOfCamelTDPData INTEGER ::= 10
```

```
O-BcsmCamelTDPData ::= SEQUENCE {
    o-BcsmTriggerDetectionPoint
                                          O-BcsmTriggerDetectionPoint,
    serviceKey
                                          ServiceKey,
    gsmSCF-Address
                                          [0] ISDN-AddressString,
    defaultCallHandling
                                          [1] DefaultCallHandling,
    extensionContainer
                                          [2] ExtensionContainer
                                                                             OPTIONAL,
```

#### **ServiceKey** ::= INTEGER (0..2147483647)

```
O-BcsmTriggerDetectionPoint ::= ENUMERATED {
    collectedInfo (2),
    routeSelectFailure (4) }
    -- exception handling:
    -- For O\text{-}BcsmCamelTDPData sequences containing this parameter with any
    -- other value than the ones listed the receiver shall ignore the whole
    -- O-BcsmCamelTDPDatasequence.
    -- For O-BcsmCamelTDP-Criteria sequences containing this parameter with any
     -- other value than the ones listed the receiver shall ignore the whole
    -- O-BcsmCamelTDP-Criteria sequence.
```

```
{\tt O-BcsmCamelTDPCriteriaList} ::= {\tt SEQUENCE} \ {\tt SIZE} \ (1..{\tt maxNumOfCamelTDPData}) \ {\tt OF}
      O-BcsmCamelTDP-Criteria
```

```
\textbf{T-BCSM-CAMEL-TDP-CriteriaList} ::= \texttt{SEQUENCE} \ \texttt{SIZE} \ (\texttt{1..maxNumOfCamelTDPData}) \ \texttt{OF}
      T-BCSM-CAMEL-TDP-Criteria
```

```
O-BcsmCamelTDP-Criteria ::= SEQUENCE {
    o-BcsmTriggerDetectionPoint
                                         O-BcsmTriggerDetectionPoint,
    destinationNumberCriteria
                                         [0] DestinationNumberCriteria
                                                                           OPTIONAL,
    basicServiceCriteria
                                         [1] BasicServiceCriteria
                                                                           OPTIONAL.
    callTypeCriteria
                                         [2] CallTypeCriteria
                                                                           OPTIONAL,
     o-CauseValueCriteria
                                          [3] O-CauseValueCriteria
                                                                            OPTIONAL,
    extensionContainer
                                         [4] ExtensionContainer
                                                                           OPTIONAL
```

```
T-BCSM-CAMEL-TDP-Criteria ::= SEQUENCE {
    t-BCSM-TriggerDetectionPoint
                                          T-BcsmTriggerDetectionPoint.
    basicServiceCriteria
                                                                             OPTIONAL.
                                          [0] BasicServiceCriteria
    t-CauseValueCriteria
                                          [1] T-CauseValueCriteria
                                                                             OPTIONAL,
```

```
DestinationNumberCriteria ::= SEQUENCE {
     matchType
                                             [0] MatchType,
     destinationNumberList
                                             [1] DestinationNumberList
                                                                                 OPTIONAL,
                                             [2] DestinationNumberLengthList OPTIONAL,
     destinationNumberLengthList
     \operatorname{\mathsf{--}} one or both of destinationNumberList and destinationNumberLengthList
     -- shall be present
```

```
DestinationNumberList ::= SEQUENCE SIZE
                                          (1..maxNumOfCamelDestinationNumbers) OF
                                         ISDN-AddressString
     -- The receiving entity shall not check the format of a number in
     -- the dialled number list
```

```
DestinationNumberLengthList ::= SEQUENCE SIZE (1..maxNumOfCamelDestinationNumberLengths) OF
                                               INTEGER(1..maxNumOfISDN-AddressDigits)
BasicServiceCriteria ::= SEQUENCE SIZE(1..maxNumOfCamelBasicServiceCriteria) OF
     Ext-BasicServiceCode
maxNumOfISDN-AddressDigits INTEGER ::= 15
maxNumOfCamelDestinationNumberLengths INTEGER ::= 3
maxNumOfCamelBasicServiceCriteria INTEGER ::= 5
                      ::= ENUMERATED {
CallTypeCriteria
     forwarded
                                           (0)
     notForwarded
                                           (1)
                ::= ENUMERATED {
MatchType
     inhibiting
                                           (0),
     enabling
                                           (1)
O-CauseValueCriteria ::= SEQUENCE SIZE(1..maxNumOfCAMEL-O-CauseValueCriteria) OF
    CauseValue
\textbf{T-CauseValueCriteria} \quad ::= \ \texttt{SEQUENCE} \ \ \texttt{SIZE} \ (1... \texttt{maxNumOfCAMEL-T-CauseValueCriteria}) \ \ \texttt{OF} \ \ \\
    CauseValue
maxNumOfCAMEL-O-CauseValueCriteria INTEGER ::= 5
maxNumOfCAMEL-T-CauseValueCriteria INTEGER ::= 5
CauseValue ::= OCTET STRING (SIZE(1))
 - Type extracted from Cause parameter in ITU-T Recommendation Q.763.
   For the use of cause value refer to ITU-T Recommendation Q.850.
DefaultCallHandling ::= ENUMERATED {
     continueCall (0) ,
     releaseCall (1) ,
     . . . }
     -- exception handling:
     -- reception of values in range 2-31 shall be treated as "continueCall"
     -- reception of values greater than 31 shall be treated as "releaseCall"
CamelCapabilityHandling ::= INTEGER(1..16)
     -- value 1 = CAMEL phase 1,
     -- value 2 = CAMEL phase 2,
     -- value 3 = CAMEL Phase 3,
     -- value 4 = CAMEL phase 4:
     -- reception of values greater than 4 shall be treated as CAMEL phase 4.
SupportedCamelPhases ::= BIT STRING {
     phase1 (0),
     phase2 (1),
     phase3 (2),
     phase4 (3)} (SIZE (1..16))
-- A node shall mark in the BIT STRING all CAMEL Phases it supports.
 -- Other values than listed above shall be discarded.
OfferedCamel4CSIs ::= BIT STRING {
                                           (0),
     o-csi
     d-csi
                                           (1),
     vt-csi
                                           (2),
                                           (3),
     t-csi
     mt-sms-csi
                                           (4),
                                           (5),
     mg-csi
     psi-enhancements
                                           (6)
} (SIZE (7..16))
 -- A node supporting Camel phase 4 shall mark in the BIT STRING all Camel4 CSIs
-- it offers.
 -- Other values than listed above shall be discarded.
```

```
OfferedCamel4Functionalities ::= BIT STRING {
    initiateCallAttempt
                                          (0),
    splitLeg
                                          (1),
    moveLeg
                                          (2),
                                          (3),
    disconnectLeg
    entityReleased
                                          (4),
    dfc-WithArgument
                                          (5),
    playTone
                                          (6),
    dtmf-MidCall
                                          (7),
    chargingIndicator
                                          (8),
    alertingDP
                                          (9),
    locationAtAlerting
                                          (10),
                                          (11),
    changeOfPositionDP
    or-Interactions
                                          (12),
    warningToneEnhancements
                                          (13),
                                          (14),
    cf-Enhancements
    subscribedEnhancedDialledServices (15),
    servingNetworkEnhancedDialledServices (16),
    criteriaForChangeOfPositionDP (17),
    serviceChangeDP
                                          (18),
    collectInformation
                                          (19)
} (SIZE (15..64))
 - A node supporting Camel phase 4 shall mark in the BIT STRING all CAMEL4
-- functionalities it offers.
-- Other values than listed above shall be discarded.
```

```
SMS-CSI ::= SEQUENCE {
                                [0] SMS-CAMEL-TDP-DataList
                                                                       OPTIONAL,
    sms-CAMEL-TDP-DataList
    camelCapabilityHandling
                                        [1] CamelCapabilityHandling
                                                                         OPTIONAL,
    extensionContainer
                                        [2] ExtensionContainer
                                                                         OPTIONAL,
    notificationToCSE
                                        [3] NULL
                                                                         OPTIONAL,
                                        [4] NULL
                                                                         OPTIONAL,
    csi-Active
     . . . }
    notificationToCSE and csi-Active shall not be present
    when MO-SMS-CSI or MT-SMS-CSI is sent to VLR or SGSN.
    They may only be included in ATSI/ATM ack/NSDC message.
    SMS-CAMEL-TDP-Data and camelCapabilityHandling shall be present in
    the SMS-CSI sequence.
    If SMS-CSI is segmented, sms-CAMEL-TDP-DataList and camelCapabilityHandling shall be
    present in the first segment
```

```
SMS-CAMEL-TDP-DataList ::= SEQUENCE SIZE (1..maxNumOfCamelTDPData) OF
SMS-CAMEL-TDP-Data
-- SMS-CAMEL-TDP-DataList shall not contain more than one instance of
-- SMS-CAMEL-TDP-Data containing the same value for sms-TriggerDetectionPoint.
```

```
SMS-CAMEL-TDP-Data ::= SEQUENCE {
   sms-TriggerDetectionPoint [0] SMS-TriggerDetectionPoint,
   serviceKey [1] ServiceKey,
   gsmSCF-Address [2] ISDN-AddressString,
   defaultSMS-Handling [3] DefaultSMS-Handling,
   extensionContainer [4] ExtensionContainer OPTIONAL,
   ...
}
```

```
SMS-TriggerDetectionPoint ::= ENUMERATED {
    sms-CollectedInfo (1),
    sms-DeliveryRequest (2)
    exception handling:
    For SMS-CAMEL-TDP-Data and MT-smsCAMELTDP-Criteria sequences containing this
    parameter with any other value than the ones listed the receiver shall ignore
    the whole sequence.
    If this parameter is received with any other value than sms-CollectedInfo
    in an SMS-CAMEL-TDP-Data sequence contained in mo-sms-CSI, then the receiver shall
    ignore the whole SMS-CAMEL-TDP-Data sequence.
    If this parameter is received with any other value than sms-DeliveryRequest
_ _
    in an SMS-CAMEL-TDP-Data sequence contained in mt-sms-CSI then the receiver shall
    ignore the whole SMS-CAMEL-TDP-Data sequence.
_ _
_ _
    If this parameter is received with any other value than sms-DeliveryRequest
    in an MT-smsCAMELTDP-Criteria sequence then the receiver shall
    ignore the whole MT-smsCAMELTDP-Criteria sequence
```

```
DefaultSMS-Handling ::= ENUMERATED {
    continueTransaction (0) ,
    releaseTransaction (1) ,
    ...}
-- exception handling:
-- reception of values in range 2-31 shall be treated as "continueTransaction"
-- reception of values greater than 31 shall be treated as "releaseTransaction"
```

```
M-CSI ::= SEQUENCE {
    mobilityTriggers
                                          MobilityTriggers,
     serviceKey
                                          ServiceKey,
                                          [0] ISDN-AddressString,
    gsmSCF-Address
                                          [1] ExtensionContainer
     extensionContainer
                                                                            OPTIONAL.
                                          [2] MIII.I.
    notificationToCSE
                                                                             OPTIONAL.
     csi-Active
                                          [3] NULL
                                                                             OPTIONAL,
     ...}
    notificationToCSE and csi-Active shall not be present when M-CSI is sent to VLR.
     They may only be included in ATSI/ATM ack/NSDC message.
```

```
MG-CSI ::= SEQUENCE {
    mobilityTriggers
                                          MobilityTriggers,
    serviceKey
                                          ServiceKey,
    gsmSCF-Address
                                          [0] ISDN-AddressString,
                                          [1] ExtensionContainer
    extensionContainer
                                                                             OPTIONAL,
                                          [2] NULL
    notificationToCSE
                                                                             OPTIONAL.
    csi-Active
                                                                             OPTIONAL.
                                          [3] NULL
    notificationToCSE and csi-Active shall not be present when MG-CSI is sent to SGSN.
    They may only be included in ATSI/ATM ack/NSDC message.
```

```
MobilityTriggers ::= SEQUENCE SIZE (1..maxNumOfMobilityTriggers) OF MM-Code
```

#### maxNumOfMobilityTriggers INTEGER ::= 10

```
MM-Code ::= OCTET STRING (SIZE (1))
 -- This type is used to indicate a Mobility Management event.
           Actions for the following MM-Code values are defined in CAMEL Phase 4:
 - -
           CS domain MM events:
           Location-update-to-other-VLR MM-Code ::= '00000000'B

MM-Code ::= '00000000'B

MM-Code ::= '00000000'B
          Location-update-in-same-VLR
                                                                                                               MM-Code ::= '00000001'B
MM-Code ::= '00000010'B
 --
           IMSI-Attach
                                                                                                                  MM-Code ::= '00000011'B
 - -
            MS-initiated-TMST-Detach
 - -
            Network-initiated-IMSI-Detach
                                                                                                                  MM-Code ::= '00000100'B
            PS domain MM events:
            Routeing-Area-update-in-same-SGSN
                                                                                                              MM-Code ::= '10000000'B
 _ _
 - -
            Routeing-Area-update-to-other-SGSN-update-from-new-SGSN
 - -
                                                                                                                  MM-Code ::= '10000001'B
            Routeing-Area-update-to-other-SGSN-disconnect-by-detach
 - -
                                                                                                                  MM-Code ::= '10000010'B
 - -
                                                                                                                  MM-Code ::= '10000011'B
            GPRS-Attach
            Network-initiated from Network-initiated from
            MS-initiated-GPRS-Detach
 - -
 - -
            Network-initiated-transfer-to-MS-not-reachable-for-paging
 - -
                                                                                                                  MM-Code ::= '10000110'B
            If the MSC receives any other MM-code than the ones listed above for the
             CS domain, then the MSC shall ignore that MM-code.
             If the SGSN receives any other MM-code than the ones listed above for the
             PS domain, then the SGSN shall ignore that MM-code.
```

```
T-CSI ::= SEQUENCE {
    t-BcsmCamelTDPDataList
                                         T-BcsmCamelTDPDataList,
     extensionContainer
                                         ExtensionContainer
                                                                            OPTIONAL,
     camelCapabilityHandling
                                         [0] CamelCapabilityHandling
                                                                            OPTIONAL,
                                         [1] NULL
    notificationToCSE
                                                                            OPTIONAL.
                                         [2] NIII.I.
    csi-Active
                                                                            OPTIONAL)
    notificationToCSE and csi-Active shall not be present when VT-CSI/T-CSI is sent
    to VLR/GMSC.
     They may only be included in ATSI/ATM ack/NSDC message.
     T-CSI shall not be segmented.
```

```
T-BcsmCamelTDPDataList ::= SEQUENCE SIZE (1..maxNumOfCamelTDPData) OF
     T-BcsmCamelTDPData
     --- T-BcsmCamelTDPDataList shall not contain more than one instance of
     --- T-BcsmCamelTDPData containing the same value for t-BcsmTriggerDetectionPoint.
     --- For CAMEL Phase 2, this means that only one instance of T-BcsmCamelTDPData is allowed
     --- with t-BcsmTriggerDetectionPoint being equal to DP12.
     --- For CAMEL Phase 3, more TDP"s are allowed.
T-BcsmCamelTDPData ::= SEQUENCE {
     t-BcsmTriggerDetectionPoint
                                          T-BcsmTriggerDetectionPoint,
     serviceKey
                                          ServiceKey,
                                           [0] ISDN-AddressString,
     gsmSCF-Address
                                           [1] DefaultCallHandling,
     defaultCallHandling
                                           [2] ExtensionContainer
                                                                              OPTIONAL.
     extensionContainer
T-BcsmTriggerDetectionPoint ::= ENUMERATED {
     termAttemptAuthorized (12),
     tBusy (13),
     tNoAnswer (14)}
     -- exception handling:
     -- For T-BcsmCamelTTPData sequences containing this parameter with any other
     -- value than the ones listed above, the receiver shall ignore the whole
     -- T-BcsmCamelTDPData sequence.
-- gprs location information retrieval types
SendRoutingInfoForGprsArg ::= SEQUENCE {
                                                [0] IMSI,
     imsi
                                                [1] GSN-Address
     ggsn-Address
                                                                              OPTIONAL,
     ggsn-Number
                                                    ISDN-AddressString,
                                                [2]
     extensionContainer
                                                [3] ExtensionContainer
                                                                              OPTIONAL.
SendRoutingInfoForGprsRes ::= SEQUENCE {
     sgsn-Address
                                                [0] GSN-Address,
                                               [1] GSN-Address OPTIONAL,
[2] AbsentSubscriberDiagnosticSM OPTIONAL,
     ggsn-Address
     mobileNotReachableReason
                                                                           OPTIONAL,
     extensionContainer
                                               [3] ExtensionContainer
-- failure report types
FailureReportArg ::= SEQUENCE {
                                                [0] IMSI,
     imsi
     ggsn-Number
                                                [1] ISDN-AddressString
     ggsn-Address
                                                [2] GSN-Address
                                                                              OPTIONAL,
     extensionContainer
                                                [3] ExtensionContainer
                                                                              OPTIONAL,
FailureReportRes ::= SEQUENCE {
     ggsn-Address
                                               [0] GSN-Address
                                                                              OPTIONAL,
     extensionContainer
                                                [1] ExtensionContainer
                                                                              OPTIONAL,
-- gprs notification types
NoteMsPresentForGprsArg ::= SEQUENCE {
     imsi
                                                [0] IMSI,
     sgsn-Address
                                                [1] GSN-Address,
     ggsn-Address
                                                [2] GSN-Address
                                                                              OPTIONAL,
     extensionContainer
                                                [3] ExtensionContainer
                                                                              OPTIONAL,
NoteMsPresentForGprsRes ::= SEQUENCE {
     extensionContainer
                                               [0] ExtensionContainer
                                                                              OPTIONAL,
-- fault recovery types
ResetArg ::= SEQUENCE {
     hlr-Number
                                          ISDN-AddressString,
     hlr-List
                                          HLR-List
                                                                              OPTIONAL,
```

-- VBS/VGCS types

```
maxNumOfVBSGroupIds INTEGER ::= 50
```

```
maxNumOfVGCSGroupIds INTEGER ::= 50
```

```
VoiceGroupCallData ::= SEQUENCE {
                                         GroupId,
    groupId
     -- groupId shall be filled with six TBCD fillers (1111)if the longGroupId is present
    extensionContainer
                                         ExtensionContainer
                                                                            OPTIONAL,
    additionalSubscriptions
                                         AdditionalSubscriptions
                                                                           OPTIONAL.
    {\tt additionalInfo}
                                         [0] AdditionalInfo
                                                                           OPTIONAL,
    longGroupId
                                         [1] Long-GroupId
                                                                            OPTIONAL }
    -- VoiceGroupCallData containing a longGroupId shall not be sent to VLRs that did not
    -- indicate support of long Group IDs within the Update Location or Restore Data
    -- request message
```

```
AdditionalInfo ::= BIT STRING (SIZE (1..136))
-- Refers to Additional Info as specified in 3GPP TS 43.068
```

```
AdditionalSubscriptions ::= BIT STRING {
    privilegedUplinkRequest (0),
    emergencyUplinkRequest (1),
    emergencyReset (2)} (SIZE (3..8))
-- Other bits than listed above shall be discarded.
```

```
GroupId ::= TBCD-STRING (SIZE (3))
    -- When Group-Id is less than six characters in length, the TBCD filler (1111)
    -- is used to fill unused half octets.
    -- Refers to the Group Identification as specified in 3GPP TS 23.003
    -- and 3GPP TS 43.068/ 43.069
```

```
Long-GroupId ::= TBCD-STRING (SIZE (4))

-- When Long-Group-Id is less than eight characters in length, the TBCD filler (1111)

-- is used to fill unused half octets.

-- Refers to the Group Identification as specified in 3GPP TS 23.003

-- and 3GPP TS 43.068/ 43.069
```

<sup>--</sup> provide subscriber info types

```
SubscriberInfo ::= SEQUENCE {
    locationInformation
                                        [0] LocationInformation
                                                                         OPTIONAL,
    subscriberState
                                        [1] SubscriberState
                                                                         OPTIONAL.
                                        [2] ExtensionContainer
    extensionContainer
                                                                         OPTIONAL,
    locationInformationGPRS
                                       [3] LocationInformationGPRS
                                                                        OPTIONAL,
                                        [4] PS-SubscriberState
    ps-SubscriberState
                                                                         OPTIONAL,
                                        [5] IMEI
                                                                         OPTIONAL.
    imei
    ms-Classmark2
                                        [6] MS-Classmark2
                                                                         OPTIONAL,
                                        [7] GPRSMSClass
    gprs-MS-Class
                                                                         OPTIONAL,
    mnpInfoRes
                                        [8] MNPInfoRes
                                                                         OPTIONAL }
  If the HLR receives locationInformation, subscriberState or ms-Classmark2 from an SGSN
   it shall discard them.
    If the HLR receives locationInformationGPRS, ps-SubscriberState or gprs-MS-Class from
    a VLR it shall discard them.
    If the HLR receives parameters which it has not requested, it shall discard them.
```

```
MNPInfoRes ::= SEQUENCE {
    routeingNumber
                                       [0] RouteingNumber
                                                                        OPTIONAL.
                                       [1] IMSI
                                      [2] ISDN-AddressString
    imsi
                                                                       OPTIONAL.
    msisdn
                                                                      OPTIONAL,
                                       [3] NumberPortabilityStatus
    numberPortabilityStatus
                                                                       OPTIONAL,
    extensionContainer
                                       [4] ExtensionContainer
                                                                       OPTIONAL,
    The IMSI parameter contains a generic IMSI, i.e. it is not tied necessarily to the
    Subscriber. MCC and MNC values in this IMSI shall point to the Subscription Network of
    the Subscriber. See 3GPP TS 23.066 [108].
```

```
RouteingNumber ::= TBCD-STRING (SIZE (1..5))
```

```
MS-Classmark2 ::= OCTET STRING (SIZE (3))

-- This parameter carries the value part of the MS Classmark 2 IE defined in

-- 3GPP TS 24.008 [35].
```

```
GPRSMSClass ::= SEQUENCE {

mSNetworkCapability [0] MSNetworkCapability,
mSRadioAccessCapability [1] MSRadioAccessCapability OPTIONAL
}
```

```
MSNetworkCapability ::= OCTET STRING (SIZE (1..8))

-- This parameter carries the value part of the MS Network Capability IE defined in

-- 3GPP TS 24.008 [35].
```

```
MSRadioAccessCapability ::= OCTET STRING (SIZE (1..50))

-- This parameter carries the value part of the MS Radio Access Capability IE defined in
-- 3GPP TS 24.008 [35].
```

```
RequestedInfo ::= SEQUENCE {
    locationInformation
                                          [0] NULL
                                                                             OPTIONAL.
                                          [1] NULL
    subscriberState
                                                                             OPTIONAL.
    extensionContainer
                                          [2] ExtensionContainer
                                                                             OPTIONAL,
                                                                             OPTIONAL,
    current Location
                                          [3] NULL
    requestedDomain
                                          [4] DomainType
                                                                             OPTIONAL.
                                          [6] NULL
    imei
                                                                             OPTIONAL.
    ms-classmark
                                                                             OPTIONAL,
                                          [5] NULL
    mnpRequestedInfo
                                          [7] NULL
                                                                             OPTIONAL }
    currentLocation shall be absent if locationInformation is absent
```

```
LocationInformation ::= SEQUENCE {
    ageOfLocationInformation
                                          AgeOfLocationInformation
                                                                            OPTIONAL,
     geographicalInformation
                                          [0] GeographicalInformation
[1] ISDN-AddressString
                                                                          OPTIONAL,
     vlr-number
                                                                             OPTIONAL.
                                          [2] LocationNumber
    locationNumber
                                                                             OPTIONAL.
     cellGlobalIdOrServiceAreaIdOrLAI
                                          [3] CellGlobalIdOrServiceAreaIdOrLAI OPTIONAL,
     extensionContainer
                                          [4] ExtensionContainer
                                                                             OPTIONAL,
     selectedLSA-Id
                                                                             OPTIONAL,
                                          [5] LSAIdentity
                                          [6] ISDN-AddressString
    msc-Number
                                                                             OPTIONAL.
     geodeticInformation
                                          [7] GeodeticInformation
                                                                             OPTIONAL.
     currentLocationRetrieved
                                          [8] NULL
                                                                             OPTIONAL,
                                          [9] NULL
    sai-Present
                                                                             OPTIONAL }
-- sai-Present indicates that the cellGlobalIdOrServiceAreaIdOrLAI parameter contains
-- a Service Area Identity.
-- currentLocationRetrieved shall be present
   if the location information were retrieved after a successfull paging.
```

```
LocationInformationGPRS ::= SEQUENCE {
                                cellGlobalIdOrServiceAreaIdOrLAI
                                                                                                                                                                                                                                                                                      [0] CellGlobalIdOrServiceAreaIdOrLAI OPTIONAL,
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                OPTIONAL,
                                routeingAreaIdentity
                                                                                                                                                                                                                                                                                    [1] RAIdentity
                                geographicalInformation
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       OPTIONAL.
                                                                                                                                                                                                                                                                                    [2] GeographicalInformation
                                                                                                                                                                                                                                                                                      [3] ISDN-AddressString
                                 sgsn-Number
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    OPTIONAL.
                                 selectedLSAIdentity
                                                                                                                                                                                                                                                                                  [4] LSAIdentity
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    OPTIONAL.
                                extensionContainer
                                                                                                                                                                                                                                                                                   [5] ExtensionContainer
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      OPTIONAL,
                                                                                                                                                                                                                                                                                   [6] NULL
                                sai-Present
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       OPTIONAL.
                                geodeticInformation
                                                                                                                                                                                                                                                                                      [7] GeodeticInformation
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       OPTIONAL.
                               currentLocationRetrieved ageOfLocationInformation
                                                                                                                                                                                                                                                                                [8] NULL
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        OPTIONAL,
                                                                                                                                                                                                                                                                                     [9] AgeOfLocationInformation OPTIONAL }
    -- sai-Present indicates that the cellGlobalIdOrServiceAreaIdOrLAI parameter contains
    -- a Service Area Identity.
    -- currentLocationRetrieved shall be present if the location information % \left( 1\right) =\left( 1\right) \left( 1\right) \left
     -- was retrieved after successful paging.
```

```
RAIdentity ::= OCTET STRING (SIZE (6))
-- Routing Area Identity is coded in accordance with 3GPP TS 29.060 [105].
-- It shall contain the value part defined in 3GPP TS 29.060 only. I.e. the 3GPP TS 29.060
-- type identifier octet shall not be included.
```

```
GeographicalInformation ::= OCTET STRING (SIZE (8))
-- Refers to geographical Information defined in 3GPP TS 23.032.
-- Only the description of an ellipsoid point with uncertainty circle
-- as specified in 3GPP TS 23.032 is allowed to be used
-- The internal structure according to 3GPP TS 23.032 is as follows:
-- Type of shape (ellipsoid point with uncertainty circle) 1 octet
-- Degrees of Latitude 3 octets
-- Degrees of Longitude 3 octets
-- Uncertainty code 1 octet
```

```
GeodeticInformation ::= OCTET STRING (SIZE (10))
    Refers to Calling Geodetic Location defined in Q.763 (1999).
    Only the description of an ellipsoid point with uncertainty circle
    as specified in Q.763 (1999) is allowed to be used
    The internal structure according to Q.763 (1999) is as follows:
        Screening and presentation indicators
                                                                            1 octet
- -
         Type of shape (ellipsoid point with uncertainty circle)
                                                                            1 octet
- -
         Degrees of Latitude
                                                                            3 octets
         Degrees of Longitude
                                                                            3 octets
         Uncertainty code
                                                                             1 octet
         Confidence
                                                                             1 octet
```

```
LocationNumber ::= OCTET STRING (SIZE (2..10))
-- the internal structure is defined in ITU-T Rec Q.763
```

```
SubscriberState ::= CHOICE {
   assumedIdle [0] NULL,
   camelBusy [1] NULL,
   netDetNotReachable NotReachableReason,
   notProvidedFromVLR [2] NULL}
```

```
PS-SubscriberState ::= CHOICE {
   notProvidedFromSGSN [0] NULL,
   ps-Detached [1] NULL,
   ps-AttachedNotReachableForPaging [2] NULL,
   ps-AttachedReachableForPaging [3] NULL,
   ps-PDP-ActiveNotReachableForPaging [4] PDP-ContextInfoList,
   ps-PDP-ActiveReachableForPaging [5] PDP-ContextInfoList,
   netDetNotReachable NotReachableReason }
```

```
PDP-ContextInfoList ::= SEQUENCE SIZE (1..maxNumOfPDP-Contexts) OF PDP-ContextInfo
```

```
PDP-ContextInfo ::= SEQUENCE {
    pdp-ContextIdentifier
                                            [0] ContextId,
     pdp-ContextActive
                                            [1] NULL
                                                                                OPTIONAL,
     pdp-Type
                                            [2] PDP-Type,
     pdp-Address
                                            [3] PDP-Address
                                                                                OPTIONAL.
     apn-Subscribed
                                            [4] APN
                                                                                OPTIONAL,
     apn-InUse
                                            [5] APN
                                                                                OPTIONAL.
                                            [6] NSAPI
                                                                                OPTIONAL,
     nsapi
                                            [7] TransactionId
     transactionId
                                                                                OPTIONAL.
     teid-ForGnAndGp
                                            [8] TEID
                                                                                OPTIONAL,
     teid-ForIu
                                            [9] TEID
                                                                                OPTIONAL,
                                            [10] GSN-Address
     ggsn-Address
                                                                                OPTIONAL.
                                            [11] Ext-QoS-Subscribed
     gos-Subscribed
                                                                                OPTIONAL,
                                            [12] Ext-QoS-Subscribed
     qos-Requested
                                                                                OPTIONAL.
     qos-Negotiated
                                            [13] Ext-QoS-Subscribed
                                                                                OPTIONAL,
     chargingId
                                            [14] GPRSChargingID
                                                                                OPTIONAL,
     chargingCharacteristics
                                            [15] ChargingCharacteristics
                                                                                OPTIONAL.
                                            [16] GSN-Address
                                                                                OPTIONAL,
     rnc-Address
                                            [17] ExtensionContainer
     extensionContainer
                                                                                OPTIONAL,
                                            [18] Ext2-QoS-Subscribed
     gos2-Subscribed
                                                                                OPTIONAL,
     -- qos2-Subscribed may be present only if qos-Subscribed is present.
                                            [19] Ext2-QoS-Subscribed
     gos2-Requested
                                                                                OPTIONAL.
     -- qos2-Requested may be present only if qos-Requested is present.
     qos2-Negotiated
                                            [20] Ext2-QoS-Subscribed
                                                                                OPTIONAL,
     -- qos2-Negotiated may be present only if qos-Negotiated is present.
                                           [21] Ext3-QoS-Subscribed
         qos3-Subscribed
                                                                                OPTIONAL,
     -- qos3-Subscribed may be present only if qos2-Subscribed is present.
qos3-Requested [22] Ext3-QoS-Subscribed
                                                                                OPTIONAL,
     -- qos3-Requested may be present only if qos2-Requested is present.
qos3-Negotiated [23] Ext3-QoS-Subscribed
     gos3-Negotiated
                                                                                OPTIONAL
     -- qos3-Negotiated may be present only if qos2-Negotiated is present.
```

```
NSAPI ::= INTEGER (0..15)
-- This type is used to indicate the Network layer Service Access Point
```

```
TransactionId ::= OCTET STRING (SIZE (1..2))

-- This type carries the value part of the transaction identifier which is used in the

-- session management messages on the access interface. The encoding is defined in

-- 3GPP TS 24.008
```

maxNumOfMSISDN INTEGER ::= 50

```
TEID ::= OCTET STRING (SIZE (4))
    This type carries the value part of the Tunnel Endpoint Identifier which is used to
     distinguish between different tunnels between the same pair of entities which communicate
    using the GPRS Tunnelling Protocol The encoding is defined in 3GPP TS 29.060.
GPRSChargingID ::= OCTET STRING (SIZE (4))
    The Charging ID is a unique four octet value generated by the GGSN when
     a PDP Context is activated. A Charging ID is generated for each activated context.
     The encoding is defined in 3GPP TS 29.060.
NotReachableReason ::= ENUMERATED {
    msPurged (0),
     imsiDetached (1),
    restrictedArea (2),
    notRegistered (3) }
-- any time interrogation info types
AnyTimeInterrogationArg ::= SEQUENCE {
     subscriberIdentity
                                          [0] SubscriberIdentity,
     requestedInfo
                                          [1] RequestedInfo,
     qsmSCF-Address
                                          [3] ISDN-AddressString,
     extensionContainer
                                          [2] ExtensionContainer
                                                                            OPTIONAL.
AnyTimeInterrogationRes ::= SEQUENCE {
     subscriberInfo
                                          SubscriberInfo,
     extensionContainer
                                          ExtensionContainer
                                                                            OPTIONAL,
-- any time information handling types
AnyTimeSubscriptionInterrogationArg ::= SEQUENCE {
     subscriberIdentity
                                          [0] SubscriberIdentity,
     requestedSubscriptionInfo
                                          [1] RequestedSubscriptionInfo,
     gsmSCF-Address
                                          [2] ISDN-AddressString,
     extensionContainer
                                          [3] ExtensionContainer
                                                                            OPTIONAL.
     longFTN-Supported
                                          [4] NULL
                                                                            OPTIONAL,
AnyTimeSubscriptionInterrogationRes ::= SEQUENCE {
    callForwardingData
                                          [1] CallForwardingData
                                                                            OPTIONAL,
    callBarringData
                                          [2] CallBarringData
                                                                            OPTIONAL,
                                         [3] ODB-Info
     odb-Info
                                                                            OPTIONAL.
     camel-SubscriptionInfo
                                          [4] CAMEL-SubscriptionInfo
                                                                            OPTIONAL,
     supportedVLR-CAMEL-Phases
                                         [5] SupportedCamelPhases
                                                                            OPTIONAL,
     supportedSGSN-CAMEL-Phases
                                          [6] SupportedCamelPhases
                                                                            OPTIONAL,
     extensionContainer
                                          [7] ExtensionContainer
                                                                            OPTIONAL,
     offeredCamel4CSIsInVLR
                                          [8] OfferedCamel4CSIs
                                                                            OPTIONAL,
     offeredCamel4CSIsInSGSN
                                          [9] OfferedCamel4CSIs
                                                                            OPTIONAL,
     msisdn-BS-List
                                          [10] MSISDN-BS-List
                                                                            OPTIONAL
RequestedSubscriptionInfo ::= SEQUENCE {
    requestedSS-Info
                                          [1] SS-ForBS-Code
                                                                            OPTIONAL,
                                          [2] NULL
                                                                            OPTIONAL.
     odb
     requestedCAMEL-SubscriptionInfo
                                          [3] RequestedCAMEL-SubscriptionInfo
                                                                                 OPTIONAL,
     supportedVLR-CAMEL-Phases
                                          [4] NULL
                                                                            OPTIONAL,
     supportedSGSN-CAMEL-Phases
                                          [5] NULL
                                                                            OPTIONAL,
     extensionContainer
                                          [6] ExtensionContainer
                                                                            OPTIONAL,
     additionalRequestedCAMEL-SubscriptionInfo
                                          [7] AdditionalRequestedCAMEL-SubscriptionInfo
                                                                            OPTIONAL.
    msisdn-BS-List
                                          [8] NULL
                                                                            OPTIONAL
MSISDN-BS-List ::= SEQUENCE SIZE (1..maxNumOfMSISDN) OF
                                         MSISDN-BS
```

```
RequestedCAMEL-SubscriptionInfo ::= ENUMERATED {
    o-CSI
     t.-CSI
                                             (1),
     vt-CSI
                                             (2),
     tif-CSI
                                             (3),
     gprs-CSI
                                             (4),
     mo-sms-CSI
                                             (5),
                                             (6),
     ss-CSI
     m-CSI
                                              (7)
     d-csi
                                              (8)
```

#### WrongPasswordAttemptsCounter ::= INTEGER (0..4)

```
CAMEL-SubscriptionInfo ::= SEQUENCE {
    o-CSI
                                          [0] O-CSI
                                                                             OPTIONAL,
    o-BcsmCamelTDP-CriteriaList
                                          [1] O-BcsmCamelTDPCriteriaList
                                                                             OPTIONAL,
    d-CSI
                                          [2] D-CSI
                                                                             OPTIONAL,
    t-CSI
                                          [3]
                                              T-CSI
                                                                             OPTIONAL,
    t-BCSM-CAMEL-TDP-CriteriaList
                                          [4] T-BCSM-CAMEL-TDP-CriteriaList OPTIONAL,
    vt-CSI
                                          [5]
                                               T-CSI
                                                                             OPTIONAL,
                                          [6] T-BCSM-CAMEL-TDP-CriteriaList OPTIONAL,
    vt-BCSM-CAMEL-TDP-CriteriaList
                                          [7]
    tif-CSI
                                              NULL
                                                                             OPTIONAL,
    tif-CSI-NotificationToCSE
                                          [8] NULL
                                                                             OPTIONAL,
    gprs-CSI
                                          [9] GPRS-CSI
                                                                             OPTIONAL,
    mo-sms-CSI
                                          [10] SMS-CSI
                                                                             OPTIONAL,
    ss-CSI
                                          [11] SS-CSI
                                                                             OPTIONAL,
    m-CSI
                                          [12] M-CSI
                                                                             OPTIONAL,
    extensionContainer
                                          [13] ExtensionContainer
                                                                             OPTIONAL,
    specificCSIDeletedList
                                          [14] SpecificCSI-Withdraw
                                                                             OPTIONAL,
    mt-sms-CSI
                                          [15] SMS-CSI
                                                                             OPTIONAL,
    mt-smsCAMELTDP-CriteriaList
                                          [16] MT-smsCAMELTDP-CriteriaList
                                                                             OPTIONAL,
                                           [17] MG-CSI
                                                                             OPTIONAL,
    mq-csi
    o-IM-CSI
                                          [18] O-CSI
                                                                             OPTIONAL,
    o-IM-BcsmCamelTDP-CriteriaList
                                          [19] O-BcsmCamelTDPCriteriaList
                                                                             OPTIONAL.
                                          [20] D-CSI
    d-IM-CSI
                                                                             OPTIONAL,
                                                                             OPTIONAL,
    vt-IM-CSI
                                          [21] T-CSI
    vt-IM-BCSM-CAMEL-TDP-CriteriaList
                                          [22] T-BCSM-CAMEL-TDP-CriteriaList OPTIONAL
```

```
AnyTimeModificationArg ::= SEQUENCE {
                                          [0] SubscriberIdentity,[1] ISDN-AddressString,
     subscriberIdentity
     gsmSCF-Address
     modificationRequestFor-CF-Info
                                           [2] ModificationRequestFor-CF-Info OPTIONAL,
     modificationRequestFor-CB-Info
                                               ModificationRequestFor-CB-Info OPTIONAL,
                                           [3]
                                           [4] ModificationRequestFor-CSI OPTIONAL,
    modificationRequestFor-CSI
                                          [5] ExtensionContainer
     extensionContainer
                                                                              OPTIONAL.
     longFTN-Supported
                                                                             OPTIONAL,
     modificationRequestFor-ODB-data
                                           [7] ModificationRequestFor-ODB-data OPTIONAL,
     modificationRequestFor-IP-SM-GW-Data [8]
                                               ModificationRequestFor-IP-SM-GW-Data OPTIONAL }
AnyTimeModificationRes ::= SEQUENCE {
     ss-InfoFor-CSE
                                           [0] Ext-SS-InfoFor-CSE
                                                                              OPTIONAL,
     camel-SubscriptionInfo
                                           [1] CAMEL-SubscriptionInfo
                                                                              OPTIONAL,
     extensionContainer
                                           [2] ExtensionContainer
                                                                              OPTIONAL,
     odb-Info
                                           [3] ODB-Info
                                                                              OPTIONAL }
ModificationRequestFor-CF-Info ::= SEQUENCE {
                                          [0] SS-Code,
[1] Ext-BasicServiceCode
     ss-Code
    basicService
                                                                              OPTIONAL,
     ss-Status
                                           [2] Ext-SS-Status
                                                                              OPTIONAL,
     forwardedToNumber
                                               AddressString
                                                                              OPTIONAL,
                                           [3]
                                           [4] ISDN-SubaddressString
     forwardedToSubaddress
                                                                              OPTIONAL.
     noReplyConditionTime
                                                                              OPTIONAL,
                                           [5] Ext-NoRepCondTime
     modifyNotificationToCSE
                                           [6]
                                               ModificationInstruction
                                                                              OPTIONAL,
     extensionContainer
                                           [7] ExtensionContainer
                                                                              OPTIONAL,
ModificationRequestFor-CB-Info ::= SEQUENCE {
    ss-Code
                                               SS-Code.
                                           [0]
                                               Ext-BasicServiceCode
                                                                              OPTIONAL,
    basicService
                                           [1]
     ss-Status
                                           [2]
                                               Ext-SS-Status
                                                                              OPTIONAL,
                                               Password
                                                                              OPTIONAL,
    password
                                           [3]
     wrongPasswordAttemptsCounter
                                           [4]
                                               WrongPasswordAttemptsCounter OPTIONAL,
     modifyNotificationToCSE
                                               ModificationInstruction
                                                                              OPTIONAL.
                                           [5]
                                           [6] ExtensionContainer
     extensionContainer
                                                                              OPTIONAL.
ModificationRequestFor-ODB-data ::= SEQUENCE {
                                               ODB-Data
     odb-data
                                           [0]
                                                                              OPTIONAL,
     modifyNotificationToCSE
                                               ModificationInstruction
                                                                              OPTIONAL,
                                           [1]
     extensionContainer
                                           [2] ExtensionContainer
                                                                              OPTIONAL.
ModificationRequestFor-CSI ::= SEQUENCE {
     requestedCamel-SubscriptionInfo
                                           [0] RequestedCAMEL-SubscriptionInfo,
     modifyNotificationToCSE
                                               ModificationInstruction OPTIONAL,
     modifyCSI-State
                                           [2] ModificationInstruction
                                                                              OPTIONAL.
                                                                             OPTIONAL,
     extensionContainer
                                           [3] ExtensionContainer
     {\tt additional Requested CAMEL-Subscription Info}
                                          [4] AdditionalRequestedCAMEL-SubscriptionInfo
-- requestedCamel-SubscriptionInfo shall be discarded if
   additional {\tt Requested CAMEL-Subscription Info}\ is\ received
ModificationRequestFor-IP-SM-GW-Data ::= SEQUENCE
     modifyRegistrationStatus
                                           [0] ModificationInstruction
                                                                              OPTIONAL,
     extensionContainer
                                           [1] ExtensionContainer
                                                                              OPTIONAL,
ModificationInstruction ::= ENUMERATED {
     deactivate
                                           (0)
```

activate

(1)

<sup>--</sup> subscriber data modification notification types

```
NoteSubscriberDataModifiedArg ::= SEQUENCE {
                                          TMST.
     imsi
                                          ISDN-AddressString,
    msisdn
     forwardingInfoFor-CSE
                                          [0] Ext-ForwardingInfoFor-CSE
                                                                             OPTIONAL,
     callBarringInfoFor-CSE
                                          [1] Ext-CallBarringInfoFor-CSE
                                                                             OPTIONAL,
                                          [2] ODB-Info
    odb-Info
                                                                             OPTIONAL,
     camel-SubscriptionInfo
                                          [3] CAMEL-SubscriptionInfo
                                                                             OPTIONAL.
                                          [4] NULL
     allInformationSent
                                                                             OPTIONAL,
     extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
```

-- mobility management event notificatioon info types

```
NoteMM-EventArg::= SEQUENCE {
    serviceKey
                                            ServiceKev.
     eventMet
                                            [0] MM-Code.
     imsi
                                            [1] IMSI,
    msisdn
                                            [2] ISDN-AddressString,
     locationInformation
                                            [3] LocationInformation
                                                                               OPTIONAL,
                                            [5] SupportedCamelPhases[6] ExtensionContainer
     supportedCAMELPhases
                                                                                OPTIONAL,
     extensionContainer
                                                                                OPTIONAL,
     locationInformationGPRS
                                            [7] LocationInformationGPRS
                                                                                OPTIONAL.
    offeredCamel4Functionalities
                                            [8] OfferedCamel4Functionalities OPTIONAL
```

```
Ext-CallBarringInfoFor-CSE ::= SEQUENCE {
                                          [0] SS-Code,
    ss-Code
                                          [1] Ext-CallBarFeatureList,
    callBarringFeatureList
    password
                                              Password
                                          [2]
                                                                             OPTIONAL,
    wrongPasswordAttemptsCounter
                                              WrongPasswordAttemptsCounter OPTIONAL,
                                          [3]
    notificationToCSE
                                          [4] NULL
                                                                             OPTIONAL,
    extensionContainer
                                          [5] ExtensionContainer
                                                                             OPTIONAL,
```

END

## 17.7.2 Operation and maintenance data types

```
MAP-OM-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-OM-DataTypes (12) version10 (10) }

DEFINITIONS

IMPLICIT TAGS

::=

BEGIN

EXPORTS
   ActivateTraceModeArg,
   ActivateTraceModeRes,
   DeactivateTraceModeArg,
   DeactivateTraceModeRes,
   TracePropagationList
```

```
;
IMPORTS
   AddressString,
   IMSI
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CommonDataTypes (18) version10 (10)}
   ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version10 (10)}
ActivateTraceModeArg ::= SEQUENCE {
                                           [0] IMSI
                                                                             OPTIONAL,
                                           [1] TraceReference,
     traceReference
     traceType
                                           [2] TraceType,
     omc-Id
                                           [3] AddressString
                                                                             OPTIONAL.
     extensionContainer
                                          [4] ExtensionContainer
                                                                             OPTIONAL,
                                                                            OPTIONAL,
     traceReference2
                                          [5] TraceReference2
     traceDepthList
                                          [6] TraceDepthList
                                                                             OPTIONAL,
                                           [7] TraceNE-TypeList
     traceNE-TypeList
                                                                             OPTIONAL,
     traceInterfaceList
                                          [8] TraceInterfaceList
                                                                             OPTIONAL,
     traceEventList
                                          [9] TraceEventList
                                                                             OPTIONAL
TraceReference ::= OCTET STRING (SIZE (1..2))
TraceReference2 ::= OCTET STRING (SIZE (3))
TraceRecordingSessionReference ::= OCTET STRING (SIZE (2))
TraceType ::= INTEGER
    (0..255)
     -- Trace types are fully defined in 3GPP TS 52.008. [61]
TraceDepthList ::= SEQUENCE {
    msc-s-TraceDepth
                                          [0] TraceDepth
                                                                             OPTIONAL.
     mgw-TraceDepth
                                          [1] TraceDepth
                                                                             OPTIONAL,
                                           [2] TraceDepth
     sgsn-TraceDepth
                                                                             OPTIONAL,
     ggsn-TraceDepth
                                          [3] TraceDepth
                                                                             OPTIONAL,
                                          [4] TraceDepth
[5] TraceDepth
     rnc-TraceDepth
                                                                             OPTIONAL,
     bmsc-TraceDepth
                                                                             OPTIONAL,
TraceDepth ::= ENUMERATED {
     minimum (0),
     medium (1),
    maximum (2),
     . . . }
-- The value medium is applicable only for RNC. For other network elements, if value medium
-- is received, value minimum shall be applied.
TraceNE-TypeList ::= BIT STRING {
    msc-s (0),
     mgw (1),
     sgsn (2),
     ggsn (3),
     bm-sc (5) } (SIZE (6..16))
   Other bits than listed above shall be discarded.
TraceInterfaceList ::= SEQUENCE {
                                           [0] MSC-S-InterfaceList
     msc-s-List
                                                                             OPTIONAL.
     mgw-List
                                           [1] MGW-InterfaceList
                                                                             OPTIONAL,
     sgsn-List
                                           [2] SGSN-InterfaceList
                                                                             OPTIONAL,
                                           [3] GGSN-InterfaceList
     ggsn-List
                                                                             OPTIONAL,
                                           [4] RNC-InterfaceList
     rnc-List
                                                                             OPTIONAL,
     bmsc-List
                                           [5] BMSC-InterfaceList
                                                                             OPTIONAL,
```

```
MSC-S-InterfaceList ::= BIT STRING {
    a (0),
    iu (1),
    mc (2),
    map-g (3),
    map-b (4),
    map-e (5),
    map-f (6),
    cap (7),
    map-d (8),
    map-c (9)} (SIZE (10..16))
-- Other bits than listed above shall be discarded.
```

```
MGW-InterfaceList ::= BIT STRING {
    mc (0),
    nb-up (1),
    iu-up (2)} (SIZE (3..8))
-- Other bits than listed above shall be discarded.
```

```
SGSN-InterfaceList ::= BIT STRING {
    gb (0),
    iu (1),
    gn (2),
    map-gr (3),
    map-gd (4),
    map-gf (5),
    gs (6),
    ge (7)} (SIZE (8..16))
-- Other bits than listed above shall be discarded.
```

```
GGSN-InterfaceList ::= BIT STRING {
    gn (0),
    gi (1),
    gmb (2)} (SIZE (3..8))
-- Other bits than listed above shall be discarded.
```

```
RNC-InterfaceList ::= BIT STRING {
    iu (0),
    iur (1),
    iub (2),
    uu (3)} (SIZE (4..8))
-- Other bits than listed above shall be discarded.
```

```
BMSC-InterfaceList ::= BIT STRING {
    gmb (0)} (SIZE (1..8))
-- Other bits than listed above shall be discarded.
```

```
TraceEventList ::= SEQUENCE {
    msc-s-List
                                           [0] MSC-S-EventList
                                                                              OPTIONAL.
    mgw-List
                                           [1] MGW-EventList
                                                                              OPTIONAL,
    sgsn-List
                                           [2] SGSN-EventList
                                                                              OPTIONAL,
    ggsn-List
                                           [3] GGSN-EventList
                                                                              OPTIONAL,
    bmsc-List
                                           [4] BMSC-EventList
                                                                              OPTIONAL,
```

```
MSC-S-EventList ::= BIT STRING {
    mo-mtCall (0),
    mo-mt-sms (1),
    lu-imsiAttach-imsiDetach (2),
    handovers (3),
    ss (4)} (SIZE (5..16))
-- Other bits than listed above shall be discarded.
```

```
MGW-EventList ::= BIT STRING {
    context (0)} (SIZE (1..8))
-- Other bits than listed above shall be discarded.
```

```
SGSN-EventList ::= BIT STRING {
   pdpContext (0),
   mo-mt-sms (1),
   rau-gprsAttach-gprsDetach (2),
   mbmsContext (3)} (SIZE (4..16))
-- Other bits than listed above shall be discarded.
```

```
GGSN-EventList ::= BIT STRING {
   pdpContext (0),
   mbmsContext (1)} (SIZE (2..8))
-- Other bits than listed above shall be discarded.
```

```
BMSC-EventList ::= BIT STRING {
    mbmsMulticastServiceActivation (0)} (SIZE (1..8))
-- Other bits than listed above shall be discarded.
```

```
TracePropagationList ::= SEQUENCE {
                                          [0] TraceReference
    traceReference
                                                                             OPTIONAL,
    traceType
                                          [1] TraceType
                                                                             OPTIONAL,
    traceReference2
                                          [2] TraceReference2
                                                                             OPTIONAL,
    traceRecordingSessionReference
                                          [3] TraceRecordingSessionReference OPTIONAL,
                                          [4] TraceDepth
    rnc-TraceDepth
                                                                             OPTIONAL,
    rnc-InterfaceList
                                          [5] RNC-InterfaceList
                                                                             OPTIONAL,
    msc-s-TraceDepth
                                          [6] TraceDepth
                                                                             OPTIONAL,
    msc-s-InterfaceList
                                          [7] MSC-S-InterfaceList
                                                                             OPTIONAL,
    msc-s-EventList
                                          [8] MSC-S-EventList
                                                                             OPTIONAL.
    mgw-TraceDepth
                                          [9] TraceDepth
                                                                             OPTIONAL,
    mgw-InterfaceList
                                          [10] MGW-InterfaceList
                                                                             OPTIONAL,
    mgw-EventList
                                          [11] MGW-EventList
                                                                             OPTIONAL,
```

```
ActivateTraceModeRes ::= SEQUENCE {
    extensionContainer [0] ExtensionContainer OPTIONAL,
    ...,
    traceSupportIndicator [1] NULL OPTIONAL
}
```

```
DeactivateTraceModeRes ::= SEQUENCE {
    extensionContainer [0] ExtensionContainer OPTIONAL,
    ...}
```

ENI

## 17.7.3 Call handling data types

```
MAP-CH-DataTypes {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CH-DataTypes (13) version10 (10)}
DEFINITIONS
IMPLICIT TAGS
BEGIN
EXPORTS
  SendRoutingInfoArg,
   SendRoutingInfoRes,
   ProvideRoamingNumberArg,
  ProvideRoamingNumberRes,
   ResumeCallHandlingArg,
   ResumeCallHandlingRes,
  NumberOfForwarding,
   SuppressionOfAnnouncement,
   CallReferenceNumber,
   SetReportingStateArg,
   SetReportingStateRes,
  StatusReportArg,
   StatusReportRes,
  RemoteUserFreeArg,
   RemoteUserFreeRes,
   IST-AlertArg,
   IST-AlertRes,
```

OPTIONAL,

extensionContainer

```
IST-CommandArg,
   IST-CommandRes,
  UU-Data,
  ReleaseResourcesArg,
   ReleaseResourcesRes
IMPORTS
   SubscriberInfo,
   SupportedCamelPhases,
   OfferedCamel4CSIs,
   CUG-Interlock,
  O-CSI,
  D-CSI,
   O-BcsmCamelTDPCriteriaList,
  T-BCSM-CAMEL-TDP-CriteriaList,
   IST-SupportIndicator,
  IST-AlertTimerValue,
  T-CSI,
  NumberPortabilityStatus
FROM MAP-MS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-MS-DataTypes (11) version10 (10)}
  ForwardingOptions,
  SS-List,
   CCBS-Feature
FROM MAP-SS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-SS-DataTypes (14) version10 (10)}
   ISDN-AddressString,
   ISDN-SubaddressString,
   FTN-AddressString,
   ExternalSignalInfo
  Ext-ExternalSignalInfo,
   IMSI,
  LMSI,
   Ext-BasicServiceCode,
  AlertingPattern,
  NAEA-PreferredCI
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-CommonDataTypes (18) version10 (10)}
  ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version10 (10)}
CUG-CheckInfo ::= SEQUENCE {
    cug-Interlock
                                          CUG-Interlock,
    cug-OutgoingAccess
                                          NULL
                                                                             OPTIONAL,
```

```
NumberOfForwarding ::= INTEGER (1..5)
```

ExtensionContainer

```
SendRoutingInfoArg ::= SEQUENCE {
                                        [0] ISDN-AddressString,
    msisdn
    cug-CheckInfo
                                        [1] CUG-CheckInfo
                                                                         OPTIONAL,
    numberOfForwarding
                                        [2] NumberOfForwarding
                                                                         OPTIONAL,
                                        [3] InterrogationType,
    interrogationType
    or-Interrogation
                                        [4] NULL
                                                                         OPTIONAL,
                                        [5] OR-Phase
    or-Capability
                                                                         OPTIONAL.
    qmsc-OrGsmSCF-Address
                                        [6] ISDN-AddressString,
    callReferenceNumber
                                       [7] CallReferenceNumber
                                                                         OPTIONAL,
    forwardingReason
                                        [8] ForwardingReason
                                                                         OPTIONAL,
    basicServiceGroup
                                       [9] Ext-BasicServiceCode
                                                                         OPTIONAL,
    networkSignalInfo
                                        [10] ExternalSignalInfo
                                                                         OPTIONAL.
    camelInfo
                                        [11] CamelInfo
                                                                         OPTIONAL.
    suppressionOfAnnouncement
                                       [12] SuppressionOfAnnouncement OPTIONAL,
    extensionContainer
                                       [13] ExtensionContainer
                                                                         OPTIONAL,
    alertingPattern
                                        [14] AlertingPattern
                                                                        OPTIONAL,
    ccbs-Call
                                        [15] NULL
                                                                          OPTIONAL,
    supportedCCBS-Phase
                                       [16] SupportedCCBS-Phase
                                                                        OPTIONAL,
                                       [17] Ext-ExternalSignalInfo
[18] IST-SupportIndicator
    additionalSignalInfo
                                                                         OPTIONAL,
                                       [18] IST-SupportIndicator
    istSupportIndicator
                                                                         OPTIONAL,
                                       [19] NULL
    pre-pagingSupported
                                                                         OPTIONAL,
    callDiversionTreatmentIndicator
                                       [20] CallDiversionTreatmentIndicator OPTIONAL,
                                       [21] NULL
                                                                         OPTIONAL,
    longFTN-Supported
    suppress-VT-CSI
                                        [22] NULL
                                                                         OPTIONAL,
                                        [23] NULL
    suppressIncomingCallBarring
                                                                         OPTIONAL.
    gsmSCF-InitiatedCall
                                       [24] NULL
                                                                         OPTIONAL,
    basicServiceGroup2
                                        [25] Ext-BasicServiceCode
                                                                         OPTIONAL,
    networkSignalInfo2
                                       [26] ExternalSignalInfo
                                                                         OPTIONAL,
    suppressMTSS
                                        [27] SuppressMTSS
                                                                         OPTIONAL,
    mtRoamingRetrySupported
                                        [28] NULL
                                                                         OPTIONAL
```

#### SuppressionOfAnnouncement ::= NULL

```
InterrogationType ::= ENUMERATED {
   basicCall (0),
   forwarding (1)}
```

```
OR-Phase ::= INTEGER (1..127)
```

```
CallReferenceNumber ::= OCTET STRING (SIZE (1..8))
```

```
ForwardingReason ::= ENUMERATED {
   notReachable (0),
   busy (1),
   noReply (2)}
```

```
SupportedCCBS-Phase ::= INTEGER (1..127)
-- exception handling:
-- Only value 1 is used.
-- Values in the ranges 2-127 are reserved for future use.
-- If received values 2-127 shall be mapped on to value 1.
```

```
CallDiversionTreatmentIndicator ::= OCTET STRING (SIZE(1))
-- callDiversionAllowed (xxxx xx01)
-- callDiversionNotAllowed (xxxx xx10)
-- network default is call diversion allowed
```

```
SendRoutingInfoRes ::= [3] SEQUENCE {
                                         [9] TMST
                                                                            OPTIONAL.
    imsi
     -- IMSI must be present if SendRoutingInfoRes is not segmented.
     -- If the TC-Result-NL segmentation option is taken the IMSI must be
     -- present in one segmented transmission of SendRoutingInfoRes.
    extendedRoutingInfo
                                        ExtendedRoutingInfo
                                                                            OPTIONAL.
                                         [3] CUG-CheckInfo
    cua-CheckInfo
                                                                            OPTIONAL.
                                         [6] NULL
    cuqSubscriptionFlag
                                                                            OPTIONAL.
    subscriberInfo
                                         [7] SubscriberInfo
                                                                            OPTIONAL,
    ss-List
                                         [1] SS-List
                                                                            OPTIONAL,
    basicService
                                         [5] Ext-BasicServiceCode
                                                                           OPTIONAL,
                                         [4] NULL
    forwardingInterrogationRequired
                                                                            OPTIONAL.
                                         [2] ISDN-AddressString
                                                                           OPTIONAL,
    mac-Address
    extensionContainer
                                         [0] ExtensionContainer
                                                                           OPTIONAL,
    naea-PreferredCI
                                         [10] NAEA-PreferredCI
                                                                           OPTIONAL.
     -- naea-PreferredCI is included at the discretion of the HLR operator.
    ccbs-Indicators
                                         [11] CCBS-Indicators
                                                                            OPTIONAL,
                                         [12] ISDN-AddressString
                                                                            OPTIONAL.
                                         [12] ISDN-AddressSSTILS
[13] NumberPortabilityStatus
    numberPortabilityStatus
                                                                           OPTIONAL,
                                         [14] IST-AlertTimerValue
    istAlertTimer
                                                                           OPTIONAL,
     supportedCamelPhasesInVMSC
                                         [15] SupportedCamelPhases
                                                                           OPTIONAL,
                                         [16] OfferedCamel4CSIs
    offeredCamel4CSIsInVMSC
                                                                           OPTIONAL,
                                         [17] RoutingInfo
    routingInfo2
                                                                           OPTIONAL.
                                         [18] SS-List
    ss-List2
                                                                            OPTIONAL.
                                         [19] Ext-BasicServiceCode
    basicService2
                                                                            OPTIONAL,
    allowedServices
                                         [20] AllowedServices
                                                                            OPTIONAL,
                                         [21] UnavailabilityCause
     unavailabilityCause
                                                                           OPTIONAL,
    releaseResourcesSupported
                                         [22] NULL
                                                                            OPTIONAL,
     gsm-BearerCapability
                                         [23] ExternalSignalInfo
                                                                            OPTIONAL
```

```
UnavailabilityCause ::= ENUMERATED {
    bearerServiceNotProvisioned
                                          (1),
     teleserviceNotProvisioned
                                          (2),
    absentSubscriber
                                          (3),
    busySubscriber
                                          (4),
    callBarred
                                          (5),
    cug-Reject
                                          (6),
     . . . }
         exception handling:
         Reception of other values than the ones listed shall result in the service
         being unavailable for that call.
```

```
ForwardingData ::= SEQUENCE {
    forwardedToNumber
                                       [5] ISDN-AddressString
                                                                         OPTIONAL,
    -- When this datatype is sent from an HLR which supports CAMEL Phase 2
    -- to a GMSC which supports CAMEL Phase 2 the GMSC shall not check the
    -- format of the number
    forwardedToSubaddress
                                        [4] ISDN-SubaddressString
                                                                         OPTIONAL.
                                                                         OPTIONAL,
    forwardingOptions
                                        [6] ForwardingOptions
    extensionContainer
                                        [7] ExtensionContainer
                                                                         OPTIONAL,
    longForwardedToNumber [8] FTN-AddressString
                                                                        OPTIONAL)
```

```
ProvideRoamingNumberArg ::= SEQUENCE {
     imsi
                                          [0] IMSI,
    msc-Number
                                          [1] ISDN-AddressString,
     msisdn
                                          [2] ISDN-AddressString
                                                                             OPTIONAL,
                                          [4] LMSI
     lmsi
                                                                             OPTIONAL,
    gsm-BearerCapability
                                          [5] ExternalSignalInfo
                                                                             OPTIONAL,
     networkSignalInfo
                                          [6] ExternalSignalInfo
                                                                             OPTIONAL.
     suppressionOfAnnouncement
                                          [7] SuppressionOfAnnouncement
                                                                            OPTIONAL,
     gmsc-Address
                                          [8] ISDN-AddressString
                                                                             OPTIONAL,
     callReferenceNumber
                                          [9] CallReferenceNumber
                                                                             OPTIONAL,
    or-Interrogation
                                          [10] NULL
                                                                             OPTIONAL,
                                          [11] ExtensionContainer
     extensionContainer
                                                                             OPTIONAL.
     alertingPattern
                                          [12] AlertingPattern
                                                                             OPTIONAL,
     ccbs-Call
                                          [13] NULL
                                                                             OPTIONAL,
     supportedCamelPhasesInInterrogatingNode [15] SupportedCamelPhases
                                                                             OPTIONAL.
     additionalSignalInfo
                                          [14] Ext-ExternalSignalInfo
                                                                             OPTIONAL,
     orNotSupportedInGMSC
                                          [16] NULL
                                                                             OPTIONAL,
    pre-pagingSupported
                                          [17] NULL
                                                                             OPTIONAL.
     longFTN-Supported
                                          [18] NULL
                                                                             OPTIONAL,
                                          [19] NULL
     suppress-VT-CSI
                                                                             OPTIONAL,
     offeredCamel4CSIsInInterrogatingNode [20] OfferedCamel4CSIs
                                                                             OPTIONAL,
     mtRoamingRetrySupported
                                          [21] NULL
                                                                             OPTIONAL
ProvideRoamingNumberRes ::= SEQUENCE {
    roamingNumber
                                          ISDN-AddressString,
     extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL.
     releaseResourcesSupported
                                          NULL
                                                                             OPTIONAL }
ResumeCallHandlingArg ::= SEQUENCE {
    callReferenceNumber
                                          [0] CallReferenceNumber
                                                                             OPTIONAL,
     basicServiceGroup
                                          [1] Ext-BasicServiceCode
                                                                             OPTIONAL,
                                          [2] ForwardingData
                                                                             OPTIONAL,
     forwardingData
                                          [3] IMSI
     imsi
                                                                             OPTIONAL,
     cug-CheckInfo
                                          [4] CUG-CheckInfo
                                                                             OPTIONAL,
     o-CSI
                                          [5] O-CSI
                                                                             OPTIONAL,
     extensionContainer
                                          [7] ExtensionContainer
                                                                             OPTIONAL,
    ccbs-Possible
                                          [8] NULL
                                                                             OPTIONAL.
    msisdn
                                          [9] ISDN-AddressString
                                                                             OPTIONAL,
     uu-Data
                                          [10] UU-Data
                                                                             OPTIONAL,
                                          [11] NULL
    allInformationSent
                                                                             OPTIONAL,
     d-csi
                                          [12] D-CSI
                                                                             OPTIONAL,
     o-BcsmCamelTDPCriteriaList
                                          [13] O-BcsmCamelTDPCriteriaList
                                                                             OPTIONAL,
     basicServiceGroup2
                                          [14] Ext-BasicServiceCode
                                                                             OPTIONAL,
     mtRoamingRetry
                                          [15] NULL
                                                                             OPTIONAL
UU-Data ::= SEQUENCE {
    uuIndicator
                                          [0] UUIndicator
                                                                             OPTIONAL.
     uui
                                          [1] UUI
                                                                             OPTIONAL,
     uusCFInteraction
                                          [2] NULL
                                                                             OPTIONAL,
                                          [3] ExtensionContainer
     extensionContainer
                                                                             OPTIONAL,
UUIndicator ::= OCTET STRING (SIZE (1))
     -- Octets are coded according to ETS 300 356
UUI ::= OCTET STRING (SIZE (1..131))
     -- Octets are coded according to ETS 300 356
ResumeCallHandlingRes ::= SEQUENCE {
     extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
     . . . }
CamelInfo ::= SEQUENCE {
    supportedCamelPhases
                                          SupportedCamelPhases,
     suppress-T-CSI
                                                                             OPTIONAL,
                                          ExtensionContainer
     extensionContainer
                                                                             OPTIONAL,
     offeredCamel4CSIs
                                          [0] OfferedCamel4CSIs
                                                                             OPTIONAL }
```

```
ExtendedRoutingInfo ::= CHOICE {
     routingInfo
                                           RoutingInfo,
                                           [8] CamelRoutingInfo}
     camelRoutingInfo
CamelRoutingInfo ::= SEQUENCE {
     forwardingData
                                           ForwardingData
                                                                              OPTIONAL,
                                           [0] GmscCamelSubscriptionInfo,
     gmscCamelSubscriptionInfo
     extensionContainer
                                           [1] ExtensionContainer
                                                                              OPTIONAL.
GmscCamelSubscriptionInfo ::= SEQUENCE {
     t-CST
                                           [0] T-CSI OPTIONAL,
     o-CSI
                                           [1] O-CSI OPTIONAL,
     extensionContainer
                                           [2] ExtensionContainer
                                                                              OPTIONAL,
     o-BcsmCamelTDP-CriteriaList
                                           [3] O-BcsmCamelTDPCriteriaList
                                                                              OPTIONAL.
     t-BCSM-CAMEL-TDP-CriteriaList
                                           [4] T-BCSM-CAMEL-TDP-CriteriaList OPTIONAL,
                                               D-CSI
                                                                              OPTIONAL }
SetReportingStateArg ::= SEQUENCE {
                                                                              OPTIONAL,
     imsi
                                           [0] IMSI
                                               LMSI
                                                                              OPTIONAL,
     lmsi
                                           [1]
     ccbs-Monitoring
                                               ReportingState
                                           [2]
                                                                              OPTIONAL,
     extensionContainer
                                           [3] ExtensionContainer
                                                                              OPTIONAL,
ReportingState ::= ENUMERATED {
     stopMonitoring
                                           (0),
     startMonitoring
                                           (1),
     . . . }
     -- exception handling:
     -- reception of values 2-10 shall be mapped to 'stopMonitoring'
     -- reception of values > 10 shall be mapped to 'startMonitoring'
SetReportingStateRes ::= SEQUENCE{
     ccbs-SubscriberStatus
                                           [0] CCBS-SubscriberStatus
                                                                              OPTIONAL,
     extensionContainer
                                           [1] ExtensionContainer
                                                                              OPTIONAL,
CCBS-SubscriberStatus ::= ENUMERATED {
     ccbsNotIdle
                                           (0),
     ccbsIdle
                                           (1),
     ccbsNotReachable
                                           (2),
     . . . }
     -- exception handling:
     -- reception of values 3-10 shall be mapped to 'ccbsNotIdle'
        reception of values 11-20 shall be mapped to 'ccbsIdle'
        reception of values > 20 shall be mapped to 'ccbsNotReachable'
\verb|StatusReportArg| ::= SEQUENCE \{
                                           [0] IMSI.
     imsi
     eventReportData
                                           [1] EventReportData
                                                                              OPTIONAL,
     callReportdata
                                           [2]
                                               CallReportData
                                                                              OPTIONAL,
     extensionContainer
                                           [3] ExtensionContainer
                                                                              OPTIONAL,
EventReportData ::= SEQUENCE{
     ccbs-SubscriberStatus
                                           [0] CCBS-SubscriberStatus
                                                                              OPTIONAL.
                                           [1] ExtensionContainer
     extensionContainer
                                                                              OPTIONAL.
CallReportData ::= SEQUENCE{
     monitoringMode
                                               MonitoringMode
                                                                              OPTIONAL,
     callOutcome
                                           [1]
                                                CallOutcome
                                                                              OPTIONAL,
     extensionContainer
                                           [2] ExtensionContainer
                                                                              OPTIONAL.
MonitoringMode ::= ENUMERATED {
     a-side
                                           (0),
     b-side
                                           (1),
     . . . }
         exception handling:
     -- reception of values 2-10 shall be mapped 'a-side'
         reception of values > 10 shall be mapped to 'b-side'
```

```
CallOutcome ::= ENUMERATED {
                                               (0),
     success
     failure
                                               (1),
     busy
                                               (2),
     . . . }
         exception handling:
     -- reception of values 3-10 shall be mapped to 'success'
-- reception of values 11-20 shall be mapped to 'failure'
     -- reception of values > 20 shall be mapped to 'busy'
StatusReportRes ::= SEQUENCE {
     extensionContainer
                                               [0] ExtensionContainer
                                                                                      OPTIONAL,
RemoteUserFreeArg ::= SEQUENCE{
                                               [0] IMSI,
     imsi
     callInfo
                                               [1] ExternalSignalInfo,
     ccbs-Feature
                                               [2] CCBS-Feature,
     translatedB-Number
                                               [3]
                                                    ISDN-AddressString,
                                               [4] NULL
     replaceB-Number
                                                                                     OPTIONAL,
                                               [5] AlertingPattern
     alertingPattern
                                                                                      OPTIONAL,
                                               [6] ExtensionContainer
     {\tt extensionContainer}
                                                                                      OPTIONAL,
RemoteUserFreeRes ::= SEQUENCE{
     ruf-Out.come
                                               [0] RUF-Outcome,
     extensionContainer
                                               [1] ExtensionContainer
                                                                                     OPTIONAL.
RUF-Outcome ::= ENUMERATED{
     accepted (0),
     rejected (1),
     noResponseFromFreeMS (2), -- T4 Expiry noResponseFromBusyMS (3), -- T10 Expiry
     udubFromFreeMS (4),
     udubFromBusyMS (5),
     . . . }
     -- exception handling:
     -- reception of values 6-20 shall be mapped to 'accepted'
     -- reception of values 21-30 shall be mapped to 'rejected'
     -- reception of values 31-40 shall be mapped to 'noResponseFromFreeMS'
     -- reception of values 41-50 shall be mapped to 'noResponseFromBusyMS'
     -- reception of values 51-60 shall be mapped to 'udubFromFreeMS'
-- reception of values > 60 shall be mapped to 'udubFromBusyMS'
IST-AlertArg ::= SEQUENCE{
                                              [0] IMSI.
     imsi
     extensionContainer
                                               [1] ExtensionContainer
                                                                                      OPTIONAL,
     . . . }
IST-AlertRes ::= SEQUENCE{
                                               [0] IST-AlertTimerValue
     istAlertTimer
                                                                                      OPTIONAL,
                                              [1] NULL
     istInformationWithdraw
                                                                                      OPTIONAL,
                                               [2] CallTerminationIndicator
     callTerminationIndicator
                                                                                      OPTIONAL,
                                               [3] ExtensionContainer
     {\tt extensionContainer}
                                                                                      OPTIONAL,
IST-CommandArg ::= SEQUENCE{
                                               [0] IMSI,
     extensionContainer
                                               [1] ExtensionContainer
                                                                                     OPTIONAL,
IST-CommandRes ::= SEQUENCE{
     extensionContainer
                                                                                      OPTIONAL,
                                               ExtensionContainer
CallTerminationIndicator ::= ENUMERATED {
     terminateCallActivityReferred
                                               (0),
     terminateAllCallActivities
                                               (1),
     . . . }
     -- exception handling:
     -- reception of values 2-10 shall be mapped to 'terminateCallActivityReferred'
-- reception of values > 10 shall be mapped to 'terminateAllCallActivities'
     -- In MSCs not supporting linkage of all call activities, any value received shall
      -- be interpreted as ' terminateCallActivityReferred '
```

END

## 17.7.4 Supplementary service data types

```
MAP-SS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-DataTypes (14) version10 (10)}
DEFINITIONS
IMPLICIT TAGS
BEGIN
EXPORTS
  RegisterSS-Arg,
  SS-Info,
  SS-Status
  SS-SubscriptionOption,
  SS-ForBS-Code,
   InterrogateSS-Res,
  USSD-Arg,
  USSD-Res,
  USSD-DataCodingScheme,
  USSD-String,
  Password,
  GuidanceInfo.
  SS-List,
  SS-InfoList,
  OverrideCategory,
  CliRestrictionOption,
  NoReplyConditionTime,
  ForwardingOptions,
  maxNumOfSS,
  SS-Data,
  SS-InvocationNotificationArg,
  SS-InvocationNotificationRes
   CCBS-Feature,
  RegisterCC-EntryArg,
  RegisterCC-EntryRes,
  EraseCC-EntryArg,
  EraseCC-EntryRes
IMPORTS
  AddressString,
  ISDN-AddressString,
   ISDN-SubaddressString,
  FTN-AddressString,
  IMSI,
  BasicServiceCode,
  AlertingPattern,
  EMLPP-Priority,
  MaxMC-Bearers,
  MC-Bearers,
  ExternalSignalInfo
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-CommonDataTypes (18) version10 (10)}
  ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version10 (10)}
  SS-Code
```

```
FROM MAP-SS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-Code (15) version10 (10)};
```

```
RegisterSS-Arg ::= SEQUENCE {
                                         SS-Code,
    ss-Code
    basicService
                                         BasicServiceCode
                                                                           OPTIONAL,
    forwardedToNumber
                                         [4] AddressString
                                                                           OPTIONAL,
                                         [6] ISDN-SubaddressString
    forwardedToSubaddress
                                                                           OPTIONAL,
    noReplyConditionTime
                                        [5] NoReplyConditionTime
                                                                          OPTIONAL,
    defaultPriority
                                        [7] EMLPP-Priority
                                                                           OPTIONAL,
    nbrUser
                                         [8] MC-Bearers
                                                                           OPTIONAL,
                                         [9] NULL
    longFTN-Supported
                                                                           OPTIONAL
```

### NoReplyConditionTime ::= INTEGER (5..30)

# ForwardingFeatureList ::= SEQUENCE SIZE (1..maxNumOfBasicServiceGroups) OF ForwardingFeature

```
ForwardingFeature ::= SEQUENCE {
    basicService
                                        BasicServiceCode
                                                                          OPTIONAL,
    ss-Status
                                        [4] SS-Status
                                                                          OPTIONAL,
                                         [5] ISDN-AddressString
    forwardedToNumber
                                                                          OPTIONAL,
    forwardedToSubaddress
                                        [8] ISDN-SubaddressString
                                                                          OPTIONAL,
    forwardingOptions
                                         [6] ForwardingOptions
                                                                          OPTIONAL,
    noReplyConditionTime
                                        [7] NoReplyConditionTime
                                                                          OPTIONAL,
    longForwardedToNumber
                                      [9] FTN-AddressString
                                                                          OPTIONAL }
```

```
SS-Status ::= OCTET STRING (SIZE (1))

-- bits 8765: 0000 (unused)
-- bits 4321: Used to convey the "P bit", "R bit", "A bit" and "Q bit",
-- representing supplementary service state information
-- as defined in TS 3GPP TS 23.011 [22]

-- bit 4: "Q bit"
-- bit 3: "P bit"
-- bit 2: "R bit"
-- bit 1: "A bit"
```

```
ForwardingOptions ::= OCTET STRING (SIZE (1))
     -- bit 8: notification to forwarding party
     -- 0 no notification
-- 1 notification
     -- bit 7: redirecting presentation
     -- 0 no presentation
-- 1 presentation
     -- bit 6: notification to calling party
     -- 0 no notification
-- 1 notification
     -- bit 5: 0 (unused)
     -- bits 43: forwarding reason
     -- 00 ms not reachable
     -- 01 ms busy
        10 no reply
11 unconditional when used in a SRI Result,
             or call deflection when used in a RCH Argument
     -- bits 21: 00 (unused)
CallBarringInfo ::= SEQUENCE {
     ss-Code
                                           SS-Code
                                                                                OPTIONAL,
     callBarringFeatureList
                                           CallBarringFeatureList,
CallBarringFeatureList ::= SEQUENCE SIZE (1..maxNumOfBasicServiceGroups) OF
                                           CallBarringFeature
CallBarringFeature ::= SEQUENCE {
     basicService
                                           BasicServiceCode
                                                                                OPTIONAL,
     ss-Status [4] SS-Status
                                           OPTIONAL,
SS-Data ::= SEQUENCE {
    ss-Code
                                           SS-Code
                                                                                OPTIONAL.
     ss-Status
                                           [4] SS-Status
                                                                                OPTIONAL,
     ss-SubscriptionOption
                                           SS-SubscriptionOption
                                                                                OPTIONAL,
                                                                               OPTIONAL,
     basicServiceGroupList
                                           BasicServiceGroupList
     defaultPriority
                                                                                OPTIONAL,
                                           EMLPP-Priority
     nbrUser
                                            [5] MC-Bearers
                                                                                OPTIONAL
SS-SubscriptionOption ::= CHOICE {
     cliRestrictionOption
                                            [2] CliRestrictionOption,
     overrideCategory
                                            [1] OverrideCategory}
CliRestrictionOption ::= ENUMERATED {
     permanent (0),
     temporaryDefaultRestricted (1),
     temporaryDefaultAllowed (2)}
{\tt OverrideCategory} \; ::= \; {\tt ENUMERATED} \; \big\{
     overrideEnabled (0),
     overrideDisabled (1)
SS-ForBS-Code ::= SEQUENCE {
     ss-Code
                                           SS-Code,
     basicService
                                           BasicServiceCode
                                                                                OPTIONAL.
     longFTN-Supported
                                            [4] NULL
                                                                                OPTIONAL }
GenericServiceInfo ::= SEQUENCE {
    ss-Status SS-Status,
     cliRestrictionOption
                                           CliRestrictionOption
                                                                                OPTIONAL,
     maximumEntitledPriority
                                            [0] EMLPP-Priority
                                                                                OPTIONAL.
     defaultPriority
                                            [1] EMLPP-Priority
                                                                                OPTIONAL,
     ccbs-FeatureList
                                            [2] CCBS-FeatureList
                                                                                OPTIONAL,
     nbrSB
                                            [3] MaxMC-Bearers
                                                                                OPTIONAL,
                                            [4] MC-Bearers
                                                                                OPTIONAL,
     nbrUser
     nbrSN
                                            [5] MC-Bearers
                                                                                OPTIONAL
```

```
CCBS-FeatureList ::= SEQUENCE SIZE (1..maxNumOfCCBS-Requests) OF
                                        CCBS-Feature
maxNumOfCCBS-Requests INTEGER ::= 5
CCBS-Feature ::= SEQUENCE {
                                         [0] CCBS-Index
     ccbs-Index
                                                                          OPTIONAL.
     b-subscriberNumber
                                        [1] ISDN-AddressString
                                                                          OPTIONAL,
                                         [2] ISDN-SubaddressString
     b-subscriberSubaddress
                                                                          OPTIONAL,
     basicServiceGroup
                                        [3] BasicServiceCode
                                                                          OPTIONAL,
CCBS-Index ::= INTEGER (1..maxNumOfCCBS-Requests)
InterrogateSS-Res ::= CHOICE {
                                         [0] SS-Status,
     ss-Status
     basicServiceGroupList
                                         [2] BasicServiceGroupList,
     forwardingFeatureList
                                         [3] ForwardingFeatureList,
     genericServiceInfo
                                         [4] GenericServiceInfo
USSD-Arg ::= SEQUENCE {
    ussd-DataCodingScheme
                                        USSD-DataCodingScheme,
     ussd-String
                                        USSD-String,
     alertingPattern
                                        AlertingPattern
                                                                          OPTIONAL,
                                         [0] ISDN-AddressString
     msisdn
                                                                          OPTIONAL
USSD-Res ::= SEQUENCE {
     ussd-DataCodingScheme
                                        USSD-DataCodingScheme,
     ussd-String
                                        USSD-String,
USSD-DataCodingScheme ::= OCTET STRING (SIZE (1))
     -- The structure of the USSD-DataCodingScheme is defined by
     -- the Cell Broadcast Data Coding Scheme as described in
     -- TS 3GPP TS 23.038 [25]
USSD-String ::= OCTET STRING (SIZE (1..maxUSSD-StringLength))
     -- The structure of the contents of the USSD-String is dependent
     -- on the USSD-DataCodingScheme as described in TS 3GPP TS 23.038 [25]
maxUSSD-StringLength INTEGER ::= 160
GuidanceInfo ::= ENUMERATED {
    enterPW (0),
     enterNewPW (1),
     enterNewPW-Again (2) }
     -- How this information is really delivered to the subscriber
     -- (display, announcement, \ldots) is not part of this
     -- specification.
SS-List ::= SEQUENCE SIZE (1..maxNumOfSS) OF
                                        SS-Code
maxNumOfSS INTEGER ::= 30
SS-InfoList ::= SEQUENCE SIZE (1..maxNumOfSS) OF
                                        SS-Info
BasicServiceGroupList ::= SEQUENCE SIZE (1..maxNumOfBasicServiceGroups) OF
                                        BasicServiceCode
maxNumOfBasicServiceGroups INTEGER ::= 13
```

```
SS-InvocationNotificationArg ::= SEQUENCE {
                                          [0] IMSI,
     imsi
                                          [1] ISDN-AddressString,
     msisdn
     ss-Event
                                          [2] SS-Code,
     -- The following SS-Code values are allowed :
                                          SS-Code ::= '00110001'B
     -- ect
                                          SS-Code ::= '01010001'B
     -- multiPTY
                                          SS-Code ::= '00100100'B
     -- cd
                                          SS-Code ::= '01000100'B
     -- ccbs
     ss-EventSpecification
                                          [3] SS-EventSpecification
                                                                             OPTIONAL,
     extensionContainer
                                          [4] ExtensionContainer
                                                                            OPTIONAL,
     b-subscriberNumber
                                          [5] ISDN-AddressString
                                                                             OPTIONAL.
     ccbs-RequestState
                                          [6] CCBS-RequestState
                                                                             OPTIONAL
CCBS-RequestState ::= ENUMERATED {
    request (0),
     recall
               (1),
              (2),
     active
     completed (3),
     suspended (4),
     frozen
              (5),
     deleted (6)
SS-InvocationNotificationRes ::= SEQUENCE {
                                                                             OPTIONAL,
     extensionContainer
                                          ExtensionContainer
SS-EventSpecification ::= SEQUENCE SIZE (1..maxEventSpecification) OF
                                          AddressString
maxEventSpecification INTEGER ::= 2
RegisterCC-EntryArg ::= SEQUENCE {
     ss-Code
                                          [0] SS-Code,
     ccbs-Data
                                          [1] CCBS-Data
                                                                             OPTIONAL,
CCBS-Data ::= SEQUENCE {
     ccbs-Feature
                                          [0] CCBS-Feature,
                                          [1] ISDN-AddressString,
     translatedB-Number
     serviceIndicator
                                          [2] ServiceIndicator
                                                                             OPTIONAL,
     callInfo
                                          [3] ExternalSignalInfo,
     networkSignalInfo
                                          [4] ExternalSignalInfo,
ServiceIndicator ::= BIT STRING {
    clir-invoked (0),
     camel-invoked (1) } (SIZE(2..32))
     -- exception handling:
     -- bits 2 to 31 shall be ignored if received and not understood
RegisterCC-EntryRes ::= SEQUENCE {
    ccbs-Feature
                                          [0] CCBS-Feature
                                                                             OPTIONAL,
EraseCC-EntryArg ::= SEQUENCE {
                                          [0] SS-Code,
     ss-Code
     ccbs-Index
                                          [1] CCBS-Index
                                                                             OPTIONAL,
     . . . }
EraseCC-EntryRes ::= SEQUENCE {
                                          [0] SS-Code,
    ss-Code
                                          [1] SS-Status
     ss-Status
                                                                             OPTIONAL,
```

#### 17.7.5 Supplementary service codes

```
MAP-SS-Code
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-Code (15) version10 (10)}
```

```
DEFINITIONS
```

: :=

BEGIN

```
SS-Code ::= OCTET STRING (SIZE (1))

-- This type is used to represent the code identifying a single
-- supplementary service, a group of supplementary services, or
-- all supplementary services. The services and abbreviations
-- used are defined in TS 3GPP TS 22.004 [5]. The internal structure is
-- defined as follows:
--
-- bits 87654321: group (bits 8765), and specific service
-- (bits 4321)
```

```
allss SS-Code ::= '00000000'B
-- reserved for possible future use
-- all SS
```

```
allLineIdentificationSS
                                         SS-Code ::= '00010000'B
     -- reserved for possible future use
     -- all line identification SS
clip
                                         SS-Code ::= '00010001'B
     -- calling line identification presentation
clir
                                         SS-Code ::= '00010010'B
     -- calling line identification restriction
                                         SS-Code ::= '00010011'B
colp
     -- connected line identification presentation
                                         SS-Code ::= '00010100'B
colr
     -- connected line identification restriction
mci
                                         SS-Code ::= '00010101'B
     -- reserved for possible future use
     -- malicious call identification
allNameIdentificationSS
                                        SS-Code ::= '00011000'B
     -- all name identification SS
                                       SS-Code ::= '00011001'B
     -- calling name presentation
     -- SS-Codes '00011010'B to '00011111'B are reserved for future
     -- NameIdentification Supplementary Service use.
```

```
allForwardingSS
                                         SS-Code ::= '00100000'B
    -- all forwarding SS
                                         SS-Code ::= '00100001'B
     -- call forwarding unconditional
allCondForwardingSS
                                         SS-Code ::= '00101000'B
     -- all conditional forwarding SS
                                         SS-Code ::= '00101001'B
    -- call forwarding on mobile subscriber busy
cfnry
                                         SS-Code ::= '00101010'B
     -- call forwarding on no reply
                                         SS-Code ::= '00101011'B
    -- call forwarding on mobile subscriber not reachable
                                         SS-Code ::= '00100100'B
cd
   -- call deflection
```

```
allCallOfferingSS SS-Code ::= '00110000'B
-- reserved for possible future use
-- all call offering SS includes also all forwarding SS
ect SS-Code ::= '00110001'B
-- explicit call transfer
mah SS-Code ::= '00110010'B
-- reserved for possible future use
-- mobile access hunting
```

```
allCallCompletionSS
                                          SS-Code ::= '01000000'B
     -- reserved for possible future use
     -- all Call completion SS
                                          SS-Code ::= '01000001'B
     -- call waiting
                                          SS-Code ::= '01000010'B
hold
     -- call hold
ccbs-A
                                          SS-Code ::= '01000011'B
     -- completion of call to busy subscribers, originating side
     -- this SS-Code is used only in InsertSubscriberData, DeleteSubscriberData
     -- and InterrogateSS
                                          SS-Code ::= '01000100'B
ccbs-B
     -- completion of call to busy subscribers, destination side
     -- this SS-Code is used only in InsertSubscriberData and DeleteSubscriberData
                                         SS-Code ::= '01000101'B
mc
     -- multicall
allMultiPartySS
                                          SS-Code ::= '01010000'B
     -- reserved for possible future use
    -- all multiparty SS
multiPTY
                                          SS-Code ::= '01010001'B
     -<u>-</u> multiparty
allCommunityOfInterest-SS
                                          SS-Code ::= '01100000'B
    -- reserved for possible future use
     -- all community of interest SS
                                          SS-Code ::= '01100001'B
     -- closed user group
allChargingSS
                                          SS-Code ::= '01110000'B
     -- reserved for possible future use
     -- all charging SS
                                          SS-Code ::= '01110001'B
aoci
     -- advice of charge information
                                          SS-Code ::= '01110010'B
     -- advice of charge charging
allAdditionalInfoTransferSS
                                          SS-Code ::= '10000000'B
    -- reserved for possible future use
     -- all additional information transfer SS
                                          SS-Code ::= '10000001'B
     -- UUS1 user-to-user signalling
                                          SS-Code ::= '10000010'B
     -- UUS2 user-to-user signalling
uus3
                                          SS-Code ::= '10000011'B
     -- UUS3 user-to-user signalling
allBarringSS
                                          SS-Code ::= '10010000'B
     -- all barring SS
barringOfOutgoingCalls
                                          SS-Code ::= '10010001'B
    -- barring of outgoing calls
                                          SS-Code ::= '10010010'B
     -- barring of all outgoing calls
                                          SS-Code ::= '10010011'B
boic
     -- barring of outgoing international calls
                                          SS-Code ::= '10010100'B
boicExHC
     -- barring of outgoing international calls except those directed
     -- to the home PLMN Country
barringOfIncomingCalls
                                         SS-Code ::= '10011001'B
      -- barring of incoming calls
                                         SS-Code ::= '10011010'B
     -- barring of all incoming calls
                                         SS-Code ::= '10011011'B
    -- barring of incoming calls when roaming outside home PLMN
     -- Country
```

```
SS-Code ::= '11110000'B
allPLMN-specificSS
plmn-specificSS-1
                                          SS-Code ::= '11110001'B
plmn-specificSS-2
                                          SS-Code ::= '11110010'B
plmn-specificSS-3
                                          SS-Code ::= '11110011'B
plmn-specificSS-4
                                          SS-Code ::= '11110100'B
plmn-specificSS-5
                                          SS-Code ::= '11110101'B
plmn-specificSS-6
                                          SS-Code ::= '11110110'B
                                          SS-Code ::= '11110111'B
plmn-specificSS-7
                                          SS-Code ::= '11111000'B
plmn-specificSS-8
plmn-specificSS-9
                                          SS-Code ::= '11111001'B
plmn-specificSS-A
                                          SS-Code ::= '11111010'B
                                          SS-Code ::= '11111011'B
plmn-specificSS-B
plmn-specificSS-C
                                          SS-Code ::= '11111100'B
plmn-specificSS-D
                                          SS-Code ::= '111111101'B
plmn-specificSS-E
                                          SS-Code ::= '111111110'B
                                          SS-Code ::= '111111111'B
plmn-specificSS-F
```

```
allLCSPrivacyException
                                          SS-Code ::= '10110000'B
    -- all LCS Privacy Exception Classes
                                          SS-Code ::= '10110001'B
universal
     -- allow location by any LCS client
                                          SS-Code ::= '10110010'B
callSessionRelated
     -- allow location by any value added LCS client to which a call/session
     -- is established from the target MS
                                          SS-Code ::= '10110011'B
callSessionUnrelated
      - allow location by designated external value added LCS clients
                                          SS-Code ::= '10110100'B
plmnoperator
      - allow location by designated PLMN operator LCS clients
                                          SS-Code ::= '10110101'B
serviceType
    -- allow location by LCS clients of a designated LCS service type
```

```
allMOLR-SS
SS-Code ::= '11000000'B
-- all Mobile Originating Location Request Classes
basicSelfLocation
SS-Code ::= '11000001'B
-- allow an MS to request its own location
autonomousSelfLocation
SS-Code ::= '11000010'B
-- allow an MS to perform self location without interaction
-- with the PLMN for a predetermined period of time
transferToThirdParty
SS-Code ::= '11000011'B
-- allow an MS to request transfer of its location to another LCS client
```

END

## 17.7.6 Short message data types

```
MAP-SM-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SM-DataTypes (16) version10 (10)}
DEFINITIONS
IMPLICIT TAGS
BEGIN
EXPORTS
  RoutingInfoForSM-Arg,
   RoutingInfoForSM-Res,
  MO-ForwardSM-Arg,
  MO-ForwardSM-Res.
  MT-ForwardSM-Arg,
  MT-ForwardSM-Res,
   ReportSM-DeliveryStatusArg,
   ReportSM-DeliveryStatusRes,
  AlertServiceCentreArg,
   InformServiceCentreArg,
   ReadyForSM-Arg,
   ReadyForSM-Res,
   SM-DeliveryOutcome,
  AlertReason,
```

```
Additional-Number,
   MT-ForwardSM-VGCS-Arg,
   MT-ForwardSM-VGCS-Res
IMPORTS
   AddressString,
   ISDN-AddressString,
   SignalInfo,
   IMSI,
   LMSI,
   ASCI-CallReference
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CommonDataTypes (18) version10 (10)}
   AbsentSubscriberDiagnosticSM
FROM MAP-ER-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ER-DataTypes (17) version10 (10)}
   ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version10 (10)}
RoutingInfoForSM-Arg ::= SEQUENCE {
                                          [0] ISDN-AddressString,
    msisdn
     sm-RP-PRI
                                          [1] BOOLEAN,
     serviceCentreAddress
                                          [2] AddressString,
    extensionContainer
                                          [6] ExtensionContainer
                                                                             OPTIONAL,
     gprsSupportIndicator
                                          [7] NULL
                                                                             OPTIONAL.
     -- gprsSupportIndicator is set only if the SMS-GMSC supports
     -- receiving of two numbers from the HLR
     sm-RP-MTI
                                          [8] SM-RP-MTI
                                                                             OPTIONAL,
     sm-RP-SMEA
                                          [9] SM-RP-SMEA
                                                                             OPTIONAL
SM-RP-MTI ::= INTEGER (0..10)
     -- 0 SMS Deliver
     -- 1 SMS Status Report
     -- other values are reserved for future use and shall be discarded if
     -- received
SM-RP-SMEA ::= OCTET STRING (SIZE (1..12))
     -- this parameter contains an address field which is encoded
     -- as defined in 3GPP TS 23.040. An address field contains 3 elements :
              address-length
              type-of-address
              address-value
RoutingInfoForSM-Res ::= SEQUENCE {
     imsi
                                          IMSI,
     locationInfoWithLMSI
                                          [0] LocationInfoWithLMSI,
     extensionContainer
                                          [4] ExtensionContainer
                                                                             OPTIONAL,
     ...}
LocationInfoWithLMSI ::= SEQUENCE {
    networkNode-Number
                                          [1] ISDN-AddressString,
     lmsi
                                          LMSI
                                                                             OPTIONAL,
     extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
     gprsNodeIndicator
                                          [5] NULL
                                                                             OPTIONAL,
     -- gprsNodeIndicator is set only if the SGSN number is sent as the
     -- Network Node Number
     additional-Number
                                          [6] Additional-Number
                                                                             OPTIONAL
     -- NetworkNode-number can be either msc-number or sgsn-number or IP-SM-GW
     -- number or SMS Router number
```

noSM-RP-OA

```
Additional-Number ::= CHOICE {
                                            [0] ISDN-AddressString,
[1] ISDN-AddressString}
     msc-Number
     sgsn-Number
     -- additional-number can be either msc-number or sgsn-number
     -- if received networkNode-number is msc-number then the
     -- additional number is sqsn-number
     -- if received networkNode-number is sgsn-number then the
     -- additional number is msc-number
MO-ForwardSM-Arg ::= SEQUENCE {
     sm-RP-DA
                                            SM-RP-DA,
     sm-RP-OA
                                            SM-RP-OA,
     sm-RP-UI
                                            SignalInfo,
     extensionContainer
                                                                                OPTIONAL,
                                            ExtensionContainer
                                                                                OPTIONAL }
MO-ForwardSM-Res ::= SEQUENCE {
     sm-RP-UI
                                                                                OPTIONAL,
                                            SignalInfo
     extensionContainer
                                            ExtensionContainer
                                                                                OPTIONAL,
MT-ForwardSM-Arg ::= SEQUENCE {
     sm-RP-DA
                                            SM-RP-DA,
     sm-RP-OA
                                            SM-RP-OA,
     sm-RP-UI
                                            SignalInfo,
     moreMessagesToSend
                                            NULL
                                                                                OPTIONAL,
                                            ExtensionContainer
     extensionContainer
                                                                                OPTIONAL,
MT-ForwardSM-Res ::= SEQUENCE {
     sm-RP-UI
                                            SignalInfo
                                                                                OPTIONAL,
     extensionContainer
                                            ExtensionContainer
                                                                                OPTIONAL,
SM-RP-DA ::= CHOICE {
     imsi
                                            [0] IMSI,
     lmsi
                                            [1] LMSI,
     serviceCentreAddressDA
                                            [4] AddressString,
     noSM-RP-DA
                                            [5] NULL}
SM-RP-OA ::= CHOICE {
     msisdn
                                            [2] ISDN-AddressString,
                                            [4] AddressString,
     serviceCentreAddressOA
```

[5] NULL}

```
ReportSM-DeliveryStatusArg ::= SEQUENCE {
     msisdn
                                             ISDN-AddressString,
     serviceCentreAddress
                                            AddressString,
     sm-DeliveryOutcome
                                            SM-DeliveryOutcome,
     absentSubscriberDiagnosticSM
                                            [0] AbsentSubscriberDiagnosticSM
                                                                                 OPTIONAL,
     extensionContainer
                                            [1] ExtensionContainer
                                                                                 OPTIONAL.
     gprsSupportIndicator
                                            [2] NULL
                                                                                 OPTIONAL,
     -- gprsSupportIndicator is set only if the SMS-GMSC supports
     -- handling of two delivery outcomes
     delivervOutcomeIndicator
                                            [3] NIII.I.
                                                                                 OPTIONAL.
     -- DeliveryOutcomeIndicator is set when the SM-DeliveryOutcome
     -- is for GPRS
     additionalSM-DeliveryOutcome
                                            [4] SM-DeliveryOutcome
                                                                                 OPTIONAL,
     -- If received, additional SM-DeliveryOutcome is for GPRS
     -- If DeliveryOutcomeIndicator is set, then AdditionalSM-DeliveryOutcome shall be absent additionalAbsentSubscriberDiagnosticSM [5] AbsentSubscriberDiagnosticSM OPTIONAL,
     -- If received additionalAbsentSubscriberDiagnosticSM is for GPRS
     -- If DeliveryOutcomeIndicator is set, then AdditionalAbsentSubscriberDiagnosticSM
     -- shall be absent
     ip-sm-gw-Indicator
                                             [6] NULL
      -- the ip-sm-gw indicator indicates by its presence that sm-DeliveryOutcome
     -- is for delivery via IMS.
     -- If present, deliveryOutcomeIndicator shall be absent.
ip-sm-gw-sm-deliveryOutcome [7] SM-DeliveryOutcome
                                                                                 OPTIONAL.
     -- If received ip-sm-gw-sm-deliveryOutcome is for delivery via IMS
     -- If ip-sm-gw-Indicator is set, then ip-sm-gw-sm-deliveryOutcome shall be absent
     ip-sm-gw-absentSubscriberDiagnosticSM [8] AbsentSubscriberDiagnosticSM OPTIONAL
     -- If received ip-sm-gw-sm-absentSubscriberDiagnosticSM is for delivery via IMS
     -- If ip-sm-gw-Indicator is set, then ip-sm-gw-sm-absentSubscriberDiagnosticSM
     -- shall be absent
SM-DeliveryOutcome ::= ENUMERATED {
     memoryCapacityExceeded (0),
     absentSubscriber (1),
     successfulTransfer (2) }
ReportSM-DeliveryStatusRes ::= SEQUENCE {
     storedMSISDN
                                             ISDN-AddressString
                                                                                 OPTIONAL,
     extensionContainer
                                             ExtensionContainer
                                                                                 OPTIONAL,
AlertServiceCentreArg ::= SEQUENCE {
     msisdn
                                            ISDN-AddressString,
     serviceCentreAddress
                                            AddressString,
InformServiceCentreArg ::= SEQUENCE {
     storedMSISDN
                                            ISDN-AddressString
                                                                                 OPTIONAL,
```

```
MW-Status ::= BIT STRING {
    sc-AddressNotIncluded (0),
    mnrf-Set (1),
    mcef-Set (2),
    mnrg-Set (3)} (SIZE (6..16))
    -- exception handling:
    -- bits 4 to 15 shall be ignored if received and not understood
```

OPTIONAL,

OPTIONAL,

```
ReadyForSM-Arg ::= SEQUENCE {
     imsi
                                          [0] TMST.
    alertReason
                                          AlertReason,
    alertReasonIndicator
                                          NULL
                                                                             OPTIONAL,
     -- alertReasonIndicator is set only when the alertReason
     -- sent to HLR is for GPRS
    extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL.
     additionalAlertReasonIndicator
                                         [1] NULL
                                                                             OPTIONAL
     -- additionalAlertReasonIndicator is set only when the alertReason
     -- sent to HLR is for IP-SM-GW
ReadyForSM-Res ::= SEQUENCE {
    extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
AlertReason ::= ENUMERATED {
    ms-Present (0),
    memoryAvailable
MT-ForwardSM-VGCS-Arg ::= SEQUENCE {
    asciCallReference
                                          ASCI-CallReference,
     sm-RP-OA
                                          SM-RP-OA,
     sm-RP-UI
                                          SignalInfo,
     extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
MT-ForwardSM-VGCS-Res ::= SEQUENCE {
    sm-RP-UI
                                          [0] SignalInfo
                                                                             OPTIONAL,
    dispatcherList
                                          [1] DispatcherList
                                                                             OPTIONAL,
```

```
DispatcherList ::=

SEQUENCE SIZE (1..maxNumOfDispatchers) OF

ISDN-AddressString
```

[2] ExtensionContainer

NULL

```
maxNumOfDispatchers INTEGER ::= 5
```

END

## 17.7.7 Error data types

ongoingCall

extensionContainer

```
MAP-ER-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ER-DataTypes (17) version10 (10)}
DEFINITIONS
IMPLICIT TAGS
: :=
BEGIN
EXPORTS
  RoamingNotAllowedParam,
   CallBarredParam,
  CUG-RejectParam,
  SS-IncompatibilityCause,
  PW-RegistrationFailureCause,
   SM-DeliveryFailureCause,
   SystemFailureParam,
   DataMissingParam,
   UnexpectedDataParam,
   FacilityNotSupParam,
   OR-NotAllowedParam,
   UnknownSubscriberParam,
  NumberChangedParam,
   UnidentifiedSubParam,
   IllegalSubscriberParam,
   IllegalEquipmentParam,
   BearerServNotProvParam,
```

plmnRoamingNotAllowed (0),
operatorDeterminedBarring

```
TeleservNotProvParam,
   TracingBufferFullParam,
  NoRoamingNbParam,
   AbsentSubscriberParam,
   BusySubscriberParam,
   NoSubscriberReplyParam,
   ForwardingViolationParam,
   ForwardingFailedParam,
   ATI-NotAllowedParam,
   SubBusyForMT-SMS-Param,
   MessageWaitListFullParam,
   AbsentSubscriberSM-Param,
   AbsentSubscriberDiagnosticSM,
   ResourceLimitationParam,
   NoGroupCallNbParam,
   IncompatibleTerminalParam,
   ShortTermDenialParam,
   LongTermDenialParam,
   UnauthorizedRequestingNetwork-Param,
   UnauthorizedLCSClient-Param,
   PositionMethodFailure-Param,
   UnknownOrUnreachableLCSClient-Param,
  MM-EventNotSupported-Param,
   ATSI-NotAllowedParam,
   ATM-NotAllowedParam,
   IllegalSS-OperationParam,
   SS-NotAvailableParam,
   SS-SubscriptionViolationParam,
   InformationNotAvailableParam,
   TargetCellOutsideGCA-Param,
  OngoingGroupCallParam
IMPORTS
  SS-Status
FROM MAP-SS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-DataTypes (14) version10 (10)}
  SignalInfo.
  BasicServiceCode,
  NetworkResource,
  AdditionalNetworkResource
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CommonDataTypes (18) version10 (10)}
  SS-Code
FROM MAP-SS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-Code (15) version10 (10)}
  ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version10 (10)}
RoamingNotAllowedParam ::= SEQUENCE {
    {\tt roamingNotAllowedCause}
                                          RoamingNotAllowedCause,
    extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
    additionalRoamingNotAllowedCause
                                          [0] AdditionalRoamingNotAllowedCause OPTIONAL }
    if the additionalRoamingNotallowedCause is received by the MSC/VLR or SGSN then the
    roamingNotAllowedCause shall be discarded.
AdditionalRoamingNotAllowedCause ::= ENUMERATED {
    supportedRAT-TypesNotAllowed (0),
RoamingNotAllowedCause ::= ENUMERATED {
```

```
CallBarredParam ::= CHOICE {
    callBarringCause
                                          CallBarringCause.
     -- call BarringCause must not be used in version 3 and higher
     extensibleCallBarredParam
                                        ExtensibleCallBarredParam
      - extensibleCallBarredParam must not be used in version <3
CallBarringCause ::= ENUMERATED {
    barringServiceActive (0),
    operatorBarring (1)}
ExtensibleCallBarredParam ::= SEQUENCE {
    callBarringCause
                                          CallBarringCause
                                                                             OPTIONAL,
    extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
    unauthorisedMessageOriginator
                                          [1] NULL
                                                                             OPTIONAL }
CUG-RejectParam ::= SEQUENCE {
    cug-RejectCause
                                          CUG-RejectCause
                                                                             OPTIONAL,
     extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
CUG-RejectCause ::= ENUMERATED {
    incomingCallsBarredWithinCUG (0),
     subscriberNotMemberOfCUG (1),
    requestedBasicServiceViolatesCUG-Constraints (5),
    calledPartySS-InteractionViolation (7) }
SS-IncompatibilityCause ::= SEQUENCE {
    ss-Code
                                          [1] SS-Code
                                                                             OPTIONAL,
    basicService
                                          BasicServiceCode
                                                                             OPTIONAL,
    ss-Status
                                          [4] SS-Status
                                                                             OPTIONAL.
PW-RegistrationFailureCause ::= ENUMERATED {
    undetermined (0), invalidFormat (1),
    newPasswordsMismatch (2) }
SM-EnumeratedDeliveryFailureCause ::= ENUMERATED {
    memoryCapacityExceeded (0),
    equipmentProtocolError (1),
    equipmentNotSM-Equipped (2),
    unknownServiceCentre (3),
    sc-Congestion (4),
    invalidSME-Address (5),
    subscriberNotSC-Subscriber (6) }
SM-DeliveryFailureCause ::= SEQUENCE {
     sm-EnumeratedDeliveryFailureCause
                                          SM-EnumeratedDeliveryFailureCause,
     diagnosticInfo
                                          SignalInfo
                                                                             OPTIONAL,
    extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
AbsentSubscriberSM-Param ::= SEQUENCE {
    absentSubscriberDiagnosticSM
                                          AbsentSubscriberDiagnosticSM
                                                                             OPTIONAL.
     -- AbsentSubscriberDiagnosticSM can be either for non-GPRS
     -- or for GPRS
    extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
     additionalAbsentSubscriberDiagnosticSM
                                              [0] AbsentSubscriberDiagnosticSM OPTIONAL }
     \hbox{\it -- if received, additional} Absent Subscriber {\tt DiagnosticSM}
     -- is for GPRS and absentSubscriberDiagnosticSM is
     -- for non-GPRS
AbsentSubscriberDiagnosticSM ::= INTEGER (0..255)
     -- AbsentSubscriberDiagnosticSM values are defined in 3GPP TS 23.040
SystemFailureParam ::= CHOICE {
    networkResource
                                          NetworkResource,
     -- networkResource must not be used in version 3
     extensibleSystemFailureParam
                                         ExtensibleSystemFailureParam
     -- extensibleSystemFailureParam must not be used in version <3
```

```
ExtensibleSystemFailureParam ::= SEQUENCE {
     networkResource
                                            NetworkResource
                                                                                OPTIONAL.
     extensionContainer
                                            ExtensionContainer
                                                                                OPTIONAL,
     additionalNetworkResource
                                            [0] AdditionalNetworkResource
                                                                                OPTIONAL,
     failureCauseParam
                                            [1] FailureCauseParam
                                                                                OPTIONAL
FailureCauseParam ::= ENUMERATED {
     limitReachedOnNumberOfConcurrentLocationRequests (0),
     -- if unknown value is received in FailureCauseParam it shall be ignored
DataMissingParam ::= SEQUENCE {
     extensionContainer
                                            ExtensionContainer
                                                                                OPTIONAL.
UnexpectedDataParam ::= SEQUENCE {
     {\tt extensionContainer}
                                            ExtensionContainer
                                                                                OPTIONAL,
FacilityNotSupParam ::= SEQUENCE {
     extensionContainer
                                            ExtensionContainer
                                                                                OPTIONAL,
     \verb|shapeOfLocationEstimateNotSupported [0] & \verb|NULL|| \\
                                                                                OPTIONAL,
     neededLcsCapabilityNotSupportedInServingNode [1] NULL
                                                                                OPTIONAL
OR-NotAllowedParam ::= SEQUENCE {
     extensionContainer
                                            ExtensionContainer
                                                                                OPTIONAL,
UnknownSubscriberParam ::= SEQUENCE {
     extensionContainer
                                            ExtensionContainer
                                                                                OPTIONAL,
     unknownSubscriberDiagnostic
                                            UnknownSubscriberDiagnostic
                                                                                OPTIONAL }
UnknownSubscriberDiagnostic ::= ENUMERATED {
     imsiUnknown (0),
     gprsSubscriptionUnknown (1),
     npdbMismatch (2) }
     -- if unknown values are received in
     -- UnknownSubscriberDiagnostic they shall be discarded
NumberChangedParam ::= SEQUENCE {
     {\tt extensionContainer}
                                            ExtensionContainer
                                                                                OPTIONAL,
UnidentifiedSubParam ::= SEQUENCE {
     extensionContainer
                                            ExtensionContainer
                                                                                OPTIONAL,
{\tt IllegalSubscriberParam} \ ::= \ {\tt SEQUENCE} \ \big\{
     {\tt extensionContainer}
                                            ExtensionContainer
                                                                                OPTIONAL,
IllegalEquipmentParam ::= SEQUENCE {
     extensionContainer
                                            ExtensionContainer
                                                                                OPTIONAL,
BearerServNotProvParam ::= SEQUENCE {
                                            ExtensionContainer
     extensionContainer
                                                                                OPTIONAL.
TeleservNotProvParam ::= SEQUENCE {
     {\tt extensionContainer}
                                            ExtensionContainer
                                                                                OPTIONAL,
TracingBufferFullParam ::= SEQUENCE {
                                            ExtensionContainer
     extensionContainer
                                                                                OPTIONAL,
NoRoamingNbParam ::= SEQUENCE {
     extensionContainer
                                            ExtensionContainer
                                                                                OPTIONAL,
```

```
AbsentSubscriberParam ::= SEQUENCE {
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL.
     absentSubscriberReason
                                           [0] AbsentSubscriberReason
                                                                              OPTIONAL }
AbsentSubscriberReason ::= ENUMERATED {
    imsiDetach (0),
     restrictedArea (1),
    noPageResponse (2),
    purgedMS (3) }
-- exception handling: at reception of other values than the ones listed the
-- AbsentSubscriberReason shall be ignored.
-- The AbsentSubscriberReason: purgedMS is defined for the Super-Charger feature
-- (see TS 23.116). If this value is received in a Provide Roaming Number response
-- it shall be mapped to the AbsentSubscriberReason: imsiDetach in the Send Routeing
-- Information response
BusySubscriberParam ::= SEQUENCE {
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL.
     ccbs-Possible
                                           [0] NULL
                                                                              OPTIONAL
     ccbs-Busy
                                           [1] NULL
                                                                              OPTIONAL }
NoSubscriberReplyParam ::= SEQUENCE {
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL,
ForwardingViolationParam ::= SEQUENCE {
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL.
ForwardingFailedParam ::= SEQUENCE {
     {\tt extensionContainer}
                                           ExtensionContainer
                                                                               OPTIONAL,
ATI-NotAllowedParam ::= SEQUENCE {
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL,
ATSI-NotAllowedParam ::= SEQUENCE {
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL,
ATM-NotAllowedParam ::= SEQUENCE {
     {\tt extensionContainer}
                                           ExtensionContainer
                                                                               OPTIONAL,
IllegalSS-OperationParam ::= SEQUENCE {
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL,
SS-NotAvailableParam ::= SEQUENCE {
     {\tt extensionContainer}
                                           ExtensionContainer
                                                                              OPTIONAL,
SS-SubscriptionViolationParam ::= SEQUENCE {
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL,
InformationNotAvailableParam ::= SEQUENCE {
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL.
SubBusyForMT-SMS-Param ::= SEQUENCE {
     {\tt extensionContainer}
                                           ExtensionContainer
                                                                              OPTIONAL,
     gprsConnectionSuspended
                                                                              OPTIONAL }
     -- If GprsConnectionSuspended is not understood it shall
     -- be <u>discarded</u>
MessageWaitListFullParam ::= SEQUENCE {
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL,
```

```
ResourceLimitationParam ::= SEQUENCE {
     extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL.
NoGroupCallNbParam ::= SEQUENCE {
    extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
IncompatibleTerminalParam ::= SEQUENCE {
    extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
ShortTermDenialParam ::= SEQUENCE {
LongTermDenialParam ::= SEQUENCE {
UnauthorizedRequestingNetwork-Param ::= SEQUENCE {
    extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
UnauthorizedLCSClient-Param ::= SEQUENCE
    unauthorizedLCSClient-Diagnostic
                                          [0] UnauthorizedLCSClient-Diagnostic
                                                                                 OPTIONAL.
                                          [1] ExtensionContainer
     extensionContainer
                                                                                 OPTIONAL,
UnauthorizedLCSClient-Diagnostic ::= ENUMERATED {
    noAdditionalInformation (0),
     clientNotInMSPrivacyExceptionList (1),
    callToClientNotSetup (2),
     privacyOverrideNotApplicable (3),
     disallowedByLocalRegulatoryRequirements (4),
     unauthorizedPrivacyClass (5),
     unauthorizedCallSessionUnrelatedExternalClient (6),
     unauthorizedCallSessionRelatedExternalClient (7) }
     exception handling:
    any unrecognized value shall be ignored
PositionMethodFailure-Param ::= SEQUENCE
    positionMethodFailure-Diagnostic
                                          [0] PositionMethodFailure-Diagnostic
                                                                                 OPTIONAL.
     extensionContainer
                                          [1] ExtensionContainer
                                                                                 OPTIONAL,
PositionMethodFailure-Diagnostic ::= ENUMERATED {
     congestion (0),
     insufficientResources (1),
     insufficientMeasurementData (2),
     inconsistentMeasurementData (3),
     locationProcedureNotCompleted (4),
     locationProcedureNotSupportedByTargetMS (5),
     qoSNotAttainable (6),
    positionMethodNotAvailableInNetwork (7),
    positionMethodNotAvailableInLocationArea (8),
     ...}
     exception handling:
     any unrecognized value shall be ignored
UnknownOrUnreachableLCSClient-Param ::= SEQUENCE {
    extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
MM-EventNotSupported-Param ::= SEQUENCE {
     extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
TargetCellOutsideGCA-Param ::= SEQUENCE {
     extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL.
OngoingGroupCallParam ::= SEQUENCE \{
     extensionContainer
                                          ExtensionContainer
                                                                             OPTIONAL,
```

END

## 17.7.8 Common data types

```
MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CommonDataTypes (18) version10 (10)}
IMPLICIT TAGS
BEGIN
EXPORTS
   -- general data types and values
  AddressString,
  ISDN-AddressString,
  maxISDN-AddressLength,
  FTN-AddressString,
  ISDN-SubaddressString,
  ExternalSignalInfo,
  Ext-ExternalSignalInfo,
  AccessNetworkSignalInfo,
  SignalInfo,
  maxSignalInfoLength,
  AlertingPattern,
  TBCD-STRING,
   -- data types for numbering and identification
  IMSI,
  TMSI,
   Identity,
   SubscriberId,
  IMEI,
  HLR-List,
  LMSI,
  GlobalCellId,
  NetworkResource,
  AdditionalNetworkResource,
  NAEA-PreferredCI,
  NAEA-CIC,
  ASCI-CallReference,
  SubscriberIdentity,
  PLMN-Id,
   -- data types for CAMEL
  CellGlobalIdOrServiceAreaIdOrLAI,
   CellGlobalIdOrServiceAreaIdFixedLength,
  LAIFixedLength,
   -- data types for subscriber management
  BasicServiceCode,
  Ext-BasicServiceCode,
  EMLPP-Info,
  EMLPP-Priority
  MC-SS-Info,
  MaxMC-Bearers
  MC-Bearers,
  Ext-SS-Status,
   -- data types for geographic location
  AgeOfLocationInformation,
  LCSClientExternalID,
  LCSClientInternalID.
  LCSServiceTypeID
IMPORTS
  TeleserviceCode,
  Ext-TeleserviceCode
FROM MAP-TS-Code {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-TS-Code (19) version10 (10)}
```

-- bits 8765 of octet n encoding digit 2n -- bits 4321 of octet n encoding digit 2(n-1) +1

maxAddressLength INTEGER ::= 20

```
BearerServiceCode,
   Ext-BearerServiceCode
FROM MAP-BS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-BS-Code (20) version10 (10)}
   SS-Code
FROM MAP-SS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-Code (15) version10 (10)}
   ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version10 (10)}
-- general data types
TBCD-STRING ::= OCTET STRING
     -- This type (Telephony Binary Coded Decimal String) is used to
     -- represent several digits from 0 through 9, *, #, a, b, c, two
     -- digits per octet, each digit encoded 0000 to 1001 (0 to 9),
     -- 1010 (*), 1011 (#), 1100 (a), 1101 (b) or 1110 (c); 1111 used
     -- as filler when there is an odd number of digits.
```

```
AddressString ::= OCTET STRING (SIZE (1..maxAddressLength))
    -- This type is used to represent a number for addressing
     -- purposes. It is composed of
        a) one octet for nature of address, and numbering plan
              indicator.
        b) digits of an address encoded as TBCD-String.
     -- a)
              The first octet includes a one bit extension indicator, a
              3 bits nature of address indicator and a 4 bits numbering
              plan indicator, encoded as follows:
     -- bit 8: 1 (no extension)
     -- bits 765: nature of address indicator
       000 unknown
         001 international number
         010 national significant number
         011 network specific number
         100 subscriber number
        101 reserved
        110 abbreviated number
111 reserved for extension
     -- bits 4321: numbering plan indicator
       0000 unknown
         0001 ISDN/Telephony Numbering Plan (Rec ITU-T E.164)
         0010 spare
         0011 data numbering plan (ITU-T Rec X.121)
         0100 telex numbering plan (ITU-T Rec F.69)
         0101 spare
         0110 land mobile numbering plan (ITU-T Rec E.212)
0111 spare
         1000 national numbering plan
        1001 private numbering plan
1111 reserved for extension
        all other values are reserved.
               The following octets representing digits of an address
              encoded as a TBCD-STRING.
```

```
maxISDN-AddressLength INTEGER ::= 9
```

```
FTN-AddressString ::=

AddressString (SIZE (1..maxFTN-AddressLength))

-- This type is used to represent forwarded-to numbers.

-- If NAI = international the first digits represent the country code (CC)

-- and the network destination code (NDC) as for E.164.
```

#### maxFTN-AddressLength INTEGER ::= 15

```
ISDN-SubaddressString ::=
               OCTET STRING (SIZE (1..maxISDN-SubaddressLength))
     -- This type is used to represent ISDN subaddresses.
     -- It is composed of

    a) one octet for type of subaddress and odd/even indicator.
    b) 20 octets for subaddress information.

         a) The first octet includes a one bit extension indicator, a
               3 bits type of subaddress and a one bit odd/even indicator,
               encoded as follows:
     -- bit 8: 1 (no extension)
     -- bits 765: type of subaddress
               000 NSAP (X.213/ISO 8348 AD2)
010 User Specified
     _ _
               All other values are reserved
     -- bit 4: odd/even indicator
               0 even number of address signals
               1 odd number of address signals
               The odd/even indicator is used when the type of subaddress
               is "user specified" and the coding is BCD.
     -- bits 321: 000 (unused)
     -- b) Subaddress information.
          The NSAP X.213/ISO8348AD2 address shall be formatted as specified
     -- by octet 4 which contains the Authority and Format Identifier
          (AFI). The encoding is made according to the "preferred binary
         encoding" as defined in X.213/ISO834AD2. For the definition
         of this type of subaddress, see ITU-T Rec I.334.
         For User-specific subaddress, this field is encoded according
         to the user specification, subject to a maximum length of 20 octets. When interworking with X.25 networks BCD coding should
          be applied.
```

#### maxISDN-SubaddressLength INTEGER ::= 21

#### SignalInfo ::= OCTET STRING (SIZE (1..maxSignalInfoLength))

```
maxSignalInfoLength INTEGER ::= 200

-- This NamedValue represents the theoretical maximum number of octets which is
-- available to carry a single instance of the SignalInfo data type,
-- without requiring segmentation to cope with the network layer service.
-- However, the actual maximum size available for an instance of the data
-- type may be lower, especially when other information elements
-- have to be included in the same component.
```

```
ProtocolId ::= ENUMERATED {
    gsm-0408 (1),
    gsm-0806 (2),
    gsm-BSSMAP (3),
    -- Value 3 is reserved and must not be used
    ets-300102-1 (4)}
```

```
Ext-ProtocolId ::= ENUMERATED {
    ets-300356 (1),
    ...
    }
-- exception handling:
-- For Ext-ExternalSignalInfo sequences containing this parameter with any
-- other value than the ones listed the receiver shall ignore the whole
-- Ext-ExternalSignalInfo sequence.
```

#### LongSignalInfo ::= OCTET STRING (SIZE (1..maxLongSignalInfoLength))

```
maxLongSignalInfoLength INTEGER ::= 2560

-- This Named Value represents the maximum number of octets which is available
-- to carry a single instance of the LongSignalInfo data type using
-- White Book SCCP with the maximum number of segments.
-- It takes account of the octets used by the lower layers of the protocol, and
-- other information elements which may be included in the same component.
```

```
AccessNetworkProtocolId ::= ENUMERATED {
    ts3G-48006 (1),
    ts3G-25413 (2),
    ...}
    -- exception handling:
    -- For AccessNetworkSignalInfo sequences containing this parameter with any
    -- other value than the ones listed the receiver shall ignore the whole
    -- AccessNetworkSignalInfo sequence.
```

```
AlertingPattern ::= OCTET STRING (SIZE (1) )
      -- This type is used to represent Alerting Pattern
            bits 8765 : 0000 (unused)
           bits 43 : type of Pattern
            00 level
      - -
                 01 category
                  10 category
                 all other values are reserved.
      -- bits 21 : type of alerting
alertingLevel-0 AlertingPattern ::= '000000000'B
alertingLevel-1 AlertingPattern ::= '000000001'B
alertingLevel-2 AlertingPattern ::= '00000010'B
      -- all other values of Alerting level are reserved
      -- Alerting Levels are defined in GSM 02.07
alertingCategory-1 AlertingPattern ::= '00000100'B
alertingCategory-2 AlertingPattern ::= '00000101'B
alertingCategory-3 AlertingPattern ::= '00000110'B
alertingCategory-4 AlertingPattern ::= '00000111'B
alertingCategory-5 AlertingPattern ::= '00001000'B
      -- all other values of Alerting Category are reserved
      -- Alerting categories are defined in GSM 02.07
```

-- data types for numbering and identification

```
IMSI ::= TBCD-STRING (SIZE (3..8))
    -- digits of MCC, MNC, MSIN are concatenated in this order.
```

```
Identity ::= CHOICE {
                                                 IMSI,
      imsi
                                                 IMSI-WithLMSI}
      imsi-WithLMSI
IMSI-WithLMSI ::= SEQUENCE {
                                                 IMSI,
      lmsi
                                                LMSI,
      -- a special value 00000000 indicates that the LMSI is not in use
ASCI-CallReference ::= TBCD-STRING (SIZE (1..8))
      -- digits of VGCS/VBS-area, Group-ID are concatenated in this order if there is a
      -- VGCS/VBS-area.
TMSI ::= OCTET STRING (SIZE (1..4))
SubscriberId ::= CHOICE {
      imsi
                                                 [0] IMSI,
                                                 [1] TMSI }
      tmsi
IMEI ::= TBCD-STRING (SIZE (8))
     -- Refers to International Mobile Station Equipment Identity
           and Software Version Number (SVN) defined in TS 3GPP TS 23.003 [17].
           If the SVN is not present the last octet shall contain the
      -- digit 0 and a filler.
          If present the SVN shall be included in the last octet.
HLR-Id ::= IMSI
      -- leading digits of IMSI, i.e. (MCC, MNC, leading digits of -- MSIN) forming HLR Id defined in TS 3GPP TS 23.003 [17].
HLR-List ::= SEQUENCE SIZE (1..maxNumOfHLR-Id) OF
maxNumOfHLR-Id INTEGER ::= 50
LMSI ::= OCTET STRING (SIZE (4))
GlobalCellId ::= OCTET STRING (SIZE (5..7))
      -- Refers to Cell Global Identification defined in TS 3GPP TS 23.003 [17].
      -- The internal structure is defined as follows:
                                              Mobile Country Code 1<sup>st</sup> digit
Mobile Country Code 2<sup>nd</sup> digit
      -- octet 1 bits 4321
                  bits 8765
                                               Mobile Country Code 3<sup>rd</sup> digit
Mobile Network Code 3<sup>rd</sup> digit
      -- octet 2 bits 4321
      ___
                  bits 8765
                                               or filler (1111) for 2 digit MNCs
Mobile Network Code 1<sup>st</sup> digit
Mobile Network Code 2<sup>nd</sup> digit
      -- octet 3 bits 4321
                 bits 8765
      -- octets 4 and 5
                                                Location Area Code according to TS 3GPP TS 24.008
 [35]
      -- octets 6 and 7
                                                Cell Identity (CI) according to TS 3GPP TS 24.008
 [35]
NetworkResource ::= ENUMERATED {
     plmn (0),
hlr (1),
      vlr (2),
      pvlr
            (3),
      controllingMSC (4),
      vmsc (5),
eir (6),
      rss (7)}
AdditionalNetworkResource ::= ENUMERATED {
      sgsn (0),
```

```
AdditionalNetworkResource ::= ENUMERATED {
    sgsn (0),
    ggsn (1),
    gmlc (2),
    gsmSCF (3),
    nplr (4),
    auc (5),
    ...,
    ue (6)}
    -- if unknown value is received in AdditionalNetworkResource
    -- it shall be ignored.
```

```
NAEA-PreferredCI ::= SEQUENCE {
                                           [0] NAEA-CIC,
    naea-PreferredCTC
                                           [1] ExtensionContainer
                                                                             OPTIONAL,
     extensionContainer
NAEA-CIC ::= OCTET STRING (SIZE (3))
     -- The internal structure is defined by the Carrier Identification
     -- parameter in ANSI T1.113.3. Carrier codes between '000' and '999' may
     -- be encoded as 3 digits using '000' to '999' or as 4 digits using
     -- '0000' to '0999'. Carrier codes between '1000' and '9999' are encoded
     -- using 4 digits.
SubscriberIdentity ::= CHOICE {
                                           [0] IMSI,
                                           [1] ISDN-AddressString
     msisdn
LCSClientExternalID ::= SEQUENCE {
                                           [0] ISDN-AddressString
     externalAddress
                                                                             OPTIONAL,
     extensionContainer
                                           [1] ExtensionContainer
                                                                             OPTIONAL,
LCSClientInternalID ::= ENUMERATED {
    broadcastService
                                           (0),
    o-andM-HPLMN
                                           (1),
    o-andM-VPLMN
                                           (2),
                                           (3),
     anonymousLocation
     targetMSsubscribedService
                                           (4),
   for a CAMEL phase 3 PLMN operator client, the value targetMSsubscribedService shall be used
LCSServiceTypeID ::= INTEGER (0..127)
     -- the integer values 0-63 are reserved for Standard LCS service types
     -- the integer values 64-127 are reserved for Non Standard LCS service types
-- Standard LCS Service Types
emergencyServices
                                               LCSServiceTypeID ::= 0
emergencyAlertServices
                                               LCSServiceTypeID ::= 1
personTracking
                                               LCSServiceTypeID ::= 2
{\tt fleetManagement}
                                               LCSServiceTypeID ::= 3
assetManagement
                                               LCSServiceTypeID ::= 4
trafficCongestionReporting
                                               LCSServiceTypeID ::= 5
roadsideAssistance
                                               LCSServiceTypeID ::= 6
                                               LCSServiceTypeID ::= 7
routingToNearestCommercialEnterprise
navigation
                                               LCSServiceTypeID ::= 8
     --this service type is reserved for use in previous releases
                                               LCSServiceTypeID ::= 9
citySightseeing
localizedAdvertising
                                               LCSServiceTypeID ::= 10
mobileYellowPages
                                               LCSServiceTypeID ::= 11
{\tt trafficAndPublicTransportationInfo}
                                               LCSServiceTypeID ::= 12
weather
                                               LCSServiceTypeID ::= 13
assetAndServiceFinding
                                               LCSServiceTypeID ::= 14
gaming
                                               LCSServiceTypeID ::= 15
findYourFriend
                                               LCSServiceTypeID ::= 16
dating
                                               LCSServiceTypeID ::= 17
chatting
                                               LCSServiceTypeID ::= 18
routeFinding
                                               LCSServiceTypeID ::= 19
                                               LCSServiceTypeID ::= 20
whereAmI
```

The values of LCSServiceTypeID are defined according to 3GPP TS 22.071.

```
-- Non Standard LCS Service Types
serv64
                                                LCSServiceTypeID ::= 64
serv65
                                                LCSServiceTypeID ::= 65
serv66
                                                LCSServiceTypeID ::= 66
serv67
                                                LCSServiceTypeID ::= 67
serv68
                                                LCSServiceTypeID ::= 68
serv69
                                                LCSServiceTypeID ::= 69
serv70
                                                LCSServiceTypeID ::= 70
serv71
                                                LCSServiceTypeID ::= 71
serv72
                                                LCSServiceTypeID ::= 72
serv73
                                                LCSServiceTypeID ::= 73
                                                LCSServiceTypeID ::= 74
serv74
serv75
                                                LCSServiceTypeID ::= 75
serv76
                                                LCSServiceTypeID ::= 76
serv77
                                                LCSServiceTypeID ::= 77
                                                LCSServiceTypeID ::= 78
serv78
serv79
                                                LCSServiceTypeID ::= 79
serv80
                                                LCSServiceTypeID ::= 80
                                                LCSServiceTypeID ::= 81
serv81
serv82
                                                LCSServiceTypeID ::= 82
                                                LCSServiceTypeID ::= 83
serv83
serv84
                                                LCSServiceTypeID ::= 84
serv85
                                                LCSServiceTypeID ::= 85
                                                LCSServiceTypeID ::= 86
serv86
serv87
                                                LCSServiceTypeID ::= 87
                                                LCSServiceTypeID ::= 88
serv88
serv89
                                                LCSServiceTypeID ::= 89
serv90
                                                LCSServiceTypeID ::= 90
                                                LCSServiceTypeID ::= 91
serv91
                                                LCSServiceTypeID ::= 92
serv92
serv93
                                                LCSServiceTypeID ::= 93
serv94
                                                LCSServiceTypeID ::= 94
serv95
                                                LCSServiceTypeID ::= 95
                                                LCSServiceTypeID ::= 96
serv96
                                                LCSServiceTypeID ::= 97
serv97
serv98
                                                LCSServiceTypeID ::= 98
serv99
                                                LCSServiceTypeID ::= 99
serv100
                                                LCSServiceTypeID ::= 100
                                                LCSServiceTypeID ::= 101
serv101
                                                LCSServiceTypeID ::= 102
serv102
                                                LCSServiceTypeID ::= 103
serv103
serv104
                                                LCSServiceTypeID ::= 104
serv105
                                                LCSServiceTypeID ::= 105
                                                LCSServiceTypeID ::= 106
serv106
serv107
                                                LCSServiceTypeID ::= 107
                                                LCSServiceTypeID ::= 108
serv108
serv109
                                                LCSServiceTypeID ::= 109
serv110
                                                LCSServiceTypeID ::= 110
                                                LCSServiceTypeID ::= 111
serv111
                                                LCSServiceTypeID ::= 112
serv112
                                                LCSServiceTypeID ::= 113
serv113
serv114
                                                LCSServiceTypeID ::= 114
                                                LCSServiceTypeID ::= 115
serv115
                                                LCSServiceTypeID ::= 116
serv116
                                                LCSServiceTypeID ::= 117
serv117
                                                LCSServiceTypeID ::= 118
serv118
serv119
                                                LCSServiceTypeID ::= 119
                                                LCSServiceTypeID ::= 120
serv120
serv121
                                                LCSServiceTypeID ::= 121
                                                LCSServiceTypeID ::= 122
serv122
serv123
                                                LCSServiceTypeID ::= 123
serv124
                                                LCSServiceTypeID ::= 124
serv125
                                                LCSServiceTypeID ::= 125
serv126
                                                LCSServiceTypeID ::= 126
                                                LCSServiceTypeID ::= 127
serv127
```

<sup>--</sup> data types for CAMEL

maxNumOfMC-Bearers INTEGER ::= 7

```
CellGlobalIdOrServiceAreaIdOrLAI ::= CHOICE {
      cellGlobalIdOrServiceAreaIdFixedLength
                                                       [0] CellGlobalIdOrServiceAreaIdFixedLength,
                                                 [1] LAIFixedLength}
      laiFixedLength
CellGlobalIdOrServiceAreaIdFixedLength ::= OCTET STRING (SIZE (7))
      -- Refers to Cell Global Identification or Service Are Identification
      -- defined in 3GPP TS 23.003.
      -- The internal structure is defined as follows:
      -- octet 1 bits 4321
                                                  Mobile Country Code 1st digit
                                                Mobile Country Code 2<sup>nd</sup> digit
Mobile Country Code 3<sup>rd</sup> digit
Mobile Network Code 3<sup>rd</sup> digit
                  bits 8765
      -- octet 2 bits 4321
                 bits 8765
                                                or filler (1111) for 2 digit MNCs
Mobile Network Code 1<sup>st</sup> digit
Mobile Network Code 2<sup>nd</sup> digit
      - -
      -- octet 3 bits 4321
                 bits 8765
      -- octets 4 and 5
                                                  Location Area Code according to 3GPP TS 24.008
                                                  Cell Identity (CI) value or
      -- octets 6 and 7
                                                  Service Area Code (SAC) value according to 3GPP TS 23.003
LAIFixedLength ::= OCTET STRING (SIZE (5))
-- Refers to Location Area Identification defined in TS 3GPP TS 23.003 [17].
      -- The internal structure is defined as follows:
                                                Mobile Country Code 1<sup>st</sup> digit
Mobile Country Code 2<sup>nd</sup> digit
Mobile Country Code 3<sup>rd</sup> digit
Mobile Network Code 3<sup>rd</sup> digit
      -- octet 1 bits 4321
                  bits 8765
      -- octet 2 bits 4321
                  bits 8765
                                                or filler (1111) for 2 digit MNCs
Mobile Network Code 1<sup>st</sup> digit
Mobile Network Code 2<sup>nd</sup> digit
      -- octet 3 bits 4321
                 bits 8765
      -- octets 4 and 5
                                                  Location Area Code according to TS 3GPP TS 24.008
-- data types for subscriber management
BasicServiceCode ::= CHOICE {
      bearerService
                                                  [2] BearerServiceCode.
      teleservice
                                                  [3] TeleserviceCode}
Ext-BasicServiceCode ::= CHOICE {
      ext-BearerService
                                                  [2] Ext-BearerServiceCode,
                                                  [3] <u>Ext-TeleserviceCode</u>}
      ext-Teleservice
EMLPP-Info ::= SEQUENCE {
     maximumentitledPriority
                                                  EMLPP-Priority,
      defaultPriority
                                                  EMLPP-Priority,
      extensionContainer
                                                                                           OPTIONAL.
                                                  ExtensionContainer
EMLPP-Priority ::= INTEGER (0..15)
     -- The mapping from the values A,B,0,1,2,3,4 to the integer-value is
      -- specified as follows where A is the highest and 4 is the lowest
      -- priority level
      -- the integer values 7-15 are spare and shall be mapped to value 4
priorityLevelA
                                                  EMLPP-Priority ::= 6
priorityLevelB
                                                  EMLPP-Priority ::= 5
priorityLevel0
                                                  EMLPP-Priority ::= 0
priorityLevel1
                                                  EMLPP-Priority ::= 1
priorityLevel2
                                                  {\tt EMLPP-Priority}:=2
priorityLevel3
                                                  EMLPP-Priority ::= 3
priorityLevel4
                                                  EMLPP-Priority ::= 4
MC-SS-Info ::= SEQUENCE {
      ss-Code
                                                  [0] SS-Code,
      ss-Status
                                                  [1] Ext-SS-Status,
      nbrSB
                                                  [2] MaxMC-Bearers,
      nbrUser
                                                  [3] MC-Bearers,
      extensionContainer
                                                                                           OPTIONAL,
                                                  [4] ExtensionContainer
MaxMC-Bearers ::= INTEGER (2..maxNumOfMC-Bearers)
MC-Bearers ::= INTEGER (1..maxNumOfMC-Bearers)
```

```
Ext-SS-Status ::= OCTET STRING (SIZE (1..5))

-- OCTET 1:
-- bits 8765: 0000 (unused)
-- bits 4321: Used to convey the "P bit", "R bit", "A bit" and "Q bit",
-- representing supplementary service state information
-- as defined in TS 3GPP TS 23.011 [22]

-- bit 4: "Q bit"

-- bit 3: "P bit"

-- bit 2: "R bit"

-- bit 1: "A bit"

-- OCTETS 2-5: reserved for future use. They shall be discarded if
-- received and not understood.
```

-- data types for geographic location

```
AgeOfLocationInformation ::= INTEGER (0..32767)

-- the value represents the elapsed time in minutes since the last
-- network contact of the mobile station (i.e. the actuality of the
-- location information).

-- value '0' indicates that the MS is currently in contact with the
-- network
-- value '32767' indicates that the location information is at least
-- 32767 minutes old
```

END

### 17.7.9 Teleservice Codes

```
MAP-TS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-TS-Code (19) version10 (10) }
DEFINITIONS
::=
BEGIN
```

```
TeleserviceCode ::= OCTET STRING (SIZE (1))

-- This type is used to represent the code identifying a single
-- teleservice, a group of teleservices, or all teleservices. The
-- services are defined in TS GSM 22.003 [4].

-- The internal structure is defined as follows:

-- bits 87654321: group (bits 8765) and specific service
-- (bits 4321)
```

```
Ext-TeleserviceCode ::= OCTET STRING (SIZE (1..5))

-- This type is used to represent the code identifying a single
-- teleservice, a group of teleservices, or all teleservices. The
-- services are defined in TS GSM 22.003 [4].

-- The internal structure is defined as follows:

-- OCTET 1:
-- bits 87654321: group (bits 8765) and specific service
-- (bits 4321)

-- OCTETS 2-5: reserved for future use. If received the
-- Ext-TeleserviceCode shall be
-- treated according to the exception handling defined for the
-- operation that uses this type.

-- Ext-TeleserviceCode includes all values defined for TeleserviceCode.
```

```
allTeleservices TeleserviceCode ::= '000000000'B
```

```
allSpeechTransmissionServices
                                          TeleserviceCode ::= '00010000'B
                                          TeleserviceCode ::= '00010001'B
telephony
                                          TeleserviceCode ::= '00010010'B
emergencyCalls
                                          TeleserviceCode ::= '00100000'B
allShortMessageServices
shortMessageMT-PP
                                          TeleserviceCode ::= '00100001'B
                                          TeleserviceCode ::= '00100010'B
shortMessageMO-PP
allFacsimileTransmissionServices
                                          TeleserviceCode ::= '01100000'B
                                          TeleserviceCode ::= '01100001'B
facsimileGroup3AndAlterSpeech
automaticFacsimileGroup3
                                          TeleserviceCode ::= '01100010'B
                                          TeleserviceCode ::= '01100011'B
facsimileGroup4
```

allVoiceGroupCallServices	TeleserviceCode ::= '10010000'B	
voiceGroupCall	TeleserviceCode ::= '10010001'B	
voiceBroadcastCall	TeleserviceCode ::= '10010010'B	

```
allPLMN-specificTS
                                          TeleserviceCode ::= '11010000'B
plmn-specificTS-1
                                          TeleserviceCode ::= '11010001'B
plmn-specificTS-2
                                          TeleserviceCode ::= '11010010'B
                                          TeleserviceCode ::= '11010011'B
plmn-specificTS-3
plmn-specificTS-4
                                          TeleserviceCode ::= '11010100'B
                                          TeleserviceCode ::= '11010101'B
plmn-specificTS-5
                                          TeleserviceCode ::= '11010110'B
plmn-specificTS-6
plmn-specificTS-7
                                          TeleserviceCode ::= '11010111'B
                                          TeleserviceCode ::= '11011000'B
plmn-specificTS-8
plmn-specificTS-9
                                          TeleserviceCode ::= '11011001'B
                                          TeleserviceCode ::= '11011010'B
plmn-specificTS-A
                                          TeleserviceCode ::= '11011011'B
plmn-specificTS-B
plmn-specificTS-C
                                          TeleserviceCode ::= '11011100'B
                                          TeleserviceCode ::= '11011101'B
plmn-specificTS-D
plmn-specificTS-E
                                          TeleserviceCode ::= '11011110'B
                                          TeleserviceCode ::= '11011111'B
plmn-specificTS-F
```

END

### 17.7.10 Bearer Service Codes

```
MAP-BS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-BS-Code (20) version10 (10) }
DEFINITIONS
::=
BEGIN
```

```
BearerServiceCode ::= OCTET STRING (SIZE (1))

-- This type is used to represent the code identifying a single
-- bearer service, a group of bearer services, or all bearer
-- services. The services are defined in TS 3GPP TS 22.002 [3].
-- The internal structure is defined as follows:
--
-- plmn-specific bearer services:
-- bits 87654321: defined by the HPLMN operator

-- rest of bearer services:
-- bit 8: 0 (unused)
-- bits 7654321: group (bits 7654), and rate, if applicable
-- (bits 321)
```

```
Ext-BearerServiceCode ::= OCTET STRING (SIZE (1..5))
     -- This type is used to represent the code identifying a single
     -- bearer service, a group of bearer services, or all bearer
     -- services. The services are defined in TS 3GPP TS 22.002 [3].
     -- The internal structure is defined as follows:
     -- OCTET 1:
     -- plmn-specific bearer services:
     -- bits 87654321: defined by the HPLMN operator
     -- rest of bearer services:
     -- bit 8: 0 (unused)
     -- bits 7654321: group (bits 7654), and rate, if applicable
     -- (bits 321)
    -- OCTETS 2-5: reserved for future use. If received the
    -- Ext-TeleserviceCode shall be
    -- treated according to the exception handling defined for the
     -- operation that uses this type.
    -- Ext-BearerServiceCode includes all values defined for BearerServiceCode.
```

allBearerServices	BearerServiceCode ::= '00000000'B
allDataCDA-Services	BearerServiceCode ::= '00010000'B
dataCDA-300bps	BearerServiceCode ::= '00010001'B
dataCDA-1200bps	BearerServiceCode ::= '00010010'B
dataCDA-1200-75bps	BearerServiceCode ::= '00010011'B
dataCDA-2400bps	BearerServiceCode ::= '00010100'B
dataCDA-4800bps	BearerServiceCode ::= '00010101'B
dataCDA-9600bps	BearerServiceCode ::= '00010110'B
general-dataCDA	<pre>BearerServiceCode ::= '00010111'B</pre>
allDataCDS-Services	BearerServiceCode ::= '00011000'B
dataCDS-1200bps	BearerServiceCode ::= '00011010'B
dataCDS-2400bps	BearerServiceCode ::= '00011100'B
dataCDS-4800bps	BearerServiceCode ::= '00011101'B
dataCDS-9600bps	BearerServiceCode ::= '00011110'B
general-dataCDS	<pre>BearerServiceCode ::= '00011111'B</pre>
allPadAccessCA-Services	BearerServiceCode ::= '00100000'B
padAccessCA-300bps	BearerServiceCode ::= '00100001'B
padAccessCA-1200bps	BearerServiceCode ::= '00100010'B
padAccessCA-1200-75bps	BearerServiceCode ::= '00100011'B
padAccessCA-2400bps	BearerServiceCode ::= '00100100'B
padAccessCA-4800bps	BearerServiceCode ::= '00100101'B
padAccessCA-9600bps	BearerServiceCode ::= '00100110'B
general-padAccessCA	<pre>BearerServiceCode ::= '00100111'B</pre>
allDataPDS-Services	BearerServiceCode ::= '00101000'B
dataPDS-2400bps	<pre>BearerServiceCode ::= '00101100'B</pre>
dataPDS-4800bps	BearerServiceCode ::= '00101101'B
dataPDS-9600bps	BearerServiceCode ::= '00101110'B
general-dataPDS	<pre>BearerServiceCode ::= '00101111'B</pre>
allAlternateSpeech-DataCDA	BearerServiceCode ::= '00110000'B
<u>-</u>	
allAlternateSpeech-DataCDS	BearerServiceCode ::= '00111000'B
*	
allSpeechFollowedByDataCDA	BearerServiceCode ::= '01000000'B
allSpeechFollowedByDataCDS	BearerServiceCode ::= '01001000'B
all peccan of towed by bacacob	Dealerselvicecode Vivvivvv b

```
-- The following non-hierarchical Compound Bearer Service
-- Groups are defined in TS 3GPP TS 22.030:
                                            BearerServiceCode ::= '01010000'B
allDataCircuitAsynchronous
     -- covers "allDataCDA-Services", "allAlternateSpeech-DataCDA" and
     -- "allSpeechFollowedByDataCDA"
                                            BearerServiceCode ::= '01100000'B
allAsvnchronousServices
     -- covers "allDataCDA-Services", "allAlternateSpeech-DataCDA",
-- "allSpeechFollowedByDataCDA" and "allPadAccessCDA-Services"
allDataCircuitSynchronous
                                            BearerServiceCode ::= '01011000'B
    -- covers "allDataCDS-Services", "allAlternateSpeech-DataCDS" and
     -- "allSpeechFollowedByDataCDS"
allSynchronousServices
                                            BearerServiceCode ::= '01101000'B
     -- covers "allDataCDS-Services", "allAlternateSpeech-DataCDS",
     -- "allSpeechFollowedByDataCDS" and "allDataPDS-Services"
-- Compound Bearer Service Group Codes are only used in call
-- independent supplementary service operations, i.e. they
-- are not used in InsertSubscriberData or in
-- DeleteSubscriberData messages.
```

```
allPLMN-specificBS
                                          BearerServiceCode ::= '11010000'B
plmn-specificBS-1
                                          BearerServiceCode ::= '11010001'B
plmn-specificBS-2
                                          BearerServiceCode ::= '11010010'B
                                          BearerServiceCode ::= '11010011'B
plmn-specificBS-3
                                          BearerServiceCode ::= '11010100'B
plmn-specificBS-4
plmn-specificBS-5
                                          BearerServiceCode ::= '11010101'B
                                          BearerServiceCode ::= '11010110'B
plmn-specificBS-6
                                          BearerServiceCode ::= '11010111'B
plmn-specificBS-7
                                          BearerServiceCode ::= '11011000'B
plmn-specificBS-8
                                          BearerServiceCode ::= '11011001'B
plmn-specificBS-9
plmn-specificBS-A
                                          BearerServiceCode ::= '11011010'B
                                          BearerServiceCode ::= '11011011'B
plmn-specificBS-B
                                          BearerServiceCode ::= '11011100'B
plmn-specificBS-C
plmn-specificBS-D
                                          BearerServiceCode ::= '11011101'B
                                          BearerServiceCode ::= '11011110'B
plmn-specificBS-E
plmn-specificBS-F
                                          BearerServiceCode ::= '11011111'B
```

END

# 17.7.11 Extension data types

```
MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version10 (10)}

DEFINITIONS

IMPLICIT TAGS
::=

BEGIN

EXPORTS

   PrivateExtension,
   ExtensionContainer,
   SLR-ArgExtensionContainer;

-- IOC for private MAP extensions
```

-- data types

PrivateExtensionList ::= SEQUENCE SIZE (1..maxNumOfPrivateExtensions) OF
PrivateExtension

maxNumOfPrivateExtensions INTEGER ::= 10

```
PCS-Extensions ::= SEQUENCE {
    ...}
```

```
SLR-Arg-PCS-Extensions ::= SEQUENCE {
    ...,
    na-ESRK-Request [0] NULL OPTIONAL }
```

END

MAP-GR-DataTypes {

# 17.7.12 Group Call data types

```
itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-GR-DataTypes (23) version10 (10)}
DEFINITIONS
IMPLICIT TAGS
BEGIN
EXPORTS
  PrepareGroupCallArg,
   PrepareGroupCallRes,
  SendGroupCallEndSignalArg,
  SendGroupCallEndSignalRes,
  ForwardGroupCallSignallingArg,
  ProcessGroupCallSignallingArg,
  SendGroupCallInfoArg,
  SendGroupCallInfoRes
IMPORTS
  ISDN-AddressString,
  IMSI,
  TMSI,
  EMLPP-Priority,
  ASCI-CallReference,
  SignalInfo,
  GlobalCellId
FROM MAP-CommonDataTypes {
  itu-t identified-organization (4) etsi (0) mobileDomain (0)
  gsm-Network (1) modules (3) map-CommonDataTypes (18) version10 (10)}
  Ext-TeleserviceCode
FROM MAP-TS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-TS-Code (19) version10 (10)}
  AdditionalInfo,
   GroupId,
```

```
Long-GroupId,
   Additional Subscriptions,
   Cksn
FROM MAP-MS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-MS-DataTypes (11) version10 (10)}
   ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version10 (10)}
PrepareGroupCallArg ::= SEQUENCE {
     teleservice
                                           Ext-TeleserviceCode,
     asciCallReference
                                           ASCI-CallReference,
     codec-Info
                                           CODEC-Info,
     cipheringAlgorithm
                                           CipheringAlgorithm,
                                           [0] GroupKeyNumber
[1] Kc
     groupKeyNumber-Vk-Id
                                                                              OPTIONAL,
     groupKey
                                                                              OPTIONAL,
     -- this parameter shall not be sent and shall be discarded if received
                                           [2] EMLPP-Priority
                                                                              OPTIONAL,
     priority
                                           [3] NULL
     uplinkFree
                                                                              OPTIONAL.
     extensionContainer
                                                                              OPTIONAL,
                                           [4] ExtensionContainer
     vstk
                                           [5] VSTK
                                                                              OPTIONAL,
     vstk-rand
                                           [6] VSTK-RAND
                                                                              OPTIONAL
VSTK ::= OCTET STRING (SIZE (16))
VSTK-RAND ::= OCTET STRING (SIZE (5))
     -- The 36 bit value is carried in bit 7 of octet 1 to bit 4 of octet 5
     -- bits 3, 2, 1, and 0 of octet 5 are padded with zeros.
PrepareGroupCallRes ::= SEQUENCE {
     groupCallNumber
                                           ISDN-AddressString,
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL.
SendGroupCallEndSignalArg ::= SEQUENCE {
                                                                              OPTIONAL,
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL,
     talkerPriority
                                                                              OPTIONAL,
                                           [0] TalkerPriority
     additionalInfo
                                           [1] Additional Info
                                                                              OPTIONAL
TalkerPriority ::= ENUMERATED {
     normal (0),
     privileged (1),
     emergency (2)}
SendGroupCallEndSignalRes ::= SEQUENCE {
     {\tt extensionContainer}
                                           ExtensionContainer
                                                                              OPTIONAL,
ForwardGroupCallSignallingArg ::= SEQUENCE {
                                           IMSI
                                                                              OPTIONAL,
     uplinkRequestAck
                                           [0] NULL
                                                                              OPTIONAL,
     uplinkReleaseIndication
                                           [1] NULL
                                                                              OPTIONAL,
     uplinkRejectCommand
                                           [2] NULL
                                                                              OPTIONAL,
     uplinkSeizedCommand
                                           [3] NULL
                                                                              OPTIONAL,
     uplinkReleaseCommand
                                           [4] NULL
                                                                              OPTIONAL,
     extensionContainer
                                           ExtensionContainer
                                                                              OPTIONAL,
     stateAttributes
                                           [5] StateAttributes
                                                                              OPTIONAL,
     talkerPriority
                                           [6] TalkerPriority
                                                                              OPTIONAL,
     additionalInfo
                                           [7] AdditionalInfo
                                                                              OPTIONAL,
     emergencyModeResetCommandFlag
                                           [8] NULL
                                                                              OPTIONAL,
     sm-RP-UI
                                           [9] SignalInfo
                                                                              OPTIONAL
```

```
ProcessGroupCallSignallingArg ::= SEQUENCE {
                                      [0] NULL
    uplinkRequest
                                                                         OPTIONAL.
    uplinkReleaseIndication
                                        [1] NULL
                                                                         OPTIONAL,
    releaseGroupCall
                                       [2] NULL
                                                                         OPTIONAL,
    extensionContainer
                                        ExtensionContainer
                                                                         OPTIONAL,
    talkerPriority
                                       [3] TalkerPriority
                                                                         OPTIONAL.
                                        [4] AdditionalInfo
    additionalInfo
                                                                         OPTIONAL,
    emergencyModeResetCommandFlag
                                       [5] NULL
                                                                         OPTIONAL }
```

```
GroupKeyNumber ::= INTEGER (0..15)
```

```
CODEC-Info ::= OCTET STRING (SIZE (5..10))
-- Refers to channel type
-- coded according to 3GPP TS 48.008 [49] and including Element identifier and Length
```

```
CipheringAlgorithm ::= OCTET STRING (SIZE (1))
    -- Refers to 'permitted algorithms' in 'encryption information'
     -- coded according to 3GPP TS 48.008 [49]:
     -- Bits 8-1
     -- 8765 4321
     -- 0000 0001
                                          No encryption
     -- 0000 0010
                                          GSM A5/1
     -- 0000 0100
                                          GSM A5/2
     -- 0000 1000
                                          GSM A5/3
     -- 0001 0000
                                          GSM A5/4
     -- 0010 0000
                                          GSM A5/5
     -- 0100 0000
                                          GSM A5/6
     -- 1000 0000
                                          GSM A5/7
```

```
SendGroupCallInfoArg ::= SEQUENCE {
                                          RequestedInfo,
    requestedInfo
    groupId
                                          Long-GroupId,
    teleservice
                                          Ext-TeleserviceCode,
    cellId
                                          [0] GlobalCellId
                                                                             OPTIONAL,
                                          [1] IMSI
[2] TMSI
                                                                             OPTIONAL,
    imsi
                                                                             OPTIONAL,
    tmsi
    additionalInfo
                                          [3] AdditionalInfo
                                                                             OPTIONAL,
    talkerPriority
                                           [4] TalkerPriority
                                                                              OPTIONAL,
                                          [5] Cksn
                                                                              OPTIONAL,
    cksn
                                          [6] ExtensionContainer
    extensionContainer
                                                                             OPTIONAL.
```

```
RequestedInfo ::= ENUMERATED {
    anchorMSC-AddressAndASCI-CallReference (0),
    imsiAndAdditionalInfoAndAdditionalSubscription (1),
    ... }
-- exception handling:
-- an unrecognized value shall be rejected by the receiver with a return error cause of
-- unexpected data value
```

```
SendGroupCallInfoRes ::= SEQUENCE {
    anchorMSC-Address
                                          [0] ISDN-AddressString
                                                                            OPTIONAL,
                                         [1] ASCI-CallReference
    asciCallReference
                                                                           OPTIONAL,
                                         [2] IMSI
    imsi
                                                                            OPTIONAL,
    additionalInfo
                                         [3] AdditionalInfo
                                                                           OPTIONAL,
    additionalSubscriptions
                                         [4] AdditionalSubscriptions
                                                                           OPTIONAL,
                                          [5] Kc
                                                                            OPTIONAL,
                                         [6] ExtensionContainer
    extensionContainer
                                                                           OPTIONAL,
```

END

# 17.7.13 Location service data types

```
MAP-LCS-DataTypes {
       itu-t identified-organization (4) etsi (0) mobileDomain (0)
 3
4
5
       gsm-Network (1) modules (3) map-LCS-DataTypes (25) version10 (10)}
    DEFINITIONS
 6
7
8
9
    IMPLICIT TAGS
    : : =
    BEGIN
10
   EXPORTS
11
       RoutingInfoForLCS-Arg,
12
       RoutingInfoForLCS-Res,
13
       ProvideSubscriberLocation-Arg,
14
15
       ProvideSubscriberLocation-Res,
       SubscriberLocationReport-Arg,
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
40
       SubscriberLocationReport-Res,
       LocationType,
       DeferredLocationEventType,
       LCSClientName,
       LCS-QoS,
       Horizontal-Accuracy,
       ResponseTime,
       Ext-GeographicalInformation,
       VelocityEstimate,
       SupportedGADShapes,
       Add-GeographicalInformation,
       LCSRequestorID,
       LCS-ReferenceNumber,
       LCSCodeword,
       AreaEventInfo,
       ReportingPLMNList,
       PeriodicLDRInfo,
       SequenceNumber
    IMPORTS
       AddressString,
       ISDN-AddressString,
       IMSI,
41
42
43
44
45
46
       LMSI.
       SubscriberIdentity,
       AgeOfLocationInformation,
       LCSClientExternalID,
       LCSClientInternalID,
       LCSServiceTypeID,
47
48
       CellGlobalIdOrServiceAreaIdOrLAI,
       PLMN-Id
49
    FROM MAP-CommonDataTypes {
50
51
52
53
54
55
56
57
58
       itu-t identified-organization (4) etsi (0) mobileDomain (0)
       gsm-Network (1) modules (3) map-CommonDataTypes (18) version10 (10)}
       ExtensionContainer,
       SLR-ArgExtensionContainer
    FROM MAP-ExtensionDataTypes {
       itu-t identified-organization (4) etsi (0) mobileDomain (0)
       gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version10 (10)}
       USSD-DataCodingScheme,
60
       USSD-String
61
    FROM MAP-SS-DataTypes {
62
       itu-t identified-organization (4) etsi (0) mobileDomain (0) gsm-Network (1) modules (3)
       map-SS-DataTypes (14) version10 (10) }
64
65
       APN,
66
       GSN-Address,
67
       SupportedLCS-CapabilitySets
68
    FROM MAP-MS-DataTypes {
69
70
71
72
73
74
75
76
77
78
       itu-t identified-organization (4) etsi (0) mobileDomain (0)
       gsm-Network (1) modules (3) map-MS-DataTypes (11) version10 (10)}
       Additional-Number
    FROM MAP-SM-DataTypes {
       itu-t identified-organization (4) etsi (0) mobileDomain (0)
       gsm-Network (1) modules (3) map-SM-DataTypes (16) version10 (10)}
```

```
RoutingInfoForLCS-Arg ::= SEQUENCE {
 80
          mlcNumber
                                                 [0] ISDN-AddressString,
 81
          targetMS
                                                 [1] SubscriberIdentity,
 82
          extensionContainer
                                                 [2] ExtensionContainer
                                                                                      OPTIONAL,
 83
          . . . }
 84
 85
    RoutingInfoForLCS-Res ::= SEQUENCE {
 86
          targetMS
                                                 [0] SubscriberIdentity,
 87
          lcsLocationInfo
                                                 [1] LCSLocationInfo,
 88
89
          extensionContainer
                                                 [2] ExtensionContainer
                                                                                      OPTIONAL,
 90
          v-gmlc-Address
                                                 [3] GSN-Address
                                                                                      OPTIONAL,
 91
          h-gmlc-Address
                                                     GSN-Address
                                                 [4]
                                                                                      OPTIONAL.
 92
          ppr-Address
                                                 [5] GSN-Address
                                                                                      OPTIONAL.
 93
          additional-v-gmlc-Address
                                                 [6]
                                                      GSN-Address
                                                                                      OPTIONAL
 94
 95
    LCSLocationInfo ::= SEQUENCE {
 96
          networkNode-Number
                                                 ISDN-AddressString,
 97
           - NetworkNode-number can be either msc-number or sgsn-number
 98
          lmsi
                                                 [0] LMSI
                                                                                      OPTIONAL,
 99
                                                 [1] ExtensionContainer
          extensionContainer
                                                                                      OPTIONAL,
100
101
          gprsNodeIndicator
                                                 [2] NULL
                                                                                      OPTIONAL,
102
           -- gprsNodeIndicator is set only if the SGSN number is sent as the Network Node Number
103
                                                 [3] Additional-Number
          additional-Number
                                                                                      OPTIONAL.
104
                                                 [4] SupportedLCS-CapabilitySets
[5] SupportedLCS-CapabilitySets
          supportedLCS-CapabilitySets
                                                                                      OPTIONAL.
105
          additional-LCS-CapabilitySets
                                                                                      OPTIONAL
106
107
108
    ProvideSubscriberLocation-Arg ::= SEQUENCE {
109
          locationType
                                                 LocationType,
110
                                                 ISDN-AddressString,
          mlc-Number
111
                                                 [0] LCS-ClientID
          lcs-ClientID
                                                                                      OPTIONAL.
112
          privacyOverride
                                                 [1] NULL
                                                                                      OPTIONAL,
113
                                                 [2] IMSI
                                                                                      OPTIONAL,
          imsi
114
          msisdn
                                                 [3] ISDN-AddressString
                                                                                      OPTIONAL,
                                                 [4] LMSI
[5] IMEI
115
          lmsi
                                                                                      OPTIONAL.
116
          imei
                                                                                      OPTIONAL.
117
          lcs-Priority
                                                 [6] LCS-Priority
                                                                                      OPTIONAL,
118
                                                 [7] LCS-QoS
          lcs-OoS
                                                                                      OPTIONAL,
119
          extensionContainer
                                                 [8] ExtensionContainer
                                                                                      OPTIONAL,
120
121
122
123
124
          . . . ,
          supportedGADShapes
                                                 [9] SupportedGADShapes
                                                                                      OPTIONAL.
          lcs-ReferenceNumber
                                                 [10] LCS-ReferenceNumber
                                                                                      OPTIONAL,
          lcsServiceTypeID
                                                 [11] LCSServiceTypeID
                                                                                      OPTIONAL,
          lcsCodeword
                                                 [12] LCSCodeword
                                                                                      OPTIONAL,
124
125
126
127
128
129
                                                                                      OPTIONAL,
          lcs-PrivacyCheck
                                                 [13] LCS-PrivacyCheck
          areaEventInfo
                                                 [14] AreaEventInfo
                                                                                     OPTIONAL,
          h-gmlc-Address
                                                 [15] GSN-Address
                                                                                      OPTIONAL,
                                                 [16] NULL
          mo-lrShortCircuitIndicator
                                                                                     OPTIONAL,
          periodicLDRInfo
                                                 [17] PeriodicLDRInfo
                                                                                     OPTIONAL,
130
131
                                                 [18] ReportingPLMNList
          reportingPLMNList
                                                                                     OPTIONAL }
132
          -- one of imsi or msisdn is mandatory
133
          -- If a location estimate type indicates activate deferred location or cancel deferred
134
          -- location, a lcs-Reference number shall be included.
135
136
     LocationType ::= SEQUENCE {
137
                                                 [0] LocationEstimateType,
          locationEstimateType
138
139
          deferredLocationEventType
                                                 [1] DeferredLocationEventType
                                                                                     OPTIONAL }
140
141
    LocationEstimateType ::= ENUMERATED {
142
                                                 (0),
          currentLocation
143
          currentOrLastKnownLocation
                                                 (1),
144
          initialLocation
                                                 (2).
145
146
          activateDeferredLocation
                                                 (3),
147
          cancelDeferredLocation
                                                 (4)
148
          notificationVerificationOnly
                                                 (5) }
149
          exception handling:
150
          a ProvideSubscriberLocation-Arg containing an unrecognized LocationEstimateType
151
          shall be rejected by the receiver with a return error cause of unexpected data value
152
```

```
153
    DeferredLocationEventType ::= BIT STRING {
154
                                                 ·(0),
          msAvailable
155
                                                 (1),
          enteringIntoArea
156
                                                 (2),
          leavingFromArea
157
                                                 (3) ,
(4) } (SIZE (1..16))
          beingInsideArea
158
         periodicLDR
159
     -- beingInsideArea is always treated as oneTimeEvent regardless of the possible value
160
     -- of occurrenceInfo inside areaEventInfo.
161
     -- exception handling:
162
     -- a ProvideSubscriberLocation-Arg containing other values than listed above in
     -- DeferredLocationEventType shall be rejected by the receiver with a return error cause of
163
164
     -- unexpected data value.
165
166
    LCS-ClientID ::= SEQUENCE {
167
          lcsClientType
                                                 [0] LCSClientType,
168
          lcsClientExternalID
                                                 [1] LCSClientExternalID
                                                                                    OPTIONAL,
169
          lcsClientDialedByMS
                                                 [2] AddressString
                                                                                    OPTIONAL,
170
171
                                                 [3] LCSClientInternalID
          lcsClientInternalID
                                                                                    OPTIONAL.
          lcsClientName
                                                 [4] LCSClientName
                                                                                    OPTIONAL,
172
173
          lcsAPN
                                                 [5] APN
                                                                                    OPTIONAL,
174
                                                 [6] LCSRequestorID
          lcsRequestorID
                                                                                    OPTIONAL
175
176
177
    LCSClientType ::= ENUMERATED {
                                                 (0),
          emergencyServices
178
179
          valueAddedServices
                                                 (1),
          plmnOperatorServices
                                                 (2),
180
          lawfulInterceptServices
                                                 (3),
181
          ...}
182
               exception handling:
183
184
               unrecognized values may be ignored if the LCS client uses the privacy override
          _ _
               otherwise, an unrecognized value shall be treated as unexpected data by a receiver
185
               a return error shall then be returned if received in a MAP invoke
186
187
    LCSClientName ::= SEQUENCE {
188
          dataCodingScheme
                                                 [0] USSD-DataCodingScheme,
189
          nameString
                                                 [2] NameString,
190
191
          lcs-FormatIndicator
                                                 [3] LCS-FormatIndicator
                                                                                    OPTIONAL }
192
193
     -- The USSD-DataCodingScheme shall indicate use of the default alphabet through the
194
     -- following encoding
195
         bit 7 6 5 4 3 2 1 0
196
               0 0 0 0 1 1 1 1
197
198
    NameString ::= USSD-String (SIZE (1..maxNameStringLength))
199
200
    maxNameStringLength INTEGER ::= 63
201
202
    LCSRequestorID ::= SEQUENCE {
203
204
          dataCodingScheme
                                                 [0] USSD-DataCodingScheme,
          requestorIDString
                                                 [1] RequestorIDString,
205
          . . . ,
206
                                                                                    OPTIONAL }
          lcs-FormatIndicator
                                                [2] LCS-FormatIndicator
207
208 RequestorIDString ::= USSD-String (SIZE (1..maxRequestorIDStringLength))
209
210
    maxRequestorIDStringLength INTEGER ::= 63
211
212
    LCS-FormatIndicator ::= ENUMERATED {
213
214
215
216
217
                                                 (0),
          logicalName
          e-mailAddress
                                                 (1),
          msisdn
                                                 (2),
          url
                                                 (3),
          sipUrl
                                                 (4).
218
219
220
    LCS-Priority ::= OCTET STRING (SIZE (1))
221
222
          -- 0 = highest priority
          -- 1 = normal priority
223
          -- all other values treated as 1
224
```

```
225
226
     LCS-QoS ::= SEQUENCE {
          horizontal-accuracy
                                                   [0] Horizontal-Accuracy
                                                                                         OPTIONAL.
227
                                                   [1] NULL
          verticalCoordinateRequest
                                                                                         OPTIONAL,
228
229
230
231
232
          vertical-accuracy
                                                   [2] Vertical-Accuracy
                                                                                         OPTIONAL,
          responseTime
                                                   [3] ResponseTime
                                                                                         OPTIONAL,
          extensionContainer
                                                   [4] ExtensionContainer
                                                                                         OPTIONAL.
          velocityRequest
                                                   [5] NULL
                                                                                         OPTIONAL
233
234
235
     Horizontal-Accuracy ::= OCTET STRING (SIZE (1))
236
237
238
          -- bit 8 = 0
           -- bits 7-1 = 7 bit Uncertainty Code defined in 3GPP TS 23.032. The horizontal location
           -- error should be less than the error indicated by the uncertainty code with 67%
239
           -- confidence
240
241
     Vertical-Accuracy ::= OCTET STRING (SIZE (1))
242
243
244
          -- bit 8 = 0
          -- bits 7-1 = 7 bit Vertical Uncertainty Code defined in 3GPP TS 23.032.
-- The vertical location error should be less than the error indicated
245
           -- by the uncertainty code with 67% confidence
246
247
     ResponseTime ::= SEQUENCE {
248
249
          responseTimeCategory
                                                   ResponseTimeCategory,
           . . . }
250
          note: an expandable SEQUENCE simplifies later addition of a numeric response time.
251
252
253
254
255
     ResponseTimeCategory ::= ENUMERATED {
          lowdelay (0),
          delaytolerant
           ...}
256
257
           exception handling:
          an unrecognized value shall be treated the same as value 1 (delaytolerant)
258
259
     SupportedGADShapes ::= BIT STRING {
260
          ellipsoidPoint (0),
261
          ellipsoidPointWithUncertaintyCircle (1),
262
263
           ellipsoidPointWithUncertaintyEllipse (2),
          polygon (3),
264
          ellipsoidPointWithAltitude (4),
265
          ellipsoidPointWithAltitudeAndUncertaintyElipsoid (5),
266
           ellipsoidArc (6) } (SIZE (7..16))
267
268
      -- A node shall mark in the BIT STRING all Shapes defined in 3GPP TS 23.032 it supports.
        exception handling: bits 7 to 15 shall be ignored if received.
269
270
271
     LCS-ReferenceNumber::= OCTET STRING (SIZE(1))
272
273
274
275
     LCSCodeword ::= SEQUENCE {
          dataCodingScheme
                                                   [0] USSD-DataCodingScheme,
          lcsCodewordString
                                                   [1] LCSCodewordString,
276
277
     LCSCodewordString ::= USSD-String (SIZE (1..maxLCSCodewordStringLength))
278
279
     maxLCSCodewordStringLength INTEGER ::= 20
280
281
282
     LCS-PrivacyCheck ::= SEQUENCE {
          callSessionUnrelated
                                                   [0] PrivacyCheckRelatedAction,
283
284
           callSessionRelated
                                                   [1] PrivacyCheckRelatedAction
                                                                                         OPTIONAL,
285
286
287
288
289
290
     PrivacyCheckRelatedAction ::= ENUMERATED {
          allowedWithoutNotification (0),
          allowedWithNotification (1),
          allowedIfNoResponse (2),
          restrictedIfNoResponse (3),
291
292
293
          notAllowed (4),
           . . . }
           exception handling:
294
          {\it a ProvideSubscriberLocation-Arg containing an unrecognized PrivacyCheckRelatedAction}
295
           shall be rejected by the receiver with a return error cause of unexpected data value
296
```

```
297
     AreaEventInfo ::= SEQUENCE {
\overline{298}
                                                      [0] AreaDefinition,
[1] OccurrenceInfo
           areaDefinition
299
                                                                                              OPTIONAL,
           occurrenceInfo
300
           intervalTime
                                                      [2] IntervalTime
                                                                                               OPTIONAL,
301
           . . . }
302
303
     AreaDefinition ::= SEQUENCE {
304
           areaList
                                                      [0] AreaList,
305
306
     AreaList ::= SEQUENCE SIZE (1..maxNumOfAreas) OF Area
307
308
309 maxNumOfAreas INTEGER ::= 10
310
311
     Area ::= SEQUENCE {
312
                                                      [0] AreaType,
           areaType
313
           areaIdentification
                                                      [1] AreaIdentification,
314
           ...}
315
316 AreaType ::= ENUMERATED {
317
318
           countryCode
                                                      (0),
           plmnId
                                                      (1),
319
320
           locationAreaId
                                                      (2),
                                                      (3),
           routingAreaId
321
           cellGlobalId
                                                      (4),
322
323
           utranCellId
                                                      (5) }
324
325
     AreaIdentification ::= OCTET STRING (SIZE (2..7))
326
327
328
329
330
331
           -- The internal structure is defined as follows:
                                                    Mobile Country Code 1<sup>st</sup> digit
Mobile Country Code 2<sup>nd</sup> digit
Mobile Country Code 3<sup>rd</sup> digit
Mobile Country Code 3<sup>rd</sup> digit
Mobile Network Code 3<sup>rd</sup> digit if 3 digit MNC included
           -- octet 1 bits 4321
                       bits 8765
           -- octet 2 bits 4321
                       bits 8765
                                                      or filler (1111)
                                                      Mobile Network Code 1<sup>st</sup> digit
Mobile Network Code 2<sup>nd</sup> digit
332
           -- octet 3 bits 4321
333
                       bits 8765
334
335
                                                      Location Area Code (LAC) for Local Area Id,
           -- octets 4 and 5
                                                      Routing Area Id and Cell Global Id
           - -
336
           -- octet 6
                                                      Routing Area Code (RAC) for Routing Area Id
337
           -- octets 6 and 7
                                                      Cell Identity (CI) for Cell Global Id
338
           -- octets 4 until 7
                                                      Utran Cell Identity (UC-Id) for Utran Cell Id
339
340
     OccurrenceInfo ::= ENUMERATED {
341
           oneTimeEvent
                                                      (0),
342
           multipleTimeEvent
                                                      (1).
343
344
     IntervalTime ::= INTEGER (1..32767)
345
346
           -- minimum interval time between area reports in seconds
347
348
     PeriodicLDRInfo ::= SEQUENCE {
349
        reportingAmount ReportingAmount,
350
          reportingInterval
                                ReportingInterval,
351
352
      -- reportingInterval x reportingAmount shall not exceed 8639999 (99 days, 23 hours,
353
      -- 59 minutes and 59 seconds) for compatibility with OMA MLP and RLP
354
355 ReportingAmount ::= INTEGER (1..maxReportingAmount)
356
357
     maxReportingAmount INTEGER ::= 8639999
358
359
     ReportingInterval ::= INTEGER (1..maxReportingInterval)
-- ReportingInterval is in seconds
360
361
362
     maxReportingInterval INTEGER ::= 8639999
363
364
     ReportingPLMNList::= SEQUENCE {
365
          plmn-ListPrioritized
                                                [0] NULL
                                                                                 OPTIONAL,
366
          plmn-List
                                                [1] PLMNList,
367
          . . . }
368
```

```
369
    PLMNList::= SEQUENCE SIZE (1..maxNumOfReportingPLMN) OF
370
                                               ReportingPLMN
371
    maxNumOfReportingPLMN INTEGER ::= 20
372
373
374
    ReportingPLMN: := SEQUENCE {
375
         plmn-Id
                                          [0] PLMN-Id,
376
         ran-Technology
                                          [1] RAN-Technology
                                                                      OPTIONAL,
377
         ran-PeriodicLocationSupport
                                         [2] NULL
                                                                      OPTIONAL,
378
379
380
    RAN-Technology ::= ENUMERATED {
381
                     (0),
         asm
382
         umts
                     (1),
383
         ...}
384
385
    ProvideSubscriberLocation-Res ::= SEQUENCE {
386
          locationEstimate
                                               Ext-GeographicalInformation,
387
          ageOfLocationEstimate
                                               [0] AgeOfLocationInformation
                                                                                  OPTIONAL.
388
          extensionContainer
                                               [1] ExtensionContainer
                                                                                  OPTIONAL,
389
390
          add-LocationEstimate
                                               [2] Add-GeographicalInformation OPTIONAL,
391
         deferredmt-lrResponseIndicator
                                               [3] NULL
                                                                                  OPTIONAL,
392
         geranPositioningData
                                               [4] PositioningDataInformation
                                                                                  OPTIONAL.
393
          utranPositioningData
                                               [5] UtranPositioningDataInfo
                                                                                  OPTIONAL.
394
         cellIdOrSai
                                               [6] CellGlobalIdOrServiceAreaIdOrLAI OPTIONAL,
395
         sai-Present
                                               [7] NULL
                                                                                OPTIONAL,
                                               [8] AccuracyFulfilmentIndicator [9] VelocityEstimate
396
         accuracyFulfilmentIndicator
                                                                                  OPTIONAL,
397
         velocitvEstimate
                                                                                  OPTIONAL.
398
         mo-lrShortCircuitIndicator
                                               [10] NULL
                                                                                  OPTIONAL,
399
          geranGANSSpositioningData
                                               [11] GeranGANSSpositioningData
                                                                                  OPTIONAL,
400
                                               [12] UtranGANSSpositioningData
         utranGANSSpositioningData
                                                                                 OPTIONAL }
401
402
     -- if deferredmt-lrResponseIndicator is set, locationEstimate is ignored.
403
404
     -- the add-LocationEstimate parameter shall not be sent to a node that did not indicate the
405
     -- geographic shapes supported in the ProvideSubscriberLocation-Arg
406
     -- The locationEstimate and the add-locationEstimate parameters shall not be sent if
407
     -- the supportedGADShapes parameter has been received in ProvideSubscriberLocation-Arg
408
     -- and the shape encoded in locationEstimate or add-LocationEstimate is not marked
409
     -- as supported in supportedGADShapes. In such a case ProvideSubscriberLocation
410
     -- shall be rejected with error FacilityNotSupported with additional indication
411
     -- shapeOfLocationEstimateNotSupported.
412
     -- sai-Present indicates that the cellIdOrSai parameter contains a Service Area Identity.
413
414
    AccuracyFulfilmentIndicator ::= ENUMERATED {
415
          requestedAccuracyFulfilled (0),
416
          requestedAccuracyNotFulfilled (1),
417
418
```

```
419 Ext-GeographicalInformation ::= OCTET STRING (SIZE (1..maxExt-GeographicalInformation))
420
          -- Refers to geographical Information defined in 3GPP TS 23.032.
421
          -- This is composed of 1 or more octets with an internal structure according to
422
423
          -- 3GPP TS 23.032
          -- Octet 1: Type of shape, only the following shapes in 3GPP TS 23.032 are allowed:
424
                    (a) Ellipsoid point with uncertainty circle
425
                     (b) Ellipsoid point with uncertainty ellipse
426
                     (c) Ellipsoid point with altitude and uncertainty ellipsoid
427
          --
                    (d) Ellipsoid Arc
428
                     (e) Ellipsoid Point
429
          -- Any other value in octet 1 shall be treated as invalid
430
          -- Octets 2 to 8 for case (a) - Ellipsoid point with uncertainty circle
431
                    Degrees of Latitude
                                                                                        3 octets
432
                    Degrees of Longitude
                                                                                        3 octets
433
                    Uncertainty code
                                                                                        1 octet
434
          -- Octets 2 to 11 for case (b) - Ellipsoid point with uncertainty ellipse:
435
          -- Degrees of Latitude
436
          --
                    Degrees of Longitude
437
                   Uncertainty semi-major axis
438
          -- Uncertainty semi-minor axis
-- Angle of major axis
-- Confidence
                                                                                        1 octet
439
                                                                                        1 octet
440
                                                                                        1 octet
441
          -- Octets 2 to 14 for case (c) - Ellipsoid point with altitude and uncertainty ellipsoid
442
                                                                                        3 octets
          -- Degrees of Latitude
443
          - -
                    Degrees of Longitude
                                                                                        3 octets
444
          Altitude
-- Uncertainty semi-major axis
-- Uncertainty semi-minor axis
-- Angle of major axis
-- Uncertainty altitude
-- Confidence
                    Altitude
                                                                                        2 octets
445
                                                                                        1 octet
446
447
                                                                                        1 octet
448
                                                                                        1 octet
449
                                                                                        1 octet
450
          -- Octets 2 to 13 for case (d) - Ellipsoid Arc
          Degrees of Longitud
Inner radius
Uncertainty radius
Offset angle
Included
451
452
453
          -- Degrees of Latitude
-- Degrees of Longitude
                                                                                        3 octets
                                                                                        3 octets
                                                                                        2 octets
454
                                                                                        1 octet
455
                                                                                        1 octet
456
457
                                                                                        1 octet
458
          -- Octets 2 to 7 for case (e) - Ellipsoid Point
-- Degrees of Latitude
459
                                                                                        3 octets
460
          --
                    Degrees of Longitude
                                                                                        3 octets
461
462
463
          -- An Ext-GeographicalInformation parameter comprising more than one octet and
464
          -- containing any other shape or an incorrect number of octets or coding according
465
          -- to 3GPP TS 23.032 shall be treated as invalid data by a receiver.
466
467
          -- An Ext-GeographicalInformation parameter comprising one octet shall be discarded
468
          -- by the receiver if an Add-GeographicalInformation parameter is received
469
          -- in the same message.
470
471
          -- An Ext-GeographicalInformation parameter comprising one octet shall be treated as
472
          -- invalid data by the receiver if an Add-GeographicalInformation parameter is not
473
          -- received in the same message.
474
```

```
maxExt-GeographicalInformation INTEGER ::= 20
```

-- the maximum length allows for further shapes in 3GPP TS 23.032 to be included in later

-- versions of 3GPP TS 29.002

475

476

477

478

```
479
    VelocityEstimate ::= OCTET STRING (SIZE (4..7))
480
          -- Refers to Velocity description defined in 3GPP TS 23.032.
481
          -- This is composed of 4 or more octets with an internal structure according to
482
          -- 3GPP TS 23.032
483
          -- Octet 1: Type of velocity, only the following types in 3GPP TS 23.032 are allowed:
484
                   (a) Horizontal Velocity
485
                   (b) Horizontal with Vertical Velocity
          --
486
          --
                   (c) Horizontal Velocity with Uncertainty
487
          --
                   (d) Horizontal with Vertical Velocity and Uncertainty
488
          -- For types Horizontal with Vertical Velocity and Horizontal with Vertical Velocity
          -- and Uncertainty, the direction of the Vertical Speed is also included in Octet 1
489
490
          -- Any other value in octet 1 shall be treated as invalid
491
          -- Octets 2 to 4 for case (a) Horizontal velocity:
492
          --
                   Bearing
                                                                                 1 octet
493
                   Horizontal Speed
                                                                                 2 octets
494
          -- Octets 2 to 5 for case (b) - Horizontal with Vertical Velocity:
495
          _ _
                   Bearing
                                                                                 1 octet
496
         --
                   Horizontal Speed
497
                   Vertical Speed
                                                                                  1 octet
498
          -- Octets 2 to 5 for case (c) - Horizontal velocity with Uncertainty:
499
                  Bearing
                                                                                  1 octet
500
501
         --
                   Horizontal Speed
                   Uncertainty Speed
502
          -- Octets 2 to 7 for case (d) - Horizontal with Vertical Velocity and Uncertainty:
503
          --
                  Bearing
                                                                                  1 octet
504
                   Horizontal Speed
                                                                                  2 octets
505
          _ _
                   Vertical Speed
                                                                                 1 octet
506
                   Horizontal Uncertainty Speed
                                                                                  1 octet
507
                   Vertical Uncertainty Speed
                                                                                  1 octet
508
```

```
PositioningDataInformation ::= OCTET STRING (SIZE (2..maxPositioningDataInformation))
```

- -- Refers to the Positioning Data defined in 3GPP TS 49.031.
- -- This is composed of 2 or more octets with an internal structure according to
- -- 3GPP TS 49.031.

509

510

511 512

513 514 515

516 517

518

519

520

521 522

523 524 525

526 527 528

529

532 533

534

535

536

537 538

539 540

```
maxPositioningDataInformation INTEGER ::= 10
```

UtranPositioningDataInfo ::= OCTET STRING (SIZE (3..maxUtranPositioningDataInfo))

- -- Refers to the Position Data defined in 3GPP TS 25.413.
- -- This is composed of the positioningDataDiscriminator and the positioningDataSet
- -- included in positionData as defined in 3GPP TS 25.413.

```
maxUtranPositioningDataInfo INTEGER ::= 11
```

```
GeranGANSSpositioningData ::= OCTET STRING (SIZE (2..maxGeranGANSSpositioningData))
```

- -- Refers to the GANSS Positioning Data defined in 3GPP TS 49.031.
- -- This is composed of 2 or more octets with an internal structure according to
- -- 3GPP TS 49.031.

```
530 maxGeranGANSSpositioningData INTEGER ::= 10
--
```

UtranGANSSpositioningData ::= OCTET STRING (SIZE (1..maxUtranGANSSpositioningData))

- -- Refers to the Position Data defined in 3GPP TS 25.413.
- -- This is composed of the GANSS-PositioningDataSet only, included in PositionData
- -- as defined in 3GPP TS 25.413.

```
maxUtranGANSSpositioningData INTEGER ::= 9
--
```

561

610

611 612

613

614

615 616

617

618

```
541
    Add-GeographicalInformation ::= OCTET STRING (SIZE (1..maxAdd-GeographicalInformation))
542
         -- Refers to geographical Information defined in 3GPP TS 23.032.
543
         -- This is composed of 1 or more octets with an internal structure according to
544
         -- 3GPP TS 23.032
545
         -- Octet 1: Type of shape, all the shapes defined in 3GPP TS 23.032 are allowed:
546
         -- Octets 2 to n (where n is the total number of octets necessary to encode the shape
547
         -- according to 3GPP TS 23.032) are used to encode the shape itself in accordance with
548
    the
549
         -- encoding defined in 3GPP TS 23.032
550
551
552
553
         -- An Add-GeographicalInformation parameter, whether valid or invalid, received
         -- together with a valid Ext-GeographicalInformation parameter in the same message
         -- shall be discarded.
554
555
         -- An Add-GeographicalInformation parameter containing any shape not defined in
556
         -- 3GPP TS 23.032 or an incorrect number of octets or coding according to
557
558
         -- 3GPP TS 23.032 shall be treated as invalid data by a receiver if not received
          -- together with a valid Ext-GeographicalInformation parameter in the same message
559
```

```
560
    maxAdd-GeographicalInformation INTEGER ::= 91
         -- the maximum length allows support for all the shapes currently defined in 3GPP TS
562
```

```
563
564
    SubscriberLocationReport-Arg ::= SEQUENCE {
565
         lcs-Event
                                               LCS-Event,
566
          lcs-ClientID
                                               LCS-ClientID.
567
         lcsLocationInfo
                                               LCSLocationInfo,
568
         msisdn
                                                [0] ISDN-AddressString
                                                                                   OPTIONAL,
569
570
                                                [1] IMSI
          imsi
                                                                                   OPTIONAL,
                                                [2] IMEI
                                                                                   OPTIONAL.
         imei
571
572
                                                [3] ISDN-AddressString
         na-ESRD
                                                                                   OPTIONAL.
         na-ESRK
                                                [4] ISDN-AddressString
                                                                                   OPTIONAL.
573
         locationEstimate
                                                [5] Ext-GeographicalInformation
                                               [6] AgeOfLocationInformation
574
575
          ageOfLocationEstimate
                                                                                   OPTIONAL,
                                               [7] SLR-ArgExtensionContainer
         slr-ArgExtensionContainer
                                                                                  OPTIONAL.
576
577
          add-LocationEstimate
                                               [8] Add-GeographicalInformation OPTIONAL,
578
          deferredmt-lrData
                                               [9] Deferredmt-lrData
                                                                                   OPTIONAL,
579
          lcs-ReferenceNumber
                                               [10] LCS-ReferenceNumber
                                                                                   OPTIONAL,
580
         geranPositioningData
                                               [11] PositioningDataInformation
                                                                                   OPTIONAL.
581
582
          utranPositioningData
                                               [12] UtranPositioningDataInfo
                                                                                   OPTIONAL,
          cellIdOrSai
                                                [13] CellGlobalIdOrServiceAreaIdOrLAI OPTIONAL,
583
         h-gmlc-Address
                                                                                   OPTIONAL,
                                               [14] GSN-Address
584
          lcsServiceTypeID
                                               [15] LCSServiceTypeID
                                                                                   OPTIONAL,
585
                                               [17] NULL
          sai-Present
                                                                                   OPTIONAL.
586
587
         pseudonymIndicator
                                               [18] NULL
                                                                                   OPTIONAL,
          accuracyFulfilmentIndicator
                                                [19] AccuracyFulfilmentIndicator OPTIONAL,
588
                                               [20] VelocityEstimate
         velocityEstimate
                                                                                   OPTIONAL.
                                               [21] SequenceNumber
[22] PeriodicLDRInfo
589
          sequenceNumber
                                                                                   OPTIONAL,
590
         periodicLDRInfo
                                                                                   OPTIONAL.
591
          mo-lrShortCircuitIndicator
                                               [23] NULL
                                                                                   OPTIONAL,
592
          geranGANSSpositioningData
                                                [24] GeranGANSSpositioningData
                                                                                   OPTIONAL,
593
         utranGANSSpositioningData
                                               [25] UtranGANSSpositioningData
                                                                                   OPTIONAL }
594
595
          -- one of msisdn or imsi is mandatory
596
          -- a location estimate that is valid for the locationEstimate parameter should
597
          -- be transferred in this parameter in preference to the add-LocationEstimate.
598
          -- the deferredmt-lrData parameter shall be included if and only if the lcs-Event
599
          -- indicates a deferredmt-lrResponse.
600
           \hbox{\it --- if the $lcs-Event indicates a} \hbox{\it deferredmt-lrResponse then the locationEstimate} \\
601
          -- and the add-locationEstimate parameters shall not be sent if the
602
          -- supportedGADShapes parameter had been received in ProvideSubscriberLocation-Arg
603
          -- and the shape encoded in locationEstimate or add-LocationEstimate was not marked
          -- as supported in supportedGADShapes. In such a case terminationCause
604
605
          -- in deferredmt-lrData shall be present with value
606
          -- shapeOfLocationEstimateNotSupported.
607
          -- If a lcs event indicates deferred mt-lr response, the lcs-Reference number shall be
608
          -- included.
609
          -- sai-Present indicates that the cellIdOrSai parameter contains a Service Area Identity.
```

```
Deferredmt-lrData ::= SEQUENCE {
     deferredLocationEventType
                                         DeferredLocationEventType,
     terminationCause
                                          [0] TerminationCause
                                                                            OPTIONAL,
     lcsLocationInfo
                                          [1] LCSLocationInfo
                                                                            OPTIONAL,
     -- lcsLocationInfo may be included only if a terminationCause is present
     -- indicating mt-lrRestart.
```

```
619
    LCS-Event ::= ENUMERATED {
620
         emergencyCallOrigination (0),
620
621
622
623
624
625
          emergencyCallRelease (1),
         mo-lr (2),
         deferredmt-lrResponse (3),
          deferredmo-lrTTTPInitiation (4)
626
627
             deferredmt-lrResponse is applicable to the delivery of a location estimate
             for an LDR initiated earlier by either the network (via an MT-LR activate deferred
628
              location) or the UE (via a deferred MO-LR TTTP initiation)
629
             exception handling:
630
              a SubscriberLocationReport-Arg containing an unrecognized LCS-Event
631
              shall be rejected by a receiver with a return error cause of unexpected data value
632
633
    TerminationCause ::= ENUMERATED {
634
         normal (0),
635
         errorundefined (1),
         internalTimeout (2),
636
637
```

```
congestion (3),
    mt-lrRestart (4),
    privacyViolation (5),
    shapeOfLocationEstimateNotSupported (6) ,
    subscriberTermination (7),
    uETermination (8),
    networkTermination (9)
-- mt-lrRestart shall be used to trigger the GMLC to restart the location procedure,
-- either because the sending node knows that the terminal has moved under coverage
-- of another MSC or SGSN (e.g. Send Identification received), or because the subscriber
-- has been deregistered due to a Cancel Location received from HLR.
-- exception handling
-- an unrecognized value shall be treated the same as value 1 (errorundefined)
```

```
| SequenceNumber ::= INTEGER (1..maxReportingAmount)
```

```
SubscriberLocationReport-Res ::= SEQUENCE {
         extensionContainer
                                                ExtensionContainer
                                                                                    OPTIONAL,
         na-ESRK
                                                [0] ISDN-AddressString
[1] ISDN-AddressString
                                                                                    OPTIONAL,
         na-ESRD
                                                                                    OPTIONAL,
          h-gmlc-Address
                                                 [2] GSN-Address
                                                                                    OPTIONAL,
         mo-lrShortCircuitIndicator
                                                [3] NULL
                                                                                    OPTIONAL,
                                                [4] ReportingPLMNList
          reportingPLMNList
                                                                                    OPTIONAL.
          lcs-ReferenceNumber
                                                [5] LCS-ReferenceNumber
                                                                                    OPTIONAL }
     -- na-ESRK and na-ESRD are mutually exclusive
     -- exception handling
668
     -- receipt of both na-ESRK and na-ESRD shall be treated the same as a return error
```

638

639

640 641

642

643

644

645

646

647

648

649 650

651

652 653

654 655

656 657

658 659

660

661

662

663

664 665

666 667

669 670

### 1 17.7.14 Void

# 18 General on MAP user procedures

## 18.1 Introduction

Clauses 18 to 25 describe the use of MAP services for GSM signalling procedures. GSM signalling procedures may involve one or several interfaces running one or several application protocols. The present document addresses only the signalling procedures which require at least the use of one MAP service.

When a signalling procedure takes place in the network, an application process invocation is created in each system component involved. Part of the application process invocation acts as a MAP user and handles one or several MAP dialogues. For each dialogue it employs an instance of the MAP service provider. It may also use other communication services to exchange information on other interfaces, but detailed description of these aspects is outside the scope of the present document.

# 18.2 Common aspects of user procedure descriptions

## 18.2.1 General conventions

For each signalling procedure the present document provides a brief textual overview accompanied by a flow diagram which represent the functional interactions between system components. Functional interactions are labelled using the MAP service name when the interaction results from a service request or by this service name followed by the symbol "ack" when this interaction results from a service response.

For each of the system components involved, the present document also provides a detailed textual description of the application process behaviour as well as an SDL diagram. SDL diagrams describe the sequence of events, as seen by the MAP-User, which occurs at MAP service provider boundaries as well as external events which occur at other interfaces and which impact on the previous sequence.

External events do not necessarily correspond to the messages of other protocols used in the system component. The MAP-user procedures are described as if a set of interworking functions (IWF) between the MAP-user and the other protocol entities was implemented (see figure 18.2/1). Such interworking functions are assumed to perform either an identity mapping or some processing or translation as required to eliminate information irrelevant to the MAP-user.

The mapping of service primitives on to protocol elements is described in clauses 14 to 17.

GSM signalling procedures are built from one or more sub-procedures (e.g. authentication, ciphering, ...). Sub-procedures from which signalling procedures are built are represented using SDL MACRO descriptions.

In case of any discrepancy between the textual descriptions and the SDL descriptions, the latter take precedence.

# 18.2.2 Naming conventions

Events related to MAP are represented by MAP service primitives. The signal names used in the SDL diagrams are derived from the service primitive names defined in clauses 7 to 12, with some lexical transformations for readability and parsability purposes (blanks between words are replaced by underscores, the first letter of each word is capitalised).

Events received and sent on other interfaces are named by appending the message or signal name to a symbol representing the interface type, with some lexical transformations for readability and parsability purposes (blanks between words are replaced by underscores, the first letter of each word is capitalised).

The following symbols are used to represent the interface types:

"I": For interfaces to the fixed network. "I" stands for ISUP interface.

"A": For interfaces between the MSC and the BSS (i.e. A-interfaces);

"Gb": For interfaces between the SGSN and the BSS (i.e. Gb-interfaces);

"OM": For network management interfaces (communication with OMC, MML interface, ...);

"SC": For interfaces to a Service Centre;

"HO\_CA": For internal interfaces to the Handover Control Application.

"US": For a local USSD application.

These naming conventions can be summarised by the following BNF description:

<Event\_Name> ::= <MAP\_Primitive> | <External\_Event>

<MAP\_Primitive> ::= <MAP\_Open> | <MAP\_Close> | <MAP\_U\_Abort> | <MAP\_P\_Abort> |

<MAP\_Specific> | <MAP\_Notice>

<MAP\_Close> ::= MAP\_Close\_Req | MAP\_Close\_Ind

<MAP\_U\_Abort> ::= MAP\_U\_Abort\_Req | MAP\_U\_Abort\_Ind

<MAP\_P\_Abort> ::= MAP\_P\_Abort\_Ind

<MAP\_Notice> ::= MAP\_Notice\_Ind

<MAP\_Specific> ::= <MAP\_Req> | <MAP\_Ind> | <MAP\_Rsp> | <MAP\_Cnf>

<MAP\_Req> ::= MAP\_<Service\_Name>\_Req

<MAP\_Ind> ::= MAP\_<Service\_Name>\_Ind

<MAP\_Rsp> ::= MAP\_<Service\_Name>\_Rsp

<MAP\_Cnf> ::= MAP\_<Service\_Name>\_Cnf

<External\_Event> ::= <Interface\_Type>\_<External\_Signal>

<Interface\_Type> ::= I | A | Gb | OM | SC | HO AC | US

<External\_Signal> ::= <Lexical\_Unit>

<Service\_Name> ::= <Lexical\_Unit>

<Lexical\_Unit> ::= <Lexical\_Component> | <Lexical\_Unit>\_ <Lexical\_Component>

<Lexical\_Component> ::= <Upper\_Case\_Letter><Letter\_Or\_Digit\_List>

<Letter\_Or\_Digit\_List> ::= <Letter\_Or\_Digit> | <Letter\_Or\_Digit\_List> <Letter\_Or\_Digit>

<Letter\_Or\_Digit> ::= <Letter> | <Digit>

<Letter> ::= <Lower\_Case\_Letter> | <Upper\_Case\_Letter>

 $<\!\!Upper\_Case\_Letter\!\!> \quad ::= A|B|C|D|E|F|G|H|I|J|K|L|M|N|O|P|Q|R|S|T|U|V|W|X|Y|Z$ 

 $<\!\!Lower\_Case\_Letter\!\!> ::= a|b|c|d|e|f|g|h|i|j|k|l|m|n|o|p|q|r|s|t|u|v|w|x|y|z$ 

<Digit> ::= 1|2|3|4|5|6|7|8|9|0

Figure 18.2/1: Interfaces applicable to the MAP-User

## 18.2.3 Convention on primitives parameters

## 18.2.3.1 Open service

When the originating and destination reference parameters shall be included in the MAP-OPEN request primitive, their value are indicated as a comment to the signal which represents this primitive.

#### 18.2.3.2 Close service

When a pre-arranged released is requested, a comment is attached to the signal which represents the MAP-CLOSE request primitive. In the absence of comment, a normal release is assumed.

## 18.2.4 Version handling at dialogue establishment

Unless explicitly indicated in subsequent clauses, the following principles regarding version handling procedures at dialogue establishment are applied by the MAP-user.

## 18.2.4.1 Behaviour at the initiating side

When a MAP user signalling procedure has to be executed, the MAP-user issues a MAP-OPEN request primitive with an appropriate application-context-name. If several names are supported (i.e. several versions) a suitable one is selected using the procedures described in clause 5.

If version n is selected (where 1 < n <= highest existing version) and a MAP-OPEN Confirm primitive is received in response to the MAP-OPEN request with a result parameter set to "refused" and a diagnostic parameter indicating "application context not supported" or "potential version incompatibility problem", the MAP-User issues a new MAP-OPEN request primitive with the equivalent version y context (where 1 <= y < n). This is informally represented in the SDL diagrams by task symbols indicating 'Perform Vr procedure".

## 18.2.4.2 Behaviour at the responding side

On receipt of a MAP-OPEN indication primitive, the MAP-User analyses the application-context-name and executes the procedure associated with the requested version context. For example, if it refers to a version one context, the associated V1 procedure is executed; if it refers to a version two context, the associated V2 procedure is executed; etc.

# 18.2.5 Abort Handling

Unless explicitly indicated in subsequent clauses, the following principles are applied by the MAP-user regarding abort handling procedures:

On receipt of a MAP-P-ABORT indication or MAP-U-ABORT Indication primitive from any MAP-provider invocation, the MAP-User issues a MAP-U-ABORT Request primitive to each MAP-provider invocation associated with the same user procedure.

If applicable a decision is made to decide if the affected user procedure has to be retried or not.

## 18.2.6 SDL conventions

The MAP SDLs make use of a number of SDL concepts and conventions, where not all of them may be widely known. Therefore, this clause outlines the use of a few concepts and conventions to improve understanding of the MAP SDLs.

The MAP User SDLs make use of SDL Processes, Procedures and Macros. Processes are independent from each other even if one process starts another one: The actions of both of them have no ordering in time. SDL Procedures and Macros are just used to ease writing of the specification: They contain parts of a behaviour used in several places, and the corresponding Procedure/Macro definition has to be expanded at the position of the Procedure/Macro call.

All Processes are started at system initialisation and live forever, unless process creation/termination is indicated explicitly (i.e. a process is created by some other process).

The direction of Input/Output Signals in the SDL graphs is used to indicate the entity to which/from which communication is directed. If a process A communicates in parallel with processes B and C, all Inputs/Outputs to/from B are directed to one side, whereas communication with C is directed to the other side. However, there has been no formal convention used that communication to a certain entity (e.g. a HLR) will always be directed to a certain side (e.g. right).

In each state all those Input Signals are listed, which result in an action and/or state change. If an Input Signal is not listed in a state, receipt of this input should lead to an implicit consumption without any action or state change (according to the SDL rules). This implicit consumption is mainly used for receipt of the MAP DELIMITER indication and for receipt of a MAP CLOSE indication, except for a premature MAP CLOSE.

## 18.3 Interaction between MAP Provider and MAP Users

Each MAP User is defined by at least one SDL process. On the dialogue initiating side, the MAP User will create a new instance of a MAP Provider implicit by issuing a MAP-OPEN request. This instance corresponds to a TC Dialogue and lives as long as the dialogue exists (see also clause 14.3). There is a fixed relation between MAP User and this Provider instance, i.e. all MAP service primitives from the MAP User for this dialogue are sent to this instance and all TC components received by this MAP Provider are mapped onto service primitives sent to this MAP User.

On the receiving side a MAP Provider instance is created implicit by receipt of a TC BEGIN indication. The corresponding MAP User is determined by the Application Context name included in this primitive, i.e. each Application Context is associated with one and only one MAP User. An instance of this User will be created implicitly by receiving a MAP-OPEN indication. Note that in some cases there exist several SDL Processes for one MAP User (Application Context), e.g. the processes Register\_SS\_HLR, Erase\_SS\_HLR, Activate\_SS\_HLR, Deactivate\_SS\_HLR, Interrogate\_SS\_HLR, and Register\_Password for the AC Network\_Functional\_SS\_Handling. In these cases, a coordinator process is introduced acting as a MAP User, which in turn starts a sub-process depending on the first MAP service primitive received.

# 19 Mobility procedures

# 19.1 Location management Procedures

The signalling procedures in this subclause support:

- Interworking between the VLR and the HLR and between the VLR and the previous VLR (PVLR) when a non-GPRS subscriber performs a location update to a new VLR service area;
- Interworking between the SGSN, the HLR and the VLR when a subscriber with both GPRS and non-GPRS subscriptions performs a routeing area update in an SGSN and the Gs interface is implemented;
- Interworking between the SGSN and the VLR when a GPRS subscriber performs a routeing area update to a new SGSN service area;
- Interworking between the HLR and the VLR and between the HLR and the SGSN to delete a subscriber record from the VLR or the SGSN;
- Interworking between the VLR and the HLR and between the SGSN and the HLR to report to the HLR that a subscriber record has been purged from the VLR or the SGSN.

The MAP co-ordinating process in the HLR to handle a dialogue opened with the network location updating context is shown in figure 19.1/1. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see clause 25.1.1.




Figure 19.1/1: Process Location\_Management\_Coordinator\_HLR

# 19.1.1 Location updating

## 19.1.1.1 General


The stage 2 specification for GPRS is in 3GPP TS 23.060 [104]. The interworking between the MAP signalling procedures and the GPRS procedures in the SGSN and the HLR is shown by the transfer of signals between these procedures.

The message flow for successful inter-VLR location updating when the IMSI can be retrieved from the PVLR is shown in figure 19.1.1/2.

The message flow for successful inter-VLR location updating when the IMSI cannot be retrieved from the PVLR is shown in figure 19.1.1/3.

The message flow for successful GPRS Attach/RA update procedure (Gs interface not installed) is shown in figure 19.1.1/4.


The message flow for successful GPRS Attach/RA update procedure combined with a successful VLR location updating (Gs interface installed) is shown in figure 19.1.1/5.



#### PVLR = Previous VLR

- A\_LU\_REQUEST (Note 1) 1)
- 2) MAP\_SEND\_IDENTIFICATION\_req/ind
- 3) MAP\_SEND\_IDENTIFICATION\_rsp/cnf
- 4) MAP\_UPDATE\_LOCATION\_req/ind
- 5) MAP\_CANCEL\_LOCATION\_req/ind
- 6)
- MAP\_CANCEL\_LOCATION\_rsp/cnf
  MAP\_ACTIVATE\_TRACE\_MODE\_req/ind (Note 2)
  MAP\_ACTIVATE\_TRACE\_MODE\_rsp/cnf (Note 2) 7)
- 8)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_reg/ind 9)
- 10) MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf
- MAP\_UPDATE\_LOCATION\_rsp/cnf 11)
- 12) A\_LU\_CONFIRM (Note 1)
- NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35]. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio
- NOTE 2: Services printed in *italics* are optional.


Figure 19.1.1/2: Message flow for location updating to a new VLR area, when the IMSI can be retrieved from the previous VLR



#### PVLR = Previous VLR

- A\_LU\_REQUEST (Note 1) 1)
- 2)
- A\_IDENTITY\_REQUEST (Note 1)
  A\_IDENTITY\_RESPONSE (Note 1) 3)
- 4) MAP\_UPDATE\_LOCATION\_req/ind
- 5) MAP\_CANCEL\_LOCATION\_req/ind
- 6) MAP\_CANCEL\_LOCATION\_rsp/cnf
- MAP\_ACTIVATE\_TRACE\_MODE\_req/ind (Note 2) 7)
- 8) MAP\_ACTIVATE\_TRACE\_MODE\_rsp/cnf (Note 2)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_req/ind 9)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf 10)
- MAP\_UPDATE\_LOCATION\_rsp/cnf 11)
- 12) A\_LU\_CONFIRM (Note 1)
- NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35]. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
- NOTE 2: Services printed in *italics* are optional.


Figure 19.1.1/3: Message flow for location updating to a new VLR area, when the IMSI cannot be retrieved from the previous VLR



#### PSGSN = Previous SGSN

- 1) Gb\_ATTACH\_REQUEST or RA\_UPDATE\_REQUEST (Note 1, note 2)
- 2) MAP\_UPDATE\_GPRS\_LOCATION\_req/ind
- 3) MAP\_CANCEL\_LOCATION\_req/ind
- 4) MAP\_CANCEL\_LOCATION\_rsp/cnf
- 5) MAP\_ACTIVATE\_TRACE\_MODE\_req/ind (Note 3)
- 6) MAP\_ACTIVATE\_TRACE\_MODE\_rsp/cnf (Note 3)
- 7) MAP\_INSERT\_SUBSCRIBER\_DATA\_req/ind
- 8) MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf
- 9) MAP\_UPDATE\_GPRS\_LOCATION\_rsp/cnf
- 10) Gb\_ATTACH\_ACCEPT or RA\_UPDATE\_ACCEPT (Note 1)
- NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35]. The services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
- NOTE 2: For security functions (authentication, ciphering, IMEI check) triggering refer to 3GPP TS 23.060 [104]. The MAP signalling invoked for these functions is described in clause 25 of the present document.
- NOTE 3: Services printed in italics are optional.
- NOTE 4: Refer to 3GPP TS 23.060 [104] for termination of the procedure and triggering of the signalling on the interface between the BSS and the SGSN.

Figure 19.1.1/4: Message flow for GPRS location updating (Gs interface not installed)



- 1) Gb\_ATTACH\_REQUEST or RA\_UPDATE\_REQUEST (Note 1, note 2)
- 2) MAP\_UPDATE\_GPRS\_LOCATION\_req/ind
- 3) MAP\_CANCEL\_LOCATION\_req/ind
- 4) MAP\_CANCEL\_LOCATION\_rsp/cnf
- MAP\_ACTIVATE\_TRACE\_MODE\_req/ind (Note 3)
  MAP\_ACTIVATE\_TRACE\_MODE\_rsp/cnf (Note 3) 5)
- 6)
- 7) MAP\_INSERT\_SUBSCRIBER\_DATA\_reg/ind
- 8) MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf
- 9) MAP\_UPDATE\_GPRS\_LOCATION\_rsp/cnf
- Gs\_LOCATION\_UPDATE\_REQUEST (Note 4) 10)
- MAP\_UPDATE\_LOCATION\_req/ind (Note 5) 11)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_req/ind 12)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf 13)
- 14) MAP\_UPDATE\_LOCATION\_rsp/cnf
- Gs\_LOCATION\_UPDATE\_ACCEPT (Note 4) 15)
- 16) Gb\_ATTACH\_ACCEPT or RA\_UPDATE\_ACCEPT (Note 1)
- 17) Gb\_TMSI\_REALLOCATION\_COMPLETE (Note 1)
- Gs\_TMSI\_REALLOCATION\_COMPLETE (Note 4) 18)
- NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35]. The services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
- NOTE 2: For security functions (authentication, ciphering, IMEI check) triggering refer to 3GPP TS 23.060 [104]. MAP processes invoked for those procedures are described in subclause 25.5.
- NOTE 3: Services printed in *italics* are optional.

- NOTE 5: For details of the procedure on the path between the SGSN and the VLR, see 3GPP TS 29.018 [106]. The services shown in chain lines indicate the trigger provided by the signalling on the path between the SGSN and the VLR, and the signalling triggered on the path between the SGSN and the VLR.
- NOTE 4: Refer to 3GPP TS 23.060 [104] for termination of the procedure and triggering of the signalling on the interface between the BSS and the SGSN.
- NOTE 5: For simplicity, the Location Cancellation procedure towards the previous VLR and optional tracing activation towards the new VLR are not shown in this figure.

Figure 19.1.1/5: Message flow for GPRS location updating (Gs interface installed)

## 19.1.1.2 Procedures in the VLR

The MAP process in the VLR for location updating for a non-GPRS subscriber is shown in figure 19.1.1/6. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

The MAP process in the VLR to retrieve the IMSI of a subscriber from the previous VLR (PVLR) is shown in figure 19.1.1/7. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2.

The process in the VLR for location updating for a GPRS subscriber when the Gs interface is installed is shown in figure 19.1.1/8.

The macro GPRS\_Location\_Update\_Completion\_VLR is shown in figure 19.1.1/9. The macro invokes a process not defined in this clause; the definition of this process can be found as follows:

Subscriber\_Present\_VLR see subclause 25.10.1.

The macro GPRS\_Update\_HLR\_VLR is shown in figure 19.1.1/10. The macro invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2;
Insert\_Subs\_Data\_VLR see subclause 25.7.1;
Activate Tracing VLR see subclause 25.9.4.

## 19.1.1.3 Procedure in the PVLR

The MAP process in the PVLR to handle a request for the IMSI of a subscriber from the new VLR is shown in figure 19.1.1/11. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1.

## 19.1.1.4 Procedure in the SGSN

The MAP process in the SGSN for location updating for a GPRS subscriber is shown in figure 19.1.1/12. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2;
Insert Subs Data SGSN see subclause 25.7.2;

Activate\_Tracing\_SGSN see subclause 25.9.5.

Sheet 2: The procedure Check\_User\_Error\_In\_Serving\_Network\_Entity is specific to Super-Charger; it is specified in 3GPP TS 23.116 [110].

## 19.1.1.5 Procedures in the HLR

The MAP process in the HLR to handle a location updating request from a VLR is shown in figure 19.1.1/13. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check\_Confirmation see subclause 25.2.2.

The MAP process in the HLR to handle a location updating request from an SGSN is shown in figure 19.1.1/14. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Check\_Indication see subclause 25.2.1;
Check\_Confirmation see subclause 25.2.2;
Control\_Tracing\_With\_SGSN\_HLR see subclause 25.9.7.

Sheet 2: The procedure Super\_Charged\_Cancel\_Location\_HLR is specific to Super-Charger; it is specified in 3GPP TS 23.116 [110]. If the HLR does not support the Super-Charger functionality, processing continues from the "No" exit of the test "Result=Pass?".

Sheet 2: The procedure Super\_Charged\_Location\_Updating\_HLR is specific to Super-Charger; it is specified in 3GPP TS 23.116 [110]. If the HLR does not support the Super-Charger functionality, processing continues from the "No" exit of the test "Result=Pass?".

Sheet 2: If the HLR supports the Administrative Restriction of Subscribers" Access feature and roaming is allowed in the VPLMN then the HLR may check the "Supported RAT Types" received from the VLR against the access restriction parameters. If this check fails then the decision box "Roaming allowed in this PLMN" shall take the exit "No".

The MAP process in the HLR to notify Short Message Service Centres that a subscriber is now reachable is shown in figure 19.1.1/15. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Alert Service Centre HLR see subclause 25.10.3.




Figure 19.1.1/6 (sheet 1 of 2): Process Update\_Location\_VLR




Figure 19.1.1/6 (sheet 2 of 2): Process Update\_Location\_VLR




Figure 19.1.1/7 (sheet 1 of 2): Process Send\_Identification\_VLR




Figure 19.1.1/7 (sheet 2 of 2): Process Send\_Identification\_VLR




Figure 19.1.1/8 (sheet 1 of 2): Process GPRS\_Update\_Location\_Area\_VLR




Figure 19.1.1/8 (sheet 2 of 2): Process GPRS\_Update\_Location\_Area\_VLR




Figure 19.1.1/9: Macro GPRS\_Location\_Update\_Completion\_VLR




Figure 19.1.1/10 (sheet 1 of 2): Macro GPRS\_Update\_HLR\_VLR




Figure 19.1.1/10 (sheet 2 of 2): Macro GPRS\_Update\_HLR\_VLR




Figure 19.1.1/11 (sheet 1 of 2): Process Send\_Identification\_PVLR




Figure 19.1.1/11 (sheet 2 of 2): Process Send\_Identification\_PVLR




Figure 19.1.1/12 (sheet 1 of 2): Process Update\_GPRS\_Location\_SGSN




Figure 19.1.1/12 (sheet 2 of 2): Process Update\_GPRS\_Location\_SGSN




Figure 19.1.1/13 (sheet 1 of 3): Process Update\_Location\_HLR




Figure 19.1.1/13 (sheet 2 of 3): Process Update\_Location\_HLR




Figure 19.1.1/13 (sheet 3 of 3): Process Update\_Location\_HLR




Figure 19.1.1/14 (sheet 1 of 2): Process Update\_GPRS\_Location\_HLR




Figure 19.1.1/14 (sheet 2 of 2): Process Update\_GPRS\_Location\_HLR




Figure 19.1.1/15: Process Subscriber\_Present\_HLR

# 19.1.2 Location Cancellation


## 19.1.2.1 General

Location cancellation is used to delete a subscriber record from the serving node (VLR or SGSN). The procedure is invoked:

- because the subscriber has registered with a new serving node, or
- because the HPLMN operator has decided to delete the subscriber record from the serving node, e.g. because the subscription has been withdrawn, or because roaming restrictions have been imposed. Location cancellation can be used to force location updating including updating of subscriber data in the serving node at the next subscriber access.

The message flow for location cancellation for a non-GPRS subscriber is shown in figure 19.1.2/1.


The message flow for location cancellation for a GPRS subscriber is shown in figure 19.1.2/2.



- 1) MAP\_UPDATE\_LOCATION\_req/ind
- MAP\_CANCEL\_LOCATION\_req/ind
- MAP\_CANCEL\_LOCATION\_rsp/cnf

NOTE: The service shown in dotted lines indicates the trigger provided by other MAP signalling.

Figure 19.1.2/1: Message flow for Location Cancellation (non-GPRS)



- 1) MAP\_UPDATE\_GPRS\_LOCATION\_req/ind
- 2) MAP\_CANCEL\_LOCATION\_req/ind
- 3) MAP\_CANCEL\_LOCATION\_rsp/cnf

NOTE: The service shown in dotted lines indicates the trigger provided by other MAP signalling.

Figure 19.1.2/2: Message flow for Location Cancellation (GPRS)

## 19.1.2.2 Procedure in the HLR

The MAP process in the HLR to cancel the location information in a VLR is shown in figure 19.1.2/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;

Check\_Confirmation see subclause 25.2.2.

The MAP process in the HLR to cancel the location information in a VLR as an independent process invoked from another process is shown in figure 19.1.2/4.

The MAP process in the HLR to cancel the location information in an SGSN is shown in figure 19.1.2/5. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;

Check\_Confirmation see subclause 25.2.2.

The MAP process in the HLR to cancel the location information in an SGSN as an independent process invoked from another process is shown in figure 19.1.2/6.

## 19.1.2.3 Procedure in the VLR

The MAP process in the VLR to handle a location cancellation request is shown in figure 19.1.2/7. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1.

## 19.1.2.4 Procedure in the SGSN

The MAP process in the SGSN to handle a location cancellation request is shown in figure 19.1.2/8. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1.




Figure 19.1.2/3: Process Cancel\_Location\_HLR




Figure 19.1.2/4: Process Cancel\_Location\_Child\_HLR




Figure 19.1.2/5: Process Cancel\_GPRS\_Location\_HLR




Figure 19.1.2/6: Process Cancel\_GPRS\_Location\_Child\_HLR




Figure 19.1.2/7: Process Cancel\_Location\_VLR




Figure 19.1.2/8: Process Cancel\_Location\_SGSN

## 19.1.3 Void


# 19.1.4 MS Purging

#### 19.1.4.1 General

O&M procedures in the VLR or SGSN can trigger MS purging either because of administrative action or because the MS has been inactive for an extended period. The O&M process in the VLR or in the SGSN should ensure that during the MS purging procedure any other attempt to access the MS record is blocked, to maintain consistency of data.


The message flow for a VLR to report MS purging to the HLR is shown in figure 19.1.4/1.

The message flow for an SGSN to report MS purging to the HLR is shown in figure 19.1.4/2.



- 1) MAP\_PURGE\_MS\_req/ind
- 2) MAP\_PURGE\_MS\_rsp/cnf

Figure 19.1.4/1: Message flow for MS purging (non-GPRS)



- 1) MAP\_PURGE\_MS\_reg/ind
- 2) MAP\_PURGE\_MS\_rsp/cnf

Figure 19.1.4/2: Message flow for MS purging (GPRS)

## 19.1.4.2 Procedure in the VLR

The MAP process in the VLR to report MS purging to the HLR is shown in figure 19.1.4/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check Confirmation see subclause 25.2.2.

## 19.1.4.3 Procedure in the SGSN

The MAP process in the SGSN to report MS purging to the HLR is shown in figure 19.1.4/4. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;

Check\_Confirmation see subclause 25.2.2.

Sheet 1: The procedure Purge\_MS\_In\_Serving\_Network\_Entity is specific to Super-Charger; it is specified in 3GPP TS 23.116 [110]. If the HLR does not support the Super-Charger functionality, processing continues from the "No" exit of the test "Result=Pass?".

#### 19.1.4.4 Procedure in the HLR

The MAP process in the HLR to handle a notification from a VLR or an SGSN that an MS record has been purged is shown in figure 19.1.4/5. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;

Check\_Indication see subclause 25.2.1.

If the notification was received from a VLR, the MAP process communicates with the location management application process specified in 3GPP TS 23.012 [23]; if the notification was received from an SGSN, the MAP process communicates with the GPRS mobility management application process specified in 3GPP TS 23.060 [104].




Figure 19.1.4/3: Process Purge\_MS\_VLR




Figure 19.1.4/4 (sheet 1 of 2): Process Purge\_MS\_SGSN




Figure 19.1.4/4 (sheet 2 of 2): Process Purge\_MS\_SGSN




Figure 19.1.4/5: Process Purge\_MS\_HLR

# 19.2 Handover procedures

# 19.2.1 General

In this subclause, the term "Inter-MSC handover" is used to denote handover or relocation between different MSCs.

The interfaces involved for Inter-MSC handover are shown in figure 19.2/1. There are two Inter-MSC handover procedures:

#### 1) Basic Inter-MSC handover:


The call is handed over from the controlling MSC(MSC—A) to another MSC(MSC—B) (figure 19.2/1a).

Figure 19.2/2 shows the message flow for a successful handover from MSC-A to MSC—B, including a request for handover number allocation from MSC-B to VLR-B.


### 2) Subsequent Inter-MSC handover:

After the call has been handed over from MSC-A to MSC-B, a further handover either to MSC-A (figure 19.2/1a) or to a third MSC (MSC-B') (figure 19.2/1b) may be necessary in order to continue the call.

Figure 19.2/3 shows the message flow for a successful subsequent handover to MSC-B'. For a successful subsequent handover to MSC-A, the messages to and from MSC-B' and VLR-B' are omitted..




# a) Basic handover procedure MSC-A to MSC-B and subsequent handover procedure MSC-B to MSC-A.



b) Subsequent handover procedure MSC-B to MSC-B'.


Figure 19.2/1: Interface structure for handover



- MAP\_PREPARE\_HANDOVER\_req/ind 1)
- 2) 3) MAP\_ALLOCATE\_HANDOVER\_NUMBER\_req/ind
- MAP\_SEND\_HANDOVER\_REPORT\_reg/ind
- 4) MAP\_PREPARE\_HANDOVER\_rsp/cnf
- 5) MAP\_SEND\_HANDOVER\_REPORT\_rsp/cnf (Note)
- 6) MAP\_PROCESS\_ACCESS\_SIGNALLING\_req/ind
- 7) MAP\_SEND\_END\_SIGNAL\_req/ind
- 8) MAP\_FORWARD\_ACCESS\_SIGNALLING\_req/ind
- 9) MAP\_PROCESS\_ACCESS\_SIGNALLING\_req/ind
- 10) MAP\_SEND\_END\_SIGNAL\_rsp/cnf

NOTE: This can be sent at any time after the connection between MSC-A and MSC-B is established.

Figure 19.2/2: Example of a successful basic handover procedure to MSC-B



- 1) MAP\_PREPARE\_HANDOVER\_req/ind
- 2) MAP\_ALLOCATE\_HANDOVER\_NUMBER\_reg/ind
- 3) MAP\_SEND\_HANDOVER\_REPORT\_req/ind
- 4) MAP\_PREPARE\_HANDOVER\_rsp/cnf
- 5) MAP\_SEND\_HANDOVER\_REPORT\_rsp/cnf (Note 1)
- 6) MAP\_PROCESS\_ACCESS\_SIGNALLING\_req/ind
- 7) MAP\_SEND\_END\_SIGNAL\_req/ind
- 8) MAP\_PREPARE\_SUBSEQUENT\_HANDOVER\_req/ind
- 9) MAP\_PREPARE\_HANDOVER\_req/ind
- 10) MAP\_ALLOCATE\_HANDOVER\_NUMBER\_req/ind
- 11) MAP\_SEND\_HANDOVER\_REPORT\_req/ind
- 12) MAP\_PREPARE\_HANDOVER\_rsp/cnf
- 13) MAP\_SEND\_HANDOVER\_REPORT\_rsp/cnf (Note 2)
- 14) MAP\_PREPARE\_SUBSEQUENT\_HANDOVER\_rsp/cnf
- 15) MAP\_PROCESS\_ACCESS\_SIGNALLING\_req/ind
- 16) MAP\_SEND\_END\_SIGNAL\_reg/ind
- 17) MAP\_SEND\_END\_SIGNAL\_rsp/cnf (Note 3)
- NOTE 1: This can be sent at any time after the connection between MSC-A and MSC-B is established.
- NOTE 2: This can be sent at any time after the connection between MSC-A and MSC-B' is established.
- NOTE 3: At this stage, the subsequent handover is complete. Any further interworking between MSC-A and MSC-B' is the same as the interworking between MSC-A and MSC-B after basic handover

Figure 19.2/3: Example of a successful subsequent handover to a third MSC

The MAP signalling procedures for inter-MSC handover support the allocation of a handover number or one or more relocation numbers and the transfer of encapsulated BSSAP or RANAP messages.

The minimum application context version for the MAP handover application context shall be:

- version 3 for inter-MSC UTRAN to UTRAN handover;
- version 3 for inter-MSC intersystem handover from GSM BSS to UTRAN;
- version 2 for inter-MSC intersystem handover from UTRAN to GSM BSS.

NOTE: If the MAP handover application context version 2 is used, subsequent handover to UTRAN is not possible.

The minimum application context version for the MAP handover application context should be version 2 for inter-MSC handover from GSM BSS to GSM BSS.

NOTE: If the MAP handover application context version 2 or lower is used, subsequent handover to UTRAN is not possible.

The BSSAP or RANAP messages encapsulated in MAP messages are processed by the Handover Control Application in each MSC. The information in the encapsulated BSSAP or RANAP messages is passed from the Handover Control Application to the MAP process at the sending end; the notation used in the SDL diagrams for the MAP processes is "HO\_CA\_MESSAGE\_ind(Message transfer)". The information in the encapsulated BSSAP or RANAP messages is passed from the MAP process to the Handover Control Application at the sending end; the notation used in the SDL diagrams for the MAP processes is "HO\_CA\_MESSAGE\_req(Message transfer)".

For details of the interworking between the A-interface and MAP procedures or the Iu-interface and MAP procedures, see 3GPP TS 23.009 [21] and 3GPP TS 29.010 [58].

# 19.2.2 Procedure in MSC-A

This subclause describes the inter-MSC handover procedure in MSC-A; it covers basic inter-MSC handover to another MSC (MSC-B) and subsequent inter-MSC handover to a third MSC (MSC-B') or back to the controlling MSC (MSC-A).

The MAP process in MSC-A to handle inter-MSC handover is shown in figure 19.2/4. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Indication see subclause 25.2.1.
Check Confirmation see subclause 25.2.2.

Communication between the MAP handover process and the Handover Control application is represented by the HO\_CA\_MESSAGE service. For a detailed description of the interworking between the Handover Control applications in different MSCs for the inter-MSC handover procedure, see 3GPP TS 23.009 [21].

### 19.2.2.1 Basic handover

The handling in MSC-A for basic inter-MSC handover is shown in sheets 1 to 6 of figure 19.2/4.

Sheet 1: The MAP\_PREPARE\_HANDOVER request may contain:

- an indication that handover number allocation is not required;
- the target Cell ID, for compatibility for handover to GSM;
- the target RNC ID, for SRNS relocation or inter-system handover from GSM to UMTS;
- the IMSI;
- UMTS encryption information and UMTS integrity protection information, which are necessary for inter-system handover from GSM to UMTS;

- GSM radio resource information (channel type).

The conditions for the presence of these parameters and the processing in MSC-B (3G\_MSC-B) are described in detail in 3GPP TS 29.010 [58] and 3GPP TS 23.009 [21].

Sheet 2: The MAP\_PREPARE\_HANDOVER confirmation contains one of:

- no handover number, if the MAP\_PREPARE\_HANDOVER request included an indication that handover number allocation is not required;
- a handover number;
- one or more relocation numbers.

Sheet 2: The MAP\_PREPARE\_HANDOVER confirmation contains BSSAP or RANAP signalling information, which is passed to the Handover Control application in MSC-A.

Sheet 2: If the MAP\_PREPARE\_HANDOVER confirmation contains an indication that MSC-B does not support multiple bearers, the Handover Control application in MSC-A may request handover of one bearer to the same cell in MSC-B.

Sheet 5: If the original MAP\_PREPARE\_HANDOVER request included a parameter indicating that handover number allocation is not required, the Handover Control application in MSC-A may request a handover number (or one or more relocation numbers); this triggers a further MAP\_PREPARE\_HANDOVER request towards MSC-B

# 19.2.2.2 Handling of access signalling

The Handover Control application in MSC-A may forward access signalling to any of the MS, RNS-B or BSS-B using the MAP\_FORWARD\_ACCESS\_SIGNALLING service; any of the MS, RNS-B or BSS-B may forward access signalling to the Handover Control application in MSC-A using the MAP\_PROCESS\_ACCESS\_SIGNALLING service. These are non-confirmed services.

# 19.2.2.3 Subsequent handover

The handling in MSC-A for subsequent inter-MSC handover is shown in sheets 7 & 8 of figure 19.2/4. If the Handover Control Application determines that the call is to be handed over to a third MSC (MSC-B') it triggers another instance of the MAP process to handle the basic handover to MSC-B', and reports the result of the subsequent handover to the instance of the MAP process which handles the dialogue with MSC-B.

Sheet 8: While the MAP process in MSC-A is waiting for the completion of subsequent handover, it relays access signalling between the Handover Control application and the MS, RNS-B or BSS-B as described in subclause 19.2.2.2.

# 19.2.3 Procedure in MSC-B

This subclause describes the handover or relocation procedure in MSC-B; it covers basic handover or relocation from the controlling MSC (MSC-A) and subsequent handover or relocation.

The MAP process in MSC-B to handle handover or relocation is shown in figure 19.2/5. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Indication see subclause 25.2.1.
Check\_Confirmation see subclause 25.2.2.

Communication between the MAP handover process and the Handover Control application is represented by the HO\_CA\_MESSAGE service. For a detailed description of the interworking between the Handover Control applications in different MSCs for the inter-MSC handover procedure, see 3GPP TS 23.009 [21].

The ordering of allocation of handover number and radio resources shown in the SDL diagrams is not mandatory.

## 19.2.3.1 Basic handover

The handling in MSC-B for basic inter-MSC handover is shown in sheets 1 to 7 of figure 19.2/5.

Sheet 2: If the MAP\_PREPARE\_HANDOVER indication included a parameter requesting multiple bearers but MSC-B does not support multiple bearers, MSC-B sends a MAP\_PREPARE\_HANDOVER response indicating that multiple bearers are not supported, and waits for a possible MAP\_PREPARE\_HANDOVER indication requesting handover of a single bearer.

Sheet 6: If the original MAP\_PREPARE\_HANDOVER indication included a parameter indicating that handover number allocation is not required, MSC-A may send a further MAP\_PREPARE\_HANDOVER request to request the allocation of a handover number (or one or more relocation numbers).

# 19.2.3.2 Handling of access signalling

The Handover Control application in MSC-A may forward access signalling to any of the MS, RNS-B or BSS-B using the MAP\_FORWARD\_ACCESS\_SIGNALLING service; any of the MS, RNS-B or BSS-B may forward access signalling to the Handover Control application in MSC-A using the MAP\_PROCESS\_ACCESS\_SIGNALLING service. These are non-confirmed services. Signals to or from any of the MS, RNS-B or BSS-B are routed through the Handover Control application in MSC-B.

# 19.2.3.3 Subsequent handover

The handling in MSC-B for subsequent inter-MSC handover is shown in sheet 8 of figure 19.2/5.

While the MAP process in MSC-B is waiting for the completion of subsequent handover, it relays access signalling between MSC-A and the MS, RNS-B or BSS-B through the Handover Control application as described in subclause 19.2.3.2.

# 19.2.4 Macro Receive Error From HO CA

This macro is used by the handover processes in MSC-A and MSC-B to receive errors from the Handover Control Application at any state of a handover process.

# 19.2.5 Procedure in VLR-B

The process in VLR-B to handle a request for a handover number is shown in figure 19.2/7. The process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Check Indication see subclause 25.2.1.




Figure 19.2/4 (sheet 1 of 8): Process HO\_MSC\_A




Figure 19.2/4 (sheet 2 of 8): Process HO\_MSC\_A




Figure 19.2/4 (sheet 3 of 8): Process HO\_MSC\_A




Figure 19.2/4 (sheet 4 of 8): Process HO\_MSC\_A




Figure 19.2/4 (sheet 5 of 8): Process HO\_MSC\_A




Figure 19.2/4 (sheet 6 of 8): Process HO\_MSC\_A




Figure 19.2/4 (sheet 7 of 8): Process HO\_MSC\_A




Figure 19.2/4 (sheet 8 of 8): Process HO\_MSC\_A




Figure 19.2/5 (sheet 1 of 8): Process HO\_MSC\_B




Figure 19.2/5 (sheet 2 of 8): Process HO\_MSC\_B




Figure 19.2/5 (sheet 3 of 8): Process HO\_MSC\_B




Figure 19.2/5 (sheet 4 of 8): Process HO\_MSC\_B




Figure 19.2/5 (sheet 5 of 8): Process HO\_MSC\_B




Figure 19.2/5 (sheet 6 of 8): Process HO\_MSC\_B




Figure 19.2/5 (sheet 7 of 8): Process HO\_MSC\_B




Figure 19.2/5 (sheet 8 of 8): Process HO\_MSC\_B




Figure 19.2/6: Macro Receive\_error\_from\_HO\_CA




Figure 19.2/7: Process HO\_VLR\_B

# 19.3 Fault recovery procedures


When a location register has restarted after a fault, the fault recovery procedures ensure that the subscriber data in the VLR or in the SGSN become consistent with the subscriber data that are stored in the HLR for the MS concerned and that the location information in the HLR, the VLR and the SGSN reflect accurately the current location of the MS.

The stage 2 specification of fault recovery procedures in location registers is 3GPP TS 23.007 [19].

# 19.3.1 VLR fault recovery procedures

## 19.3.1.1 General

Restoration of an IMSI record in a VLR can be triggered by a location registration request from the MS or by a request from the HLR for a roaming number to route a mobile terminated call to the MS. If the restoration is triggered by a location registration request from the MS, the VLR performs the location updating procedure described in 3GPP TS 23.012 [23] and subclause 19.1.1 of the present document. If the restoration is triggered by a request for a roaming number, the VLR provides the roaming number and triggers an independent dialogue to restore the subscriber data as described in 3GPP TS 23.018 [97]. The message flow for data restoration triggered by a request for a roaming number is shown in figure 19.3.1/1.



- 1) MAP\_PROVIDE\_ROAMING\_NUMBER\_reg/ind
- MAP PROVIDE ROAMING NUMBER rsp/cnf
- 3) MAP\_SEND\_AUTHENTICATION\_INFO\_req/ind (Note 1, note 2)
- 4) MAP\_SEND\_AUTHENTICATION\_INFO\_rsp/cnf (Note 1, note 2)
- 5) MAP\_RESTORE\_DATA\_req/ind
- 6) MAP\_ACTIVATE\_TRACE\_MODE\_reg/ind (Note 1, note 3)
- 7) MAP\_ACTIVATE\_TRACE\_MODE\_rsp/cnf (Note 1, note 3)
- 8) MAP\_INSERT\_SUBSCRIBER\_DATA\_req/ind
- 9) MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf
- 10) MAP\_RESTORE\_DATA\_rsp/cnf

NOTE 1: Services printed in *italics* are optional.

NOTE 2: If authentication is required.

NOTE 3: If subscriber tracing is active in the HLR.

# Figure 19.3/1: Message flow for VLR restoration at mobile terminated call set-up

# 19.3.1.2 Procedure in the VLR

The procedure in the VLR to handle a dialogue for subscriber data restoration is defined in subclause 21.2.6 of the present document.

## 19.3.1.3 Procedure in the HLR

The MAP process in the HLR to handle a request for data restoration in the VLR is shown in figure 19.3.1/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Check\_Indication see subclause 25.2.1;

Control\_Tracing\_With\_VLR\_HLR see subclause 25.9.6.




Figure 19.3.1/2: Process Restore\_Data\_HLR

#### 19.3.2 HLR fault recovery procedures

#### 19.3.2.1 General


For the HLR, periodic back-up of data to non-volatile memory is mandatory.

Data that have been changed after the last back-up and before the restart of the HLR cannot be recovered by reload from the non-volatile memory. Therefore, a restoration procedure is triggered for each IMSI record that has been affected by the HLR fault at the first authenticated radio contact with the MS concerned.

As an implementation option, a notification can be forwarded to the MS to alert the subscriber to check the parameters for supplementary services that allow subscriber controlled input (MAP\_FORWARD\_CHECK\_SS\_INDICATION service). If the VLR receives this notification from the HLR it shall forward the notification to the MS. If the Gsinterface is implemented the VLR shall not forward this notification.

The message flow for HLR restoration for a non-GPRS subscriber is shown in figure 19.3.2/1.


The message flow for HLR restoration for a GPRS subscriber is shown in figure 19.3.2/2.



- MAP\_RESET\_reg/ind 1)
- 2) MAP\_PROCESS\_ACCESS\_REQUEST\_req/ind
- 3) MAP\_UPDATE\_LOCATION\_req/ind
- 4)
- MAP\_ACTIVATE\_TRACE\_MODE\_req/ind (Note 1, Note 2)
  MAP\_ACTIVATE\_TRACE\_MODE\_rsp/cnf (Note 1, Note 2) 5)
- 6) MAP\_INSERT\_SUBSCRIBER\_DATA\_req/ind
- MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf 7)
- MAP\_UPDATE\_LOCATION\_rsp/cnf 8)
- 9) MAP\_FORWARD\_CHECK\_SS\_INDICATION\_req/ind (Note 1)
- MAP\_FORWARD\_CHECK\_SS\_INDICATION\_reg/ind (Note 1) 10)

NOTE 1: Services printed in *italics* are optional. NOTE 2: If subscriber tracing is active in the HLR.

Figure 19.3.2/1: Message flow for HLR restoration (non-GPRS)



- MAP\_RESET\_reg/ind 1)
- MAP\_UPDATE\_GPRS\_LOCATION\_req/ind 2)
- 3)
- MAP\_ACTIVATE\_TRACE\_MODE\_req/ind (Note 1, Note 2)
  MAP\_ACTIVATE\_TRACE\_MODE\_rsp/cnf (Note 1, Note 2) 4)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_req/ind 5)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf 6)
- MAP UPDATE GPRS LOCATION rsp/cnf

NOTE 1: Services printed in *italics* are optional. NOTE 2: If subscriber tracing is active in the HLR.

Figure 19.3.2/2: Message flow for HLR restoration (GPRS)

#### 19.3.2.2 Procedure in the HLR

The MAP process in the HLR to notify the relevant serving nodes that the HLR has restarted is shown in figure 19.3.2/3.

The SGSN address list includes one instance of the address of each SGSN in which (according to the HLR data retrieved from the non-volatile memory) there is at least one subscriber registered who is affected by the HLR restart.

The VLR address list includes one instance of the address of each VLR in which (according to the HLR data retrieved from the non-volatile memory) there is at least one subscriber registered who is affected by the HLR restart.

The MAP process in the HLR to notify a VLR that the HLR has restarted is shown in figure 19.3.2/4. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive Open Cnf see subclause 25.1.2.

The MAP process in the HLR to notify an SGSN that the HLR has restarted is shown in figure 19.3.2/5. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

see subclause 25.1.2. Receive\_Open\_Cnf

#### Procedure in the VLR 19.3.2.3

The MAP process in the VLR to handle a notification that an HLR has restarted is shown in figure 19.3.2/6. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1. The VLR uses the HLR number or the HLR identity list included in the MAP\_RESET indication to identify the IMSI records which are affected by the HLR restart.

# 19.3.2.4 Procedure in the SGSN

The MAP process in the SGSN to handle a notification that an HLR has restarted is shown in figure 19.3.2/6. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind

see subclause 25.1.1.

The SGSN uses the HLR number or the HLR identity list included in the MAP\_RESET indication to identify the IMSI records which are affected by the HLR restart.




Figure 19.3.2/3: Process Restart\_HLR




Figure 19.3.2/4: Process Send\_Reset\_To\_VLR\_HLR




Figure 19.3.2/5: Process Send\_Reset\_To\_SGSN\_HLR




Figure 19.3.2/6: Process Receive\_Reset\_VLR





Figure 19.3.2/7: Process Receive\_Reset\_SGSN

# 19.4 Mobility Management event notification procedure

# 19.4.1 General

The Mobility Management event notification procedure is used to notify a gsmSCF about the successful completion of a Mobility Management event.

The message flow for Mobility Management event notification is shown in figure 19.4/1.



- MAP\_REPORT\_MM\_EVENT\_reg/ind
- 2) MAP\_REPORT\_MM\_EVENT\_rsp/cnf

Figure 19.5/1: Message flow for Mobility Management event notification

# 19.4.2 Procedure in the VLR or SGSN

The MAP process in the VLR or the SGSN to report a Mobility Management event to the gsmSCF is shown in figure 19.4/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation: see subclause 25.2.2.

# 19.4.3 Procedure in the gsmSCF

The MAP process in the gsmSCF to handle the report of a Mobility Management event is shown in figure 19.4/3. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;




Figure 19.4/2: Process Notify\_MM\_Event\_VLR\_Or\_SGSN




Figure 19.4/3: Process Notify\_MM\_Event\_gsmSCF

### 19.4 HLR Insert Subscriber Data macros

### 19.5.1 Macro Insert\_Subs\_Data\_Framed\_HLR

This macro is used to transfer subscriber data to the VLR as part of an existing dialogue for location updating or data restoration. The macro invokes a macro and a process not defined in this clause; the definitions of the macro and the process can be found as follows:

Wait\_For\_Insert\_Subs\_Data\_Cnf see subclause 25.7.5;
Send Insert Subs Data HLR: see subclause 25.7.7.

The HLR may wait for each MAP\_INSERT\_SUBSCRIBER\_DATA request to be acknowledged before it sends the next request, or it may handle the requests and the confirmations in parallel.

If the VLR has indicated that it does not support a service or feature (e.g. Closed User Group or Advice Of Charge Charging Level) which the HLR operator regards as essential for the subscriber, the macro Wait\_for\_Insert\_Subs\_Data\_Cnf takes the Replace\_Service exit; the HLR sets the Roaming Restriction Due To Unsupported Feature flag to roaming restricted and sends Roaming Restriction Due To Unsupported Feature in a subsequent MAP\_INSERT\_SUBSCRIBER\_DATA request.

If the HLR operator does not regard the unsupported service or feature as essential for the subscriber but the macro Wait\_for\_Insert\_Subs\_Data\_Cnf takes the Replace\_Service exit, the HLR sends the data for a replacement service in a subsequent MAP\_INSERT\_SUBSCRIBER\_DATA request.

If subscriber data for CAMEL Phase 2 or later services are sent to a VLR which does not support the appropriate phase of CAMEL, the service behaviour may be unpredictable or incorrect. The HLR should therefore ensure that at the conclusion of a stand alone Insert Subscriber data procedure the data in the VLR do not require a capability that the VLR does not have. Possible mechanisms to ensure this are described in 3GPP TS 23.078 [98].

The HLR should send a Forwarded-to number which is not in E.164 international format to the VLR only when the HLR has ascertained that the VLR supports CAMEL Phase 2 or later. Thus, the ISD message containing the Forwarded-to number which is not in E.164 international format shall be sent to the VLR only if the HLR previously received confirmation from the VLR at Location Update that CAMEL Phase 2 or later is supported.

## 19.5.2 Macro Insert\_GPRS\_Subs\_Data\_Framed\_HLR

This macro is used to transfer subscriber data to the SGSN as part of an existing dialogue for location updating. The macro invokes a macro and a process not defined in this clause; the definitions of the macro and the process can be found as follows:

Wait\_For\_Insert\_GPRS\_Subs\_Data\_Cnf see subclause 25.7.5; Send\_Insert\_Subs\_Data\_HLR: see subclause 25.7.7.

The HLR may wait for each MAP\_INSERT\_SUBSCRIBER\_DATA request to be acknowledged before it sends the next request, or it may handle the requests and the confirmations in parallel.

If the SGSN has indicated that it does not support a service or feature which the HLR operator regards as essential for the subscriber, the macro Wait\_for\_Insert\_GPRS\_Subs\_Data\_Cnf takes the Replace\_Service exit; the HLR sets the Roaming Restricted In SGSN Due To Unsupported Feature flag to roaming restricted and sends Roaming Restricted In SGSN Due To Unsupported Feature in a subsequent MAP\_INSERT\_SUBSCRIBER\_DATA request.

If the HLR operator does not regard the unsupported service or feature as essential for the subscriber but the macro Wait\_for\_Insert\_GPRS\_Subs\_Data\_Cnf takes the Replace\_Service exit, the HLR sends the data for a replacement service in a subsequent MAP\_INSERT\_SUBSCRIBER\_DATA request.




Figure 19.5/1: Macro Insert\_Subs\_Data\_Framed\_HLR




Figure 19.5/2: Macro Insert\_GPRS\_Subs\_Data\_Framed\_HLR

# 20 Operation and maintenance procedures

### 20.1 General

The Operation and Maintenance procedures are used to support operation and maintenance of the network.

The following procedures exist for operation and maintenance purposes:

- i) Tracing procedures;
- ii) Subscriber Data Management procedures;
- iii) Subscriber Identity procedure.

The following application contexts refer to complex MAP Users consisting of several processes:

- subscriberDataManagementContext;
- tracingContext.

Each of these two application contexts needs a co-ordinating process in the VLR or in the SGSN as described in the following subclauses.

### 20.1.1 Tracing Co-ordinator for the VLR

The Tracing Co-ordinator process in the VLR is shown the figure 20.1/1. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind

see subclause 25.1.1.

## 20.1.2 Tracing Co-ordinator for the SGSN

The Tracing Co-ordinator process in the SGSN is shown in figure 20.1/2. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind

see subclause 25.1.1.

## 20.1.3 Subscriber Data Management Co-ordinator for the VLR

The Subscriber Data Management Co-ordinator process in the VLR is shown in figure 20.1/3. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind

see subclause 25.1.1.

## 20.1.4 Subscriber Data Management Co-ordinator for the SGSN

The Subscriber Data Management Co-ordinator process in the SGSN is shown in figure 20.1/4. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind

see subclause 25.1.1.




Figure 20.1/1: Process Co\_Tracing\_VLR




Figure 20.1/2: Process Co\_Tracing\_SGSN




Figure 20.1/3: Process Co\_SDM\_VLR





Figure 20.1/4: Process Co\_SDM\_SGSN

#### 20.2 Tracing procedures

Three types of tracing procedures exist:


- i) Subscriber tracing management procedures;
- ii) Subscriber tracing procedures;
- iii) Event tracing procedures.

The subscriber tracing management procedures are used to manage the status and the type of the tracing. The subscriber tracing activation procedure is used at location updating or data restoration when the trace mode of a subscriber is set active in the HLR or, as a stand alone procedure, when the subscriber is already registered and the trace mode becomes active in the HLR. The procedures to activate tracing in the VLR are shown in figures 20.2/1 and 20.2/3. The procedures to activate tracing in the SGSN are shown in figures 20.2/2 and 20.2/4.




- 1) Subscriber Tracing Activation
- 2)
- MAP\_ACTIVATE\_TRACE\_MODE\_req/ind MAP\_ACTIVATE\_TRACE\_MODE\_rsp/cnf
- Subscriber Tracing Activation Accepted

Figure 20.2/1: Stand-alone subscriber tracing activation procedure for non-GPRS




- **Subscriber Tracing Activation**
- 2) MAP\_ACTIVATE\_TRACE\_MODE\_reg/ind
- 3) MAP\_ACTIVATE\_TRACE\_MODE\_rsp/cnf
- 4) Subscriber Tracing Activation Accepted

Figure 20.2/2: Stand-alone subscriber tracing activation procedure for GPRS



- MAP\_UPDATE\_LOCATION or MAP\_RESTORE\_DATA\_req/ind 1)
- MAP\_ACTIVATE\_TRACE\_MODE\_req/ind MAP\_ACTIVATE\_TRACE\_MODE\_rsp/cnf 2)
- 3)
- MAP\_UPDATE\_LOCATION\_rsp/cnf or MAP\_RESTORE\_DATA\_rsp/cnf

Figure 20.2/3: Subscriber tracing activation procedure at location updating or data restoration




- MAP\_UPDATE\_GPRS\_LOCATION\_req/ind 1)
- 2) MAP\_ACTIVATE\_TRACE\_MODE\_req/ind MAP\_ACTIVATE\_TRACE\_MODE\_rsp/cnf
- 3)
- MAP\_UPDATE\_GPRS\_LOCATION\_rsp/cnf

Figure 20.2/4: Subscriber tracing activation procedure at GPRS location updating


The MAP\_ACTIVATE\_TRACE\_MODE request includes the IMSI, trace reference, trace type and identity of the OMC.

The subscriber tracing deactivation procedure is used when tracing of a subscriber in the VLR or in the SGSN is no longer required. The procedures are shown in figures 20.2/5 and 20.2/6.



- 1) Subscriber Tracing Deactivation
- 2) MAP\_DEACTIVATE\_TRACE\_MODE\_req/ind
- 3) MAP\_DEACTIVATE\_TRACE\_MODE\_rsp/cnf
- 4) Subscriber Tracing Deactivation Accepted


Figure 20.2/5: Subscriber tracing deactivation procedure for non-GPRS



- 1) Subscriber Tracing Deactivation
- 2) MAP\_DEACTIVATE\_TRACE\_MODE\_req/ind
- 3) MAP\_DEACTIVATE\_TRACE\_MODE\_rsp/cnf
- 4) Subscriber Tracing Deactivation Accepted

Figure 20.2/6: Subscriber tracing deactivation procedure for GPRS

The subscriber tracing procedures are used when the VLR detects any subscriber related activity for which the trace mode is activated, e.g. the VLR receives a MAP\_PROCESS\_ACCESS\_REQUEST indication. The procedure is shown in figure 20.2/7.



- 1) MAP\_PROCESS\_ACCESS\_REQUEST\_req/ind
- 2) MAP\_TRACE\_SUBSCRIBER\_ACTIVITY\_req/ind
- Subscriber tracing information

Figure 20.2/7: Subscriber tracing procedure in the serving MSC

### 20.2.1 Subscriber tracing activation procedure

### 20.2.1.1 Procedures in the HLR

A subscriber tracing activation request from the OMC starts the appropriate process in the HLR:

ATM\_With\_VLR\_HLR if tracing is required in the MSC/VLR, ATM\_With\_SGSN\_HLR if tracing is required in the SGSN.

The process in the HLR to activate tracing in the VLR is shown in figure 20.2/8. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2.

Sheet 1: If the Repeat attempt counter has reached its limit, the test "Repeat Attempt" takes the "No" exit; otherwise the test takes the "Yes" exit. The number of repeat attempts and the interval between successive repeat attempts are operator options.

The process in the HLR to activate tracing in the SGSN is shown in figure 20.2/9. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check Confirmation see subclause 25.2.2.

Sheet 1: If the Repeat attempt counter has reached its limit, the test "Repeat Attempt" takes the "No" exit; otherwise the test takes the "Yes" exit. The number of repeat attempts and the interval between successive repeat attempts are operator options.

#### 20.2.1.2 Procedure in the VLR

The process in the VLR to activate tracing in a stand-alone dialogue is shown in figure 20.2/10. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check\_Indication see subclause 25.2.1.

### 20.2.1.3 Procedure in the SGSN

The process in the SGSN to activate tracing in a stand-alone dialogue is shown in figure 20.2/11. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check\_Indication see subclause 25.2.1.

## 20.2.2 Subscriber tracing deactivation procedure

### 20.2.2.1 Procedures in the HLR

A subscriber tracing deactivation request from the OMC starts the appropriate process in the HLR: DTM\_HLR\_With\_VLR if tracing is no longer required in the MSC/VLR, DTM\_HLR\_With\_SGSN if tracing is no longer required in the SGSN.

The process in the HLR to deactivate tracing in the VLR is shown in figure 20.2/12. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2.

Sheet 1: If the Repeat attempt counter has reached its limit, the test "Repeat Attempt" takes the "No" exit; otherwise the test takes the "Yes" exit. The number of repeat attempts and the interval between successive repeat attempts are operator options.

The process in the HLR to deactivate tracing in the SGSN is shown in figure 20.2/13. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2.

Sheet 1: If the Repeat attempt counter has reached its limit, the test "Repeat Attempt" takes the "No" exit; otherwise the test takes the "Yes" exit. The number of repeat attempts and the interval between successive repeat attempts are operator options.

### 20.2.2.2 Procedure in the VLR

The process in the VLR to deactivate tracing is shown in figure 20.2/14. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check\_Indication see subclause 25.2.1.

### 20.2.2.3 Procedure in the SGSN

The process in the SGSN to deactivate tracing is shown in figure 20.2/15. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check\_Indication see subclause 25.2.1.




Figure 20.2/8 (sheet 1 of 2): Process ATM\_With\_VLR\_HLR




Figure 20.2/8 (sheet 2 of 2): Process ATM\_With\_VLR\_HLR




Figure 20.2/9 (sheet 1 of 2): Process ATM\_with\_SGSN\_HLR




Figure 20.2/9 (sheet 2 of 2): Process ATM\_with\_SGSN\_HLR




Figure 20.2/10: Process ATM\_Standalone\_VLR




Figure 20.2/11: Process ATM\_Standalone\_SGSN




Figure 20.2/12 (sheet 1 of 2): Process DTM\_with\_VLR\_HLR




Figure 20.2/12 (sheet 2 of 2): Process DTM\_with\_VLR\_HLR




Figure 20.2/13 (sheet 1 of 2): Process DTM\_with\_SGSN\_HLR




Figure 20.2/13 (sheet 2 of 2): Process DTM\_with\_SGSN\_HLR




Figure 20.2/14: Process DTM\_Standalone\_VLR





Figure 20.2/15: Process DTM\_Standalone\_SGSN

## 20.3 Subscriber data management procedures

Two types of subscriber data management procedures exist:

- 1) Subscriber Deletion;
- 2) Subscriber Data Modification.


The subscriber deletion and subscriber data modification procedures are initiated by the OMC (see figures 20.3/1, 20.3/2, 20.3/3 and 20.3/4).



- 1) Delete Subscriber
- 2) MAP\_CANCEL\_LOCATION\_req/ind
- MAP\_CANCEL\_LOCATION\_rsp/cnf
- 4) Subscriber Deleted

Figure 20.3/1: Subscriber deletion procedure for non-GPRS


In the subscriber deletion procedure for a non-GPRS subscriber the subscriber data are removed from the VLR and the HLR. The HLR uses the MAP\_CANCEL\_LOCATION service.



- 1) Delete GPRS Subscriber
- 2) MAP\_CANCEL\_LOCATION\_req/ind
- 3) MAP\_CANCEL\_LOCATION\_rsp/cnf
- 4) GPRS Subscriber Deleted

Figure 20.3/2: Subscriber deletion procedure for GPRS

In the subscriber deletion procedure for a GPRS subscriber the subscriber data are removed from the SGSN and the HLR. The HLR uses the MAP\_CANCEL\_LOCATION service.



- 1) Modify Subscriber Data
- 2) MAP\_CANCEL\_LOCATION\_req/ind, MAP\_INSERT\_SUBSCRIBER\_DATA\_req/ind or MAP\_DELETE\_SUBSCRIBER\_DATA\_req/ind
- 3) MAP\_CANCEL\_LOCATION\_rsp/cnf, MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf or MAP\_DELETE\_SUBSCRIBER\_DATA\_rsp/cnf
- 4) Subscriber Data Modified

Figure 20.3/3: Subscriber data modification procedure for non-GPRS

- 1) Modify Subscriber Data
- 2) MAP\_CANCEL\_LOCATION\_req/ind, MAP\_INSERT\_SUBSCRIBER\_DATA\_req/ind or MAP\_DELETE\_SUBSCRIBER\_DATA\_req/ind
- MAP\_CANCEL\_LOCATION\_rsp/cnf, MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf or MAP\_DELETE\_SUBSCRIBER\_DATA\_rsp/cnf
- 4) Subscriber Data Modified

Figure 20.3/4: Subscriber data modification procedure for GPRS

In the subscriber data modification procedure the subscriber data are modified in the HLR and when necessary also in the VLR or in the SGSN. The HLR initiates one of the MAP\_INSERT\_SUBSCRIBER\_DATA, MAP\_DELETE\_SUBSCRIBER\_DATA or MAP\_CANCEL\_LOCATION services depending on the modified data.

## 20.3.1 Subscriber deletion procedure

### 20.3.1.1 Procedure in the HLR

The subscriber deletion process in the HLR is shown in figure 20.3/5. The MAP process invokes processes not defined in this clause; the definitions of these processes can be found as follows:

Cancel\_GPRS\_Location\_Child\_HLR see subclause 19.1.2.2;
Cancel\_Location\_Child\_HLR see subclause 19.1.2.2.

### 20.3.1.2 Procedure in the VLR

The subscriber deletion procedure in the VLR is described in subclause 19.1.2.3 of the present document.

### 20.3.1.3 Procedure in the SGSN

The subscriber deletion procedure in the SGSN is described in subclause 19.1. 2.4 of the present document.

### 20.3.2 Subscriber data modification procedure

#### 20.3.2.1 Procedure in the HLR

The OMC can modify the subscriber data in several different ways. The modifications can be categorised in the following groups:

- 1) data shall be modified in the HLR; no effect in the VLR;
- 2) data shall be modified in both the HLR and the VLR:
- 3) withdrawal of a basic service or a supplementary service requiring change to VLR data;
- 4) modification affects the roaming permission for the subscriber and the subscriber record shall be removed from the VLR data base;
- 5) withdrawal of non-GPRS Subscription caused by a change of Network Access Mode;
- 6) data shall be modified in the HLR; no effect in the SGSN;
- 7) data shall be modified in both the HLR and the SGSN;
- withdrawal of GPRS subscription data or a basic service or a supplementary service requiring change to SGSN data;
- modification affects the roaming permission for the subscriber and the subscriber record shall be removed from the SGSN data base;
- 10) withdrawal of GPRS Subscription caused by a change of Network Access Mode;
- 11) authentication algorithm or authentication key of the subscriber is modified.

In cases 2 and 7 the HLR uses the MAP INSERT SUBSCRIBER DATA service.

In cases 3 and 8 the HLR uses the MAP\_DELETE\_SUBSCRIBER\_DATA service.

In cases 4, 5, 9, 10 and 11 the HLR uses the MAP\_CANCEL\_LOCATION service.

If the deletion of subscriber data fails, the HLR may repeat the request; the number of repeat attempts and the time in between are HLR operator options, depending on the error returned by the VLR or the SGSN.

The subscriber data modification process in the HLR is shown in figure 20.3/6. The MAP process invokes processes not defined in this clause; the definitions of these processes can be found as follows:

Insert\_Subs\_Data\_Stand\_Alone\_HLR see subclause 25.7.3;
Cancel\_Location\_Child\_HLR see subclause 19.1.2.2;
Insert\_GPRS\_Subs\_Data\_Stand\_Alone\_HLR see subclause 25.7.4;
Cancel GPRS Location Child HLR see subclause 19.1.2.2.

The macro Delete\_Subscriber\_Data\_HLR is shown in figure 20.3/7. The macro invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2.

The macro Delete\_GPRS\_Subscriber\_Data\_HLR is shown in figure 20.3/8. The macro invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2.

### 20.3.2.2 Procedures in the VLR

The process in the VLR to update subscriber data in a stand-alone dialogue is shown in figure 20.3/9. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Check\_Indication see subclause 25.2.1;
Insert\_Subs\_Data\_VLR see subclause 25.7.1.

The process in the VLR to delete subscriber data is shown in figure 20.3/10. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check\_Indication see subclause 25.2.1.

### 20.3.2.3 Procedures in the SGSN

The process in the SGSN to update subscriber data in a stand-alone dialogue is shown in figure 20.3/11. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Check\_Indication see subclause 25.2.1;
Insert\_Subs\_Data\_SGSN see subclause 25.7.2.

The process in the SGSN to delete subscriber data is shown in figure 20.3/12. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check\_Indication see subclause 25.2.1.




Figure 20.3/5: Process Delete\_Subscriber\_HLR




Figure 20.3/6 (sheet 1 of 2): Process Modify\_Data\_HLR




Figure 20.3/6 (sheet 2 of 2): Process Modify\_Data\_HLR




Figure 20.3/7: Macro Delete\_Subscriber\_Data\_HLR




Figure 20.3/8: Macro Delete\_GPRS\_Subscriber\_Data\_HLR




Figure 20.3/9 (sheet 1 of 2): Process Ins\_Subs\_Data\_Stand\_Alone\_VLR




Figure 20.3/9 (sheet 2 of 2): Process Ins\_Subs\_Data\_Stand\_Alone\_VLR




Figure 20.3/10: Process Delete\_Subs\_Data\_VLR




Figure 20.3/11 (sheet 1 of 2): Process Ins\_Subs\_Data\_Stand\_Alone\_SGSN




Figure 20.3/11 (sheet 2 of 2): Process Ins\_Subs\_Data\_Stand\_Alone\_SGSN





Figure 20.3/12: Process Delete\_Subs\_Data\_SGSN

### Subscriber Identity procedure 20.4

In the subscriber identity procedure the IMSI of the subscriber is retrieved from the HLR. The procedure is shown in figure 20.4/1.



- 1) Identity request
- 2)
- MAP\_SEND\_IMSI\_req/ind MAP\_SEND\_IMSI\_rsp/cnf 3)
- 4) Identity confirm

Figure 20.4/1: The subscriber identity procedure

#### 20.4.1 Procedure in the VLR

The subscriber identity process in the VLR is shown in figure 20.4/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

#### 20.4.2 Procedure in the HLR

The subscriber identity process in the HLR is shown in figure 20.4/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

see subclause 25.1.1; Receive\_Open\_Ind Check\_Indication see subclause 25.2.1.




Figure 20.4/2: Process Send\_IMSI\_VLR




Figure 20.4/3: Process Send\_IMSI\_HLR

# 21 Call handling procedures

### 21.1 General

The MAP call handling procedures are used:

- to retrieve routeing information to handle a mobile terminating call;
- to transfer control of a call back to the GMSC if the call is to be forwarded;
- to retrieve and transfer information between anchor MSC and relay MSC for inter MSC group calls / broadcast calls:
- to handle the reporting of MS status for call completion services;
- to handle the notification of remote user free for CCBS;
- to handle the alerting and termination of ongoing call activities for a specific subscriber;
- to handle early release of no longer needed resources.

The procedures to handle a mobile originating call and a mobile terminating call after the call has arrived at the destination MSC do not require any signalling over a MAP interface. These procedures are specified in 3GPP TS 23.018 [97].

The stage 2 specification for the retrieval of routeing information to handle a mobile terminating call is in 3GPP TS 23.018 [97]; modifications to this procedure for CAMEL are specified in 3GPP TS 23.078 [98], for optimal routeing of a basic mobile-to-mobile call in 3GPP TS 23.079 [99] and for CCBS in 3GPP TS 23.093 [107]. The interworking between the MAP signalling procedures and the call handling procedures for each entity (GMSC, HLR and VLR) is shown by the transfer of signals between these procedures.

The stage 2 specification for the transfer of control of a call back to the GMSC if the call is to be forwarded is in 3GPP TS 23.079 [99]. The interworking between the MAP signalling procedures and the call handling procedures for each entity (VMSC and GMSC) is shown by the transfer of signals between these procedures.

The stage 2 specifications for inter MSC group calls / broadcast calls are in 3GPP TS 43.068 [100] and 3GPP TS 43.069 [101]. The interworking between the MAP signalling procedures and the group call /broadcast call procedures for each entity (Anchor MSC and Relay MSC) is shown by the transfer of signals between these procedures.


The interworking between the call handling procedures and signalling protocols other than MAP are shown in 3GPP TS 23.018, 3GPP TS 23.078 and 3GPP TS 23.079 [99].

The stage 2 specification for the handling of reporting of MS status for call completion services and notification of remote user free for CCBS is in 3GPP TS 23.093 [107].

# 21.2 Retrieval of routing information


### 21.2.1 General

The message flows for successful retrieval of routeing information for a mobile terminating call are shown in figure 21.2/1 (mobile terminating call which has not been optimally routed) and 21.2/2 (mobile-to-mobile call which has been optimally routed). The message flow for successful retrieval of routeing information for a gsmSCF initiated call is shown in figure 21.2/3.




- 1) I\_IAM (Note 1)
- 2) MAP\_SEND\_ROUTING\_INFORMATION\_req/ind (Note 2)
- 3) MAP\_PROVIDE\_SUBSCRIBER\_INFO\_req/ind (Note 3, Note 4)
- 4) MAP\_PROVIDE\_SUBSCRIBER\_INFO\_rsp/cnf (Note 4)
- 5) MAP\_SEND\_ROUTING\_INFORMATION\_rsp/cnf (Note 4)
- 6) MAP\_SEND\_ROUTING\_INFORMATION\_req/ind (Note 4)
- 7) MAP\_PROVIDE\_ROAMING\_NUMBER\_req/ind
- 8) MAP\_PROVIDE\_ROAMING\_NUMBER\_rsp/cnf
- 9) MAP\_SEND\_ROUTING\_INFORMATION\_rsp/cnf
- 10) I\_IAM (Note 1)
- 11) MAP\_RESTORE\_DATA\_req/ind (Note 4)
- 12) MAP\_INSERT\_SUBSCRIBER\_DATA\_req/ind (Note 4)
- 13) MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf (Note 4)
- 12) MAP\_RESTORE\_DATA\_rsp/cnf (Note 4)
- NOTE 1: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. For further details on the TUP and ISUP procedures refer to the following ITU-T Recommendations and ETSI specification:
  - Q.721-725 Telephone User Part (TUP);
  - ETS 300 356-1 Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.
- NOTE 2: This service may also be used by an ISDN exchange for obtaining routing information from the HLR.
- NOTE 3: As a network operator option, the HLR sends MAP\_PROVIDE\_SÜBSCRİBER\_INFORMATION to the VLR. For further details on the CAMEL procedures refer to 3GPP TS 23.078 [98].
- NOTE 4: Services printed in italics are optional.

Figure 21.2/1: Message flow for retrieval of routeing information (non-optimally routed call)



- 1) I\_IAM (Note 1)
- 2) MAP\_SEND\_ROUTING\_INFORMATION\_reg/ind
- 3) MAP\_PROVIDE\_SUBSCRIBER\_INFO\_reg/ind (Note 2)
- 4) MAP\_PROVIDE\_SUBSCRIBER\_INFO\_rsp/cnf (Note 2)
- 5) MAP\_PROVIDE\_ROAMING\_NUMBER\_req/ind (Note 2)
- 6) MAP\_PROVIDE\_ROAMING\_NUMBER\_rsp/cnf (Note 2)
- 7) MAP\_SEND\_ROUTING\_INFORMATION\_rsp/cnf
- 8) I\_IAM (Note 1)
- 9) MAP\_RESTORE\_DATA\_reg/ind (Note 3)
- 10) MAP\_INSERT\_SUBSCRIBER\_DATA\_req/ind (Note 3)
- 11) MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf (Note 3)
- 12) MAP\_RESTORE\_DATA\_rsp/cnf (Note 3)
- NOTE 1: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. For further details on the TUP and ISUP procedures refer to the following ITU-T Recommendations & ETSI specification:
  - Q.721-725 Telephone User Part (TUP);
  - ETS 300 356-1 Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.
- NOTE 2: For Optimal Routeing phase 1, only one of the information flows for Provide Subscriber Info and Provide Roaming Number is used.
- NOTE 3: Services printed in italics are optional.

Figure 21.2/2: Message flow for retrieval of routeing information (optimally routed call)



- MAP\_SEND\_ROUTING\_INFORMATION\_req/ind
- 2) MAP\_SEND\_ROUTING\_INFORMATION\_rsp/cnf (Note 1)
- 3) MAP\_SEND\_ROUTING\_INFORMATION\_reg/ind (Note 1)
- 4) MAP\_PROVIDE\_ROAMING\_NUMBER\_req/ind
- 5) MAP\_PROVIDE\_ROAMING\_NUMBER\_rsp/cnf
- MAP\_SEND\_ROUTING\_INFORMATION\_rsp/cnf MAP\_RESTORE\_DATA\_req/ind (Note 1) 6)
- 7)
- 8) MAP\_INSERT\_SUBSCRIBER\_DATA\_req/ind (Note 1)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf (Note 1) 9)
- MAP\_RESTORE\_DATA\_rsp/cnf (Note 1)

NOTE 1: Services printed in *italics* are optional.

Figure 21.2/3: Message flow for retrieval of routeing information for a gsmSCF initiated call

The following MAP services are used to retrieve routing information:

MAP\_SEND\_ROUTING\_INFORMATION see subclause 10.1; MAP PROVIDE ROAMING NUMBER see subclause 10.2; MAP\_PROVIDE\_SUBSCRIBER\_INFO see subclause 8.11.2; MAP\_RESTORE\_DATA see subclause 8.10.3.

#### 21.2.2 Procedure in the GMSC

The MAP process in the GMSC to retrieve routeing information for a mobile terminating call is shown in figure 21.2/6. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

Sheet 1: if the MAP SEND ROUTING INFORMATION request included the OR Interrogation parameter, the test "OR interrogation?" takes the "Yes" exit; otherwise the test takes the "No" exit.

## 21.2.9 Process in the gsmSCF

For the purposes of retrieving routing information from the HLR, the gsmSCF takes the role of the GMSC and follows the process specified in subclause 21.2.2.

### 21.2.4 Procedure in the HLR

The MAP process in the HLR to retrieve routeing information for a mobile terminating call is shown in figure 21.2/7. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2.

Sheet 3: if the MAP\_PROVIDE\_ROAMING\_NUMBER request included the OR Interrogation parameter, the test "OR interrogation?" takes the "Yes" exit; otherwise the test takes the "No" exit.

## 21.2.5 Procedure in the VLR to provide a roaming number

The MAP process in the VLR to provide a roaming number for a mobile terminating call is shown in figure 21.2/8. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;

## 21.2.6 Procedure in the VLR to restore subscriber data

The MAP process in the HLR to restore subscriber data is shown in figure 21.2/9. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2;
Insert\_Subs\_Data\_VLR see subclause 25.7.1;
Activate Tracing VLR see subclause 25.9.4.

# 21.2.7 Procedure in the VLR to provide subscriber information

The MAP process in the VLR to provide subscriber information for a mobile terminating call subject to CAMEL invocation is shown in figure 21.2/9. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;

554




Figure 21.2/6 (sheet 1 of 2): Process SRI\_GMSC




Figure 21.2/6 (sheet 2 of 2): Process SRI\_GMSC




Figure 21.2/7 (sheet 1 of 3): Process SRI\_HLR




Figure 21.2/7 (sheet 2 of 3): Process SRI\_HLR




Figure 21.2/7 (sheet 3 of 3): Process SRI\_HLR




Figure 21.2/8: Process PRN\_VLR




Figure 21.2/9: Process Restore\_Data\_VLR





Figure 21.2/10: Process PSI\_VLR

# 21.3 Transfer of call handling

### 21.3.1 General

The message flow for successful transfer of call handling to forward a call is shown in figure 21.3/1.



- MAP\_RESUME\_CALL\_HANDLING\_req/ind
- 2) MAP\_SEND\_ROUTING\_INFORMATION\_req/ind (Note 2)
- 3) MAP\_SEND\_ROUTING\_INFORMATION\_rsp/cnf (Note 2)
- 4) MAP\_RESUME\_CALL\_HANDLING\_rsp/cnf
- 5) I\_REL (Note 1)
- 6) I IAM (Note 1)
- NOTE 1: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. For further details on the TUP and ISUP procedures refer to the following ITU-T Recommendations & ETSI specification:
  - Q.721-725 Telephone User Part (TUP);
  - ETS 300 356-1 Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.

NOTE 2: Services printed in *italics* are optional.

Figure 21.3/1: Message flow for transfer of call handling

If the HLR indicated in the response to the original request for routeing information that forwarding interrogation is required, the GMSC executes the Send Routeing Information procedure with the HLR to obtain forwarding information; otherwise the GMSC uses the forwarding data which were sent in the MAP\_RESUME\_CALL\_HANDLING req/ind.

### 21.3.2 Process in the VMSC

The MAP process in the VMSC to retrieve routeing information for a mobile terminating call is shown in figure 21.3/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;

Check\_Confirmation see subclause 25.2.2.

If the capacity of a message signal unit in the lower layers of the protocol is enough to carry all the information which has to be sent to the GMSC, the test "Segmentation needed?" takes the "No" exit; otherwise the test takes the "Yes" exit.

### 21.3.3 Process in the GMSC

The MAP process in the GMSC to handle a request for the GMSC to resume call handling is shown in figure 21.3/3. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;

If the parameter All Information Sent was present in the MAP\_RESUME\_CALL\_HANDLING indication, the test "All Information Sent" takes the "Yes" exit; otherwise the test takes the "No" exit.




Figure 21.3/2: Process RCH\_VMSC





Figure 21.3/3: Process RCH\_GMSC

# 21.4 Inter MSC Group Call Procedures

### 21.4.1 General

The message flow for successful inter MSC group call / broadcast call set-up is shown in figure 21.4/1.



- 1) I\_IAM (Note 1)
- 2) MAP\_PREPARE\_GROUP\_CALL\_req/ind
- 3) MAP\_PREPARE\_GROUP\_CALL\_rsp/cnf
- 4) I\_IAM (Note 1)
- 5) MAP\_SEND\_GROUP\_CALL\_END\_SIGNAL\_req/ind
- 6) I\_ACM (Note 1)
- 7) I\_ACM (Note 1)
- 8) MAP\_FORWARD\_GROUP\_CALL\_SIGNALLING\_req/ind (Note 2)
- 9) MAP\_PROCESS\_GROUP\_CALL\_SIGNALLING\_req/ind (Note 2)
- 10) MAP\_SEND\_GROUP\_CALL\_END\_SIGNAL\_rsp/cnf
- 11) I\_REL (Note 3)
- 12) I\_REL (Note 3)
- NOTE 1: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. For further details on the TUP and ISUP procedures refer to the following ITU-T Recommendations and ETSI specification:
  - Q.721-725 Telephone User Part (TUP);
  - ETS 300 356-1 Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.
- NOTE 2: The MAP\_FORWARD\_GROUP\_CALL\_SIGNALLING and
  - MAP\_PROCESS\_GROUP\_CALL\_SIGNALLING services are not applicable for voice broadcast calls.
- NOTE 3: The call can be released from the PSTN/ISDN or the Relay MSC

Figure 21.4/1: Message flow for inter MSC group call / broadcast call

### 21.4.2 Process in the Anchor MSC

The MAP process in the Anchor MSC to retrieve and transfer information from / to the Relay MSC for VBS and VGCS calls is shown in figure 21.4/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Indication see subclause 25.2.1; Check\_Confirmation see subclause 25.2.2.

# 21.4.3 Process in the Relay MSC

The MAP process in the Relay MSC to receive and transfer information from / to the Anchor MSC for VBS and VGCS calls is shown in figure 21.4/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.2; Check\_Indication see subclause 25.2.1.




Figure 21.4/2 (sheet 1 of 2): Process ASCI\_Anchor\_MSC




Figure 21.4/2 (sheet 2 of 2): Process ASCI\_Anchor\_MSC




Figure 21.4/3 (sheet 1 of 2): Process ASCI\_Relay\_MSC




Figure 21.4/3 (sheet 2 of 2): Process ASCI\_Relay\_MSC

# 21.4A Inter MSC Group Call Info Retrieval

### 21.4A.1 General

The message flow for successful inter MSC group call info retrieval is shown in figure 21.4A/1.




Figure 21.4A/1: Message flow for inter MSC group call info retrieval

### 21.4A.2 Process in the MSC

The MAP process in the MSC to retrieve and group call information is shown in figure 21.4A/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2.
Receive\_Open\_Ind see subclause 25.1.2;




Figure 21.4A/2 (sheet 1 of 2): Process Group\_Call\_Info\_Retrieval\_MSC




Figure 21.4A/2 (sheet 2 of 2): Process Group\_Call\_Info\_Retrieval\_MSC

### 21.5 Void

# 21.6 CCBS: monitoring and reporting the status of the subscriber


## 21.6.1 Reporting co-ordinator process in the VLR

The MAP co-ordinating process in the VLR to handle a dialogue opened with the reporting application context is shown in figure 21.6/6. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1.

# 21.6.2 Setting the reporting state – stand-alone

The message flow for setting the reporting state in a stand-alone dialogue is shown in figure 21.6/1.



- 1) MAP\_SET\_REPORTING\_STATE\_req/ind
- 2) MAP\_SET\_REPORTING\_STATE\_rsp/cnf

Figure 21.6/1: Message flow for setting the reporting state – stand-alone dialogue

### 21.6.2.1 Process in the HLR

The MAP process in the HLR to set the reporting state in the VLR in a stand-alone dialogue is shown in figure 21.6/7. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

The result of a request to stop reporting is not reported to the CCBS application in the HLR.


### 21.6.2.2 Process in the VLR

The MAP process in the VLR to set the reporting state is shown in figure 21.6/8.

The macro Set\_Reporting\_State\_VLR is shown in figure 21.6/9.


# 21.6.3 Status Reporting

The message flows for reporting the status of a subscriber are shown in figures 21.6/2 and 21.6/3.



- MAP\_STATUS\_REPORT\_req/ind 1)
- 2) MAP\_STATUS\_REPORT\_rsp/cnf

Figure 21.6/2: Message flow for status reporting, when monitoring continues in the VLR



- MAP\_STATUS\_REPORT\_req/ind 1)
- 2)
- MAP\_STATUS\_REPORT\_rsp/cnf MAP\_SET\_REPORTING\_STATE\_req/ind 3)
- MAP\_SET\_REPORTING\_STATE\_rsp/cnf

Figure 21.6/3: Message flow for status reporting, when monitoring stops

The MAP\_SET\_REPORTING\_STATE request is used to stop monitoring in the VLR. If the HLR requires the VLR to continue monitoring, it closes the dialogue without sending a MAP\_SET\_REPORTING\_STATE request.

#### 21.6.3.1 Process in the VLR

The MAP process in the VLR to send a status report to the HLR is shown in figure 21.6/10. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

see subclause 25.1.2; Receive\_Open\_Cnf Check\_Confirmation see subclause 25.2.2.

This process can be used to report:

- an event, such as the user becoming free, or
- the result of a CCBS call attempt

to the HLR

#### 21.6.3.2 Process in the HLR

The MAP process in the HLR to handle a status report is shown in figure 21.6/11. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;

It is an implementation option whether to send the MAP\_DELIMITER request before invoking the macro Set\_Reporting\_State\_HLR.


The macro Receive\_Status\_Report\_HLR is shown in figure 21.6/12.

The macro Set\_Reporting\_State\_HLR is shown in figure 21.6/13. The macro invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check\_Confirmation see subclause 25.2.2.

### 21.6.4 CCBS: Remote User Free

The message flows for handling remote user free are shown in figures 21.6/4 and 21.6/5.



- 1) MAP\_REMOTE\_USER\_FREE\_req/ind
- 2) MAP\_REMOTE\_USER\_FREE\_rsp/cnf

Figure 21.6/4: Remote User Free: recall not accepted



- 1) MAP\_REMOTE\_USER\_FREE\_req/ind
- 2) MAP\_REMOTE\_USER\_FREE\_rsp/cnf
- 3) MAP\_STATUS\_REPORT\_req/ind
- MAP\_STATUS\_REPORT\_rsp/cnf

#### Figure 21.6/5: Remote User Free: recall accepted

#### 21.6.4.1 Process in the HLR

The MAP process in the HLR to handle Remote User Free is shown in figure 21.6/14. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

#### 21.6.3.2 Process in the VLR

The MAP process in the VLR to handle Remote User Free is shown in figure 21.6/15. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check\_Confirmation see subclause 25.2.2.




Figure 21.6/6: Process Reporting\_Coord\_VLR




Figure 21.6/7: Process Set\_Reporting\_State\_Stand\_Alone\_HLR




Figure 21.6/8: Process Set\_Reporting\_State\_VLR




Figure 21.6/9: Macro Receive\_Set\_Reporting\_State\_VLR




Figure 21.6/10 (sheet 1 of 2): Process Send\_Status\_Report\_VLR




Figure 21.6/10 (sheet 2 of 2): Process Send\_Status\_Report\_VLR




Figure 21.6/11: Process Status Report\_HLR




Figure 21.6/12: Macro Receive\_Status\_Report\_HLR




Figure 21.6/13: Macro Set\_Reporting\_State\_HLR




Figure 21.6/14: Process Remote\_User\_Free\_HLR




Figure 21.6/15 (sheet 1 of 2): Process Remote\_User\_Free\_VLR




Figure 21.6/15 (sheet 2 of 2): Process Remote\_User\_Free\_VLR

### 21.7 Void


## 21.8 Void

# 21.9 Immediate Service Termination (IST)

#### 21.9.1 IST Alert

The Immediate Service Termination Alert procedure is used to keep track of the call activities performed by subscribers who are marked as being subject to IST monitoring and, possibly, to terminate the call activities for which the alert was sent, or all the call activities related to the subscriber for whom the alert was sent.

The message flow for alerting is shown in figure 21.9/1; the MSC may be a Visited MSC or a Gateway MSC.



- 1) MAP\_IST\_ALERT\_req/ind
- 2) MAP\_IST\_ALERT\_rsp/cnf

Figure 21.9/1: Message flow for IST Alert

#### 21.9.1.1 Procedure in the MSC

The MAP process in the MSC (Visited MSC or Gateway MSC) is shown in figure 21.9/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check Confirmation see subclause 25.2.2.

#### 21.9.1.2 Procedure in the HLR


The MAP process in the HLR is shown in figure 21.9/4. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;

### 21.9.2 IST Command

The Immediate Service Termination Command procedure is used to terminate the call activities related to a subscriber.

The message flow for the IST Command procedure is shown in figure 21.9/2; the MSC may be a Visited MSC or a Gateway MSC.



- 1) MAP\_IST\_COMMAND\_req/ind
- 2) MAP\_IST\_COMMAND\_rsp/cnf

Figure 21.9/2: Message flow for IST Command

#### 21.9.2.1 Procedure in the HLR

The MAP process in the HLR is shown in figure 21.9/5. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

#### 21.9.2.2 Procedure in the MSC

The MAP process in the MSC is shown in figure 21.9.6. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1.




Figure 21.9/3: Process IST\_Alert\_MSC




Figure 21.9/4: Process IST\_Alert\_HLR




Figure 21.9/5: Process IST\_Command\_HLR





Figure 21.9/6: Process IST\_Command\_MSC

## 21.10 Resource Management

#### 21.10.1 General

The message flow for successful release of resources is shown in figure 21.10/1.



- 1) I\_IAM (Note 1)
- 2) MAP\_SEND\_ROUTING\_INFORMATION\_req/ind
- 3) MAP\_PROVIDE\_ROAMING\_NUMBER\_req/ind
- 4) I\_REL (Note 1)
- 5) MAP\_PROVIDE\_ROAMING\_NUMBER\_rsp/cnf
- 6) MAP\_SEND\_ROUTING\_INFORMATION\_rsp/cnf
- 7) MAP\_RELEASE\_RESOURCES (Note 2)
- NOTE 1: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. For further details on the TUP and ISUP procedures refer to the following ITU-T Recommendations & ETSI specification:
  - Q.721-725 Telephone User Part (TUP);
  - ETS 300 356-1 Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.

NOTE 2: Services printed in *italics* are optional.

Figure 21.10/1: Message flow for early release of resources

### 21.3.2 Process in the GMSC

The MAP process in the GMSC to release resources is shown in figure 21.10/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

#### 21.3.3 Process in the VMSC

The MAP process in the VMSC to handle a request for the GMSC to release resources is shown in figure 21.10/3. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;




Figure 21.10/2: Process Release Resources\_GMSC




Figure 21.10/3: Process Release Resources\_VMSC

# 22 Supplementary services procedures

## 22.1 Supplementary service co-ordinator processes

## 22.1.1 Supplementary service co-ordinator process for the MSC

The co-ordinator process in the MSC to handle a CM connection request with CM service type Supplementary service activation is shown in figure 22.1/1. The process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Process\_Access\_Request\_MSC see subclause 25.4.1.

#### 22.1.2 Void

## 22.1.3 Functional supplementary service co-ordinator process for the HLR

The MAP co-ordinator process in the HLR to handle a dialogue opened with the networkFunctionalSS application context is shown in figure 22.1/3. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1.

# 22.1.4 Call completion supplementary service co-ordinator process for the HLR

The MAP co-ordinator process in the HLR to handle a dialogue opened with the callCompletion application context is shown in figure 22.1/4. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive Open Ind see subclause 25.1.1.




Figure 22.1/1 (sheet 1 of 2): Process SS\_Coordinator\_MSC




Figure 22.1/1 (sheet 2 of 2): Process SS\_Coordinator\_MSC
Figure 22.1/2 void




Figure 22.1/3: Process SS\_Coordinator\_HLR




Figure 22.1/4: Process CC\_Coordinator\_HLR

#### 22.2 Registration procedure

#### 22.2.1 General

The registration procedure is used to register data related to a supplementary service in the HLR. The registration procedure is a fully transparent communication between the MS and the HLR, except that some services may be invoked as a result of the procedure, as described in the clauses below.


The registration procedure is shown in figure 22.2.1/1.

The following services may be used:

MAP\_PROCESS\_ACCESS\_REQUEST (see clauses 8 and 25); MAP\_TRACE\_SUBSCRIBER\_ACTIVITY (see clauses 9 and 25); MAP PROVIDE IMSI (see clauses 8 and 25); MAP\_FORWARD\_NEW\_TMSI (see clauses 8 and 25); MAP\_AUTHENTICATE (see clauses 8 and 25); MAP\_SET\_CIPHERING\_MODE (see clauses 8 and 25); MAP\_CHECK\_IMEI (see clauses 8 and 25); MAP\_READY\_FOR\_SM (see clauses 12 and 25); MAP\_INSERT\_SUBSCRIBER\_DATA (see clauses 8 and 25);

The following service is certainly used:

MAP\_REGISTER\_SS (defined in clause 11).



- 1) A\_CM\_SERV\_REQ (Note 1)
- 2) MAP\_PROCESS\_ACCESS\_REQUEST (Note 2)
- 3) A\_REGISTER\_SS (Note 1)
- 4) MAP\_REGISTER\_SS\_req/ind
- 5)
- MAP\_REGISTER\_SS\_req/ind MAP\_REGISTER\_SS\_rsp/cnf 6)
- 7) MAP\_REGISTER\_SS\_rsp/cnf
- 8) A\_REGISTER\_SS ack (Note 1)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_req/ind (Note 3) 9)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf (Note 3) 10)

NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35], 3GPP TS 24.010 [36], 3GPP TS 24.08x and 3GPP TS 24.09x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.

NOTE 2: For details of the Process Access Request procedure, refer to subclause 25.4 in the present document.

NOTE 3: Services printed in *italics* are optional.

Figure 22.2.1/1: Message flow for supplementary service registration

### 22.2.2 Procedure in the MSC

The A\_REGISTER\_SS service indication received by the MAP process in the MSC contains the SS-Code and any parameters that are related to the supplementary service.

The MAP user transfers the received information to the VLR in the MAP\_REGISTER\_SS request without checking the contents of the service indication. Rules for the mapping are described in 3GPP TS 29.011 [59].

The information in the MAP\_REGISTER\_SS confirm from the VLR is relayed to the MS in the A\_REGISTER\_SS response message as described in 3GPP TS 24.08x, 3GPP TS 24.08x and 3GPP TS 29.011.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]).

The registration process in the MSC is shown in figure 22.2.2/1.

#### 22.2.3 Procedure in the VLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2;
Process Access Request VLR see subclause 25.4.2.

The MAP process in the VLR transfers the information received in the MAP\_REGISTER\_SS indication to the HLR in the MAP\_REGISTER\_SS request without checking the contents. The MAP\_OPEN request includes the IMSI of the subscriber as the destination reference and the VLR number as the originating reference.

If the MAP\_REGISTER\_SS confirm is properly formed and contains a result or a user error, the MAP process in the VLR shall transfer the information contained in this primitive to the MSC in the MAP\_REGISTER\_SS response.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]).

The registration process in the VLR is shown in figure 22.2.3/1.

### 22.2.4 Procedure in the HLR

The MAP process invokes a macro and a process not defined in this clause; the definitions of the macro and process can be found as follows:

Check\_Indication see subclause 25.2.1;
Insert\_Subs\_Data\_Stand\_Alone\_HLR see subclause 25.7.3.

The supplementary service request shall be processed according to 3GPP TS 23.011 [22] and the 23.08x and 23.09x-series of technical specifications. This handling may lead to a successful result, a partially successful result or an error being returned.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]):

The registration process in the HLR is shown in figure 22.2.4/1.




Figure 22.2.2/1: Process Register\_SS\_MSC




Figure 22.2.3/1 (sheet 1 of 2): Process Register\_SS\_VLR




Figure 22.2.3/1 (sheet 2 of 2): Process Register\_SS\_VLR




Figure 22.2.4/1: Process Register\_SS\_HLR

#### 22.3 Erasure procedure

#### 22.3.1 General

The erasure procedure is used to erase data related to a supplementary service in the HLR. The erasure procedure is a fully transparent communication between the MS and the HLR, except that some services may be invoked as a result of the procedure, as described in the clauses below.


The erasure procedure is shown in figure 22.3.1/1.

The following services may be used:

MAP\_PROCESS\_ACCESS\_REQUEST (see clauses 8 and 25); MAP\_TRACE\_SUBSCRIBER\_ACTIVITY (see clauses 9 and 25); MAP\_PROVIDE\_IMSI (see clauses 8 and 25); MAP\_FORWARD\_NEW\_TMSI (see clauses 8 and 25); MAP\_AUTHENTICATE (see clauses 8 and 25); MAP\_SET\_CIPHERING\_MODE (see clauses 8 and 25); MAP\_CHECK\_IMEI (see clauses 8 and 25); MAP\_READY\_FOR\_SM (see clauses 12 and 25); MAP\_INSERT\_SUBSCRIBER\_DATA (see clauses 8 and 25);

The following service is certainly used:

MAP\_ERASE\_SS (defined in clause 11).



- 1) A\_CM\_SERV\_REQ (Note 1)
- 2) MAP\_PROCESS\_ACCESS\_REQUEST (Note 2)
- 3) A\_ERASE\_SS (Note 1)
- 4) MAP\_ERASE\_SS\_req/ind
- 5)
- MAP\_ERASE\_SS\_req/ind MAP\_ERASE\_SS\_rsp/cnf 6)
- MAP\_ERASE\_SS\_rsp/cnf 7) 8) A\_ERASE\_SS ack (Note 1)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_req/ind (Note 3) 9)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf (Note 3) 10)

- NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35], 3GPP TS 24.010 [36], 3GPP TS 24.08x and 3GPP TS 24.09x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
- NOTE 2: For details of the Process Access Request procedure, refer to subclause 25.4 in the present document.
- NOTE 3: Services printed in italics are optional.

Figure 22.3.1/1: Message flow for supplementary service erasure

## 22.3.2 Procedure in the MSC

The MSC procedure for erasure is identical to that specified for registration in subclause 22.2.2. The text and diagrams in subclause 22.2.2 apply with all references to registration changed to erasure.

### 22.3.3 Procedure in the VLR

The VLR procedure for erasure is identical to that specified for registration in subclause 22.2.3. The text and diagrams in subclause 22.2.3 apply with all references to registration changed to erasure.

#### 22.3.4 Procedure in the HLR

The HLR procedure for erasure is identical to that specified for registration in subclause 22.2.4. The text and diagrams in subclause 22.2.4 apply with all references to registration changed to erasure.

## 22.4 Activation procedure

### 22.4.1 General

The fo

The activation procedure is used to activate a supplementary service in the HLR. The activation procedure is a fully transparent communication between the MS and the HLR, except that some services may be invoked as a result of the procedure, as described in the clauses below.

(see clauses 8 and 25):

The activation procedure is shown in figure 22.4.1/1.


MAP PROCESS ACCESS REQUEST

The following services may be used:

MAP\_ACTIVATE\_SS

MINI_INCCESS_NCCESS_NEQCEST	(see clauses o and 23);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(see clauses 9 and 25);
MAP_PROVIDE_IMSI	(see clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(see clauses 8 and 25);
MAP_AUTHENTICATE	(see clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(see clauses 8 and 25);
MAP_CHECK_IMEI	(see clauses 8 and 25);
MAP_READY_FOR_SM	(see clauses 12 and 25);
MAP_GET_PASSWORD	(defined in clause 11);
MAP_INSERT_SUBSCRIBER_DATA	(see clauses 8 and 25);
ollowing service is certainly used:	

(defined in clause 11).



- 1) A\_CM\_SERV\_REQ (Note 1)
- MAP\_PROCESS\_ACCESS\_REQUEST (Note 2) 2)
- 3) A\_ACTIVATE\_SS (Note 1)
- MAP\_ACTIVATE\_SS\_req/ind MAP\_ACTIVATE\_SS\_req/ind 4)
- 5)
- 6) MAP\_GET\_PASSWORD\_reg/ind (Note 3)
- 7) MAP\_GET\_PASSWORD\_req/ind (Note 3)
- 8) A\_GET\_PASSWORD (Note 1, Note 3)
- 9) A\_GET\_PASSWORD ack (Note 1, Note 3)
- 10) MAP\_GET\_PASSWORD\_rsp/cnf (Note 3)
- 11) MAP GET PASSWORD rsp/cnf (Note 3)
- MAP\_ACTIVATE\_SS\_rsp/cnf 12)
- MAP\_ACTIVATE\_SS\_rsp/cnf 13)
- A\_ACTIVATE\_SS ack (Note 1) 14)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_req/ind (Note 3) 15)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf (Note 3) 16)
- NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35], 3GPP TS 24.010 [36], 3GPP TS 24.08x and 3GPP TS 24.09x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
- NOTE 2: For details of the Process Access Request procedure, refer to subclause 25.4 of this document.
- NOTE 3: Services printed in *italics* are optional.

Figure 22.4.1/1: Message flow for supplementary service activation

#### 22.4.2 Procedure in the MSC

The A\_ACTIVATE\_SS service indication received by the MAP user in the MSC contains the SS-Code and any parameters related to the supplementary service.

The MSC transfers the received information to the VLR in the MAP ACTIVATE SS request without checking the contents of the service indication. Rules for the mapping are described in 3GPP TS 29.011 [59].

The information in the MAP\_ACTIVATE\_SS confirm from the VLR is relayed to the MS in the A\_ACTIVATE\_SS response message, as described in TS 24.08x, 3GPP TS 24.08x and 3GPP TS 29.011.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]).

The activation process in the MSC is shown in figure 22.4.2/1.

#### 22.4.3 Procedure in the VLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2;
Process Access Request VLR see subclause 25.4.2.

The MAP process in the VLR transfers the information received in the MAP\_ACTIVATE\_SS indication to the HLR in the MAP\_ACTIVATE\_SS request without checking the contents. The MAP\_OPEN request includes the IMSI of the subscriber as the destination reference and the VLR number as the originating reference.

If the MAP\_REGISTER\_SS confirm is properly formed and contains a result or a user error, the MAP process in the VLR shall transfer the information contained in this primitive to the MSC in the MAP\_ACTIVATE\_SS response.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]).

The activation process in the VLR is shown in figure 22.4.3/1.

#### 22.4.4 Procedure in the HLR

The MAP process invokes a macro and a process not defined in this clause; the definitions of the macro and process can be found as follows:

Check\_Indication see subclause 25.2.1;
Insert\_Subs\_Data\_Stand\_Alone\_HLR see subclause 25.7.3.

The supplementary service request shall be processed according to 3GPP TS 23.011 [22] and the 23.08x and 23.09x-series of technical specifications. This handling may lead to a successful result, a partially successful result or an error being returned.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]):

The activation process in the HLR is shown in figure 22.4.4/1.




Figure 22.4.2/1: Process Activate\_SS\_MSC




Figure 22.4.3/1 (sheet 1 of 2): Process Activate\_SS\_VLR




Figure 22.4.3/1 (sheet 2 of 2): Process Activate\_SS\_VLR




Figure 22.4.4/1 (sheet 1 of 2): Process Activate\_SS\_HLR




Figure 22.4.4/1 (sheet 2 of 2): Process Activate\_SS\_HLR

# 22.5 Deactivation procedure

## 22.5.1 General

The deactivation procedure is used to deactivate a supplementary service in the HLR. The deactivation procedure is a fully transparent communication between the MS and the HLR, except that some services may be invoked as a result of the procedure, as described in the clauses below.


The deactivation procedure is shown in figure 22.5.1/1.

The following services may be used:

MAP\_PROCESS\_ACCESS\_REQUEST (see clauses 8 and 25); MAP\_TRACE\_SUBSCRIBER\_ACTIVITY (see clauses 9 and 25); MAP\_PROVIDE\_IMSI (see clauses 8 and 25); MAP\_FORWARD\_NEW\_TMSI (see clauses 8 and 25); MAP\_AUTHENTICATE (see clauses 8 and 25); MAP\_SET\_CIPHERING\_MODE (see clauses 8 and 25); MAP\_CHECK\_IMEI (see clauses 8 and 25); (see clauses 12 and 25); MAP\_READY\_FOR\_SM MAP\_GET\_PASSWORD (defined in clause 11); MAP\_INSERT\_SUBSCRIBER\_DATA (see clauses 8 and 25);

The following service is certainly used:

MAP\_DEACTIVATE\_SS (defined in clause 11).



1) A\_CM\_SERV\_REQ (Note 1)

- MAP PROCESS ACCESS REQUEST (Note 2) 2) 3) A\_DEACTIVATE\_SS (Note 1)
- MAP\_DEACTIVATE\_SS\_req/ind 4) 5) MAP\_DEACTIVATE\_SS\_req/ind
- 6) MAP\_GET\_PASSWORD\_reg/ind (Note 3)
- 7) MAP\_GET\_PASSWORD\_req/ind (Note 3)
- 8) A GET PASSWORD (Note 1, Note 3)
- 9) A\_GET\_PASSWORD ack (Note 1, Note 3)
- 10) MAP\_GET\_PASSWORD\_rsp/cnf (Note 3)
- MAP\_GET\_PASSWORD\_rsp/cnf (Note 3) 11)
- MAP\_DEACTIVATE\_SS\_rsp/cnf MAP\_DEACTIVATE\_SS\_rsp/cnf 12)
- 13)
- A\_DEACTIVATE\_SS ack (Note 1) 14)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_reg/ind (Note 3) 15)
- MAP\_INSERT\_SUBSCRIBER\_DATA\_rsp/cnf (Note 3) 16)
- NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35], 3GPP TS 24.010 [36], 3GPP TS 24.08x and 3GPP TS 24.09x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
- NOTE 2: For details of the Process Access Request procedure, refer to subclause 25.4 in the present document.
- NOTE 3: Services printed in *italics* are optional.

Figure 22.5.1/1: Message flow for supplementary service deactivation

#### 22.5.2 Procedure in the MSC

The MSC procedure for deactivation is identical to that specified for activation in subclause 22.4.2. The text and diagrams in subclause 22.4.2 apply with all references to activation changed to deactivation.

#### 22.5.3 Procedures in the VLR

The VLR procedure for deactivation is identical to that specified for activation in subclause 22.4.3. The text and diagrams in subclause 22.4.3 apply with all references to activation changed to deactivation.

#### 22.5.4 Procedures in the HLR

The HLR procedure for deactivation is identical to that specified for activation in subclause 22.4.4. The text and diagrams in subclause 22.4.4 apply with all references to activation changed to deactivation.

#### 22.6 Interrogation procedure

#### 22.6.1 General

The interrogation procedure is used to retrieve information related to a supplementary service from the VLR or the HLR. It is the VLR which decides whether an interrogation request should be forwarded to the HLR or not. Some nonsupplementary service related services may be invoked as a result of the procedure, as described in the clauses below.

The interrogation procedure is shown in figure 22.6.1/1.


The following services may be used:

```
MAP_PROCESS_ACCESS_REQUEST
                                     (see clauses 8 and 25);
MAP_TRACE_SUBSCRIBER_ACTIVITY (see clauses 9 and 25);
MAP_PROVIDE_IMSI
                                     (see clauses 8 and 25);
MAP_FORWARD_NEW_TMSI
                                     (see clauses 8 and 25);
MAP AUTHENTICATE
                                     (see clauses 8 and 25);
MAP_SET_CIPHERING_MODE
                                     (see clauses 8 and 25);
```

MAP\_CHECK\_IMEI (see clauses 8 and 25); MAP\_READY\_FOR\_SM (see clauses 12 and 25);

The following service is certainly used:

MAP INTERROGATE SS (defined in clause 11).



- 1) A\_CM\_SERV\_REQ (Note 1)
- MAP\_PROCESS\_ACCESS\_REQUEST (Note 2)
- 3) A\_INTERROGATE\_SS (Note 1)
- 4) MAP\_INTERROGATE\_SS\_req/ind
- 5) MAP\_INTERROGATE\_SS\_reg/ind
- 6) MAP\_INTERROGATE\_SS\_rsp/cnf
- 7) MAP\_INTERROGATE\_SS\_rsp/cnf
- 8) A\_INTERROGATE\_SS ack (Note 1)
- NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35], 3GPP TS 24.010 [36], 3GPP TS 24.08x and 3GPP TS 24.09x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
- NOTE 2: For details of the Process Access Request procedure, refer to subclause 25.4 in the present document.
- NOTE 3: Services printed in italics are optional.

Figure 22.6.1/1: Message flow for supplementary service interrogation

#### 22.6.2 Procedure in the MSC

The MSC procedures for interrogation are identical to those specified for registration in subclause 22.2.2. The text and diagrams in subclause 22.2.2 apply with all references to registration changed to interrogation.

#### 22.6.3 Procedures in the VLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2;
Process\_Access\_Request\_VLR see subclause 25.4.2.

The interrogation is answered either by the VLR or by the HLR, depending on the service interrogated.

#### 1) Interrogation to be handled by the VLR

The supplementary service request shall be processed according to 3GPP TS 23.011 [22] and the 23.08x and 23.09x-series of technical specifications. This handling may lead to a successful result, a partially successful result or an error being returned.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]).

#### 2) Interrogation to be handled by the HLR

If the interrogation is to be handled by the HLR, the MAP process in the VLR transfers the information received in the MAP\_INTERROGATE\_SS indication to the HLR in the MAP\_INTERROGATE\_SS request without checking the contents of the service indication. The MAP\_OPEN request includes the IMSI of the subscriber as the destination reference and the VLR number as the originating reference.

If the MAP\_INTERROGATE\_SS confirm is properly formed and contains a result or a user error, the MAP process in the VLR shall transfer the information contained in this primitive to the MSC in the MAP\_INTERROGATE\_SS response.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]).

The Interrogation process in the VLR is shown in figure 22.6.3/1.

## 22.6.4 Procedure in the HLR

The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check Indication

see subclause 25.2.1.

The HLR acts as follows:

The interrogation is answered either by the VLR or by the HLR, depending on the service interrogated.

#### 1) Interrogation to be handled by the VLR

If the interrogation procedure should have been answered by the VLR, then the HLR assumes that the VLR does not support the interrogated supplementary service, and returns the SS Not Available error to the VLR.

#### 2) Interrogation to be handled by HLR

The supplementary service request shall be processed according to 3GPP TS 23.011 [22] and the 23.08x and 23.09x-series of technical specifications. This handling may lead to either a successful result or an error being returned.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]).

The Interrogation process in the HLR is shown in figure 22.6.4/1.




Figure 22.6.3/1 (sheet 1 of 2): Process Interrogate\_SS\_VLR




Figure 22.6.3/1 (sheet 2 of 2): Process Interrogate\_SS\_VLR




Figure 22.6.4/1: Process Interrogate\_SS\_HLR

# 22.7 Void

Figure 22.7.2/1 void

Figure 22.7.3/1 void

# 22.8 Password registration procedure

## 22.8.1 General

The password registration procedure is used to register a password in the HLR. The password registration procedure is a fully transparent communication between the MS and the HLR, except that some services may be invoked as a result of the procedure, as described below.


(defined in clause 11).

The password registration procedure is shown in figure 22.8.1/1.

The following services may be used:

MAP\_GET\_PASSWORD

MAP_PROCESS_ACCESS_REQUEST	(see clauses 8 and 25);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(see clauses 9 and 25);
MAP_PROVIDE_IMSI	(see clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(see clauses 8 and 25);
MAP_AUTHENTICATE	(see clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(see clauses 8 and 25);
MAP_CHECK_IMEI	(see clauses 8 and 25);
MAP_READY_FOR_SM	(see clauses 12 and 25);
The following services are certainly used:	
MAP_REGISTER_PASSWORD	(defined in clause 11);



- 1) A\_CM\_SERV\_REQ (Note 1)
- 2) MAP\_PROCESS\_ACCESS\_REQUEST (Note 2)
- 3) A\_REGISTER\_PASSWORD (Note 1)
- 4) MAP\_REGISTER\_PASSWORD\_req/ind
- 5) MAP\_REGISTER\_PASSWORD\_req/ind
- MAP\_GET\_PASSWORD\_req/ind (Note 3)
- 7) MAP\_GET\_PASSWORD\_req/ind (Note 3)
- 8) A\_GET\_PASSWORD (Note 1, Note 3)
- 9) A\_GET\_PASSWORD (Note 1, Note 3)

  4. GET\_PASSWORD ack (Note 1, Note 3)
- 10) MAP\_GET\_PASSWORD\_rsp/cnf (Note 3)
- 11) MAP\_GET\_PASSWORD\_rsp/cnf (Note 3)
- 12) MAP\_GET\_PASSWORD\_req/ind (Note 3)
- 13) MAP\_GET\_PASSWORD\_req/ind (Note 3)
- 14) A\_GET\_PASSWORD (Note 1, Note 3)
- 15) A\_GET\_PASSWORD ack (Note 1, Note 3)
- 16) MAP\_GET\_PASSWORD\_rsp/cnf (Note 3)
- 17) MAP\_GET\_PASSWORD\_rsp/cnf (Note 3)
- 18) MAP\_GET\_PASSWORD\_req/ind (Note 3)
- 19) MAP\_GET\_PASSWORD\_req/ind (Note 3)
- 20) A\_GET\_PASSWORD (Note 1, Note 3)
- A\_GET\_PASSWORD ack (Note 1, Note 3)
- 22) MAP\_GET\_PASSWORD\_rsp/cnf (Note 3)
- 23) MAP\_GET\_PASSWORD\_rsp/cnf (Note 3)
- 24) MAP\_REGISTER\_PASSWORD\_rsp/cnf25) MAP\_REGISTER\_PASSWORD\_rsp/cnf
- 26) A\_REGISTER\_PASSWORD (Note 1)

- NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35], 3GPP TS 24.010 [36], 3GPP TS 24.08x and 3GPP TS 24.09x. Services shown in dotted lines are triggers/ triggered signalling on the radio path.
- NOTE 2: For details of the Process Access Request procedure, refer to subclause 25.4 in the present document.
- NOTE 3: The use of each of the three MAP\_GET\_PASSWORD operations is described in subclause 22.8.4.

#### Figure 22.8.1/1: Message flow for supplementary service password registration

## 22.8.2 Procedure in the MSC

The password registration procedure in the MSC is identical to that for activation specified in subclause 22.4.2. All the text and diagrams in subclause 22.4.2 apply with all references to activation changed to password registration.

### 22.8.3 Procedure in the VLR

The password registration procedure in the VLR is identical to that for activation specified in subclause 22.4.3. All the text and diagrams in subclause 22.4.3 apply with all references to activation changed to password registration.

#### 22.8.4 Procedure in the HLR

The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check Indication

see subclause 25.2.1.

The HLR shall process the MAP\_REGISTER\_PASSWORD indication as specified in 3GPP TS 23.011 [22]. During the handling of password registration, the password procedure is initiated (as specified in 3GPP TS 23.011 [22]) This involves the sending of MAP\_GET\_PASSWORD requests to the VLR.

The password registration process in the HLR is shown in figure 22.8.4/1.




Figure 22.8.4/1 (sheet 1 of 2): Process Register\_PW\_HLR




Figure 22.8.4/1 (sheet 2 of 2): Process Register\_PW\_HLR

# 22.9 Mobile Initiated USSD procedure

### 22.9.1 General

The procedure supports supplementary service signalling procedures which allow PLMN specific services to be introduced.

The message flow for the procedure can be found in 3GPP TS 23.090 [34].

The following services may be used:

MAP_PROCESS_ACCESS_REQUEST	(see clauses 8 and 25);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(see clauses 9 and 25);
MAP_PROVIDE_IMSI	(see clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(see clauses 8 and 25);
MAP_AUTHENTICATE	(see clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(see clauses 8 and 25);
MAP_CHECK_IMEI	(see clauses 8 and 25);
MAP_READY_FOR_SM	(see clauses 12 and 25);
MAP_UNSTRUCTURED_SS_REQUEST	(defined in clause 11);
MAP_UNSTRUCTURED_SS_NOTIFY	(defined in clause 11).

The following service is certainly used:

MAP\_PROCESS\_UNSTRUCTURED\_SS\_REQUEST (defined in clause 11).

#### 22.9.2 Procedure in the MSC

The process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check\_Confirmation see subclause 25.2.2.

The A\_PROCESS\_UNSTRUCTURED\_SS\_REQUEST from the MS contains information input by the user; the message may be fed to an application contained locally in the MSC or to the VLR. The rules for determining this are specified in 3GPP TS 23.090 [34].

#### 1) Message Destined for the VLR

If the message is destined for the VLR then the MSC shall transfer the message to the VLR using the mapping specified in detail in 3GPP TS 29.011 [59].

#### 2) Message Destined for the Local Application

If the message is destined for the local USSD application then the MSC shall transfer the information contained in the message to the application.

The process in the MSC is shown in figure 22.9.2/1.

### 22.9.3 Procedure in the VLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2;

Process\_Access\_Request\_VLR see subclause 25.4.2.

The MAP\_PROCESS\_UNSTRUCTURED\_SS\_REQUEST from the MSC contains information input by the user; the message may be fed to an application contained locally in the VLR or to the HLR. The rules for determining this are specified in 3GPP TS 23.090 [34].

#### 1) Message Destined for the HLR

If the message is destined for the HLR then the VLR shall transfer the message transparently to the HLR.

#### 2) Message Destined for the Local Application

If the message is destined for the local USSD application then the VLR shall transfer the information contained in the message to the application.

The process in the VLR is shown in figure 22.9.3/1.

## 22.9.4 Procedure in the HLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2.

The MAP\_PROCESS\_UNSTRUCTURED\_SS\_REQUEST from the VLR contains information input by the user. If the alphabet used for the message is understood then the message shall be fed to an application contained locally in the HLR or to the gsmSCF or to a secondary HLR where the USSD application is located.

#### 1) Message Destined for the Local Application

If the message is destined for the local USSD application then the HLR shall transfer the information contained in the message to the local application.

#### 2) Message Destined for the gsmSCF or the secondary HLR

If the message is destined for the gsmSCF or the secondary HLR then the primary HLR shall transfer the message transparently to the next node.

The process in the primary HLR is shown in figure 22.9.4/1.

## 22.9.5 Procedures in the gsmSCF/secondary HLR

The MAP process invokes a macro not defined in this clause; the definition of this macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1.

The process in the gsmSCF or secondary HLR is shown in figure 22.9.5/1.




Figure 22.9.2/1 (sheet 1 of 3): Process MS\_Init\_USSD\_MSC




Figure 22.9.2/1 (sheet 2 of 3): Process MS\_Init\_USSD\_MSC




Figure 22.9.2/1 (sheet 3 of 3): Process MS\_Init\_USSD\_MSC




Figure 22.9.3/1 (sheet 1 of 4): Process MS\_Init\_USSD\_VLR




Figure 22.9.3/1 (sheet 2 of 4): Process MS\_Init\_USSD\_VLR




Figure 22.9.3/1 (sheet 3 of 4): Process\_MS\_Init\_USSD\_VLR




Figure 22.9.3/1 (sheet 4 of 4): Process\_MS\_Init\_USSD\_VLR
Figure 22.9.3/2 void




Figure 22.9.4/1 (sheet 1 of 4): Process MS\_Init\_USSD\_HLR




Figure 22.9.4/1 (sheet 2 of 4): Process MS\_Init\_USSD\_HLR




Figure 22.9.4/1 (sheet 3 of 4): Process MS\_Init\_USSD\_HLR




Figure 22.9.4/1 (sheet 4 of 4): Process MS\_Init\_USSD\_HLR




Figure 22.9.5/1 (sheet 1 of 2): Process MS\_Init\_USSD\_gsmSCF\_Secondary\_HLR




Figure 22.9.5/1 (sheet 2 of 2): Process MS\_Init\_USSD\_gsmSCF\_Secondary\_HLR

# 22.10 Network initiated USSD procedure

#### 22.10.1 General

The procedure supports supplementary service signalling procedures which allow PLMN specific services to be introduced.

The message flow for the procedure can be found in 3GPP TS 23.090 [34].

The following services may be used:

```
MAP_PAGE (see clauses 8 and 25);

MAP_SEARCH_FOR_MOBILE_SUBSCRIBER (see clauses 8 and 25);

MAP_PROCESS_ACCESS_REQUEST (see clauses 8 and 25);

MAP_AUTHENTICATE (see clauses 8 and 25);

MAP_SET_CIPHERING_MODE (see clauses 8 and 25);

MAP_FORWARD_NEW_TMSI (see clauses 8 and 25);

MAP_READY_FOR_SM (see clauses 12 and 25).
```

At least one of the following services will certainly be used, and both may be used:

MAP\_UNSTRUCTURED\_SS\_REQUEST (defined in clause 11);

MAP\_UNSTRUCTURED\_SS\_NOTIFY (defined in clause 11).

#### 22.10.2 Procedure in the MSC

The process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

```
Receive_Open_Ind see subclause 25.1.1;
Receive_Open_Cnf see subclause 25.1.2;
Page_MSC see subclause 25.3.1;
Search_For_MS_MSC see subclause 25.3.2;
Process_Access_Request_MSC see subclause 25.4.1.
```

The process in the MSC is shown in figure 22.10.2/1.

#### 22.10.3 Procedure in the VLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

```
Receive_Open_Ind see subclause 25.1.1;
Receive_Open_Cnf see subclause 25.1.2;
Check_Indication see subclause 25.2.1;
Check Confirmation see subclause 25.2.2.
```

The process in the VLR is shown in figure 22.10.3/1.

#### **MSC Initiated USSD**

If a USSD application in the MSC wishes to use the network initiated USSD procedure, and a connection to the MS does not exist then the MSC opens a dialogue with the VLR. This dialogue leads to the VLR performing page or search using the macro Start\_USSD\_VLR.

#### Macro Start\_USSD\_VLR

The macro invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Check\_Confirmation see subclause 25.2.1;
Process\_Access\_Request\_VLR see subclause 25.4.2.

The macro is shown in figure 22.10.3/2.

#### 22.10.4 Procedure in the HLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Indication see subclause 25.2.1;
Check Confirmation see subclause 25.2.2.

The process in the primary HLR is shown in figures 22.10.4/1 and 22.10.4/2.

### 22.10.5 Procedure in the gsmSCF or secondary HLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2.

The procedure in the gsmSCF or secondary HLR is shown in figure 22.10.5/1.




Figure 22.10.2/1 (sheet 1 of 4): Process NW\_Init\_USSD\_MSC




Figure 22.10.2/1 (sheet 2 of 4): Process NW\_Init\_USSD\_MSC




Figure 22.10.2/1 (sheet 3 of 4): Process NW\_Init\_USSD\_MSC




Figure 22.10.2/1 (sheet 4 of 4): Process NW\_Init\_USSD\_MSC




Figure 22.10.3/1 (sheet 1 of 5): Process NW\_Init\_USSD\_VLR




Figure 22.10.3/1 (sheet 2 of 5): Process NW\_Init\_USSD\_VLR




Figure 22.10.3/1 (sheet 3 of 5): Process NW\_Init\_USSD\_VLR




Figure 22.10.3/1 (sheet 4 of 5): Process NW\_Init\_USSD\_VLR




Figure 22.10.3/1 (sheet 5 of 5): Process NW\_Init\_USSD\_VLR




Figure 22.10.3/2 (sheet 1 of 2): Macro Start\_USSD\_VLR




Figure 22.10.3/2 (sheet 2 of 2): Macro Start\_USSD\_VLR




Figure 22.10.4/1 (sheet 1 of 5): Process NW\_Init\_USSD\_HLR




Figure 22.10.4/1 (sheet 2 of 5): Process NW\_Init\_USSD\_HLR




Figure 22.10.4/1 (sheet 3 of 5): Process NW\_Init\_USSD\_HLR




Figure 22.10.4/1 (sheet 4 of 5): Process NW\_Init\_USSD\_HLR




Figure 22.10.4/1 (sheet 5 of 5): Process NW\_Init\_USSD\_HLR




Figure 22.10.4/2: Macro Start\_USSD\_HLR




Figure 22.10.5/1 (sheet 1 of 2): Process NW\_Init\_USSD\_gsmSCF\_secondary\_HLR




Figure 22.10.5/1 (sheet 2 of 2): Process NW\_Init\_USSD\_gsmSCF\_Secondary\_HLR

### 22.11 Common macros for clause 22

The following macros are used for the description of more than one of the supplementary service processes described in clause 22.

## 22.11.1 SS Password handling macros

#### Macro Get\_Password\_MSC

This macro is used by the MSC to relay a request for password from the VLR to the MS, and to relay a response from the MS back to the VLR. The macro is shown in figure 22.11.1/1.

#### Macro Get\_Password\_VLR

This macro is used by the VLR to relay a request for password from the HLR to the MSC, and to relay a response from the MSC back to the HLR. The macro invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check\_Indication

see subclause 25.2.1.

The macro is shown in figure 22.11.1/2.

### 22.11.2 Void




Figure 22.11.1/1: Macro Get\_Password\_MSC




Figure 22.11.1/2: Macro Get\_Password\_VLR

Figure 22.11.2/1 void

Figure 22.11.2/2 void

Figure 22.11.2/3 void

Figure 22.11.2/4 void

Figure 22.11.2/5 void

# 22.12 Supplementary Service Invocation Notification procedure

#### 22.12.1 General

The Supplementary Service Invocation Notification procedure is used to notify a gsmSCF about the invocation of a GSM Supplementary Service.

(defined in clause 11).

The supplementary service invocation notification procedure is shown in figure 22.12.1/1.

The following service is certainly used:

MAP\_SS\_INVOCATION\_NOTIFY

MSC gsmSCF

- 1) MAP\_SS\_INVOCATION\_NOTIFY\_req/ind
- 2) MAP\_SS\_INVOCATION\_NOTIFY\_rsp/cnf

Figure 22.12.1/1: Message flow for supplementary service invocation notification

#### 22.12.2 Procedure in the MSC

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check Confirmation see subclause 25.2.2.

The supplementary service invocation notification process in the MSC is shown in figure 22.12.2/1.

## 22.12.3 Procedure in the gsmSCF

The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1.

The supplementary service invocation notification process in the smSCF is shown in figure 22.12.3/1.




Figure 22.12.2/1: Process Notify\_SS\_Invocation\_MSC




Figure 22.12.3/1: Process Note\_SS\_Invocation\_gsmSCF


# 22.13 Activation of a CCBS request

#### 22.13.1 General

The message flow to activate a CCBS request is shown in figure 22.13.1/1.

The following service is certainly used:

MAP\_REGISTER\_CC\_ENTRY (defined in clause 11).



- 1) MAP\_REGISTER\_CC\_ENTRY\_req/ind
- 2) MAP\_REGISTER\_CC\_ENTRY\_rsp/cnf

Figure 22.13.1/1: Message flow to activate a CCBS request

#### 22.13.2 Procedure in the VLR

The MAP process in the VLR to activate a CCBS request is shown in figure 22.13.2/1. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

#### 22.13.3 Procedure in the HLR

The MAP process in the HLR to activate a CCBS request is shown in figure 22.13.2/1.




Figure 22.13.2/1: Process Register\_CC\_Entry\_VLR




Figure 22.13.3/1: Process Register\_CC\_Entry\_HLR


# 22.14 Deactivation of a CCBS request

#### 22.14.1 General

The message flow to deactivate a CCBS request is shown in figure 22.14.1/1.

The following service is certainly used:

MAP\_ERASE\_CC\_ENTRY (defined in clause 11).



- 1) MAP\_ERASE\_CC\_ENTRY\_req/ind
- 2) MAP\_ERASE\_CC\_ENTRY\_rsp/cnf

Figure 22.14.1/1: Message flow to deactivate a CCBS request

#### 22.14.2 Procedure in the VLR

The MAP process in the VLR to deactivate a CCBS request is shown in figure 22.14.2/1. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

#### 22.14.3 Procedure in the HLR

The MAP process in the HLR to deactivate a CCBS request is shown in figure 22.14.2/1.




Figure 22.14.2/1: Process Erase\_CC\_Entry\_VLR




Figure 22.14.3/1: Process Erase\_CC\_Entry\_HLR

# 23 Short message service procedures

### 23.1 General

The short message service procedures are used to control both mobile originated and mobile terminated short message transfer

Four procedures exist for short message services:

- mobile originated short message service transfer;
- mobile terminated short message service transfer;
- short message alert procedure;
- short message delivery status report procedure.

The following application context refers to a complex MAP user consisting of several processes:

- shortMessageGatewayContext.

This application context needs a co-ordinating process in the HLR. Additionally a co-ordinating process needed for the mobile originated situation in the MSC, because the A\_CM\_SERV\_REQ message does not distinguish between mobile originated short message transfer and the short message alert procedures.

NOTE: the A\_CM\_SERV\_REQ message is not used for SMS over GPRS. The modelling is based on the assumption that the SGSN will trigger the appropriate process, according to whether an RP\_MO\_DATA or an RP\_SM\_MEMORY\_AVAILABLE is received over the LLC layer.

## 23.1.1 Mobile originated short message service Co-ordinator for the MSC

The process starts when the MSC receives an A\_CM\_SERV\_REQ message (see 3GPP TS 24.008 [35]), with a CM service type indicating short message service, from the A-interface. The process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Process\_Access\_Request\_MSC see subclause 25.4.1.

If the macro Process\_Access\_Request\_MSC takes the "OK" exit (which means that the MSC has sent an A\_CM\_SERVICE\_ACCEPT to the MS), , the MS initiates mobile originated short message transfer or sends an indication that it has memory available for more short messages.

The SMS Co-ordinator process in the MSC is shown in figure 23.1/1.

## 23.1.2 Short message Gateway Co-ordinator for the HLR

The process starts when the HLR receives a MAP\_OPEN indication using when the application context shortMessageGatewayContext. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1.

The SM Gateway Co-ordinator process in the HLR is shown in figure 23.1/2.

If the Receive\_Open\_Ind macro takes the Vr exit then HLR shall perform the MAP dialogue as specified for the appropriate application context version. Depending on the subscriber data, handling at the MAP user application level may be performed as specified in subclauses 23.3.2 and 23.5.2 of the present document:




Figure 23.1/1 (sheet 1 of 2): Process Co\_SMS\_MSC




Figure 23.1/1 (sheet 2 of 2): Process Co\_SMS\_MSC





Figure 23.1/2: Process Co\_SM\_Gateway\_HLR

#### 23.2 The mobile originated short message transfer procedure

The mobile originated short message service procedure is used to forward a short message from a mobile subscriber to a Service Centre. The message flow for the mobile originated short message service procedure is shown in figure 23.2/1.



- Short Message (3GPP TS 24.011 [37]). 1)
- 2) MAP\_SEND\_INFO\_FOR\_MO\_SMS (\*).
- 3) MAP\_SEND\_INFO\_FOR\_MO\_SMS\_ACK (\*).
- 4) TCAP BEGIN (\*\*)
- 4a) TCAP CONTINUE (\*\*)
- MAP\_MO\_FORWARD\_SHORT\_MESSAGE. 4b)
- 5) Short message (3GPP TS 23.040).
- Short message Acknowledgement (3GPP TS 23.040).
- 6) 7) MAP\_MO\_FÖRWARD\_SHÖRT\_MESSAGE\_ACK.
- 8) Short Message Acknowledgement (3GPP TS 24.011 [37]).
- Messages 2) and 3) are not used by the SGSN.
- lf

the capacity of a message signal unit in the lower layers of the protocol is enough to carry the content of the MAP\_OPEN request and the content of the MAP\_MO\_FORWARD\_SHORT\_MESSAGE request in a single TC message

a)

b) the Interworking MSC operator and the serving node (MSC or SGSN) operator agreed not to use the TCAP handshake countermeasure against SMS fraud for messages exchanged between their networks (see 3GPP TS 33.204 [34a])

the TCAP handshake may be omitted.

Figure 23.2/1: Mobile originated short message transfer

In addition the following MAP services are used:

```
MAP_PROCESS_ACCESS_REQUEST
                                           (see subclause 8.3); (*)
MAP_AUTHENTICATE
                                           (see subclause 8.5); (*)
MAP_SET_CIPHERING_MODE
                                           (see subclause 8.6); (*)
```

MAP\_PROVIDE\_IMSI (see subclause 8.9); (\*)

MAP\_CHECK\_IMEI (see subclause 8.7);

MAP\_FORWARD\_NEW\_TMSI (see subclause 8.9); (\*)

MAP\_TRACE\_SUBSCRIBER\_ACTIVITY (see subclause 9.1); (\*)

MAP\_READY\_FOR\_SM (see subclause 12.4).

(\*) These services are not used by the SGSN.

## 23.2.1 Procedure in the serving MSC

Any CAMEL-specific handling defined in this subclause is omitted if the MSC does not support CAMEL control of MO SMS, or if the subscriber does not have a subscription for CAMEL control of MO SMS.

The process starts when the MSC receives a short message from the MS. The process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Indication see subclause 25.2.1;
Check Confirmation see subclause 25.2.2.

Sheet 1: If the MSC is integrated with the SMS-IWMSC, it communicates directly with the Short Message Service Centre (SMSC) using one of the protocols described in 3GPP TS 23.039 [25a]; otherwise it communicates with the SMS-IWMSC using MAP.

Sheet 3: If the capacity of a message signal unit in the lower layers of the protocol is enough to carry the content of the MAP\_OPEN request and the content of the MAP\_MO\_FORWARD\_SHORT\_MESSAGE request in a single TC message, the test "Message segmentation needed" takes the "No" exit; otherwise the test takes the "Yes" exit.

Sheet 3:The decision box "TCAP Handshake required" takes the "yes" or "no" exit depending on agreements between the serving MSC's operator and the SMS-IWMSC's operator (see 3GPP TS 33.204 [34a]).

The mobile originated short message service process in the MSC is shown in figure 23.2/2.

#### 23.2.2 Procedure in the VLR

Any CAMEL-specific handling defined in this subclause is omitted if the VLR does not support CAMEL control of MO SMS.

The process starts when the VLR receives a dialogue opening request followed by a MAP\_PROCESS\_ACCESS\_REQUEST including a CM service type Short Message Service. The process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Check\_Indication see subclause 25.2.1;
Process\_Access\_Request\_VLR see subclause 25.4.2.

The mobile originated short message transfer process in the VLR is shown in figure 23.2/3.

#### 23.2.3 Procedure in the SGSN

Any CAMEL-specific handling defined in this subclause is omitted if the SGSN does not support CAMEL control of MO SMS, or if the subscriber does not have a subscription for CAMEL control of MO SMS.

The process starts when the SGSN receives a short message received from the MS over the Gb interface. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;

Check\_Confirmation see subclause 25.2.2.

Sheet 2: If the capacity of a message signal unit in the lower layers of the protocol is enough to carry the content of the MAP\_OPEN request and the content of the MAP\_MO\_FORWARD\_SHORT\_MESSAGE request in a single TC message, the test "Message segmentation needed" takes the "No" exit; otherwise the test takes the "Yes" exit.

Sheet 2:The decision box "TCAP Handshake required" takes the "yes" or "no" exit depending on agreements between the serving SGSN's operator and the SMS-IWMSC's operator (see 3GPP TS 33.204 [34a]).

The mobile originated short message service process in the SGSN is shown in figure 23.2/4.

## 23.2.4 Procedure in the SMS Interworking MSC (SMS-IWMSC)

This procedure applies only when the SMS-IWMSC is not integrated with the serving MSC or SGSN.

The process starts when the SMS-IWMSC receives a dialogue opening request with the application context shortMsgMO-RelayContext. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Check\_Indication see subclause 25.2.1.

Sheet 1:The decision box "TCAP Handshake required" takes the "yes" or "no" exit depending on agreements between the SMS-IWMSC's operator and the serving node's operator (see 3GPP TS 33.204 [34a]).

The mobile originated short message service transfer process in the SMS-IWMSC is shown in figure 23.2/5.




Figure 23.2/2 (sheet 1 of 4): Process MO\_SM\_MSC




Figure 23.2/2 (sheet 2 of 4): Process MO\_SM\_MSC




Figure 23.2/2 (sheet 3 of 4): Process MO\_SM\_MSC




Figure 23.2/2 (sheet 4 of 4): Process MO\_SM\_MSC




Figure 23.2/3 (sheet 1 of 2): Process MOSM\_VLR




Figure 23.2/3 (sheet 2 of 2): Process MO\_SM\_VLR




Figure 23.2/4 (sheet 1 of 3): Process MO\_SM\_SGSN

697




Figure 23.2/4 (sheet 2 of 3): Process MO\_SM\_SGSN




Figure 23.2/4 (sheet 3 of 3): Process MO\_SM\_SGSN




Figure 23.2/5 (sheet 1 of 2): Process MO\_SM\_IWMSC




Figure 23.2/5 (sheet 2 of 2): Process MO\_SM\_IWMSC

# 23.3 The mobile terminated short message transfer procedure

The mobile terminated short message transfer procedure is used for forwarding a short message or several short messages from a Service Centre to a mobile subscriber. The message flow for the mobile terminated short message procedure for a single short message transfer is shown in figure 23.3/1.




Figure 23.3/1: Mobile terminated short message service procedures

- 1) Short Message (3GPP TS 23.040).
- 2) MAP\_SEND\_ROUTING\_INFO\_FOR\_SM.
- 3) MAP\_SEND\_ROUTING\_INFO\_FOR\_SM\_ACK.
- 4) TCAP BEGIN (\*\*\*)
- 4a) TCAP CONTINUE (\*\*\*)
- 4b) MAP\_MT\_FORWARD\_SHORT\_MESSAGE.
- 5) MAP\_SEND\_INFO\_FOR\_MT\_SMS (\*).
- 5a) MAP\_CONTINUE\_CAMEL\_SMS\_HANDLING (\*)(\*\*)
- 5b) MAP\_SEND\_INFO\_FOR\_MT\_SMS (\*)(\*\*)
- 6) MAP\_PAGE/MAP\_SEARCH\_FOR\_MOBILE\_SUBSCRIBER (\*).
- 7) Page (3GPP TS 24.008 [35]).
- 8) Page response (3GPP TS 24.008 [35]).
- 9) MAP\_PROCESS\_ACCESS\_REQUEST\_ACK and MAP\_SEARCH\_FOR\_MOBILE\_SUBSCRIBER\_ACK (\*).
- 10) MAP\_SEND\_INFO\_FOR\_MT\_SMS\_ACK (\*).
- 11) Short Message (3GPP TS 24.011 [37])
- 12) Short Message Acknowledgement (3GPP TS 24.011 [37]).
- 13) MAP\_MT\_FORWARD\_SHORT\_MESSAGE\_ACK.
- 14) Short Message Acknowledgement (3GPP TS 23.040).
- (\*) Messages 5), 5a), 5b), 6), 9), and 10) are not used by the SGSN.
- (\*\*) These messages are used only for a subscriber provisioned with MT-SMS-CSI in the VLR.
- (\*\*\*) If
  - a)
  - the capacity of a message signal unit in the lower layers of the protocol is enough to carry the content of the MAP\_OPEN request and the content of the MAP\_MT\_FORWARD\_SHORT\_MESSAGE request in a single TC message,

and

 the SMS Gateway MSC operator and the serving node (MSC or SGSN) operator agreed not to use the TCAP handshake countermeasure against SMS fraud for messages exchanged between their networks (see 3GPP TS 33.204 [34a])

then

the TCAP handshake may be omitted.

The message flow for the mobile terminated short message procedure for multiple short message transfer is shown in figure 23.3/2.




Figure 23.3/2: Mobile terminated short message procedure for multiple short message transfer

- 1) Short Message (3GPP TS 23.040 [26]).
- 2) MAP\_SEND\_ROUTING\_INFO\_FOR\_SM.
- 3) MAP\_SEND\_ROUTING\_INFO\_FOR\_SM\_ACK.
- 4)
- TCAP BEGIN (\*\*\*)
  TCAP CONTINUE (\*\*\*) 4a
- MAP\_MT\_FORWARD\_SHORT\_MESSAGE (note 1). 4b)
- MAP\_SEND\_INFO\_FOR\_MT\_SMS (\*). 5)
- MAP\_CONTINUE\_CAMEL\_SMS\_HANDLING (\*)(\*\*) 5a)
- MAP\_SEND\_INFO\_FOR\_MT\_SMS (\*)(\*\*) 5b)
- MAP\_PAGE/MAP\_SEARCH\_FOR\_MOBILE\_SUBSCRIBER (\*). 6)
- Page (3GPP TS 48.008 [49]). 7)
- 8) Page response (3GPP TS 24.008 [35]).
- 9) MAP\_PROCESS\_ACCESS\_REQUEST\_ACK and
  - MAP\_SEARCH\_FOR\_MOBILE\_SUBSCRIBER\_ACK (\*).
- MAP\_SEND\_INFO\_FOR\_MT\_SMS\_ACK (\*). 10)
- Short Message (3GPP TS 24.011 [37]). 11)
- Short Message Acknowledgement (3GPP TS 24.011 [37]). 12)
- 13) MAP\_MT\_FORWARD\_SHORT\_MESSAGE\_ACK.
- 14) Short Message Acknowledgement (3GPP TS 23.040 [26]).
- 15) Short Message (3GPP TS 23.040 [26]).

- 16) MAP\_MT\_FORWARD\_SHORT\_MESSAGE (note 2).
- 17) Short Message (3GPP TS 24.011 [37]).
- 18) Short Message Acknowledgement (3GPP TS 24.011 [37]).
- 19) MAP\_MT\_FORWARD\_SHORT\_MESSAGE\_ACK.
- 20) Short Message Acknowledgement (3GPP TS 23.040 [26]).
- (\*) Messages 5), 5a), 5b) 6), 9), and 10) are not used by the SGSN.
- (\*\*) These messages are used only for a subscriber provisioned with MT-SMS-CSI in the VLR.
- (\*\*\*) I
  - a) the capacity of a message signal unit in the lower layers of the protocol is enough to carry the content of the MAP\_OPEN request and the content of the MAP\_MT\_FORWARD\_SHORT\_MESSAGE request in a single TC message, and
  - b) the SMS Gateway MSC operator and the serving node (MSC or SGSN) operator agreed not to use the TCAP handshake countermeasure against SMS fraud for messages exchanged between their networks (see 3GPP TS 33.204 [34a]) then the TCAP handshake may be omitted.

NOTE 1: The 'More Messages To Send' flag is TRUE. NOTE 2: The 'More Messages To Send' flag is FALSE.

In the multiple short message transfer the service MAP\_MT\_FORWARD\_SHORT\_MESSAGE can be used several times. However, the short message transfer is always acknowledged to the Service Centre before the next short message is sent.

In addition the following MAP services are used:

MAP PROCESS ACCESS REQUEST (see subclause 8.3); (\*) MAP PAGE (see subclause 8.2); (\*) MAP\_SEARCH\_FOR\_MS (see subclause 8.2); (\*) MAP\_AUTHENTICATE (see subclause 8.5); (\*) MAP\_SET\_CIPHERING\_MODE (see subclause 8.6); (\*) MAP\_CHECK\_IMEI (see subclause 8.7); MAP\_FORWARD\_NEW\_TMSI (see subclause 8.9); (\*) MAP\_REPORT\_SM\_DELIVERY\_STATUS (see subclause 12.3); MAP\_INFORM\_SERVICE\_CENTRE (see subclause 12.6); MAP TRACE SUBSCRIBER ACTIVITY (see subclause 9.1); (\*) MAP\_READY\_FOR\_SM (see subclause 12.4).

(\*) These services are not used by the SGSN.

A message flow example for the mobile terminated short message procedure for a single short message transfer in an environment that makes use of an SMS Router for MT-short-message-transfer is shown in figure 23.3/2a.

NOTE: This message flow can be applied only if no IP-SM-GW deployed in the same network.




Figure 23.3/2a Mobile terminated short message procedure with SMS Router

- 1) Short Message (3GPP TS 23.040 [26])
- 2) & 3) MAP\_SEND\_ROUTING\_INFO\_FOR\_SM

NOTE: The HLR relays the message MAP\_SEND\_ROUTING\_INFO\_FOR\_SM received from the SMS-GMSC to the SMS- Router on SCCP level. How this is done is implementation specific.

- 4) MAP\_SEND\_ROUTING\_INFO\_FOR\_SM
- MAP\_SEND\_ROUTING\_INFO\_FOR\_SM\_ACK and conditionally MAP\_INFORM\_SERVICE\_CENTRE
- 6) MAP\_SEND\_ROUTING\_INFO\_FOR\_SM\_ACK and conditionally MAP\_INFORM\_SERVICE\_CENTRE
- 7) Conditionally: Inform Service Centre (3GPP TS 23.040 [26])
- 8) MAP\_MT\_FORWARD\_SHORT\_MESSAGE

NOTE: In this example the SMS-GMSC decides to attempt delivery via MSC. Therefore the SCCP called party SSN shall be set to SSN for MSC

- 9) MAP\_MT\_FORWARD\_SHORT\_MESSAGE
- 10) MAP\_MT\_FORWARD\_SHORT\_MESSAGE\_ERROR

NOTE: In this example delivery via the MSC is unsuccessful e.g. due to IMSI detached

- 11) MAP\_MT\_FORWARD\_SHORT\_MESSAGE\_ERROR
- 12) MAP\_MT\_FORWARD\_SHORT\_MESSAGE

NOTE: In this example the SMS-GMSC decides to retry delivery via the SGSN. Therefore the SCCP called party SSN shall be set to the SSN for SGSN.

- 13) MAP\_MT\_FORWARD\_SHORT\_MESSAGE
   14) MAP\_MT\_FORWARD\_SHORT\_MESSAGE\_ACK
   NOTE: In this example delivery via SGSN is successful
- 15) MAP MT FORWARD SHORT MESSAGE ACK
- 16) Conditionally: MAP\_REPORT\_SM\_DELIVERY\_STATUS

NOTE: In this example unsuccessful delivery via MSC and successful delivery via SGSN is reported

17) MAP\_REPORT\_SM\_DELIVERY\_STATUS\_Ack

18) Short Message Acknowledgement (3GPP TS 23.040 [26]).

A message flow example for the mobile terminated short message procedure for a single short message transfer in an environment that makes use of an IP-SM-GW (see 3GPP TS 23.204 [134]) for MT-short-message-transfer is shown in figure 23.3/2b.

NOTE: SMS Routers can apply this message flow as well.




Figure 23.3/2b Mobile terminated short message procedure with IP-SM-GW

- 1) Short Message (3GPP TS 23.040 [26])
- 2) MAP\_SEND\_ROUTING\_INFO\_FOR\_SM
- the message is forwarded to the IP-SM-GW assigned to the recipient of the SM
- 3) MAP\_SEND\_ROUTING\_INFO\_FOR\_SM
- 4) MAP\_SEND\_ROUTING\_INFO\_FOR\_SM
  - since the message is received from an IP-SM-GW, it is not forwarded to an IP-SM-GW
- 5) MAP\_SEND\_ROUTING\_INFO\_FOR\_SM\_ACK and conditionally MAP\_INFORM\_SERVICE\_CENTRE
- 6) MAP\_SEND\_ROUTING\_INFO\_FOR\_SM\_ACK and conditionally MAP\_INFORM\_SERVICE\_CENTRE

The IP-SM-GW returns its own address within the network node number parameter

- 7) Conditionally: Inform Service Centre (3GPP TS 23.040 [26])
- MAP\_MT\_FORWARD\_SHORT\_MESSAGE 8)
- 9)
- MAP\_MT\_FORWARD\_SHORT\_MESSAGE\_ACK
  Conditionally: MAP\_REPORT\_SM\_DELIVERY\_STATUS 10)

NOTE 1: As an IP-SM-GW is deployed the message is acknowledged ignoring its content

- MAP\_REPORT\_SM\_DELIVERY\_STATUS\_Ack
- Conditionally: MAP\_REPORT\_SM\_DELIVERY\_STATUS 12) since the message is received from an IP-SM-GW, it is processed
- MAP\_REPORT\_SM\_DELIVERY\_STATUS\_Ack

NOTE 2: Step 12 and 13 is independent of steps 10, 11, and 14. They can run in parallel.

Short Message Acknowledgement (3GPP TS 23.040 [26]). 14)

#### 23.3.1 Procedure in the SMS-GMSC

Any CAMEL-specific handling described in this subclause is omitted if the SMS-GMSC does not support CAMEL. CAMEL-specific handling is invoked only if the SMS-GMSC is integrated with the VMSC.

The process starts when the SMS-GMSC receives an SC\_RP\_MT\_DATA indication from a Service Centre. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;

Check Confirmation see subclause 25.2.2.

Process MT SM GMSC sheet 1: If the MAP SEND ROUTING INFO FOR SM confirmation included an LMSI, it shall be included in the sm-RP-DA information field of the first MAP\_MT\_FORWARD\_SHORT\_MESSAGE request sent to the serving MSC. In this case, the IMSI shall be included in the Destination Reference of the MAP\_OPEN request. The SMS-GMSC shall not send an LMSI to an SGSN. If the SMS-GMSC does not send an LMSI to the serving node, the sm-RP-DA information field in the first MAP\_MT\_FORWARD\_SHORT\_MESSAGE request sent to the serving MSC or SGSN shall contain the IMSI, and the Destination Reference in the MAP\_OPEN request shall not be present. The parameter SM RP OA shall contain the Service Centre address.

Process MT SM GMSC sheet 1: The indication of which number belongs to the SGSN and which to the MSC, received from the HLR in the MAP\_SEND\_ROUTING\_INFO\_FOR\_SM confirm (see subclause 23.3.2) will enable the SMS-GMSC to map the causes received from one or both serving nodes into the appropriate causes for non GPRS, GPRS or both, and send them to the SC and the HLR.

Process MT\_SM\_GMSC sheet 2: The SMS-GMSC maps "Unexpected data value" and "System failure" MAP errors from the serving node to a "System failure" RP ERROR error cause. The mapping between other MAP error causes and the RP\_ERROR error cause is given in 3GPP TS 23.040 [26] and 3GPP TS 24.011 [37].

Process MT\_SM\_GMSC sheet 2: If the SMS-GMSC receives both MSC and SGSN numbers from the HLR as routeing information, it may choose which serving node to use for the first delivery attempt.

Process MT SM GMSC sheet 2: If the SMS-GMSC makes two delivery attempts, it may report the result of each delivery attempt to the HLR according to the conditions described below.

Procedure MT SM Delivery Attempt GMSC sheet 1: if the macro MT SM Transfer MSC takes the Error exit, the SMS-GMSC maps the MAP User Error to the corresponding SC RP error, as defined in 3GPP TS 23.040 [26].

Procedure MT\_SM\_Delivery\_Attempt\_GMSC sheet 3: The decision box "TCAP Handshake required" takes the "yes" or "no" exit depending on agreements between the GMSC's operator and the serving node's operator (see 3GPP TS 33.204 [34a]).

Procedure MT SM Delivery Attempt GMSC sheet 1, sheet 2, sheet 4, sheet 5: The SMS-GMSC invokes the macro Report SM Delivery Stat GMSC if:

- the reason received from the serving node for failure to deliver the message is absent subscriber\_SM, unidentified subscriber or SM delivery failure with error cause "MS memory capacity exceeded", and the SC address is not yet included in the MWD set, or
- the reason received from the serving node for failure to deliver the message is absent subscriber\_SM, unidentified subscriber or SM delivery failure with error cause MS memory capacity exceeded, and the

corresponding flag in the HLR (as indicated in the information received in the MAP\_INFORM\_ SERVICE CENTRE) is not set, or

- the reason received from the serving node (MSC or SGSN) for failure to deliver the message is absent subscriber\_SM and the absent subscriber diagnostic is different from the absent subscriber diagnostic received in the MAP INFORM SERVICE CENTRE.

Procedure MT\_SM\_Delivery\_Attempt\_GMSC sheet 1, sheet 2, sheet 4, sheet 5: If absent subscriber diagnostic information (see 3GPP TS 23.040 [26]) is included with the absent subscriber\_SM error indication then the SMS-GMSC relays this information to the HLR using the MAP\_REPORT\_SM\_DELIVERY\_STATUS service.

Procedure MT\_SM\_Delivery\_Attempt\_GMSC sheet 1, sheet 4: The More Messages To Send flag is set to TRUE or FALSE according to the information received from the Service Centre.

Procedure MT\_SM\_Delivery\_Attempt\_GMSC sheet 3: If the capacity of a message signal unit in the lower layers of the protocol is enough to carry the content of the MAP\_OPEN request and the content of the MAP\_MT\_FORWARD\_SHORT\_MESSAGE request in a single TC message, the test "Message segmentation needed" takes the "No" exit; otherwise the test takes the "Yes" exit.

The mobile terminated short message transfer process in the SMS-GMSC is shown in figure 23.3/3. The procedure MT\_SM\_Delivery\_Attempt\_GMSC is shown in figure 23.3/4. The macro MT\_SM\_Transfer\_MSC is shown in figure 23.3/7.

### 23.3.2 Procedure in the HLR

The process starts when the HLR receives a MAP\_SEND\_ROUTING\_INFO\_FOR\_SM indication from the SMS-GMSC. If an SMS Router is deployed, the HLR receives MAP\_SEND\_ROUTING\_INFO\_FOR\_SM from the SMS Router (step 4 in figure 23.3/2a); relaying a message received from the SMS-GMSC to the SMS Router on SCCP level (steps 2 and 3 in figure 23.3/2a) is done by implementation specific means and is not shown in figure 23.3/5.

The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check\_Indication see subclause 25.2.1.

Sheet 3: If the SMS-GMSC does not support GPRS functionality, it uses the protocol defined in the Release 96 version of this specification. The parameter "msc-Number" in "RoutingInfoForSM-Res" in the Release 96 version of the protocol definition corresponds to the parameter "networkNode-Number" in "RoutingInfoForSM-Res" in the Release 97 (and later) version of the protocol definition; therefore if the HLR populates the parameter "networkNode-Number" with the SGSN number, the Release 96 SMS-GMSC will interpret the SGSN number as an MSC number. If the HLR populates the "gprsNodeIndicator" parameter in the MAP\_SEND\_ROUTING\_INFO\_FOR\_SM response, a Release 96 SMS-GMSC will silently discard the parameter.

Sheet 5: If the HLR received a LMSI from the VLR at location updating, it shall include the LMSI in the MAP\_SEND\_ROUTING\_INFO\_FOR\_SM response only if the MAP\_SEND\_ROUTING\_INFO\_FOR\_SM response also includes the MSC number.

The mobile terminated short message transfer process in the HLR is shown in figure 23.3/5.

# 23.3.3 Procedure in the Serving MSC

Any CAMEL-specific handling defined in this subclause is omitted if the MSC does not support CAMEL control of MT SMS, or if the subscriber does not have a subscription for CAMEL control of MT SMS.

The process starts when the MSC receives a dialogue opening request with the application context shortMsgMT-RelayContext. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;

Check Indication see subclause 25.2.1.

The mobile terminated short message transfer process in the serving MSC is shown in figure 23.3/6

Procedure MT\_SM\_VMSC sheet 1: The decision box "TCAP Handshake required" takes the "yes" or "no" exit depending on agreements between the Serving MSC's operator and the SMS Gateway MSC's operator (see 3GPP TS 33.204 [34a]).

The macro MT\_SM\_Transfer\_MSC may be invoked either in a stand-alone serving MSC or in a serving MSC which is integrated with the SMS-GMSC. It is used to transfer the first MT short message of a possible sequence of messages. The macro invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Check\_Confirmation see subclause 25.2.2.

Page\_MSC see subclause 25.3.1;

Search\_for\_MS\_MSC see subclause 25.3.2;

Process\_Access\_Request\_MSC see subclause 25.4.1;

Trace\_Subscriber\_Activity\_MSC see subclause 25.9.1.

The macro MT\_SM\_Transfer\_MSC is shown in figure 23.3/7. The macro Check\_Subscr\_Identity\_For\_MT\_SMS is shown in figure 23.3/8.

#### 23.3.4 Procedure in the VLR

Any CAMEL-specific handling defined in this subclause is omitted if the VLR does not support CAMEL control of MT SMS.

The process starts when the VLR receives a dialogue opening request from the MSC. The process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Check\_Indication see subclause 25.2.1;
Check\_Confirmation see subclause 25.2.2;
Process Access Request VLR see subclause 25.4.2.

The mobile terminated short message transfer process in the VLR is shown in figure 23.3/9.

#### 23.3.5 Procedure in the SGSN

Any CAMEL-specific handling defined in this subclause is omitted if the SGSN does not support CAMEL control of MT SMS, or if the subscriber does not have a subscription for CAMEL control of MT SMS.

The process starts when the SGSN receives a dialogue opening request with the application context shortMsgMT-RelayContext. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Check Indication see subclause 25.2.1.

The mobile terminated short message transfer process in the SGSN is shown in figure 23.3/10.

Procedure MT\_SM\_SGSN sheet 1: The decision box "TCAP Handshake required" takes the "yes" or "no" exit depending on agreements between the Serving SGSN's operator and the SMS Gateway MSC's operator (see 3GPP TS 33.204 [34a]).

The macro MT\_SM\_Transfer\_SGSN is used to transfer the first MT short message of a possible sequence of messages. It is shown in figure 23.3/11.

The macro Check\_Subscr\_Identity\_For\_MT\_SMS is shown in figure 23.3/8. The page and search procedures are shown in figures 23.3/12 and 23.3/13.

#### 23.3.6 Procedure in the SMS Router

If SMS Router is deployed together with IP-SM-GW, then mobile terminated short message transfer process for IP-SM-GW applies as described in subclause 23.3.7.

The mobile terminated short message transfer process in the SMS Router is shown in figure 23.3/14.

Procedure MT\_SM\_SMS\_ROUTER sheet 2: Allocated MT Correlation IDs have a limited lifetime, managed by Timer T1. The value of Timer T1 shall be operator configurable (its value being dependant on such factors as subscriber base, network size, number of roaming/SMS-interworking partners, average and peak SMS traffic load, etc.).

Procedure MT\_SM\_SMS\_ROUTER sheet 2: MAP parameters to be stored against the MT Correlation ID are IMSI, networkNode-Number, gprsNodeIndicator, and additional-Number (if and as received within MAP\_SEND\_ROUTING\_INFO\_FOR\_SHORT\_MESSAGE\_cnf), and optionally MSISDN as received within MAP\_SEND\_ROUTING\_INFO\_FOR\_SHORT\_MESSAGE\_ind from the SMS-GMSC (and relayed by the HLR)). The SMS Router may also store the GT, or just the CC and NDC parts of the GT, of the SMS-GMSC from which the MAP\_SEND\_ROUTING\_INFO\_FOR\_SHORT\_MESSAGE\_ind was received.

Procedure MT\_SM\_SMS\_ROUTER sheet 3: The SCCP called party SSN received with Open\_ind is used to decide whether the new dialogue is opend with the MSC or with the SGSN.

Procedure MT\_SM\_SMS\_ROUTER sheet 4: The decision box "Retry expected" takes the "Yes" exit if two addresses were received from the HLR, the first delivery attempt was unsuccessful, and the second attempt has not yet been made.

Procedure MT\_SM\_SMS\_ROUTER sheet 4: The task "Release MT Correlation ID" includes deleting of data stored against the MT Correlation ID.

### 23.3.7 Procedure in the IP-SM-GW

Process MT\_SM\_IPSMGW sheet 3: After unsuccessful delivery via the S-CSCF the IP-SM-GW may retry delivery via MSC and/or SGSN if MSC address and/or SGSN address are available (unless the reported error was 'memory capacity exceeded' in which case a retry shall not be done). If the retry is successful, a positive response is returned to the SMS-GMSC. If the retry is unsuccessful, an error indication is returned to the SMS-GMSC as follows: If one of the error indications received from S-CSCF, MSC, or SGSN is AbsentsSubscriberSM or UnidentifiedSubscriber, this error shall be returned to the SMS-GMSC.

Process MT\_SM\_IPSMGW sheet 3: The IP-SM-GW invokes the macro Report\_SM\_Delivery\_Stat\_IPSMGW if:

- the reason for failure to deliver the message is absent subscriber\_SM, unidentified subscriber or SM delivery failure with error cause "MS memory capacity exceeded", and the SC address is not yet included in the MWD set, or
- the reason for failure to deliver the message is absent subscriber\_SM, unidentified subscriber or SM delivery failure with error cause MS memory capacity exceeded, and the corresponding flag in the HLR (as indicated in the information received in the MAP\_INFORM\_SERVICE\_CENTRE) is not set, or
- the reason for failure to deliver the message is absent subscriber\_SM and the absent subscriber diagnostic is different from the absent subscriber diagnostic received in the MAP\_INFORM\_SERVICE\_CENTRE.

The mobile terminated short message transfer process in the IP-SM-GW is shown in figure 23.3/15.




Figure 23.3/3 (sheet 1 of 2): Process MT\_SM\_GMSC




Figure 23.3/3 (sheet 2 of 2): Process MT\_SM\_GMSC




Figure 23.3/4 (sheet 1 of 8): Procedure MT\_SM\_Delivery\_Attempt\_GMSC




Figure 23.3/4 (sheet 2 of 8): Procedure MT\_SM\_Delivery\_Attempt\_GMSC




Figure 23.3/4 (sheet 3 of 8): Procedure MT\_SM\_Delivery\_Attempt\_GMSC




Figure 23.3/4 (sheet 4 of 8): Procedure MT\_SM\_Delivery\_Attempt\_GMSC




Figure 23.3/4 (sheet 5 of 8): Procedure MT\_SM\_Delivery\_Attempt\_GMSC




Figure 23.3/4 (sheet 6 of 8): Procedure MT\_SM\_Delivery\_Attempt\_GMSC




Figure 23.3/4 (sheet 7 of 8): Procedure MT\_SM\_Delivery\_Attempt\_GMSC




Figure 23.3/4 (sheet 8 of 8): Procedure MT\_SM\_Delivery\_Attempt\_GMSC




Figure 23.3/5 (sheet 1 of 6): Process MT\_SM\_HLR




Figure 23.3/5 (sheet 2 of 6): Process MT\_SM\_HLR




Figure 23.3/5 (sheet 3 of 6): Process MT\_SM\_HLR




Figure 23.3/5 (sheet 4 of 6): Process MT\_SM\_HLR




Figure 23.3/5 (sheet 5 of 6): Process MT\_SM\_HLR




Figure 23.3/5 (sheet 6 of 6): Process MT\_SM\_HLR




Figure 23.3/5a (sheet 1 of 1): Procedure Perform\_Relaying




Figure 23.3/6 (sheet 1 of 4): Procedure MT\_SM\_VMSC




Figure 23.3/6 (sheet 2 of 4): Procedure MT\_SM\_VMSC




Figure 23.3/6 (sheet 3 of 4): Procedure MT\_SM\_VMSC




Figure 23.3/6 (sheet 4 of 4): Procedure MT\_SM\_VMSC




Figure 23.3/7 (sheet 1 of 4): Macro MT\_SM\_Transfer\_MSC




Figure 23.3/7 (sheet 2 of 4): Macro MT\_SM\_Transfer\_MSC




Figure 23.3/7 (sheet 3 of 4): Macro MT\_SM\_Transfer\_MSC




Figure 23.3/7 (sheet 4 of 4): Macro MT\_SM\_Transfer\_MSC




Figure 23.3/8: Macro Check\_Subscr\_Identity\_For\_MT\_SMS




Figure 23.3/9 (sheet 1 of 3): Process MT\_SM\_VLR




Figure 23.3/9 (sheet 2 of 3): Process MT\_SM\_VLR




Figure 23.3/9 (sheet 3 of 3): Process MT\_SM\_VLR




Figure 23.3/10 (sheet 1 of 4): Process MT\_SM\_SGSN




Figure 23.3/10 (sheet 2 of 4): Process MT\_SM\_ SGSN




Figure 23.3/10 (sheet 3 of 4): Process MT\_SM\_ SGSN




Figure 23.3/10 (sheet 4 of 4): Process MT\_SM\_ SGSN




Figure 23.3/11 (sheet 1 of 3): Macro MT\_SM\_TRANSFER\_SGSN

746




Figure 23.3/11 (sheet 2 of 3): Macro MT\_SM\_TRANSFER\_SGSN




Figure 23.3/11 (sheet 3 of 3): Macro MT\_SM\_TRANSFER\_SGSN




Figure 23.3/12 (sheet 1 of 1): Procedure Page\_SMS\_SGSN

749




Figure 23.3/13 (sheet 1 of 1): Procedure Search\_SMS\_SGSN




Figure 23.3/14 (sheet 1 of 4): Process MT\_SM\_ SMS\_ROUTER




Figure 23.3/14 (sheet 2 of 4): Process MT\_SM\_ SMS\_ROUTER




Figure 23.3/14 (sheet 3 of 4): Process MT\_SM\_ SMS\_ROUTER




Figure 23.3/14 (sheet 4 of 4): Process MT\_SM\_ SMS\_ROUTER




Figure 23.3/15 (sheet 1 of 3): Process MT\_SM\_ IPSMGW




Figure 23.3/15 (sheet 2 of 3): Process MT\_SM\_ IPSMGW





Figure 23.3/15 (sheet 3 of 3): Process MT\_SM\_ IPSMGW

#### 23.4 The Short Message Alert procedure

The Short Message Alert procedure is used to alert the Service Centre when the mobile subscriber is active after a short message transfer has failed because the mobile subscriber is not reachable, or when the MS has indicated that it has memory capacity to accept a short message.


The message flow for the Short Message Alert procedure for the case when the mobile subscriber was not reachable is shown in figure 23.4/1.



- 1) CM Service Request (\*\*), Page response or Location Updating (3GPP TS 24.008 [35]).
- MAP\_PROCESS\_ACCESS\_REQUEST / MAP\_UPDATE\_LOCATION\_AREA (\*\*). 2)
- MAP\_READY\_FOR\_SM (Mobile Present) / MAP\_UPDATE\_LOCATION / 3) Supplementary Service Control Request (\*).
- MAP\_READY\_FOR\_SM\_ACK (\*). 4)
- MAP\_ALERT\_SERVICE\_CENTRE (notes 1 and 2). 5)
- Alert Service Centre (3GPP TS 23.040). 6)
- MAP\_ALERT\_SERVICE\_CENTRE\_ACK. 7)
- NOTE 1: To all Service Centres in the Message Waiting List.
- The HLR initiates the MAP\_ALERT\_SERVICE\_CENTRE service only if the MS Memory Capacity Exceeded flag is clear.
- For GPRS, messages 3) and 4) are sent/received by the SGSN. (\*) (\*\*)
- These messages are not used by the SGSN.

Figure 23.4/1: Short message alert procedure (Mobile is present)

The message flow for the Short Message Alert procedure for the case where the MS indicates that it has memory capacity to accept one or more short messages is shown in figure 23.4/2.



- SM memory capacity available (3GPP TS 24.011 [37]). 1)
- 2) MAP\_READY\_FOR\_SM (Memory Available) (\*).
- 3) MAP\_READY\_FOR\_SM (Memory Available) (\*\*).
- 4) MAP\_READY\_FOR\_SM\_ACK (\*\*).
- 5) MAP\_READY\_FOR\_SM\_ACK (\*).
- SM memory capacity available (Acknowledge) (3GPP TS 24.011 [37]). 6)
- MAP\_ALERT\_SERVICE\_CENTRE (note). Alert Service Centre (3GPP TS 23.040). 7)
- 8)
- MAP\_ALERT\_SERVICE\_CENTRE\_ACK. 9)
- NOTE: To all Service Centres in the Message Waiting List.
- Messages 2) and 5) are not used by the SGSN.
- (\*) (\*\*) For GPRS, messages 3) and 4) are sent/received by the SGSN.


Figure 23.4/2: Short message alert procedure (MS memory capacity available)

In addition the following MAP services are used in the MS memory available case:

MAP_PROCESS_ACCESS_REQUEST	(see subclause 8.3); (*)
MAP_AUTHENTICATE	(see subclause 8.5); (*)
MAP_SET_CIPHERING_MODE	(see subclause 8.6); (*)
MAP_PROVIDE_IMSI	(see subclause 8.9); (*)
MAP_CHECK_IMEI	(see subclause 8.7);
MAP_FORWARD_NEW_TMSI	(see subclause 8.9); (*)
MAP_TRACE_SUBSCRIBER_ACTIVITY	(see subclause 9.1). (*)

(\*) These services are not used by the SGSN.

The Short Message Alert procedure when the MS indicates successful transfer after polling is shown in figure 23.4/3.



- 1) MAP\_REPORT\_SM\_DELIVERY\_STATUS (Successful Transfer).
- 2) MAP\_REPORT\_SM\_DELIVERY\_STATUS\_ACK.
- MAP\_ALERT\_SERVICE\_CENTRE (note).
- 4) Alert Service Centre (3GPP TS 23.040).
- 5) MAP\_ALERT\_SERVICE\_CENTRE\_ACK.

NOTE: To all Service Centres in the Message Waiting List.

Figure 23.4/3: Short message alert procedure (Successful transfer after polling)

# 23.4.1 Procedure in the Serving MSC – the MS has memory available

The process starts when the MSC receives a notification from the MS that it has memory available. The process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check\_Confirmation see subclause 25.2.2.

The short message alert process in the MSC for the MS memory capacity available case is shown in figure 23.4/4.

#### 23.4.2 Procedures in the VLR

### 23.4.2.1 The Mobile Subscriber is present

If the VLR successfully handles a MAP\_PROCESS\_ACCESS\_REQUEST indication or a MAP\_UPDATE\_LOCATION\_AREA indication while the MS Not Reachable Flag (MNRF) is set, the VLR sends a MAP\_READY\_FOR\_SM request to the HLR. The Alert Reason is set to indicate that the mobile subscriber is present for non GPRS. If authentication fails during the handling of a MAP\_PROCESS\_ACCESS\_REQUEST indication or a MAP\_UPDATE\_LOCATION\_AREA indication, the VLR shall not send a MAP\_READY\_FOR\_SM request to the HLR. The process in the VLR is described in detail in subclause 25.10.1.

## 23.4.2.2 The MS has memory available

The process starts when the VLR receives dialogue opening request followed by a MAP\_PROCESS\_ACCESS\_REQUEST indication including a CM service type Short Message Service. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;

Receive\_Open\_Cnf see subclause 25.1.2;

Check\_Indication see subclause 25.2.1;
Check Confirmation see subclause 25.2.2.

The short message alert process in the VLR for the MS memory capacity available case is shown in figure 23.4/5.

### 23.4.3 Procedures in the SGSN

#### 23.4.3.1 The Mobile Subscriber is present

If the SGSN successfully handles a Page response, Attach request or Routing Area Update request message (3GPP TS 24.008 [35]), while the MS Not Reachable for GPRS (MNRG) flag is set, the SGSN sends a MAP\_READY\_FOR\_SM request to the HLR. The Alert Reason is set to indicate that the mobile subscriber is present for GPRS. If authentication fails during the handling of a Page response, Attach request or Routing Area Update request, the SGSN shall not send a MAP\_READY\_FOR\_SM request to the HLR

The process in the SGSN is described in detail in subclause 25.10.23.

## 23.4.3.2 The Mobile Equipment has memory available

The process starts when the SGSN receives an RP\_SM\_MEMORY\_AVAILABLE indication from the MS. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

The short message alert procedure in the SGSN for the MS memory capacity available case is shown in figure 23.4/6.

### 23.4.4 Procedure in the HLR

The process starts when the HLR receives a dialogue opening request using the application context mwdMngtContext. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Check\_Indication see subclause 25.2.1;
Alert\_Service\_Centre\_HLR see subclause 25.10.3.

Sheet 1: If the dialogue opening request is from an SGSN, version 2 and version 1 of the application context are not applicable.

The short message alert process in the HLR is shown in figure 23.4/7.

# 23.4.5 Procedure in the SMS Interworking MSC

The process starts when the SMS-IWMSC receives a dialogue opening request using the application context shortMsgAlertContext. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Check\_Indication see subclause 25.2.1.

The short message alert process in the SMS-IWMSC is shown in figure 23.4/8.




Figure 23.4/4: Procedure SM\_Alert\_MSC




Figure 23.4/5 (sheet 1 of 2): Procedure SM\_Alert\_VLR




Figure 23.4/5 (sheet 2 of 2): Procedure SM\_Alert\_VLR




Figure 23.4/6 (sheet 1 of 2): Process SM\_Alert\_SGSN




Figure 23.4/6 (sheet 2 of 2): Process SM\_Alert\_SGSN




Figure 23.4/7 (sheet 1 of 2): Process SM\_Alert\_HLR




Figure 23.4/7 (sheet 2 of 2): Process SM\_Alert\_HLR





Figure 23.4/8: Process Alert\_SC\_IWMSC

# 23.5 The SM delivery status report procedure

The SM delivery status report procedure is used:

- to set the Service Centre address into the message waiting list in the HLR after short message delivery has failed because the subscriber is absent or unidentified or the memory capacity is exceeded. The procedure sets:
  - the Memory Capacity Exceeded Flag (MCEF) in the HLR if the MS memory does not have room for more messages;
  - and/or the MS Not Reachable Flag for non-GPRS if there is no record for the subscriber in the VLR or the subscriber does not respond to paging for delivery via the MSC;
  - and/or the MS Not Reachable for GPRS (MNRG) flag if there is no record for the subscriber in the SGSN or the subscriber does not respond to paging for delivery via the SGSN;
  - and/or the UE Not Reachable for IP (UNRI) flag if delivery via the IMS was not successful.
- to report to the HLRthat delivery has succeeded. The conditions for report of a successful delivery are described in subclause 23.3.1.

The message flow for the SM delivery status report procedure is shown in figure 23.5/1.



- MAP\_MT\_FORWARD\_SHORT\_MESSAGE\_ACK/\_NACK (Absent subscriber\_SM, unidentified subscriber or memory capacity exceeded).
- 2) MAP\_REPORT\_SM\_DELIVERY\_STATUS. (The HLR ignores the content of this message when an IP-SM-GW is deployed)
- 2a) MAP\_REPORT\_SM\_DELIVERY\_STATUS (sent only by IP-SM-GW)
- 2b) MAP-REPORT\_SM\_DELIVERY\_STATUS\_ACK.
- MAP\_REPORT\_SM\_DELIVERY\_STATUS\_ACK.
- 4) Short Message Negative Acknowledgement (3GPP TS 23.040).

Figure 23.5/1: Short message delivery status report procedure

### 23.5.1 Procedure in the SMS-GMSC

The conditions for the GMSC to invoke the short message delivery status report procedure are specified in subclause 23.3.1.

The short message delivery status report macro in the SMS-GMSC is shown in figure 23.5/2.

# 23.5.2 Procedure in the HLR

When the HLR receives a MAP\_REPORT\_SM\_DELIVERY\_STATUS indication while an IP-SM-GW is deployed in the network and the message is not received from an IP-SM-GW or SMS Router, it ignores the information received in the message; otherwise it acts as described in subclause 23.6, macro Report\_SM\_Delivery\_Stat\_HLR.

The short message delivery status report process in the HLR is shown in figure 23.5/3.

# 23.5.3 Procedure in the IP-SM-GW

The conditions for the IP-SM-GW and for SMS Router, if deployed with IP-SM-GW, to invoke the short message delivery status report procedure are specified in subclause 23.3.7.

The short message delivery status report macro in the IP-SM-GW is shown in figure 23.5/4.




Figure 23.5/2: Macro Report\_SM\_Delivery\_Stat\_GMSC




Figure 23.5/3: Process SM\_Delivery\_Status\_Report\_HLR




Figure 23.5/4: Macro Report\_SM\_Delivery\_Stat\_IPSMGW

# 23.6 The macro Report\_SM\_Delivery\_Stat\_HLR

This macro is invoked when the HLR receives a MAP\_REPORT\_SM\_DELIVERY\_STATUS indication from the SMS-GMSC. The macro invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Check\_Indication see subclause 25.2.1;
Alert\_Service\_Centre\_HLR see subclause 25.10.3.

Sheet 1: If the MAP\_REPORT\_SM\_DELIVERY\_STATUS indication did not include the GPRS support indicator, the HLR deduces the domain for which the delivery report applies as follows:

- if the subscriber is a GPRS-only subscriber, the report applies for GPRS;
- if the subscriber is a non-GPRS-only subscriber, the report applies for non-GPRS;
- if the subscriber is a GPRS and non-GPRS subscriber and the subscription option for MT SMS delivery when the SMS-GMSC does not support GPRS is set to "Delivery via the SGSN", the report applies for GPRS;
- if the subscriber is a GPRS and non-GPRS subscriber and the subscription option for MT SMS delivery when the SMS-GMSC does not support GPRS is set to "Delivery via the MSC", the report applies for non-GPRS;

The short message delivery status report macro in the HLR is shown in figure 23.6/1.




Figure 23.6/1 (sheet 1 of 2): Macro Report\_SM\_Delivery\_Stat\_HLR




Figure 23.6/1 (sheet 2 of 2): Macro Report\_SM\_Delivery\_Stat\_HLR

# 23.7 The mobile terminated short message transfer procedure for VGCS

The mobile terminated short message transfer for VGCS procedure is used for forwarding a short message from a Service Centre to the group call anchor MSC. The message flow for the mobile terminated short message transfer procedure for VGCS is shown in figure 23.7/1.




Figure 23.7/1: Mobile terminated short message for VGCS service procedures

- 1) Short Message (3GPP TS 23.040).
- 2) TCAP BEGIN (\*)
- 3) TCAP CONTINUE (\*)
- 4) MAP\_MT\_FORWARD\_SM\_FOR\_VGCS.
- 5) GCR\_SMS\_INTERROGATION (3GPP TS 43.068).
- 6) GCR\_SMS\_INTERROGATION\_ACK (3GPP TS 43.068).
- 7) MAP\_MT\_FORWARD\_SM\_FOR\_VGCS\_ACK.
- 8) Short Message Acknowledgement (3GPP TS 23.040).
- (\*) If
  - a)

- the capacity of a message signal unit in the lower layers of the protocol is enough to carry the content of the MAP\_OPEN request and the content of the MAP\_MT\_FORWARD\_SM\_FOR\_VGCS request in a single TC message,

and

 the SMS Gateway MSC operator and the serving node (Anchor-MSC) operator agreed not to use the TCAP handshake countermeasure against SMS fraud for messages exchanged between their networks (see 3GPP TS 33.204 [34a])

then

the TCAP handshake may be omitted.

## 23.7.1 Procedure in the SMS-GMSC

The process starts when the SMS-GMSC receives an SC\_RP\_MT\_DATA indication from a Service Centre. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2;

Check\_Confirmation see subclause 25.2.2.

The mobile terminated short message transfer for VGCS process in the SMS-GMSC is shown in figure 23.7/2.

### 23.7.2 Procedure in the Anchor MSC

The process starts when the MSC receives a dialogue opening request with the application context shortMsgMT-Relay-VGCS-Context. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;

The mobile terminated short message transfer for VGCS process in the Anchor MSC is shown in figure 23.7/3

Procedure MT\_SM\_VGCS\_GMSC sheet 1: The decision box "TCAP Handshake required" takes the "yes" or "no" exit depending on agreements between the Serving MSC's operator and the SMS Gateway MSC's operator (see 3GPP TS 33.204 [34a]).




Figure 23.7/2 (sheet 1 of 2): Process MT\_SM\_VGCS\_GMSC




Figure 23.7/2 (sheet 2 of 2): Process MT\_SM\_VGCS\_GMSC




Figure 23.7/3 (sheet 1 of 2): Process MT\_SM\_VGCS\_Anchor MSC




Figure 23.7/3 (sheet 2 of 2): Process MT\_SM\_VGCS\_Anchor MSC

# 24 GPRS process description

The MAP GPRS procedures are used for the Network Requested PDP-Context Activation procedures.

The stage 2 specification for General Packet Radio Service (GPRS) is in 3GPP TS 23.060 [104].

# 24.1 Procedure for retrieval of routeing information for GPRS

# 24.1.1 Process in the GGSN

The MAP process in the GGSN to request routeing information for a network requested PDP context activation is shown in figure 24.1/2. The MAP process invokes macros not defined in this clause; the definition of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

# 24.1.2 Process in the HLR

The MAP process in the HLR to provide routing information for a network-requested PDP context activation is shown in figure 24.1/1. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Check Indication see subclause 25.2.1.




Figure 24.1/1: Process SRI\_GPRS\_GGSN

786




Figure 24.1/2: Process SRI\_GPRS\_HLR

# 24.2 Procedure for reporting failure to establish a network requested PDP context

## 24.2.1 Process in the GGSN

The MAP process in the GGSN to report the failure to establish a network requested PDP context is shown in figure 24.2/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

## 24.2.2 Process in the HLR

The MAP process in the HLR to handle a notification from the GGSN that a network requested PDP context could not be established is shown in figure 24.2/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;

Check Indication see subclause 25.2.1.




Figure 24.2/1: Process Failure\_Report\_GGSN




Figure 24.2/2: Process Failure\_Report\_HLR

# 24.3 Procedure for reporting that an MS has become reachable for GPRS

## 24.3.1 Process in the HLR

The MAP process in the HLR to report that an MS is reachable for GPRS is shown in figure 24.3/1. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

# 24.3.2 Process in the GGSN for Note Ms Present For Gprs

The MAP process in the GGSN to handle a notification that the subscriber is present for GPRS again is shown in figure 24.3/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1; Check\_Indication see subclause 25.2.1.




Figure 24.3/1: Process Note\_MS\_Present\_For\_GPRS\_HLR




Figure 24.3/2: Process Note\_MS\_Present\_For\_GPRS\_GGSN

# 24A CSE interrogation and control of subscriber data

### 24A.1 General

The MAP procedures for interrogation and control of subscriber data are used to allow the CSE:

- to retrieve subscriber data from the HLR;
- to modify subscriber data in the HLR;
- to receive notification from the HLR when there is a change in subscriber data;
- to request information about the location of a subscriber from the HLR or the GMLC;
- to request information about the state of a subscriber from the HLR.

The following application context refers to a complex MAP user consisting of several processes:

- anyTimeInfoHandlingContext

This application context needs a co-ordinating process in the HLR.

The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;

The Any Time Info Handling Co-ordinator process in the HLR is shown in figure 24A.1/1.




Figure 24A.1/1: Process Co\_ATIH\_HLR

## 24A.2 Any Time Subscription Interrogation procedure

#### 24A.2.1 General

The message flow for successful retrieval of subscription information related to an any time subscription interrogation from the CAMEL server are shown in figure 24A.1/1. In an IP Multimedia Core Network, an IM-SSF can take on the role of a gsmSCF for this procedure (see 3GPP TS 23.278 [125]).




Figure 24A.2/1: Message flow for any time subscription interrogation

The following MAP service is used to retrieve requested information:

MAP\_ANY\_TIME\_SUBSCRIPTION\_INTERROGATION see subclause 8.11.3.

## 24A.2.2 Process in the gsmSCF

The MAP process in the gsmSCF to obtain subscription information in response to a request from the application process in the gsmSCF is shown in figure 24A.2/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2

#### 24A.2.3 Process in the HLR

The MAP process in the HLR to provide subscription information in response to an interrogation from the CAMEL server is shown in figure 24A.2/3. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check\_Indication see subclause 25.2.2

If the MAP\_ANY\_TIME\_SUBSCRIPTION\_INTERROGATION service response cannot be carried in a single TC-Result component, it is carried in one or more TC-Result-NL components (each sent in a TC-CONTINUE), followed by a TC-Result-L component in a TC-END message.




Figure 24A.2/2: Process ATSI\_gsmSCF




Figure 24A.2/3: Process ATSI\_HLR

# 24A.3 Any Time Modification procedure

### 24A.3.1 General

The message flow for successful modification of subscription information related to an any time modification request from the CAMEL server is shown in figure 24A.3/1




Figure 24A.3/1: Message flow for any time modification

The following MAP service is used to modify subscription information:

MAP\_ANY\_TIME\_MODIFICATION

see subclause 8.11.4.

### 24A.3.2 Process in the gsmSCF

The MAP process in the gsmSCF to modify subscription information in response to a request from the application process in the gsmSCF is shown in figure 24A.3/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check Confirmation see subclause 25.2.2

#### 24A.3.3 Process in the HLR

The MAP process in the HLR to modify subscriber information in response to a modification request from the CAMEL server is shown in figure 24A.3/3. The MAP process invokes a macro and a process not defined in this clause; the definitions of these can be found as follows:

Check\_Indication see subclause 25.2.2; Insert\_Subs\_Data\_Stand\_Alone\_HLR see subclause 25.7.3;

If the macro takes the OK exit, the MAP process waits for a service indication.

If the MAP\_ANY\_TIME\_MODIFICATION service response cannot be carried in a single TC-Result component, it is carried in one or more TC-Result-NL components (each sent in a TC-CONTINUE), followed by a TC-Result-L component in a TC-END message.

If the serving node (VLR or SGSN) is to be updated after the modification, the MAP process creates an instance of the appropriate process (Insert\_Subs\_Data\_Stand\_Alone\_HLR for VLR update, Insert\_GPRS\_Subs\_Data\_Stand\_Alone\_HLR for SGSN update).




Figure 24A.3/2: Process ATM\_gsmSCF




Figure 24A.3/3: Process ATM\_HLR

## 24A.4 Subscriber Data Modification Notification procedure

#### 24A.4.1 General

The Subscriber Data Modification Notification procedure is used to notify a gsmSCF about the modification of subscriber data. In an IP Multimedia Core Network, an IM-SSF can take on the role of a gsmSCF for this procedure.

The stage 2 specification for Subscriber Data Modification Notification is in 3GPP TS 23.078 [98] and 3GPP TS 23.278 [125]. The interworking between the MAP signalling procedures and the Subscriber Data Modification Notification procedures for each entity (HLR, gsmSCF) is shown by the transfer of signals between these processes.

The following services are used:




Figure 24A.4/1: Message flow for subscriber data modification notification

The following MAP service is used to send the notification to the gsmSCF:

MAP\_NOTE\_SUBSCRIBER\_DATA\_MODIFIED

see subclause 8.11.5.

#### 24A.4.2 Process in the HLR

The MAP process in the HLR to send modified data to the gsmSCF is shown in figure 24A.4/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

If the required information cannot be carried in a single MAP\_NOTE\_SUBSCRIBER\_DATA\_MODIFIED service request, the HLR segments the information into two or more requests. The "All Information Sent" parameter is omitted from each request except the last.

Sheet 2: If the MAP\_NOTE\_SUBSCRIBER\_DATA\_MODIFIED service request contained the "All Information Sent" parameter, the test "All information sent" takes the "Yes" exit.

# 24A.4.3 Process in the gsmSCF

The MAP process in the gsmSCF to handle a notification to the gsmSCF of change of subscriber data is shown in figure 24A.4/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1; Check\_Indication see subclause 25.2.1 If the MAP\_NOTE\_SUBSCRIBER\_DATA\_MODIFIED service indication contained the "All Information Sent" parameter, the test "All information sent" takes the "Yes" exit.

If the test "All information sent" takes the "No" exit, the MAP process stores the data received in the MAP\_NOTE\_SUBSCRIBER\_DATA\_MODIFIED service indication. If the test "All information sent" takes the "Yes" exit, the MAP process assembles the data received in all the MAP\_NOTE\_SUBSCRIBER\_DATA\_MODIFIED service indications received in the dialogue and sends the assembled data to the application process in the gsmSCF.




Figure 24A.4/2 (sheet 1 of 2): Process NSDC\_HLR




Figure 24A.4/2 (sheet 2 of 2): Process NSDC\_HLR





Figure 24A.4/3: Process NSDC\_gsmSCF

## 24A.5 Any Time Interrogation procedure

### 24A.5.1 General

The message flows for successful retrieval of subscriber information related to an any time interrogation from the CAMEL server are shown in figure 24A.5/1 for interrogation directed to an HLR and figure 24A.5/2 for interrogation directed to a GMLC.



- 1) MAP\_ANY\_TIME\_INTERROGATION\_req/ind
- 2) MAP\_PROVIDE\_SUBSCRIBER\_INFO\_reg/ind
- 3) MAP\_PROVIDE\_SUBSCRIBER\_INFO\_rsp/cnf
- MAP\_ANY\_TIME\_INTERROGATION\_rsp/cnf


Figure 24A.5/1: Message flow for any time interrogation (gsmSCF to HLR)

The following MAP services are used to retrieve information about the status and/or location of a subscriber:

MAP\_ANY\_TIME\_INTERROGATION see subclause 8.11.1;

MAP\_PROVIDE\_SUBSCRIBER\_INFO see subclause 8.11.2.

The HLR sends the MAP\_PROVIDE\_SUBSCRIBER\_INFO request to the SGSN or the VLR, according to the domain for which the gsmSCF requested the information.



- 1) MAP\_ANY\_TIME\_INTERROGATION\_req/ind
- MAP\_ANY\_TIME\_INTERROGATION\_rsp/cnf

Figure 24A.5/2: Message flow for any time interrogation (gsmSCF to GMLC)

The following MAP service is used to retrieve location information from a GMLC:

MAP\_ANY\_TIME\_INTERROGATION see subclause 8.11.1;

In addition, the GMLC may use MAP Services specific to Location Services.

### 24A.5.2 Procedures in the gsmSCF

The process in the gsmSCF to request information about the location and/or state of a subscriber from the HLR is shown in figure 24A.5/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

The process in the gsmSCF to request location information from the GMLC is shown in figure 24A.5/4. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

#### 24A.5.3 Procedure in the HLR

The MAP process in the HLR to provide subscriber information in response to an interrogation from the CAMEL server is shown in figure 24A.5/5. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1;
Receive\_Open\_Cnf see subclause 25.1.2;
Check\_Confirmation see subclause 25.2.2.

### 24A.5.4 Procedure in the GMLC

The MAP process in the GMLC to provide location information in response to a request from the gsmSCF is shown in figure 24A.5/6. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1.




Figure 24A.5/3: Process ATI\_To\_HLR\_gsmSCF




Figure 24A.5/4: Process ATI\_To\_GMLC\_gsmSCF




Figure 24A.5/5 (sheet 1 of 2): Process ATI\_HLR




Figure 24A.5/5 (sheet 2 of 2): Process ATI\_HLR




Figure 24A.5/6: Process ATI\_GMLC

# 24B Location Services process description

## 24B.1 Routeing information retrieval procedure for LCS

### 24B.1.1 General

The message flow for successful retrieval of routeing information related to location services is shown in figure 24B.1/1.




Figure 24B.1/1: Message flow for retrieval of routeing information for LCS

The following MAP service is used to retrieve routeing information:

MAP\_SEND\_ROUTING\_INFO\_FOR\_LCS

see subclause 13A.1.

### 24B.1.2 Process in the GMLC

The MAP process in the GMLC to request routeing information for LCS is shown in figure 24B.1/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

#### 24B.1.3 Process in the HLR

The MAP process in the HLR to handle a request for routeing information for LCS is shown in figure 24B.1/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1; Check\_Indication see subclause 25.2.1.




Figure 24B.1/2: Process SRI\_LCS\_GMLC




Figure 24B.1/3: Process SRI\_LCS\_HLR

# 24B.2 Provide Subscriber Location procedure

#### 24B.2.1 General

The message flow for successful retrieval of the location information of a target MS related to location services is shown in figure 24B.1/1.




Figure 24B.2/1: Message flow for retrieval of location information

The following MAP service is used to retrieve location information:

MAP\_PROVIDE\_SUBSCRIBER\_LOCATION

see subclause 13A.2.

#### 24B.2.2 Process in the GMLC

The MAP process in the GMLC to request location information from an MSC or an SGSN is shown in figure 24B.2/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check Confirmation see subclause 25.2.2.

#### 24B.2.3 Process in the MSC

The MAP process in the MSC to handle a request for location information from a GMLC is shown in figure 24B.2/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1; Check\_Indication see subclause 25.2.1.

### 24B.2.4 Process in the SGSN

The MAP process in the SGSN to handle a request for location information from a GMLC is shown in figure 24B.2/4. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1; Check\_Indication see subclause 25.2.1.




Figure 24B.2/2: Process PSL\_GMLC




Figure 24B.2/3: Process PSL\_MSC




Figure 24B.2/4: Process PSL\_SGSN

# 24B.3 Subscriber Location Report procedure

#### 24B.3.1 General

The message flow for successful report of the location information of a target MS related to location services is shown in figure 24B.3/1.




Figure 24B.3/1: Message flow for report of the location information

The following MAP services are used to report location information:

MAP SUBSCRIBER LOCATION REPORT

see subclause 13A.3.

### 24B.3.2 Process in the MSC

The MAP process in the MSC to send a subscriber location report to the GMLC is shown in figure 24B.3/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check Confirmation see subclause 25.2.2.

#### 24B.3.3 Process in the SGSN

The MAP process in the SGSN to send a subscriber location report to the GMLC is shown in figure 24B.3/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Cnf see subclause 25.1.2; Check\_Confirmation see subclause 25.2.2.

### 24B.3.4 Process in the GMLC

The MAP process in the GMLC to handle a subscriber location report is shown in figure 24B.3/4. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive\_Open\_Ind see subclause 25.1.1; Check\_Indication see subclause 25.2.1.




Figure 24B.3/2: Process SLR\_MSC




Figure 24B.3/3: Process SLR\_SGSN




Figure 24B.3/4: Process SLR\_GMLC

# 25 General macro description

# 25.1 MAP\_OPEN handling macros

### 25.1.1 Macro Receive\_Open\_Ind

This macro is used by a MAP service-user procedure when a peer entity requests opening of a dialogue.

### 25.1.2 Macro Receive\_Open\_Cnf

This macro is used by a user procedure after it has requested opening of a dialogue towards a peer entity.




Figure 25.1/1 (sheet 1 of 2): Macro Receive\_Open\_Ind




Figure 25.1/1 (sheet 2 of 2): Macro Receive\_Open\_Ind




Figure 25.1/2: Macro Receive\_Open\_Cnf




Figure 25.1/3: Macro Check\_Reference

# 25.2 Macros to check the content of indication and confirmation primitives

## 25.2.1 Macro Check\_Indication

This macro checks that an indication includes all the parameters required by the application, no more and no less, and that the parameters are all within the correct range. It does not handle syntax checking; that is part of the function of the MAP protocol machine.

#### 25.2.2 Macro Check\_Confirmation

This macro checks whether a confirmation contains an error or a result, and if it contains a result whether the result is correctly formed.




Figure 25.2/1: Macro Check\_Indication




Figure 25.2/2: Macro Check\_Confirmation

## 25.3 The page and search macros

#### 25.3.1 Macro PAGE\_MSC

This macro is called if an unstructured SS notification, a network-initiated unstructured SS request or a mobile terminating short message is to be delivered to the MS and the current location area identity of the MS is known in the VLR.

If an MM-connection over the radio link already exists for the given IMSI, the MSC sets the access connection status according to the characteristics of the existing connection (i.e. RR-connection established, ciphering mode on/off, MM-connection existing and authenticated or not).

If the MSC pages the MS and the VLR provided the TMSI, the MSC uses it to identify the MS at the radio interface; otherwise the MSC uses the IMSI. The MSC also uses the IMSI to determine the page group (see 3GPP TS 24.008 [35]).

If the MS responds with a channel request containing an establishment cause which is not "answer to paging" the MSC sends a MAP\_PAGE response primitive with user error Busy Subscriber. This gives priority to the mobile originating request. Alternatively, as an implementation option, the MSC may treat this as a response to paging, which gives priority to the mobile terminating request.

If the paging is for MT SMS delivery and the VLR aborts the transaction before the MSC receives a response from the MS, the MSC aborts the transaction with the SMS-GMSC.

#### 25.3.2 Macro Search\_For\_MS\_MSC

This macro is called if an unstructured SS notification, a network-initiated unstructured SS request or a mobile terminating short message is to be delivered to the MS and the current location area identity of the MS is not known in VLR.

If an MM-connection over the radio link already exists for the given IMSI, the MSC returns a MAP\_SEARCH\_FOR\_MS response containing the IMSI and current location area identification of the called MS to the VLR and sets the access connection status according to the characteristics of the existing connection (i.e. RR-connection established, ciphering mode on/off, MM-connection existing and authenticated or not).

If the MSC pages the MS, the MSC uses the IMSI to identify the subscriber and the page group (see 3GPP TS 24.008 [35]).

If the MS responds with a channel request containing an establishment cause which is not "answer to paging" the MSC sends a MAP\_SEARCH\_FOR\_MS response with user error Busy Subscriber. This gives priority to the mobile originating request. Alternatively, as an implementation option, the MSC may treat this as a response to paging, which gives priority to the mobile terminating request.

If the paging is for MT SMS delivery and the VLR aborts the transaction before the MSC receives a response from the MS, the MSC aborts the transaction with the SMS-GMSC.




Figure 25.3/1: Macro Page\_MSC




Figure 25.3/2: Macro Search\_for\_MS\_MSC

## 25.4 Macros for handling an Access Request

These macros are invoked when a MS accesses the network, e.g. to submit an MO short message or when responding to paging. The macros handle identification and authentication of the mobile subscriber as well as invocation of security related features (see 3GPP TS 42.009 [6]).

#### 25.4.1 Macro Process Access Request MSC

Sheet 1: The MAP\_PROCESS\_ACCESS\_REQUEST request includes the following parameters:

- the received subscriber identification (IMSI, TMSI);
- the CM service type, indicating the type of request;
- the status of the access connection, i.e. whether a connection to this MS already exists and if so, whether it is already authenticated and ciphered;
- the current location area id of the MS: and
- the CKSN received from the MS.

Sheet 2, sheet 3: If the MSC receives an A\_SETUP indication while it is waiting for further instructions from the VLR or for the acknowledgment of TMSI reallocation from the MS, the MSC saves the setup request for processing after control has returned from the macro Process\_Access\_Request\_MSC to the calling process.

Sheet 3: When the MSC is waiting for a possible instruction to allocate a new TMSI, a MAP\_DELIMITER indication indicates that TMSI reallocation is not required.

Sheet 3: If the MS sends a TMSI reallocation failure in response to the TMSI reallocation command, the MSC takes the OK exit; the VLR treats the lack of response as a provider error (see macro Process\_Access\_Request\_VLR).

#### 25.4.2 Macro Process\_Access\_Request\_VLR

Sheet 3: If the MSC does not send a positive response to the MAP\_FORWARD\_NEW\_TMSI request, this is treated as a MAP\_FORWARD\_NEW\_TMSI confirmation containing a provider error. The Macro takes the Error exit. If TMSI reallocation does not succeed, the old TMSI is frozen, to prevent it from being reallocated. In this case, both old and new TMSIs are regarded as valid.

## 25.4.3 Macro Obtain\_Identity\_VLR

This macro is invoked by the macro Process\_Access\_Request\_VLR if the subscriber's identity is not known in the VLR.

It is an operator option to allow or prevent retrieval of the IMSI without encryption.

## 25.4.4 Process Update\_Location\_Child\_VLR

This process is started when the subscriber successfully accesses the network, e.g. for mobile originated short message submission, response to paging or supplementary services handling.

The procedure Notify\_gsmSCF is specified in 3GPP TS 23.078.




Figure 25.4/1 (sheet 1 of 3): Macro Process\_Access\_Request\_MSC




Figure 25.4/1 (sheet 2 of 3): Macro Process\_Access\_Request\_MSC




Figure 25.4/1 (sheet 3 of 3): Macro Process\_Access\_Request\_MSC




Figure 25.4/2 (sheet 1 of 3): Macro Process\_Access\_Request\_VLR




Figure 25.4/2 (sheet 2 of 3): Macro Process\_Access\_Request\_VLR




Figure 25.4/2 (sheet 3 of 3): Macro Process\_Access\_Request\_VLR




Figure 25.4/3: Macro Obtain\_Identity\_VLR




Figure 25.4/4 (sheet 1 of 2): Process Update\_Location\_Child\_VLR




Figure 25.4/4 (sheet 2 of 2): Process Update\_Location\_Child\_VLR

## 25.5 Authentication macros and processes

The following macros are used in the network in order to enable authentication of a mobile subscriber.

#### 25.5.1 Macro Authenticate MSC

This macro is used by the MSC to relay a request for authentication transparently from the VLR to the MS, wait for a response from the MS and relay the response from the MS back to the VLR.

#### 25.5.2 Macro Authenticate VLR

This macro is used by the VLR to control the authentication of a subscriber.

Sheet 1: The test "Received SRES=Expected SRES" indicates:

- a comparison of the Signed RESult received from the MS with the Signed RESult received from the HLR, if GSM authentication is used (see 3GPP TS 43.020 [24]), or
- a comparison of the RESult received from the MS with the expected RESult received from the HLR, if UMTS authentication is used (see 3GPP TS 33.102).

#### 25.5.3 Macro Obtain\_Authent\_Params\_VLR

This macro is used by the VLR to request authentication vectors from the HLR.

Sheet 1, sheet 2, sheet 3: It is an operator option whether to allow the re-use of old authentication triplets.

Sheet 2, sheet 3: Old UMTS quintuplets shall not be re-used.

Sheet 2: if the VLR requests more authentication vectors in the same dialogue, the subsequent MAP\_SEND\_AUTHENTIFICATION\_INFO request has no parameters.

#### 25.5.4 Process Obtain Authentication Sets VLR

This process is initiated by the VLR to fetch authentication vectors from a subscriber's HLR independently of any other processing.

#### 25.5.6 Process Obtain\_Authent\_Sets\_SGSN

The procedure for authentication when the serving node is an SGSN is described in 3GPP TS 23.060 [104] and 3GPP TS 24.008 [35].

This Process is used by the SGSN to request authentication vectors from the HLR.

Sheet 1, sheet 2: It is an operator option whether to allow the re-use of old authentication triplets.

Sheet 2: Old UMTS quintuplets shall not be re-used.

#### 25.5.6 Process Obtain\_Authent\_Sets\_HLR

This process is used to provide authentication vectors (triplets or quintuplets) in response to a request from a VLR or an SGSN.

Upon receipt of an authentication information request for a UMTS subscriber, the HLR shall return authentication quintuplets. If the user is a GSM subscriber, the HLR shall return authentication triplets.

## 25.5.7 Authentication Failure Reporting

#### 25.5.7.1 General

The Authentication Failure Report procedure is used to notify an HLR about the occurrence of an authentication failure in the SGSN or VLR.

The message flows for this procedure are shown in figures 25.5/7& 25.5/8.




Figure 25.5/7: Message Flow for Authentication Failure Report – VLR to HLR




Figure 25.5/8: Message Flow for Authentication Failure Report – SGSN to HLR

- 25.5.7.2 Process in the VLR
- 25.5.7.3 Process in the SGSN
- 25.5.7.4 Process in the HLR




Figure 25.5/1: Macro Authenticate\_MSC




Figure 25.5/2 (sheet 1 of 2): Macro Authenticate\_VLR




Figure 25.5/2 (sheet 2 of 2): Macro Authenticate\_VLR

850




Figure 25.5/3 (sheet 1 of 3): Macro Obtain\_Authent\_Params\_VLR




Figure 25.5/3 (sheet 2 of 3): Macro Obtain\_Authent\_Params\_VLR




Figure 25.5/3 (sheet 3 of 3): Macro Obtain\_Authent\_Params\_VLR




Figure 25.5/4: Process Obtain\_Authent\_Sets\_VLR




Figure 25.5/5 (sheet 1 of 2): Process Obtain\_Authent\_Sets\_SGSN




Figure 25.5/5 (sheet 2 of 2): Process Obtain\_Authent\_Sets\_SGSN




Figure 25.5/6 (sheet 1 of 2): Process Obtain\_Authent\_Sets\_HLR




Figure 25.5/6 (sheet 2 of 2): Process Obtain\_Authent\_Sets\_HLR




Figure 25.5/7: Procedure Check\_Available\_Vectors




Figure 25.5/9: Process Report\_Authentication\_Failure\_VLR




Figure 25.5/10: Process Report\_Authentication\_Failure\_SGSN




Figure 25.5/11: Process Note\_Authentication\_Failure\_HLR

## 25.6 IMEI Handling Macros

The following macros are used in the network in order to enable handling and checking of the mobile equipment identity.

#### 25.6.1 Macro Check\_IMEI\_MSC

This macro is used by the MSC to receive a request from the VLR, relay it to the EIR, and pass the result from the EIR back to the VLR.

Sheet 1: If the dialogue with the EIR drops back to a previous protocol version and the EIR returned an error, the MSC relays the error to the VLR in the MAP\_CHECK\_IMEI response. If the dialogue with the EIR failed, or the EIR returned a badly formed result, the MSC sends a System Failure error to the VLR in the MAP\_CHECK\_IMEI response.

#### 25.6.2 Macro Check IMEI VLR

This macro is used by the VLR to control the check of a mobile equipment's IMEI. It may also be used to request the BMUEF from the EIR.

#### 25.6.3 Process Check\_IMEI\_SGSN

This process is used by the SGSN to control the check of a mobile equipment's IMEI. It may also be used to request the BMUEF from the EIR.

#### 25.6.4 Process Check\_IMEI\_EIR

This process is used by the EIR to obtain the status of a mobile equipment, upon request from the MSC or from the SGSN. It may also be used to obtain the BMUEF.

#### 25.6.5 Macro Obtain\_IMEI\_MSC

This macro is used by the MSC to respond to a request from the VLR to provide the IMEI.

### 25.6.6 Macro Obtain\_IMEI\_VLR

This macro is used by the VLR to obtain the IMEI from the MSC.




Figure 25.6/1 (sheet 1 of 2): Macro Check\_IMEI\_MSC




Figure 25.6/1 (sheet 2 of 2): Macro Check\_IMEI\_MSC




Figure 25.6/2: Macro Check\_IMEI\_VLR




Figure 25.6/3 (sheet 1 of 2): Process Check\_IMEI\_SGSN




Figure 25.6/3 (sheet 2 of 2): Process Check\_IMEI\_SGSN




Figure 25.6/4: Process Check\_IMEI\_EIR




Figure 25.6/5: Macro Obtain\_IMEI\_MSC




Figure 25.6/6: Macro Obtain\_IMEI\_VLR

## 25.7 Insert Subscriber Data macros and processes

#### 25.7.1 Macro Insert\_Subs\_Data\_VLR

This macro is used by any procedure in the VLR that triggers the reception of subscriber data (e.g. Update Location or Restore Data).

#### 25.7.2 Macro Insert Subs Data SGSN

This macro is used by any procedure that triggers the reception of subscriber data (e.g. Update GPRS Location).

### 25.7.3 Process Insert\_Subs\_Data\_Stand\_Alone\_HLR

This process is used by HLR to transfer subscriber data to the VLR in a stand alone mode, i.e. in a separate dialogue. This is done whenever a change of subscriber data is performed either by the operator or by the subscriber and this change has to be reported to the VLR.

Sheet 1: The HLR may wait for each MAP\_INSERT\_SUBSCRIBER\_DATA request to be acknowledged before it sends the next request, or it may handle the requests and the confirmations in parallel.

Sheet 1, sheet 2: If the VLR has indicated that it does not support a service or feature (e.g. Closed User Group or Advice Of Charge Charging Level) which the HLR operator regards as essential for the subscriber, the macro Wait\_for\_Insert\_Subs\_Data\_Cnf takes the Replace\_Service exit; the HLR sets the Roaming Restriction Due To Unsupported Feature flag to roaming restricted and sends Roaming Restriction Due To Unsupported Feature in a subsequent MAP\_INSERT\_SUBSCRIBER\_DATA request.

Sheet 1, sheet 2: If the HLR operator does not regard the unsupported service or feature as essential for the subscriber but the macro Wait\_for\_Insert\_Subs\_Data\_Cnf takes the Replace\_Service exit, the HLR sends the data for a replacement service in a subsequent MAP\_INSERT\_SUBSCRIBER\_DATA request.

Sheet 2: It is an operator option whether to repeat the download of subscriber data if the VLR returns an error response. The number of repeat attempts and the interval between them is also an operator option, depending on the error response from the VLR.

If subscriber data for CAMEL Phase 2 or later services are sent to a VLR which does not support the appropriate phase of CAMEL, the service behaviour may be unpredictable or incorrect. The HLR should therefore ensure that at the conclusion of a stand alone Insert Subscriber data procedure the data in the VLR do not require a capability that the VLR does not have. Possible mechanisms to ensure this are described in 3GPP TS 23.078 [98].

The HLR should send a Forwarded-to number which is not in E.164 international format to the VLR only when the HLR has ascertained that the VLR supports CAMEL Phase 2 or later. Thus, the ISD message containing the Forwarded-to number which is not in E.164 international format shall be sent to the VLR only if the HLR previously received confirmation from the VLR at Location Update that CAMEL Phase 2 or later is supported.

## 25.7.4 Process Insert GPRS Subs Data Stand Alone HLR

This process is used by the HLR to transfer subscriber data from the HLR to the SGSN in a stand alone mode, i.e. in a separate dialogue. This is done whenever a change of subscriber data is performed either by the operator or by the subscriber and this change has to be reported to the SGSN.

Sheet 1: The HLR may wait for each MAP\_INSERT\_SUBSCRIBER\_DATA request to be acknowledged before it sends the next request, or it may handle the requests and the confirmations in parallel.

Sheet 1, sheet 2: If the SGSN has indicated that it does not support a service or feature which the HLR operator regards as essential for the subscriber, the macro Wait\_for\_Insert\_GPRS\_Subs\_Data\_Cnf takes the Replace\_Service exit; the HLR sets the Roaming Restricted In SGSN Due To Unsupported Feature flag to roaming restricted and sends Roaming Restricted In SGSN Due To Unsupported Feature in a subsequent MAP\_INSERT\_SUBSCRIBER\_DATA request.

Sheet 1, sheet 2: If the HLR operator does not regard the unsupported service or feature as essential for the subscriber but the macro Wait\_for\_Insert\_GPRS\_Subs\_Data\_Cnf takes the Replace\_Service exit, the HLR sends the data for a replacement service in a subsequent MAP\_INSERT\_SUBSCRIBER\_DATA request.

Sheet 2: It is an operator option whether to repeat the download of subscriber data if the SGSN returns an error response. The number of repeat attempts and the interval between them is also an operator option, depending on the error response from the SGSN.

### 25.7.5 Macro Wait for Insert Subs Data Cnf

This macro is used by any process or macro that describes the handling in the HLR of the transfer of subscriber data to the VLR (e.g. Update Location or Restore Data).

#### 25.7.6 Macro Wait\_for\_Insert\_GPRS\_Subs\_Data\_Cnf

This macro is used by any process or macro that describes the handling in the HLR of the transfer of subscriber data to the SGSN (e.g. Update GPRS Location).

#### 25.7.7 Process Send\_Insert\_Subs\_Data\_HLR

This process is used by any process or macro in the HLR where a MAP\_INSERT\_SUBSCRIBER\_DATA request is sent to the VLR or to the SGSN.




Figure 25.7/1: Macro Insert\_Subs\_Data\_VLR




Figure 25.7/2: Macro Insert\_Subs\_Data\_SGSN




Figure 25.7/3 (sheet 1 of 2): Process Insert\_Subs\_Data\_Stand\_Alone\_HLR




Figure 25.7/3 (sheet 2 of 2): Process Insert\_Subs\_Data\_Stand\_Alone\_HLR




Figure 25.7/4 (sheet 1 of 2): Process Insert\_GPRS\_Subs\_Data\_Stand\_Alone\_HLR




Figure 25.7/4 (sheet 2 of 2): Process Insert\_GPRS\_Subs\_Data\_Stand\_Alone\_HLR




Figure 25.7/5: Macro Wait\_for\_Insert\_Subs\_Data\_Cnf




Figure 25.7/6: Macro Wait\_for\_Insert\_GPRS\_Subs\_Data\_Cnf




Figure 25.7/7: Process Send\_Insert\_Subs\_Data\_HLR

## 25.8 Request IMSI Macros

## 25.8.1 Macro Obtain\_IMSI\_MSC

This macro describes the handling of the request received from the VLR to provide the IMSI of a subscriber (e.g. at Location Updating).

## 25.8.2 Macro Obtain\_IMSI\_VLR

This macro describes the way VLR requests the MSC the IMSI of a subscriber (e.g. at Location Updating).




Figure 25.8/1: Macro Obtain\_IMSI\_MSC




Figure 25.8/2: Macro Obtain\_IMSI\_VLR

## 25.9 Tracing macros

## 25.9.1 Macro Trace\_Subscriber\_Activity\_MSC

This macro shows the handling in the MSC for a request from the VLR to trace the activity of a subscriber.

### 25.9.2 Macro Trace\_Subscriber\_Activity\_VLR

This macro is called during the handling of subscriber activity in the VLR to activate tracing if necessary.

### 25.9.3 Macro Trace\_Subscriber\_Activity\_SGSN

This macro is called during the handling of subscriber activity in the SGSN to activate tracing if necessary.

### 25.9.4 Macro Activate\_Tracing\_VLR

This macro shows the handling in the VLR for a request from the HLR to activate tracing for a subscriber.

## 25.9.5 Macro Activate\_Tracing\_SGSN

This macro shows the handling in the SGSN for a request from the HLR to activate tracing for a subscriber.

## 25.9.6 Macro Control\_Tracing\_With\_VLR\_HLR

This macro shows the handling in the HLR to activate tracing in the VLR if it is required during a dialogue between the VLR and the HLR

## 25.9.7 Macro Control\_Tracing\_With\_SGSN\_HLR

This macro shows the handling in the HLR to activate tracing in the SGSN if it is required during a dialogue between the SGSN and the HLR




Figure 25.9/1: Macro Trace\_Subscriber\_Activity\_MSC




Figure 25.9/2: Macro Trace\_Subscriber\_Activity\_VLR




Figure 25.9/3: Macro Trace\_Subscriber\_Activity\_SGSN




Figure 25.9/4: Macro Activate\_Tracing\_VLR




Figure 25.9/5: Macro Activate\_Tracing\_SGSN




Figure 25.9/6: Macro Control\_Tracing\_With\_VLR\_HLR




Figure 25.9/7: Macro Control\_Tracing\_With\_SGSN\_HLR

## 25.10 Short Message Alert procedures

### 25.10.1 Process Subscriber\_Present\_VLR

The VLR invokes the process Subscriber\_Present\_VLR when the mobile subscriber becomes active. The general description of the short message alert procedures is in subclause 23.4 of the present document.

#### 25.10.2 Process SubscriberPresent\_SGSN

The SGSN invokes the process Subscriber\_Present\_SGSN when it receives a Page response, a GPRS Attach request or a Routing area update request message (3GPP TS 24.008 [35]). The general description of the short message alert procedures is in subclause 23.4 of the present document.

#### 25.10.3 Macro Alert Service Centre HLR

The HLR invokes the macro Alert\_Service\_Centre\_HLR when Service Centre(s) are to be alerted.

#### 25.10.4 Process Alert\_SC\_HLR

It is an operator option to resend the MAP\_ALERT\_SERVICE\_CENTRE request to the SMS-IWMSC if the alert is unsuccessful. The number of repeat attempts and the interval between them is also an operator option. The service centre address should be purged from the MWD list if the alert is consistently unsuccessful.




Figure 25.10/1: Process Subscriber\_Present\_VLR




Figure 25.10/2: Process Subscriber\_Present\_SGSN




Figure 25.10/3: Macro Alert\_Service\_Centre\_HLR




Figure 25.10/4: Process Alert\_SC\_HLR

## Annex A (informative):

## ASN.1 Cross-reference listing and fully expanded sources

The ASN.1 Cross-reference listing and the fully expanded ASN.1 sources of the MAP protocol are provided for information at  $\frac{\text{http://www.3gpp.org/ftp/Specs/archive/29\_series/29.002/ASN.1/}{\text{http://www.3gpp.org/ftp/Specs/archive/29\_series/29.002/ASN.1/}}$ 

# Annex B (informative): Void

## Annex C (informative): Message Segmentation Mechanisms

Various segmentation mechanisms are in use to overcome the problem where a MAP parameter carried in an Invoke, Result (or Error) component is too long to fit into a single SCCP UDT message. These mechanisms are:

## C.1 SCCP segmentation

Instead of one UDT message several XUDT messages are used according to

Signalling Connection Control Part, Signalling System no. 7 ITU-T recommendation (07/96) Q.711 to Q.716 ("White Book SCCP").

This mechanism may be used for all MAP messages. If no segmentation mechanism at the TCAP or MAP level is available, this is the only remaining possibility.

This mechanism has no impact on the MAP provider level and above; the MAP provider sees the parameter as being sent in a single segment.

It should be noted that not all SCCP transit nodes (world wide) currently support the transfer of XUDT messages. Therefore XUDT messages may be lost without notice, depending on the route the message takes. The routes which successive messages take between two end points can differ because of load balancing. It is therefore recommended that this mechanism is used only for:

- a) messages which do not cross PLMN boundaries (when the PLMN operator ensures that all SCCP transit nodes within his PLMN support White Book SCCP)
- b) messages with low priority i.e. loss of the message does not result in serious misoperation.

It should be noted that the decision whether or not a message crosses PLMN boundaries needs to be taken at the MAP application level; it is therefore based on the message's operation code rather than on the SCCP called party address, i.e. only messages which never cross PLMN boundaries due to the type of message (SendIdentification, SendRoutingInfo without OR, AnyTimeInterrogation, ...) can be regarded as not crossing PLMN boundaries.

## C.2 TCAP segmentation

At the TCAP level the following segmentation mechanisms are available:

## C.2.1 Empty Begin

In a dialogue with AC version >1 the first forward message (Begin) must contain a Dialogue Portion. Instead of sending the Dialogue Portion and the Component Portion in the first forward message, an empty Begin (i.e. without a Component Portion) is sent, followed (after successful dialogue establishment) by a Continue message which can carry a longer Component Portion since no Dialogue Portion is present in the second forward message.

## C.2.2 Empty Continue

In a dialogue with AC version >1 the first backward message (Continue / End) must contain a Dialogue Portion. Instead of sending the Dialogue Portion and the Component Portion in the first backward message, an empty Continue (i.e. without a Component Portion) is sent, followed by a Continue/End message which can carry a longer Component Portion since no Dialogue Portion is present in the second backward message.

#### C.2.3 TC-Result-NL

A Result component may be segmented into one or several Result-Not-Last components followed by a Result-Last component. As specified in subclause 15.6.3, the MAP user parameter shall be split so that each segment is compatible with the type defined for the parameter of the result of the associated operation.

Note that this segmentation mechanism runs the risk that the message carrying the Result-Last component arrives before the message carrying a Result-Not-Last component which results in failure. The use of SCCP class 1 "Sequence guaranteed", which raises the chance of in sequence delivery, is recommended.

# C.3 MAP Segmentation

At the MAP level the following segmentation mechanisms are available:

# C.3.1 Invoke without explicit indication

An Invoke component may be segmented into several Invoke components. These may be sent in burst mode (in which case SCCP class 1 is recommended) or in acknowledged mode. The receiving node does not get an indication of whether or not more segments will be received, so it must not close the dialogue. The MAP user parameter shall be split so that each segment is compatible with the type defined for the parameter of the invoke of the associated operation.

# C.3.2 Invoke with explicit indication

An Invoke component may be segmented into several Invoke components sent in acknowledged mode. Each component contains at the MAP level an indication of whether or not subsequent components will follow. The receiving node terminates the dialogue when the last component is received. The MAP user parameter shall be split so that each segment is compatible with the type defined for the parameter of the invoke of the associated operation.

### C.3.3 Result

A Result (last) component may be segmented into several Result (last) components sent in acknowledged mode where a new (empty) Invoke component serves as an acknowledgment. The last segment is not acknowledged. The MAP user parameter shall be split so that each segment is compatible with the type defined for the parameter of the result of the associated operation.

The following tables show the applicability of the mechanisms described above:

# AC Version 4:

Parameter	SCCP-	Empty Begin	Empty	TC-Result-NL	Invoke without	Invoke with	Result
	segmentation		Continue		indication	indication	
ResumeCallHandlingArg	allowed	not allowed	n.a.	n.a.	not allowed	recommended	n.a.

## AC Version 3:

Parameter	SCCP- segmentation	Empty Begin	Empty Continue	TC-Result-NL	Invoke without indication	Invoke with indication	Result
InsertSubscriberDataArg	risky	not allowed	n.a.	n.a.	recommended	n.a.	n.a.
SendIdentificationRes	allowed	n.a.	not allowed	not allowed	n.a.	n.a.	recommended
PrepareHO-Arg	allowed	not allowed	n.a.	n.a.	not allowed	n.a.	n.a.
PrepareHO-Res	allowed	n.a.	recommended	not recommended	n.a.	n.a.	not allowed
ProcessAccessSignalling-Arg	allowed	n.a.	n.a.	n.a.	not allowed	n.a.	n.a.
ForwardAccessSignalling-Arg	allowed	n.a.	n.a.	n.a.	not allowed	n.a.	n.a.
PrepareSubsequentHO-Arg	allowed	n.a.	n.a.	n.a.	not allowed	n.a.	n.a.
PrepareSubsequentHO-Res	allowed	n.a.	n.a	not recommended	n.a.	n.a.	not allowed
SendAuthenticationInfoRes	risky	n.a.	not allowed	not allowed	n.a.	n.a.	recommended
ProvideSubscriberInfoRes	allowed	n.a.	not allowed	not recommended	n.a.	n.a.	not allowed
AnyTimeInterrogationRes	allowed	n.a.	not allowed	not recommended	n.a.	n.a.	not allowed
AnyTimeModificationRes	allowed	n.a.	not allowed	recommended	n.a.	n.a.	not allowed
AnyTimeSubscriptionInterrogationRes	allowed	n.a.	not allowed	recommended	n.a.	n.a.	not allowed
noteSubscriberDataModifiedArg	allowed	not allowed	n.a.	n.a.	not allowed	recommended	n.a.
SendRoutingInfoRes	allowed	n.a.	not allowed	recommended	n.a.	n.a.	not allowed
MO-ForwardSM-Arg	risky	recommended	n.a.	n.a.	not allowed	n.a.	n.a.
MT-ForwardSM-Arg	risky	recommended	n.a.	n.a.	not allowed	n.a.	n.a.

## 902

#### AC Version 2:

Parameter	SCCP- segmentation	Empty Begin	Empty Continue	TC-Result-NL	Invoke without indication	Invoke with indication	Result
InsertSubscriberDataArg	risky	not allowed	not allowed	n.a.	recommended	n.a.	n.a.
SendIdentificationRes	allowed	n.a.	not allowed	not recommended	n.a.	n.a.	not allowed
SendAuthenticationInfoRes	risky	n.a.	not allowed	not recommended	n.a.	n.a.	not allowed
ForwardSM-Arg	risky	recommended	n.a.	n.a.	not allowed	n.a.	n.a.
PrepareHO-Res	allowed	n.a.	recommended	not recommended	n.a.	n.a.	not allowed

#### AC Version 1:

Parameter	SCCP- segmentation	Empty Begin	Empty Continue	TC-Result-NL	Invoke without indication	Invoke with indication	Result
InsertSubscriberDataArg	risky	n.a.	n.a.	n.a.	recommended	n.a.	n.a.
SentParameterList	risky	n.a.	n.a.	recommended	n.a.	n.a.	not allowed

In the tables above the keywords "recommended", "allowed", "risky", "not recommended", "not allowed" and "n.a." are used as follows:

#### "recommended"

indicates that the normative part of this specification explicitly specifies the use of this mechanism for the parameter in question;

#### "allowed"

indicates that the normative part of this specification allows the use of this mechanism for the sending node and mandates support of this mechanism for the receiving node;

#### "risky"

indicates that the mechanism is "allowed". However, the use of this mechanism for the parameter in question may result in serious misoperation because SCCP transit nodes are not guaranteed to support XUDT messages.

#### "not recommended"

indicates that the normative part of this specification does not explicitly specify the use of this mechanism for the parameter in question.

#### "not allowed"

indicates that the normative part of this specification implicitly prohibits the use of this mechanism for the parameter in question.

#### "n.a."

indicates that the mechanism is not applicable for the parameter in question.

# Annex D (informative): Void

# Annex E (informative): Change History

SMG#	TDoc	SPEC	VERS	CR	REV	PHAS E	CAT	SUBJECT	NEW_VERS	WORKITEM
04	N2-99227	29.002	3.0.0	A002	3	R98	Α	Use of E interface	3.1.0	
04	N2-99578	29.002	3.0.0	A003		R98	В	Introduction of TIF-CSI for Call Deflection	3.1.0	
04	N2-99233	29.002	3.0.0	A004		R98	Α	Clarification in ASN.1 encoding of O-CSI and T-CSI	3.1.0	
04	N2-99269	29.002	3.0.0	A005		R98	С	Introduction of MSISDN in USSD operation	3.1.0	
04	N2-99650	29.002	3.0.0	A006		R98	Α	Modification of the O-CSI ASN.1 structure	3.1.0	
04	N2-99250	29.002	3.0.0	A007		R98	Α	Adding of MAP_DELIMITER_req to the Status report operation	3.1.0	
04	N2-99628	29.002	3.0.0	A008		R98	Α	Correction to the Purge MS "Detailed procedure in the HLR"	3.1.0	
04	N2-99677	29.002	3.0.0	A009		R98	Α	Adding of MNP-indicator to the SRI ack	3.1.0	
04	N2-99228	29.002	3.0.0	A010		R98	F	New subscription options for call forwarding	3.1.0	
04	N2-99585	29.002	3.0.0	A011		R98	С	Adding the support of ANSI SCCP which is required in North America (World Zone 1)	3.1.0	
04	N2-99515	29.002	3.0.0	A012		R98	Α	Introduction of 3-digit MNCs correction	3.1.0	
04	N2-99520	29.002	3.0.0	A013		R98	F	Export of NAEA-CIC	3.1.0	
04	N2-99548	29.002	3.0.0	A014		R98	D	Clarification to text to identify how the LSA data relevant in the current VPLMN can be determined	3.1.0	
04	3C99-468	29.002	3.0.0	A015		R97	F	Alignment with 04.80	3.1.0	
04	N2-99519	29.002	3.0.0	A016		R98	Α	VBS data	3.1.0	
04	N2-99461	29.002	3.0.0	A017		R98	F	Introduction of Data Missing error to the Resume Call Handling	3.1.0	
04	N2-99583	29.002	3.0.0	A018		R97	F	Removal of 3-digit MNCs	3.1.0	
04	N2-99676	29.002	3.0.0	A019		R98	Α	Corrections of mapping from MAP service to TC service	3.1.0	
04	3C99-206	29.002	3.0.0	A020		R98	В	Introduction of UUS service to Resume Call Handling	3.1.0	
05	N2-99906	29.002	3.1.0	021		R99	Α	Clarification on VLR CAMEL Subscription Info	3.2.0	CAMEL Phase 2
05	N2-99908	29.002	3.1.0	022		R99	Α	Clarification on DestinationNumberCriteria	3.2.0	CAMEL Phase 2
05	N2-99910	29.002	3.1.0	023		R99	Α	Removal of TDP-Criteria from RCH	3.2.0	CAMEL Phase 2
05	N2-99934	29.002	3.1.0	025		R99	Α	Various corrections related to GGSN-HLR Interface.	3.2.0	GPRS
05	N2-99936	29.002	3.1.0	034		R99	Α	Update Location handling for GPRS- only subscription	3.2.0	GPRS
05	N2-99938	29.002	3.1.0	035		R99	A	Correction of OP & AC definitions for NoteMS-PresentForGPRS	3.2.0	GPRS
05	N2-99952	29.002	3.1.0	036		R99	A	Removal of redundant information from RCH	3.2.0	UUS
05	N2-99956	29.002	3.1.0	026	4	R99	A	OR capability IE in PRN	3.2.0	TEI
05	N2-99964	29.002	3.1.0	024	1	R99	Α	GMSC-CAMEL phase 2 support IE in PRN	3.2.0	CAMEL Phase 2
05	N2-99A19	29.002	3.1.0	028		R99	A	Alignment of 29.002 with 02.67	3.2.0	eMLPP
05	N2-99A45	29.002	3.1.0	029	1	R99	В	Non-CAMEL IST implementation		IST
05	N2-99B57	29.002	3.1.0	027	2	R99	В	Addition of the information elements and the ASN.1 definitions for Prepaging	3.2.0	Pre-Paging
05	N2-99C27	29.002	3.1.0	042		R99	Α	Clarification on 'Supported CAMEL Phases' in ISD ack	3.2.0	CAMEL Phase 2
05	N2-99C78	29.002	3.1.0	044		R99	Α	Editing error correction on VLR capabilities	3.2.0	SoLSA
05	N2-99D06	29.002	3.1.0	043	1	R99	Α	Addition of exception handling to the CancellationType	3.2.0	GPRS
05	N2-99D33	29.002	3.1.0	046		R99	A	Clarification of LR-REJECT cause corresponding to RoamingRestrictionDueTo UnsupportedFeature	3.2.0	TEI

SMG#	TDoc	SPEC	VERS	CR	REV	PHAS E	CAT	SUBJECT	NEW_VERS	WORKITEM
05	N2-99D35	29.002	3.1.0	047		R99		Clarification of returning the MSISDN in SRIack	3.2.0	MNP
06	N2-99G06	29.002	3.2.0	033	3	R99	С	Introduction of the Super-Charger Concept in TS 29.002	3.3.0	Super Charger
06	N2-99G18	29.002	3.2.0	032	2	R99	С	Introduction of White Book SCCP in MAP	3.3.0	TEI
06	N2-99G50	29.002	3.2.0	070		R99	Α	Addition of GGSN number for the SRIforGPRS	3.3.0	GPRS
06	N2-99J88	29.002	3.2.0	075	1	R99	В	Introduction of Follow Me	3.3.0	Follow Me
06	N2-99K12 N2-99K24		3.2.0	077		R99	A	Use of SSN for GPRS	3.3.0	GPRS
06	N2-99K24 N2-99K52	29.002	3.2.0	069	1	R99 R99	A C	Correction of the USSD procedure in the HLR.  MAP Impacts for Location Services	3.3.0	USSD & Follow Me Location Services
	142 33132	25.002	0.2.0	000	'	1133		(LCS)	0.0.0	Location oct vices
06	N2-99K58	29.002	3.2.0	045	4	R99	В	Authentication Enhancements	3.3.0	Security
06	N2-99K60	29.002	3.2.0	050	5	R99	С	QoS-Subscribed field modification	3.3.0	QoS enhancements
06	N2-99L20	29.002	3.2.0	073	1	R99	С	Introduction of CAMEL Phase 3 in 3GPP TS 29.002	3.3.0	CAMEL Phase 3
06	N2-99J52	29.002	3.2.0	074		R99	D	Restructuring of MAP Location Management Procedures for the Circuit Switched Domain	3.3.0	TEI
06	N2-99J92	29.002	3.2.0	068		R99	В	Update of SDLs to support Super- Charger	3.3.0	Super-Charger
			3.3.0					New version created to fix a CR implementation error	3.3.1	
07	N2B00043 6	29.002	3.3.1	048	5	R99	В	Introduction of Multicall	3.4.0	Multicall
07	N2B00031 9	29.002	3.3.1	059	1	R99	В	Alternative solution for ALR	3.4.0	CAMEL phase 3
07	N2B00046 1		3.3.1	063	4	R99	В	MNP Database Mismatch	3.4.0	MNP
07	N2B00037 5	29.002	3.3.1	066	5	R99	В	Addition of the FTN-AddressString	3.4.0	Call Forwarding Enhancements
07	N2B00045 6		3.3.1	079	4	R99	С	Correction of SS Invocation Notification for CCBS	3.4.0	CAMEL Phase 3
07	N2A00002 3		3.3.1	080		R99	F	Corrections to ATSI, ATM, NCSD	3.4.0	CAMEL Phase 3
07	N2B00004 6	29.002	3.3.1	083		R99	A	Privacy notification/verification for call related privacy class	3.4.0	Location Services (LCS)
07	N2B00014 2	29.002	3.3.1	084	2	R99	В	Addition of CS Allocation/retention priority	3.4.0	QoS enhancements
07	N2B00014 4		3.3.1	086	1	R99	D	Editorial cleanup of 29.002	3.4.0	TEI
07	N2B00010 0		3.3.1	087		R99	Α	Correction of LSA information	3.4.0	SoLSA
07	N2B00006 7		3.3.1	089		R99	F	Security interworking between release 99 and pre-99 MSC/VLRs	3.4.0	Security
07	N2B00011 3		3.3.1	090	1	R99	В	Improving GPRS charging efficiency	3.4.0	GPRS
07	N2B00012 0		3.3.1	094	2	R99	С	QoS-Subscribed field enhancements	3.4.0	QoS enhancements
07	N2B00032 2		3.3.1	095	1	R99	С	RANAP support on the E-interface	3.4.0	Handover
07	N2B00019 1		3.3.1	099	5	R99	В	UMTS Authentication	3.4.0	Security
07	N2B00046 6 N2B00037		3.3.1	100	5	R99 R99	В	Support of 3G Handover, including Multicall Introduction of Service Area	3.4.0	Multicall TEI
07	N2B00037 2 N2B00038		3.3.1	101	2	R99	F	Identification  Clarification on Authentication Info	3.4.0	Security
07	0 N2B00033		3.3.1	102	1	R99	В	Retrieval Addition of UMTS security to MAP B	3.4.0	Security
07	0 N2B00024		3.3.1	103	<u> </u>	R99	F	interface  Re-Synchronisation Info	3.4.0	UMTS Security
07	4 N2B00032		3.3.1	105	1	R99	C	Introduction of additional service	3.4.0	Handover
07	4 N2B00028		3.3.1	107		R99	D	parameters for inter-system handover Removal of architectural information	3.4.0	TEI
	1							from clause 4		

SMG#	TDoc	SPEC	VERS	CR	REV	PHAS E	CAT	SUBJECT	NEW_VERS	WORKITEM
07	N2- 000454	29.002	3.3.1	110	1	R99	В	Introduction of Authentication Failure Report	3.4.0	Security
07	N2B00035 7	29.002	3.3.1	111		R99	В	Use of MAP private extensions to implement region-specific requirements	3.4.0	TEI
07	N2B00047 0	29.002	3.3.1	112		R99	Α	Prioritisation of MAP application context related to VGCS/VBS	3.4.0	ASCI Phase 2
07	N2B00047 2	29.002	3.3.1	113		R99	F	Correction of SS-Codes for LCS	3.4.0	LCS
08	N4- 000098	29.002	3.4.0	115	1	R99	F	Minor corrections to CAMEL3 NSDC/ATM/ATSI information flows	3.5.0	CAMEL Phase 3
80	N4- 000094	29.002	3.4.0	117	1	R99	Α	Using DSD to delete CCBS-B from the subscriber	3.5.0	CCBS
08	N4- 000089	29.002	3.4.0	118	1	R99	F	Indication in PRN of support of Long FTNs	3.5.0	CF enhancements
80	N4- 000073	29.002	3.4.0	120	1	R99	F	QoS-Subscribed field enhancements	3.5.0	QoS enhancements
80	N4- 000050	29.002	3.4.0	121		R99	F	Correction of introduction of additional service parameters for inter-system handover	3.5.0	Handover/Relocation
80	N4- 000100	29.002	3.4.0	122	2	R99	С	Proposed information flow on NSDC	3.5.0	CAMEL Phase 3
80	N4- 000321	29.002	3.4.0	124	3	R99	С	CAMEL Subscription Info	3.5.0	CAMEL Phase 3
80	N4- 000068	29.002	3.4.0	125		R99	Α	Clarification to GMLC List definition	3.5.0	LCS
80	N4- 000320	29.002	3.4.0	127	1	R99	F	Optionality of parameters in d-csi and in sms-csi	3.5.0	CAMEL Phase 3
08	N4- 000209	29.002	3.4.0	130		R99	F	Version 3 tags for handover messages	3.5.0	Handover
08	N4- 000211	29.002	3.4.0	132		R99	Α	Correction of version handling at dialogue establishment	3.5.0	TEI
80	N4- 000357	29.002	3.4.0	133	1	R99	F	Various corrections and/or cleanup to 29.002	3.5.0	TEI
80	N4- 000217	29.002	3.4.0	134		R99	Α	Correction of errors in Figure 25.1/1: Macro Receive_Open_Ind	3.5.0	TEI
08	N4- 000326	29.002	3.4.0	135	1	R99	В	Addition of charging characteristics per PDP context	3.5.0	TEI
08	N4- 000264	29.002	3.4.0	138		R99	F	Clarification of SAI-ack segmentation procedure	3.5.0	Security
80	N4- 000392	29.002	3.4.0	139	1	R99	Α	Indication of unsupported position method	3.5.0	LCS
08	N4- 000276	29.002	3.4.0	141		R99	Α	Clarification for ReportSM- DeliveryStatus operation	3.5.0	GPRS
80	N4- 000349	29.002	3.4.0	142	1	R99	С	Addition of a parameter in the subsequent Handover from UMTS to GSM with Multicall	3.5.0	Multicall
80	N4- 000278	29.002	3.4.0	143		R99	D	Editorial correction to MSC-A handover SDLs	3.5.0	Multicall
80	N4- 000378	29.002	3.4.0	144	1	R99	Α	Use of NAM parameter with MAP- INSERT-SUBSCRIBER-DATA service between HLR and SGSN	3.5.0	GPRS
80	N4- 000293	29.002	3.4.0	145		R99	F	Addition of state attributes in Forward group call signalling	3.5.0	ASCI
80	N4- 000294	29.002	3.4.0	146		R99	F	New user error "target cell outside group call area" in MAP Prepare Handover message	3.5.0	ASCI
80	N4- 000374	29.002	3.4.0	149		R99	Α	Correction to the description of MAP-MO-Forward-Short-Message service	3.5.0	TEI
80	N4- 000407	29.002	3.5.0	148	4	R00	В	Changes to MAP for secure transport of MAP messages	4.0.0	Security
80		29.002	4.0.0			R00		Version 4.0.1 created to allow inclusion of automatic update of Annexes A and B and of section 17	4.0.1	
09	N4- 000543	29.002	4.0.1	152	1	R00	F	Clarifications for secure MAP transport	4.1.0	Core Network Security
09	N4- 000539	29.002	4.0.1	153	1	R00	D	Generalization of version handling text in clause 18.2.4	4.1.0	TEI
09	N4- 000491	29.002	4.0.1	158		R00	Α	Deletion of informative Annexe C	4.1.0	TEI
09	N4- 000540	29.002	4.0.1	159		R00	Α	Aligning 29.002 with 25.413 (UTRAN In Interface RANAP Signalling)	4.1.0	Handover

SMG#	TDoc	SPEC	VERS	CR	REV	PHAS E	CAT	SUBJECT	NEW_VERS	WORKITEM
09	N4- 000541	29.002	4.0.1	160		R00	Α	AUTS and AUTN parameter length	4.1.0	Security
09	N4- 000744	29.002	4.0.1	161	2	R00	Α	Clarification on Authentication Failure Report ack	4.1.0	Security
09	N4- 000666	29.002	4.0.1	163	1	R00	Α	Correction on Location Information	4.1.0	CAMEL phase 3
09	N4- 000777	29.002	4.0.1	174	2	R00	Α	Optionality of parameters in GPRS- CSI	4.1.0	CAMEL phase 3
09	N4- 000788	29.002	4.0.1	176	1	R00	Α	Correction to QoS indication	4.1.0	LCS
09	N4- 000747	29.002	4.0.1	178	1	R00	Α	Clarification of use of Radio Resource Information	4.1.0	Handover
09	N4- 000750	29.002	4.0.1	180	2	R00	Α	Correction to MSC-A handover SDLs	4.1.0	TEI
09	N4- 000736	29.002	4.0.1	182		R00	Α	Removal of LSAldentity from NoteMM- EventArg	4.1.0	CAMEL phase 3
09	N4- 000772	29.002	4.0.1	184		R00	Α	LCS Support for CAMEL Phase 3	4.1.0	LCS
09	N4- 000751	29.002	4.0.1	186	1	R00	Α	Correction to MSC-A handover SDLs	4.1.0	TEI
09	N4- 000779	29.002	4.0.1	188		R00	Α	Clarification for segmentation of D-CSI and SMS-CSI	4.1.0	CAMEL phase 3
10	N4- 000912	29.002	4.0.1	166	3	Rel-4	А	Corrections and clarifications for USSD procedures on the HLR - gsmSCF interface	4.2.0	USSD
10	N4- 000908	29.002	4.1.0	191	1	Rel-4	Α	Corrections of ISD data structure for CAMEL phase 3	4.2.0	CAMEL phase 3
10	N4- 001069	29.002	4.1.0	193	2	Rel-4	Α	USSD Corrections for Follow Me	4.2.0	USSD
10	N4- 001071	29.002	4.1.0	196	1	Rel-4	Α	GSM to 3G Handover: MAP parameter Target Cell ID	4.2.0	Handover
10	N4- 000921	29.002	4.1.0	198		Rel-4	Α	ASN.1 description of targetCellId	4.2.0	Handover
10	N4- 001073	29.002	4.1.0	200	1	Rel-4	Α	IMSI in MAP_PREPARE_HANDOVER	4.2.0	Handover
10	N4- 001076	29.002	4.1.0	208	1	Rel-4	Α	Alignment of the Target RNC-ID	4.2.0	Handover
10	N4- 001089	29.002	4.1.0	211	1	Rel-4	Α	Export of GSN-Address data type	4.2.0	CAMEL phase 3
10	N4- 001095	29.002	4.1.0	212		Rel-4	Α	Transport of long RANAP messages on MAP-E interface	4.2.0	Handover
-	-	29.002	4.2.0	-	-	Rel-4	-	Automatic update of annexes A and B	4.2.1	-
11	N4- 010036	29.002	4.2.1	206	1	Rel-4	Α	Correction to LCS application context	4.3.0	LCS
11	N4- 010276	29.002	4.2.1	215	2	Rel-4	В	Add parameters to ISD and SRI for GPRS to handle ODB for PS	4.3.0	ODB enhancements
11	N4- 010033	29.002	4.2.1	217		Rel-4	Α	Correction to maximum number of RAB's	4.3.0	Multicall
11	N4- 010198	29.002	4.2.1	222	2	Rel-4	В	PS domain support for LCS Release 4	4.3.0	LCS
11	N4- 010058	29.002	4.2.1	224		Rel-4	Α	Failure of Update GPRS Location when HLR is not reachable	4.3.0	GPRS R97
11	N4- 010287	29.002	4.2.1	231	1	Rel-4	В	Extension of call related privacy class for LCS Release 4	4.3.0	LCS
11	N4- 010375	29.002	4.2.1	232	2	Rel4	В	Maximum number of LCS Clients	4.3.0	LCS
11	N4- 010261	29.002	4.2.1	234		Rel-4	В	MAP over IP according to SIGTRAN	4.3.0	SS7IP
11	N4- 010465	29.002	4.2.1	236	1	Rel-4	В	Requesting node type in authentication set request	4.3.0	SEC1-EHCS
11	N4- 010360	29.002	4.2.1	246		Rel-4	Α	Adding EXPORT definition for LSAIdentity	4.3.0	Camel 3

SMG#	TDoc	SPEC	VERS	CR	REV	PHAS E	CAT	SUBJECT	NEW_VERS	WORKITEM
11	N4- 010361	29.002	4.2.1	247		Rel-4	A	Removing duplicate parameters from ss-CSI	4.3.0	CAMEL 3
11	N4- 010362	29.002	4.2.1	248		Rel-4	А	Correction to description of SS- CSI in HLR to VLR information flow	4.3.0	CAMEL 3
11	N4- 010365	29.002	4.2.1	250		Rel-4	Α	GSM to UMTS handover: addition of MAP parameter RNC ID	4.3.0	Handover
11	N4- 010393	29.002	4.2.1	252		Rel-4	Α	Clarification of the use of multicall bearer information	4.3.0	Multicall
11	N4- 010428	29.002	4.2.1	258		Rel-4	Α	Adding EXPORT definition for GeographicalInformation	4.3.0	Camel 3
11	N4- 010446	29.002	4.2.1	260		Rel-4	Α	Failure of Authentication Parameter GPRS when HLR is not reachable	4.3.0	GPRS R97
11	N4- 010484	29.002	4.2.1	262	1	Rel-4	Α	Correction to D-CSI	4.3.0	CAMEL 3
12	N4- 010728	29.002	4.3.0	239	4	Rel-4	Α	Addition of selected UMTS algorithm indication to the handover procedures	4.4.0	Handover
12	N4- 010730	29.002	4.3.0	241	4	Rel-4	А	Addition of allowed GSM algorithms indication to the handover procedures	4.4.0	Handover
12	N4- 010733	29.002	4.3.0	244	4	Rel-4	Α	Addition of allowed UMTS algorithm indication to the handover procedures	4.4.0	Handover
12	N4- 010735	29.002	4.3.0	245	4	Rel-4	Α	Addition of selected GSM algorithm indication to the handover procedures	4.4.0	Handover
12	N4- 010739	29.002	4.3.0	254	2	Rel-4	Α	Addition of radio resource list to the handover procedures	4.4.0	Multicall
12	NP- 010247	29.002	4.3.0	256	3	Rel-4	Α	Addition of GSM channel type and GSM chosen channel indications to handover procedures	4.4.0	Handover
12	N4- 010787	29.002	4.3.0	264	3	Rel-4	Α	Add support in MAP for all shapes defined in 23.032	4.4.0	LCS
12	N4- 010633	29.002	4.3.0	270	1	Rel-4	Α	Correction to description of RNCId parameter	4.4.0	Handover
12	N4- 010635	29.002	4.3.0	272	1	Rel-4	Α	Correction to Encryption Information and Integrity Protection parameters	4.4.0	Handover
12	N4- 010767	29.002	4.3.0	279	3	Rel-4	Α	Essential drawbacks on services due to introduction of Super- Charger function	4.4.0	TEI
12	N4- 010741	29.002	4.3.0	283	1	Rel-4	Α	Introduction of selected Rab-id to the Process Access Signalling operation	4.4.0	Multicall
12	N4- 010673	29.002	4.3.0	285		Rel-4	Α	Mistake in the definition of Authentication Failure Report Application Context	4.4.0	SEC
12	N4- 010551	29.002	4.3.0	266		Rel-4	А	Add support in MAP for Ellipsoid Point	4.4.0	LCS
12	N4- 010778	29.002	4.3.0	168	5	Rel-4	С	Security Header modification	4.4.0	Security
12	N4- 010785	29.002	4.3.0	267	3	Rel-4	С	Additional Parameters in Authentication Failure Report	4.4.0	SEC1 - EHCS
12	N4- 010783	29.002	4.3.0	268	3	Rel-4	F	MS presence notification procedure for LCS	4.4.0	LCS1

SMG#	TDoc	SPEC	VERS	CR	REV	PHAS E	CAT	SUBJECT	NEW_VERS	WORKITEM
12	N4- 010790	29.002	4.3.0	289	2	Rel-4	F	Component level granularity of protection	4.4.0	SEC1
		29.002	4.4.0			Rel-4		Corrupted headers fixed	4.4.1	
13	N4- 010840	29.002	4.4.1	290		Rel-4	F	Clarifications on long forwarded- to numbers	4.5.0	TEI4
13	N4- 010929	29.002	4.4.1	291	1	Rel-4	F	Corrections for Deferred MT-LR	4.5.0	LCS1
13	N4- 010930	29.002	4.4.1	292	2	Rel-4	F	Clarifications on SupportedLCS- CapabilitySets	4.5.0	LCS1
13	N4- 010958	29.002	4.4.1	295	2	Rel4	F	Corrections on the introduction of LCS for PS domain	4.5.0	LCS1
13	N4- 010970	29.002	4.4.1	302	2	Rel-4	F	Additional SGSN related values to Access Type	4.5.0	SEC1-EHCS
13	N4- 010976	29.002	4.4.1	306		Rel-4	А	Addition of data type definitions to EXPORT statements for the usage in CAP	4.5.0	CAMEL3
13	N4- 011017	29.002	4.4.1	307	2	Rel-4	Α	Minimum MAP application context for intersystem MSC handover from GSM to UMTS	4.5.0	Handover
13	N4- 011019	29.002	4.4.1	309	2	Rel-4	A	Minimum MAP application context for intersystem MSC handover from UMTS to GSM	4.5.0	Handover
13	N4- 010845	29.002	4.4.1	277	1	Rel4	F	Correction on the SDL of NW initiated USSD operations	4.5.0	TEI
13		29.002	4.4.1			Rel-4		Editorial Clean up	4.5.0	
14	N4- 011031	29.002	4.5.0	313		Rel-4	Α	Clarification on LCS parameters in MAP	4.6.0	LCS1
14	N4- 011043	29.002	4.5.0	314		Rel-4	F	Handling of linked operations in the MAP protocol machine	4.6.0	TEI4
14	N4- 011285	29.002	4.5.0	316		Rel-4	F	Corrections on the SDL diagrams for LCS	4.6.0	LCS1
14	N4- 011198	29.002	4.5.0	318	1	Rel-4	Α	Indication of deletion of CSI in Notify Subscriber Data Change	4.6.0	CAMEL3
14	N4- 011074	29.002	4.5.0	320		Rel-4	Α	Correct length of Add- GeographicalInformation	4.6.0	LCS
14	N4- 011091	29.002	4.5.0	322		Rel-4	Α	Clarify encoding of RNC Id	4.6.0	Handover
14	N4- 011094	29.002	4.5.0	324		Rel-4	A	Clarify encoding of RANAP parameters in MAP	4.6.0	Handover
14	N4- 011097	29.002	4.5.0	325		Rel-4	F	Clarifications on long forwarded-to numbers	4.6.0	TEI4
14	N4- 011227	29.002	4.5.0	331	1	Rel-4	A	Clarification of methodology for maintaining data consistency in Supercharger	4.6.0	TEI
14	N4- 011173	29.002	4.5.0	334		Rel-4	Α	Addition of RAB ID to Prepare Handover procedure	4.6.0	Multicall
14	N4- 011175	29.002	4.5.0	336		Rel-4	Α	Correction to the Allowed GSM Algorithms parameter	4.6.0	Handover
14	N4- 011177	29.002	4.5.0	337	1	Rel-4	F	Correction of references	4.6.0	TEI4
14	N4- 011190	29.002	4.5.0	339		Rel-4	А	CUG-Info is not exported from 29.002	4.6.0	CAMEL3
14	N4- 011209	29.002	4.5.0	341		Rel-4	Α	Clarification on NSCD when data is withdrawn	4.6.0	CAMEL phase 3
14	N4- 011211	29.002	4.5.0	343		Rel-4	Α	Clarification of sending CAMEL information in stand alone ISD case	4.6.0	CAMEL phase 3
14	N4- 011262	29.002	4.5.0	344		Rel-4	F	Correction of the priority for 'SRI for LCS'	4.6.0	LCS1

SMG#	TDoc	SPEC	VERS	CR	REV	PHAS E	CAT	SUBJECT	NEW_VERS	WORKITEM
14	N4- 011273	29.002	4.5.0	347		Rel-4	Α	ASN.1 correction	4.6.0	CAMEL
14	N4- 011437	29.002	4.5.0	349	2	Rel-4	F	Handling of MNRR in the HLR & SMS-GMSC	4.6.0	TEI4
14	N4- 011433	29.002	4.5.0	354	1	Rel-4	Α	Minimum MAP application context for G2G inter-MSC handover	4.6.0	Handover
14	N4- 011439	29.002	4.5.0	359	2	Rel-4	Α	Alignment of parameter lengths with those prescribed in 08.08	4.6.0	TEI
14	N4- 011423	29.002	4.5.0	360	1	Rel-4	F	Aligning the security header elements with TS33.200	4.6.0	TEI-4
14	N4- 011394	29.002	4.5.0	364		Rel-4	Α	Syntax error in the ATM result and ATSI result	4.6.0	CAMEL phase 3
14	N4- 011381	29.002	4.6.0	355	1	Rel-5	В	LCS Capability Handling for UE"s	5.0.0	TEI5
15	N4- 020300	29.002	5.0.0	368	4	Rel-5	В	Collective CAMEL Phase 4 CR	5.1.0	CAMEL4
15	N4- 020013	29.002	5.0.0	373		Rel-5	Α	Inclusion of complete ODB data in ATSI and NSDC	5.1.0	CAMEL3
15	N4- 020266	29.002	5.0.0	381	2	Rel-5	В	Introduction of the 'Requestor ID'	5.1.0	LCS1
15	N4- 020068	29.002	5.0.0	386		Rel-5	Α	Correction to AC version of gprsLocationInfoRetrievalContext	5.1.0	TEI4
15	N4- 020248	29.002	5.0.0	390	1	Rel-5	Α	Incomplete description of Restore Data parameters	5.1.0	TEI4
15	N4- 020183	29.002	5.0.0	403		Rel-5	Α	Clarification on CODEC-Info	5.1.0	TEI
15	N4- 020250	29.002	5.0.0	407	1	Rel-5	Α	ODB alignment	5.1.0	TEI4
16	N4- 020530	29.002	5.1.0	428	2	Rel-5	Α	LCS: error handling if shape not supported by GMLC	5.2.0	LCS1
16	N4- 020622	29.002	5.1.0	453		Rel-5	Α	Addition of Radio Resource List to the Forward Access Signalling operation	5.2.0	Multicall
16	N4- 020641	29.002	5.1.0	460		Rel-5	Α	Clarification on Resume Call Handling	5.2.0	TEI
16	N4- 020746	29.002	5.1.0	440	2	Rel-5	Α	Clarification on SendAuthenticationInfo	5.2.0	TEI
16	N4- 020750	29.002	5.1.0	446	1	Rel-5	A	Addition of Service Handover parameters to MAP Handover messages	5.2.0	Handover
16	N4- 020318	29.002	5.1.0	398		Rel-5	С	Check of NAM and Requesting Node Type on receipt of SendAuthenticationInfo	5.2.0	TEI4
16	N4- 020333	29.002	5.1.0	410		Rel-5	Α	Handling the MNRR flag in the HLR & SMS-GMSC	5.2.0	TEI4
16	N4- 020499	29.002	5.1.0	420	1	Rel-5	A	Clarfication of introducing Session related and unrelated class	5.2.0	LCS1-PS
16	N4- 020511	29.002	5.1.0	430	1	Rel-5	Α	Corrections on the introduction of LCS for PS domain	5.2.0	LCS
16	N4- 020743	29.002	5.1.0	448	1	Rel-5	Α	Corrections in SS-code chapter	5.2.0	TEI
16	N4- 020408	29.002	5.1.0	423		Rel-5	С	Clarification of handling of MT-SMS-TPDU-Type and SMS-TDP	5.2.0	CAMEL4
16	N4- 020410	29.002	5.1.0	425		Rel-5	Α	Clarify conditions to trigger restart of MTLR-Deferred procedure	5.2.0	LCS1
16	N4- 020468	29.002	5.1.0	414	1	Rel-5	F	Corrections to the handling of Any Time Interrogation and Provide Subscriber Info	5.2.0	CAMEL4

SMG#	TDoc	SPEC	VERS	CR	REV	PHAS E	CAT	SUBJECT	NEW_VERS	WORKITEM
16	N4- 020476	29.002	5.1.0	435	1	Rel-5	D	Change PS-connected in PS-PDPactive	5.2.0	CAMEL4
16	N4- 020483	29.002	5.1.0	422	1	Rel-5	F	Triggering of gsmSCF for MT-SMS-CSI	5.2.0	CAMEL4
16	N4- 020485	29.002	5.1.0	408	2	Rel-5	С	Transferring the MS classmark & IMEI to the gsmSCF	5.2.0	CAMEL4
16	N4- 020543	29.002	5.1.0	441		Rel-5	F	Correction of Object Identifiers for ASN.1 modules	5.2.0	TEI
16	N4- 020608	29.002	5.1.0	450		Rel-5	С	Enhancement to LCS in the PS domain	5.2.0	LCS
16	N4- 020623	29.002	5.1.0	454		Rel-5	F	Addition of Location Information GPRS to Note MM Event operation	5.2.0	CAMEL4-NMM
16	N4- 020703	29.002	5.1.0	421	4	Rel-5	В	LCS: Codeword and Service Type	5.2.0	LCS1
16	N4- 020756	29.002	5.1.0	436	2	Rel-5	В	Splitting of CAMEL phase 4	5.2.0	CAMEL4
17	N4- 021001	29.002	5.2.0	437	3	Rel-5	F	Compatible upgrade to ASN.1:1997 of 29.002	5.3.0	TEI
17	NP- 020399	29.002	5.2.0	462	2	Rel-5	F	Introduction of GERAN classmark	5.3.0	TEI
17	N4- 020841	29.002	5.2.0	465		Rel-5	F	Clarification on Call Deflection	5.3.0	Call Deflection
17	N4- 021040	29.002	5.2.0	470	1	Rel-5	F	Correction to the usage of "Roaming not allowed" error	5.3.0	TEI5
17	N4- 021041	29.002	5.2.0	471	1	Rel-5	Α	Clarifications on Send Identification	5.3.0	TEI
17	N4- 021094	29.002	5.2.0	479	2	Rel-5	С	Handling of partial implementations of CAMEL phase 4	5.3.0	CAMEL4
17	N4- 021047	29.002	5.2.0	480		Rel-5	С	Removal of ChargingNotification feature	5.3.0	CAMEL4
17	N4- 020810	29.002	5.2.0	481		Rel-5	В	CR29.002-443 (rel5) on extensions to ATM for CAMEL control of IMS	5.3.0	IMS-CAMEL
17	N4- 020809	29.002	5.2.0	482		Rel-5	В	CR to 29.002 for the support of the MAP Si interface	5.3.0	IMS-CAMEL
18	N4- 021290	29.002	5.3.0	499		Rel-5	А	Correction to segmentation of O-CSI and T-CSI	5.4.0	CAMEL3
18	N4- 021418	29.002	5.3.0	508		Rel-5	Α	ODB correction	5.4.0	CAMEL3
18	N4- 021563	29.002	5.3.0	511	1	Rel-5	Α	Addtion of reference number to deferred location request procedure	5.4.0	LCS1
18	N4- 021573	29.002	5.3.0	516	2	Rel-5	А	Correction to the Service Handover parameters	5.4.0	Multicall
18	N4- 021299	29.002	5.3.0	442	3	Rel-5	F	Description of MT SM delivery via two serving nodes	5.4.0	TEI5
18	N4- 021294	29.002	5.3.0	474	2	Rel-5	F	Correction of handling of MT- SMS in the SGSN	5.4.0	CAMEL4
18	N4- 021124	29.002	5.3.0	475		Rel-5	F	ODB and CB for SMS	5.4.0	TEI5
18	N4- 021153	29.002	5.3.0	486		Rel-5	F	Correction of IMEI check for SGSN	5.4.0	TEI5
18	N4- 021467	29.002	5.3.0	489	5	Rel-5	F	Available codecs list and selected codec indication	5.4.0	TEI5
18	N4- 021194	29.002	5.3.0	490		Rel-5	F	Clarification of the use of Requested CAMEL Subscription Info parameters	5.4.0	CAMEL4

SMG#	TDoc	SPEC	VERS	CR	REV	PHAS E	CAT	SUBJECT	NEW_VERS	WORKITEM
18	N4- 021252	29.002	5.3.0	495		Rel-5	F	Correction to RCH – adding O- CSI trigger criteria	5.4.0	CAMEL4
18	N4- 021264	29.002	5.3.0	496		Rel-5	F	Additional MM-Code for MG-CSI	5.4.0	CAMEL4
18	N4- 021296	29.002	5.3.0	497	1	Rel-5	F	Additional handling of partial implementations of CAMEL phase 4	5.4.0	CAMEL4
18	N4- 021383	29.002	5.3.0	512		Rel-5	F	Correcion of Codeword Handling	5.4.0	LCS1-PS
18	N4- 021443	29.002	5.3.0	513		Rel-5	F	Reference to TS 23.078 in TS 29.002 regarding handling of VMSC address is missing	5.4.0	CAMEL4
18	N4- 021524	29.002	5.3.0	521	1	Rel-5	F	Editorial clean-up	5.4.0	TEI5
18	N4- 021531	29.002	5.3.0	522		Rel-5	F	Introduction of the CHOICE element 'netDetNotReachable' for PS-SubscriberState	5.4.0	CAMEL4
18	N4- 021260	29.002	5.4.0	491	1	Rel-6	В	Addition of LCS Format Indicator to LCS Client ID	6.0.0	LCS2
18	N4- 021504	29.002	5.4.0	517	2	Rel-6	В	Addition of V-GMLC Address to the Update Location and Update GPRS Location requests	6.0.0	LCS2
18	N4- 021567	29.002	5.4.0	518	3	Rel-6	В	Addition of V-GMLC and H-GMLC Addresses to the Send Routing Info for LCS response	6.0.0	LCS2
18-	N4- 021506	29.002	5.4.0	519	2	Rel-6	В	Addition of PPR Address to the Send Routing Info for LCS response	6.0.0	LCS2
19	N4- 030234	29.002	6.0.0	509	3	Rel-6	С	Introduction of Call Barring for SMS in PS domain	6.1.0	TEI6
19	N4- 030325	29.002	6.0.0	524	3	Rel-6	A	Clean-up of SMS procedures chapter	6.1.0	TEI5
19	NP- 030068	29.002	6.0.0	545	2	Rel-6	A	Correction to interactions between CAMEL control of MO SMS and barring	6.1.0	CAMEL3
19	N4- 030061	29.002	6.0.0	526		Rel-6	F	Incrementing ASN.1 module versions	6.1.0	TEI6
19	N4- 030063	29.002	6.0.0	528		Rel-6	Α	LCS diagnostic alignment	6.1.0	LCS1
19	N4- 030054	29.002	6.0.0	529		Rel-6	F	Addition of LCS Capability Set 4	6.1.0	LCS2
19	N4- 030301	29.002	6.0.0	533	1	Rel-6	Α	Correction to the definitions of Radio Resource List and BSSMAP Service Handover List	6.1.0	Multicall
19	N4- 030305	29.002	6.0.0	541	2	Rel-6	Α	Handover of Group Calls where MSC-B has bearer established	6.1.0	TEI
19	N4- 030287	29.002	6.0.0	551	1	Rel-6	А	Change of SS-Code List description for Insert Subscriber Data	6.1.0	TEI
19	N4- 030289	29.002	6.0.0	559	1	Rel-6	Α	Missing of 'Continue Monitoring message' in SDL 21.7_3.2	6.1.0	TEI5
19	N4- 030297	29.002	6.0.0	563	1	Rel-6	A	Alignment of TS 29.002 with TS 23.107 regarding QoS subscribed data	6.1.0	TEI5
19	N4- 030222	29.002	6.0.0	566	1	Rel-6	F	Introduction of MSC Number as a new parameter in MAP-SEND-IDENTIFICATION operation	6.1.0	LCS2
20	N4- 030692	29.002	6.1.0	536	2	Rel-6	Α	Additional SGSN Related Access Type – Detach	6.2.0	SEC1-EHCS

SMG#	TDoc	SPEC	VERS	CR	REV	PHAS E	CAT	SUBJECT	NEW_VERS	WORKITEM
20	N4- 030658	29.002	6.1.0	568	4	Rel-6	A	Addition of Positioning Data IE to Provide Subscriber Location and Send Location Report	6.2.0	LCS
20	N4- 030638	29.002	6.1.0	574	1	Rel-6	F	Provision of SDL diagrams and removal of redundant text in chapter 25	6.2.0	TEI6
20	N4- 030713	29.002	6.1.0	595	2	Rel-6	Α	Removal of redundant text from 29.002 Chapter 23	6.2.0	TEI5
20	N4- 030439	29.002	6.1.0	599		Rel-6	Α	LCS Client external ID	6.2.0	LCS
20	N4- 030682	29.002	6.1.0	607	1	Rel-6	F	Provision of SDL diagrams and removal of redundant text in chapter 22	6.2.0	TEI5
20	N4- 030608	29.002	6.1.0	608	1	Rel-6	В	Addition of LCS capability sets to MAP_SRI_for_LCS response	6.2.0	LCS2
20	N4- 030647	29.002	6.1.0	612	1	Rel-6	Α	Enhancement of the CheckIMEI operation to retrieve the BMUEF	6.2.0	Late UE
20	N4- 030678	29.002	6.1.0	619	1	Rel-6	Α	Correction to naming of PRN parameter	6.2.0	CAMEL4
20	N4- 030609	29.002	6.1.0	624	1	Rel-6	F	Addition of Privacy Check Related Action to Provide Subscriber Location request	6.2.0	LCS2
20	N4- 030642	29.002	6.1.0	610	1	Rel-6	Α	Transfer of UE-specific behaviour bitmap at handover	6.2.0	Late UE
20	N4- 030601	29.002	6.1.0	633		Rel-6	Α	Missing SMSs over MSC even if the MS is capable of such sending	6.2.0	TEI5
21	N4- 031043	29.002	6.2.0	584	2	Rel-6	Α	Correction to MAP Process Secure_MAP_DSM SDLs	6.3.0	MAP Security
21	N4- 031053	29.002	6.2.0	664	1	Rel-6	Α	Correction of encoding description of Group-Id	6.3.0	ASCI
21	N4- 030828	29.002	6.2.0	657		Rel-6	Α	Reduce maximum length of 'LCS Requestor ID' and 'LCS Codeword'.	6.3.0	LCS2
21	N4- 030922	29.002	6.2.0	647	1	Rel-6	Α	UESBI -IU format	6.3.0	LATE-UE
21	N4- 031069	29.002	6.2.0	616	3	Rel-6	Α	Incorrect Charging with MNP	6.3.0	CAMEL4
21	N4- 031057	29.002	6.2.0	660	2	Rel-6	Α	Notification of the 2 <sup>nd</sup> BSG in case of Late CF with OR	6.3.0	SCUDIF
21	N4- 031059	29.002	6.2.0	614	3	Rel-6	Α	HLR Interrogation for SCUDIF calls	6.3.0	SCUDIF
21	N4- 030785	29.002	6.2.0	644		Rel-6	D	Removal of tables in section 7.6	6.3.0	TEI6
21	N4- 030806	29.002	6.2.0	649		Rel-6	F	Correction of References	6.3.0	TEI
21	N4- 030815	29.002	6.2.0	648		Rel-6	D	Correction of wrong AC name in the table in 17.1.6	6.3.0	TEI6
21	N4- 030824	29.002	6.2.0	654		Rel-6	В	New LCS Service Types	6.3.0	LCS
21	N4- 030951	29.002	6.2.0	671		Rel-6	D	SS-Barring Category	6.3.0	TEI
21	N4- 031006	29.002	6.2.0	650	1	Rel-6	F	Add SGSN, GGSN, GMLC, gsmSCF, NPLR and AuC to network resource parameter	6.3.0	TEI6
21	N4- 0301038	29.002	6.2.0	645	1	Rel-6	В	Introduction of North American Interim Location Based Routing of Emergency Call	6.3.0	LCS2
21	N4- 031065	29.002	6.2.0	674		Rel-6	F	Positioning Data for UTRAN LCS	6.3.0	LCS2

SMG#	TDoc	SPEC	VERS	CR	REV	PHAS E	CAT	SUBJECT	NEW_VERS	WORKITEM
21	N4- 030953	29.002	6.2.0	637	1	Rel-6	A	Provision of SDL diagrams and removal of redundant text in chapter 19	6.3.0	TEI5
21	N4- 030745	29.002	6.2.0	639		Rel-6	Α	Provision of SDL diagrams and removal of redundant text in chapter 20	6.3.0	TEI5
21	N4- 030747	29.002	6.2.0	641		Rel-6	Α	Provision of SDL diagrams and removal of redundant text in chapter 21	6.3.0	TEI5
21	N4- 030748	29.002	6.2.0	642		Rel-6	F	Removal of SIWF description	6.3.0	TEI6
21	N4- 030749	29.002	6.2.0	643		Rel-6	D	Deletion of redundant Annex D	6.3.0	TEI6
22	N4- 031098	29.002	6.3.0	677		Rel-6	В	Enhancements for the Partial Implementation for "Change of position procedure armed with criteria"	6.4.0	TEI6
22	N4- 031135	29.002	6.3.0	687		Rel-6	В	Collective CR for Rel-6 Enhanced Dialled Services	6.4.0	EDCAMEL
22	N4- 031274	29.002	6.3.0	648	2	Rel-6	D	Message Segmentation Mechanisms	6.4.0	TEI6
22	N4- 031315	29.002	6.3.0	703		Rel-6	В	Addition of requestingPLMN- ID to Send Authentication Info Request	6.4.0	TEI6
22	N4- 031372	29.002	6.3.0	680	2	Rel-6	F	Addition of CGI to LCS procedures	6.4.0	LCS2
22	N4- 031373	29.002	6.3.0	696	2	Rel-6	F	Include v-gmlc parameter in RESTORE DATA MAP message	6.4.0	LCS2
22	N4- 031365	29.002	6.3.0	702	2	Rel-6	В	Deferred MT-LR Area Event	6.4.0	LCS2
22	N4- 031132	29.002	6.3.0	686		Rel-6	Α	More spare bits for CAMEL4 enhancements	6.4.0	CAMEL4
22	N4- 031163	29.002	6.3.0	692		Rel-6	Α	Clarification on D-CSI segmentation	6.4.0	CAMEL4
22	N4- 031342	29.002	6.3.0	676	2	Rel-6	Α	MNP correction for prepaid charging	6.4.0	MNP
22	N4- 031338	29.002	6.3.0	695	1	Rel-6	А	Remove reduntant option for retrieval of routeing information in figure 21.2.3	6.4.0	TEI5
22	N4- 031108	29.002	6.3.0	679		Rel-6	F	Modification of description for conditions on inclusion of Positioning Data	6.4.0	LCS2
22	N4- 031317	29.002	6.3.0	689	2	Rel-6	Α	HSDPA impacts to MAP	6.4.0	HSDPA
22	NP- 030533	29.002	6.3.0	704		Rel-6	F	EXPORT data types to CAP (Change of position armed with criteria)	6.4.0	TEI6
23	N4- 040310	29.002	6.4.0	668	3	Rel-6	A	Codec Modification/ Mid-Call Codec Negotiation after Inter- MSC Relocation	6.5.0	OoBTC
23	N4- 040193	29.002	6.4.0	670	2	Rel-6	Α	Correction of Inter-MSC SRSN Relocation procedure	6.5.0	OoBTC
23	N4- 040249	29.002	6.4.0	701	3	Rel-6	В	Introduction of Presence Stage 3 (Ph, Pc and Pg) to the MAP interface	6.5.0	PRESNC
23	N4- 040333	29.002	6.4.0	708	2	Rel-6	F	Correction to Insert Subscriber Data message for LCS SS	6.5.0	LCS
23	N4- 040328	29.002	6.4.0	709	1	Rel-6	F	SCCP segmentation for Inter PLMN MAP message	6.5.0	TEI6

SMG#	TDoc	SPEC	VERS	CR	REV	PHAS E	CAT	SUBJECT	NEW_VERS	WORKITEM
23	N4- 040327	29.002	6.4.0	711	2	Rel-6	F	Inclusion of UTRAN Positioning Data parameter	6.5.0	LCS2
23	N4- 040284	29.002	6.4.0	717	1	Rel-6	В	Include administrative restriction subscription parameter	6.5.0	TEI6
23	N4- 040340	29.002	6.4.0	720	2	Rel-6	Α	Add new Unavailability cause for SCUDIF	6.5.0	SCUDIF
23	N4- 040171	29.002	6.4.0	721		Rel-6	F	CR implemented by fault	6.5.0	TEI6
23	N4- 040182	29.002	6.4.0	724		Rel-6	F	Removal of R-GMLC Address	6.5.0	LCS2
23	N4- 040322	29.002	6.4.0	725	1	Rel-6	В	MO-LR Service Identity support	6.5.0	LCS2
23	N4- 040267	29.002	6.4.0	726	1	Rel-6	В	CAMEL4 SCUDIF notification during active call for prepay	6.5.0	SCCAMEL
24	N4- 040520	29.002	6.5.0	731		Rel-6	F	Introduction of North American Interim Location Based Routing of Emergency Call	6.6.0	LCS2
24	N4- 040585	29.002	6.5.0	735		Rel-6	F	Modify IMEI parameter usage definition in MAP-PSL and MAP-SLR	6.6.0	TEI6
24	N4- 040600	29.002	6.5.0	736		Rel-6	F	Addition of SAI-Present indication to the LCS procedures	6.6.0	LCS2
24	N4- 040601	29.002	6.5.0	737		Rel-6	F	Clarification on the use of MSISDN parameter for Follow Me functionality	6.6.0	TAI6
24	N4-04732	29.002	6.5.0	734	1	Rel-6	F	Add Additional V-GMLC parameter in MAP-SRI-INFO-FOR-LCS	6.6.0	LCS2
24	N4- 040736	29.002	6.5.0	718	6	Rel-6	В	Addition of IMEISV to Update Location Procedure for ADD function	6.6.0	TEI6
25	N4- 040929	29.002	6.6.0	739		Rel-6	В	Export of UU-Data data type	6.7.0	TEI6
25	N4- 041021	29.002	6.6.0	743		Rel-6	D	Wrong SDL flow page implemented	6.7.0	TEI6
25	N4- 041128	29.002	6.6.0	732	2	Rel-6	В	Pre-Paging Resource Optimization	6.7.0	TEI6
26	N4- 041272	29.002	6.7.0	747		Rel-6	F	Incorrect Implementation of CR 731	6.8.0	LCS2
26	N4- 041477	29.002	6.7.0	752		Rel-6	F	Correction to the service response parameters of ATI	6.8.0	TEI6
26	N4- 041662	29.002	6.7.0	746	1	Rel-6	В	Introducing VGCS/VBS ciphering	6.8.0	SECGKYV
26	N4- 041683	29.002	6.7.0	757	2	Rel-6	F	Clarification about returning authentication data for a subscriber (GSM or UMTS)	6.8.0	TEI6
26	N4- 041684	29.002	6.7.0	748	1	Rel-6	F	LCS Capability Handling for UE's	6.8.0	TEI6
26	N4- 041685	29.002	6.7.0	753	1	Rel-6	F	Enable NA-ESRD Provision from a GMLC for E911 Location in North America	6.8.0	LCS2
26	N4- 041641	29.002	6.7.0	740	2	Rel-6	В	SMS Fraud countermeasures	6.8.0	TEI6
27	N4- 050212	29.002	6.8.0	749	1	Rel-6	В	Management Based Activation Impacts	6.9.0	OEM-TRACE
27	N4- 050369	29.002	6.8.0	761	1	Rel-6-	F	Addition of LAI to SendIdentification Request	6.9.0	TEI6
27	N4- 050430	29.002	6.8.0	760	1	Rel-6	F	Subscribed Charging Characteristics	6.9.0	TEI6

SMG#	TDoc	SPEC	VERS	CR	REV	PHAS E	CAT	SUBJECT	NEW_VERS	WORKITEM
27	N4- 050444	29.002	6.8.0	759	1	Rel-6	С	Addition of TCAP-Handshake for MO-ForwardSM	6.9.0	TEI6
27	N4- 050446	29.002	6.8.0	745	2	Rel-6	В	Introduction of Hop Counter for Send Identification	6.9.0	TEI6
27	N4- 050463	29.002	6.8.0	738	8	Rel-6	F	Rel-6 trace management additions to trace activation and deactivation procedures	6.9.0	OEM-Trace
27	N4- 050467	29.002	6.8.0	763	2	Rel-6	F	Pseudonym indicator support in MO-LR	6.9.0	LCS2
28	C4- 050737	29.002	6.9.0	769	1	Rel-6	F	Correction to Trace parameters to allow trace at the BM-SC	6.10.0	OAM-Trace
28	C4- 050832	29.002	6.9.0	770	6	Rel-6	F	Full RANAP support of network initiated SCUDIF	6.10.0	TEI6
28	C4- 050895	29.002	6.9.0	766	2	Rel-6	F	Clarification on the use of Access Restriction Data parameter	6.10.0	TEI5
28	C4- 050784	29.002	6.10.0	765	1	Rel-7	В	Addition of CollectInformation procedure to OfferedCAMEL4Functionalities	7.0.0	CAMELR7
29	C4- 051013	29.002	7.0.0	771		Rel-7	F	ASN.1 module version update	7.1.0	TEI
29	C4- 051295	29.002	7.0.0	776	2	Rel-7	В	Enabling the Providing of Velocity	7.1.0	LCS-7
29	C4- 051333	29.002	7.0.0	772	1	Rel-7	В	Support of talker priorities and talker identity presentation	7.1.0	EGCS
29	C4- 051334	29.002	7.0.0	773	1	Rel-7	В	Delivery of SMS to voice group call	7.1.0	EGCS
29	C4- 051368	29.002	7.0.0	777	2	Rel-7	В	CS data Mobile Terminating calls from PSTN	7.1.0	TEI7
29	C4- 051336	29.002	7.0.0	780	2	Rel-7	Α	Correction on misalignment with stage 2 for Location Services	7.1.0	TEI6
30	C4- 051775	29.002	7.1.0	783	2	Rel-7	Α	Addition of UMTS Trace parameters to handover procedure	7.2.0	TEI6
31	C4- 060320	29.002	7.2.0	794	1	Rel-7	Α	Addition of UMTS Trace parameters to handover procedure	7.3.0	TEI6
31	C4- 060295	29.002	7.2.0	790	1	Rel-7	С	Removal of MAPsec material	7.3.0	SEC7-TCAP
31	C4- 060315	29.002	7.2.0	787	1	Rel-7	С	addition of "supported RAT types indicator" during location/routing area update	7.3.0	TEI7
31	C4- 060378	29.002	7.2.0	792	1	Rel-7	В	Addition of Periodic Location Feature Support	7.3.0	LCS3
31	C4- 060434	29.002	7.2.0	781	3	Rel-7	С	New LocationType for the notification based on current location of target UE	7.3.0	LCS7
31	C4- 060318	29.002	7.2.0	788	1	Rel-7	F	SMS Relay Application Context Names for Version 1	7.3.0	TEI7
31	C4- 060041	29.002	7.2.0	789		Rel-7	F	Precision on segmentation of MAP GPRSSubscriptionData parameter	7.3.0	TEI7
31	C4- 060250	29.002	7.2.0	801		Rel7	С	Improvements to VGCS Call Establishment	7.3.0	TEI
31	C4- 060011	29.002	7.2.0	786		Rel-7	F	Addition of Authentication Domains in MAP Send Authentication Info	7.3.0	TEI7
32	C4- 060813	29.002	7.3.0	0808	2	Rel-7	С	List of MSISDNs and Basic Service Code for MAP Any Time Subscription Interrogation.	7.4.0	TEI7
32	C4- 060499	29.002	7.3.0	0803		Rel-7	F	Correction of LCS parameter for emergency call usage	7.4.0	LCS7

SMG#	TDoc	SPEC	VERS	CR	REV	PHAS E	CAT	SUBJECT	NEW_VERS	WORKITEM
32	C4- 060680	29.002	7.3.0	0814		Rel-7	F	SSN for FFN	7.4.0	TEI7
32	C4- 060706	29.002	7.3.0	0817		Rel-7	F	Removal of MAPsec material	7.4.0	SEC7-TCAP
33	CP- 060522	29.002	7.4.0	0818	1	Rel-7	F	Removal of ASN.1 Expanded Source	7.5.0	TEI7
33	C4- 061047	29.002	7.4.0	0805	1	Rel-7	В	Interoperability between VBS/VGCS and RANflex	7.5.0	VGCSflex
34	CP- 060741	29.002	7.5.0	0795	1	Rel-7	В	Support of SMS over IP networks	7.6.0	SMSIP
34	C4- 061800	29.002	7.5.0	0828	1	Rel-7	F	Extension of Group ID	7.6.0	EVGCS
34	C4- 061633	29.002	7.5.0	0829		Rel-7	F	Addition of Teleservice Code to SendGroupCallInfo	7.6.0	VGCSFlex
34	C4- 061775	29.002	7.5.0	0834		Rel-7	F	Accuracy Fulfillment Indicator parameter to MAP SLR for deferred MT-LR	7.6.0	TEI7
34	C4- 060693	29.002	7.5.0	0832	2	Rel-7	С	Optional Suppress Terminating Services Bit String in SRI	7.6.0	TEI7
35	C4- 070096	29.002	7.6.0	0836		Rel-7	F	Corrections to RAB Configuration Indicator and Iu- Selected codec	7.7.0	TEI7
35	C4- 070228	29.002	7.6.0	0835	1	Rel-7	В	Addition of capability to route MT-SMs via the HPLMN of the receiving MS	7.7.0	SMSviaH
36	C4- 070387	29.002	7.7.0	0848		Rel-7	F	Mobile Termination whilst the MS is moving to another MSC	7.8.0	MTmovMS
36	C4- 070475	29.002	7.7.0	0841	2	Rel-7	В	Addition of SMS over IP functionality	7.8.0	SMSIP
36	C4- 070780	29.002	7.7.0	0852	1	Rel-7	F	Detailed procedure in the IP-SM-GW	7.8.0	SMSIP
37	C4- 070952	29.002	7.8.0	0860		Rel-7	F	LMSI For MT-SMS	7.9.0	TEI7
37	C4- 071054	29.002	7.8.0	0861		Rel-7	В	QoS Extension	7.9.0	TEI7
37	C4- 071206	29.002	7.8.0	0867		Rel-7	F	Missing update to figure 23.5/3 in the implementation of CR 0852r1	7.9.0	SMSIP
37	C4- 071284	29.002	7.8.0	0855	3	Rel-7	F	Limit on number of concurrent MT-LR location requests	7.9.0	TEI7
37	C4- 071347	29.002	7.8.0	0866	2	Rel-7	Α	NPI for the call forwarding to number	7.9.0	TEI4
37	C4- 071348	29.002	7.8.0	0865	2	Rel-7	F	Corrections to SMS over IP handling	7.9.0	SMSIP
38	C4- 071996	29.002	7.9.0	0874	1	Rel-7	F	Behaviour of the IP-SM-GW for SM Delivery Status Report	7.10.0.	SMSIP
38	C4- 071854	29.002	7.9.0	0880		Rel-7	F	Restriction on the use of ccbs-A SS indication	7.10.0	TEI7
38	C4- 071814	29.002	7.9.0	0878		Rel-7	F	Removal of CCBS_Call_Report_Ack and Event_Report_Ack	7.10.0	TEI7
39	C4- 080266	29.002	7.10.0	0884		Rel-7	F	Updating of RAT Types	7.11.0	TEI7
40	C4- 081276	29.002	7.11.0	0887	1	Rel-7	F	Extension of Group ID	7.12.0	TEI7
44	C4- 091070	29.002	7.12.0	0918		Rel-7	F	SMS over IP	7.13.0	SMSIP
46	C4- 093691	29.002	7.13.0	0940		Rel-7	F	Alignment of specifications on Usage of MAP_SEND_AUTHENTICATI ON_INFO	7.14.0	TEI7
48	C4- 101234	29.002	7.14.0	0969		Rel-7	Α	CR implementation CR 642	7.15.0	TEI6

SMG#	TDoc	SPEC	VERS	CR	REV	PHAS E	CAT	SUBJECT	NEW_VERS	WORKITEM
48	C4- 101401	29.002	7.14.0	0965	1	Rel-7		Correction to missing GANSS position data in Provide Subscriber Location and Provide Subscriber Location Report services	7.15.0	TEI7

# History

	Document history									
V7.7.0	March 2007	Publication								
V7.8.0	June 2007	Publication								
V7.9.0	October 2007	Publication								
V7.10.0	January 2008	Publication								
V7.11.0	April 2008	Publication								
V7.12.0	July 2008	Publication								
V7.13.0	July 2009	Publication								
V7.14.0	February 2010	Publication								
V7.15.0	June 2010	Publication								